

Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system 323, 1.6i CAT 1991 to 1994

Type	B6. SOHC 16V 66kW	
Capacity (cm ³) / number of cylinders	1598 / 4	
Compression ratio / pressure	bar	9.2 / ≥7.8
Oil pressure	bar	[3.0 to 4.0]
Oil temperature	°C	–
Valve clearance - inlet	mm	0: Hyd.
Valve clearance - exhaust	mm	0: Hyd.
Firing order	1-3-4-2	
No 1 cylinder position	TBE	
Thermostat opening temperature	°C	86.5 to 89.5
Radiator cap pressure	bar	0.76 to 1.04

Fuel system 323, 1.6i CAT 1991 to 1994

Idle speed - manual [auto]	rpm	750±50
Fast idle speed - manual [auto]	rpm	–
CO @ idle speed [3000 rpm] - see page VI	%	≤0.3
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO ₂ @ idle speed [3000 rpm] - see page VI	%	–
O ₂ @ idle speed [3000 rpm] - see page VI	%	–
Carburettor / fuel injection	Mazda	
Type / ref	EGI EFI	
Main jet / needle	–	
Injection pressure	bar	2.6 to 3.2
Pump pressure	bar	4.4 to 5.9
Octane rating	RON	91[U]

Ignition system 323, 1.6i CAT 1991 to 1994

Type	Electronic	
Ignition coil	–	
Primary resistance	ohms	0.81 to 0.99
Ballast resistor	ohms	–
Voltage - Tmnl 15(+) to earth	V	–
Distributor	Hitachi	
Points gap (air gap)	mm	–
Dwell angle	° (%)	–
Condenser capacity	µF	–
Rotation	Anticlockwise	
Ignition timing - basic [static	° Crankshaft @ rpm	10±1 BTDC @ 750±50
V = Vacuum NV = No Vacuum	NV	
Total ignition advance	° Crankshaft @ rpm	–
	° Crankshaft @ rpm	–
	° Crankshaft @ rpm	–
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	–
	° Crankshaft @ rpm	–
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	–
Spark plugs	NGK	
Type	BKR5E-11	
Electrode gap	mm	1.00 to 1.10

Electrical system 323, 1.6i CAT 1991 to 1994

Battery	V / CC / RC	12 / 60Ah
Alternator voltage / full load current / engine rpm	14.1 to 14.7 / 65 / 2500	
Starter motor current / voltage - cranking	A / V	–
- locked	A / V	–

Running gear 323, 1.6i CAT 1991 to 1994

Brakes -		
Front (min. friction material thickness)	mm	2.0
Rear (min. friction material thickness)	mm	1.0

Tyres		
Saloon	Size	155x13: 175/70x13
Estate / Van	Size	–
Pressure - front / rear - Saloon	bar	1.9 / 1.8
- Estate / Van	bar	–

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	+2.0±3.0
Camber		-5'±45'
Castor		+2°5'±45'
King pin inclination		+12°25'

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	+2.0±3.0
Camber		-20'±45'

Torque wrench settings 323, 1.6i CAT 1991 to 1994


Cylinder head - stage 1	Nm	40
- stage 2	Nm	76 to 81
Cylinder head - stage 3	Nm	–
- stage 4	Nm	–
Big-end bearings	Nm	29 to 34
Main bearings	Nm	54 to 59
Clutch cover	Nm	18 to 26
Flywheel [driveplate]	Nm	96 to 103
Front hubs	Nm	235 to 319 N
Rear hubs	Nm	177 to 235
Wheel nuts / bolts	Nm	118
Spark plugs	Nm	15 to 23

Capacities 323, 1.6i CAT 1991 to 1994


Engine oil & filter	litres	3.2
Gearbox - 4-speed [5-speed]	litres	2.7
Automatic transmission - refill	litres	5.8
Final drive	litres	WT
Cooling system	litres	5.0 [AT: 6.0]
Fuel tank	litres	50. Saloon,F: 55

Notes and Illustrations


1: Idle speed 2: CO / Mixture



1598 cm³, 16V



1598 cm³, 16V



EGI EFI