

Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



# Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

### Engine and cooling system Maestro 2.0i 1984 to 1989

Type		20H SOHC
Capacity (cm <sup>3</sup> ) / number of cylinders		1994 / 4
Compression ratio / pressure	bar	9.0 / _
Oil pressure	bar	0.7 [3.8]
Oil temperature	°C	_
Valve clearance - inlet	mm	0.31±0.01 <sup>1</sup>
Valve clearance - exhaust	mm	0.31±0.01 <sup>1</sup>
Firing order		1-3-4-2
No 1 cylinder position		TBE
Thermostat opening temperature	°C	88
Radiator cap pressure	bar	1.04

### Fuel system Maestro 2.0i 1984 to 1989

Idle speed - manual [auto]	rpm	745±45 (ECU control) <sup>2</sup>
Fast idle speed - manual [auto]	rpm	_
CO @ idle speed [3000 rpm] - see page VI	%	1.0 to 1.5 (ECU 84399) <sup>3</sup>
HC @ idle speed [3000 rpm] - see page VI	ppm	≤1200
CO <sub>2</sub> @ idle speed [3000 rpm] - see page VI	%	_
O <sub>2</sub> @ idle speed [3000 rpm] - see page VI	%	_
Carburettor / fuel injection		Lucas-Bosch
Type / ref		MPI hot-wire
Main jet / needle		_
Injection pressure	bar	2.5 to 3.0
Pump pressure	bar	4.1
Octane rating	RON	97[L]

### Ignition system Maestro 2.0i 1984 to 1989

Type		Computerized
Ignition coil		Unipart GCL 143
Primary resistance	ohms	0.71 to 0.81
Ballast resistor	ohms	_
Voltage - Tmnl 15(+) to earth	V	_
Distributor		Lucas
Points gap (air gap)	mm	_
Dwell angle	° (%)	_
Condenser capacity	µF	_
Rotation		Anticlockwise
Ignition timing - basic [static	° Crankshaft @ rpm	14 BTDC @ 1500
V = Vacuum NV = No Vacuum		NV
Total ignition advance	° Crankshaft @ rpm	40 BTDC @ 1500
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	_
Spark plugs		Unipart/Champion
Type		GSP4452 / RN7YC
Electrode gap	mm	1.0. 87 ▶: 0.85

### Electrical system Maestro 2.0i 1984 to 1989

Battery	V / CC / RC	12 / 360 / 60
Alternator voltage / full load current / engine rpm		14.0 / 55, 65 / 3000
Starter motor current / voltage - cranking	A / V	65 / 12
- locked	A / V	360 / 7.0

### Running gear Maestro 2.0i 1984 to 1989

<b>Brakes -</b>		
Front (min. friction material thickness)	mm	3.0
Rear (min. friction material thickness)	mm	1.5

<b>Tyres</b>		
Saloon	Size	175/65x14: 185/55x15
Estate / Van	Size	_
Pressure - front / rear - Saloon	bar	2.0 / 2.0 <sup>4</sup>
- Estate / Van	bar	_

### Front suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	[0±8']
Camber		A: -15'±21'. B: +30'±21' <sup>5</sup>
Castor		+37'±30'
King pin inclination		A: +12°30'±30'. B:+12°33'±30 <sup>5</sup>

### Rear suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	[+30' to 1°]
Camber		-0.5°±0.5°

### Torque wrench settings Maestro 2.0i 1984 to 1989

Cylinder head - stage 1	Nm	45
- stage 2	Nm	80
Cylinder head - stage 3	Nm	+ 90° or to 108°
- stage 4	Nm	_
Big-end bearings	Nm	55 Lightly oiled
Main bearings	Nm	105 Lightly oiled
Clutch cover	Nm	23
Flywheel [driveplate]	Nm	58 bolts marked H <sup>7</sup>
Front hubs	Nm	203
Rear hubs	Nm	68
Wheel nuts / bolts	Nm	72
Spark plugs	Nm	18


### Capacities Maestro 2.0i 1984 to 1989

Engine oil & filter	litres	4.9
Gearbox - 4-speed [5-speed]	litres	[2.2]
Automatic transmission - refill	litres	_
Final drive	litres	WT
Cooling system	litres	8.5
Fuel tank	litres	50


### Notes and Illustrations

- <sup>1</sup>Adjust only if less than 0.20
- <sup>2</sup>625±25, setting with air valve closed
- <sup>3</sup>2.0 to 2.5 (ECU 84413, 84497, 84498)
- <sup>4</sup>175/65. 185/55: 2.1 / 2.1
- <sup>5</sup>A = early, B = later models
- <sup>6</sup>Whichever occurs first
- <sup>7</sup>Bolts marked X: 85

1: Idle speed    2: CO / Mixture



1994 cm<sup>3</sup>



MPI