

Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



# Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

## Engine and cooling system Toledo 1.6i 1994 to 1997

Type		1F SOHC 52kW
Capacity (cm <sup>3</sup> ) / number of cylinders		1595 / 4
Compression ratio / pressure	bar	9.0 / ≥7.0
Oil pressure	bar	[2.0]
Oil temperature	°C	80
Valve clearance - inlet	mm	0: Hyd.
- exhaust	mm	0: Hyd.
Firing order		1-3-4-2
No 1 cylinder position		TBE
Thermostat opening temperature	°C	85
Radiator cap pressure	bar	1.2 to 1.5

## Fuel system Toledo 1.6i 1994 to 1997

Idle speed - manual [auto]	rpm	700 to 1000 N/A
Fast idle speed - manual [auto]	rpm	2500 to 2800
CO @ idle speed [3000 rpm] - see page VI	%	≤0.5 [≤0.3]
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO <sub>2</sub> @ idle speed [3000 rpm] - see page VI	%	-
O <sub>2</sub> @ idle speed [3000 rpm] - see page VI	%	-
Carburettor / fuel injection		Bosch
Type / ref		Mono-Motronic
Main jet / needle		-
Injection pressure	bar	0.50
Pump pressure	bar	-
Octane rating	RON	95[U]

## Ignition system Toledo 1.6i 1994 to 1997

Type		Motronic
Ignition coil		Bosch
Primary resistance	ohms	0.52 to 0.76
Ballast resistor	ohms	-
Voltage - Tmnl 15(+) to earth	V	-
Distributor		Bosch
Points gap (air gap)	mm	-
Dwell angle	° (%)	-
Condenser capacity	µF	-
Rotation		Clockwise
Ignition timing - basic [static V = Vacuum NV = No Vacuum]	° Crankshaft @ rpm	6±1 BTDC @ 700 to 1000 N/A
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	-
	° Crankshaft @ rpm	-
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	-
	° Crankshaft @ rpm	-
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	-
Spark plugs		NGK/Bosch
Type		BUR5ET / W8LTCR
Electrode gap	mm	0.70 to 0.90 / 0.90 to 1.10

## Electrical system Toledo 1.6i 1994 to 1997

Battery	V / CC / RC	12 / 175 / 36Ah
Alternator voltage / full load current / engine rpm		12.5 to 14.5 / 65, 90 / 3000
Starter motor current / voltage - cranking	A / V	-
- locked	A / V	-

## Running gear Toledo 1.6i 1994 to 1997

<b>Brakes -</b>		
Front (min. friction material thickness)	mm	7.0 with backing
Rear (min. friction material thickness)	mm	2.5

<b>Tyres</b>		
Saloon	Size	175/70x13: 185/60x14
Estate / Van	Size	-
Pressure - front / rear - Saloon	bar	2.1 / 1.8
- Estate / Van	bar	-

## Front suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	0±1.0
Camber		-30'±20'
Castor		+1°30'±30'
King pin inclination		-

## Rear suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	20'±10'
Camber		-1°30'±10'


## Torque wrench settings Toledo 1.6i 1994 to 1997

Cylinder head - stage 1	Nm	40
- stage 2	Nm	60
- stage 3	Nm	+ 90°
- stage 4	Nm	+ 90°
Big-end bearings	Nm	30 + 90°
Main bearings	Nm	65
Clutch cover	Nm	20
Flywheel [driveplate]	Nm	60 + 90° N
Front hubs	Nm	260
Rear hubs	Nm	WSM
Wheel nuts / bolts	Nm	110
Spark plugs	Nm	25

## Capacities Toledo 1.6i 1994 to 1997

Engine oil & filter	litres	3.8
Gearbox - 4-speed [5-speed]	litres	2.0
Automatic transmission - refill	litres	-
Final drive	litres	WT
Cooling system	litres	6.2
Fuel tank	litres	55

## Notes and Illustrations

1595 cm<sup>3</sup>