

Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system Toledo 1.8i 16V 1991 to 1992

Type		KR DOHC 16V 98kW
Capacity (cm ³) / number of cylinders		1781 / 4
Compression ratio / pressure	bar	10.0 / ≥7.5
Oil pressure	bar	[2.0]
Oil temperature	°C	80
Valve clearance - inlet	mm	0: Hyd.
- exhaust	mm	0: Hyd.
Firing order		1-3-4-2
No 1 cylinder position		TBE
Thermostat opening temperature	°C	85
Radiator cap pressure	bar	1.3 to 1.5

Fuel system Toledo 1.8i 16V 1991 to 1992

Idle speed - manual [auto]	rpm	1000±50
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	1.0±0.5
HC @ idle speed [3000 rpm] - see page VI	ppm	≤1200
CO ₂ @ idle speed [3000 rpm] - see page VI	%	—
O ₂ @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		Bosch
Type / ref		K-Jetronic
Main jet / needle		—
Injection pressure	bar	3.5 to 4.1
Pump pressure	bar	4.7 to 5.4
Octane rating	RON	98[E 98 RON]

Ignition system Toledo 1.8i 16V 1991 to 1992

Type		FEI
Ignition coil		—
Primary resistance	ohms	0.6 to 0.8
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor		Bosch
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		Clockwise
Ignition timing - basic [static	° Crankshaft @ rpm	6±1 BTDC @ 1000±50
V = Vacuum NV = No Vacuum		V
Total ignition advance	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs		Bosch/Champion
Type		F6DTC / C6BYC
Electrode gap	mm	0.70 to 0.90

Electrical system Toledo 1.8i 16V 1991 to 1992

Battery	V / CC / RC	12 / 265 / 54Ah
Alternator voltage / full load current / engine rpm		12.5 to 14.5 / 65, 90 / 3000
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	—

Running gear Toledo 1.8i 16V 1991 to 1992

Brakes -		
Front (min. friction material thickness)	mm	7.0 with backing
Rear (min. friction material thickness)	mm	7.0 with backing
Tyres		
Saloon	Size	195/50x15: 185/60x14
Estate / Van	Size	—
Pressure - front / rear - Saloon	bar	2.2 / 2.0
- Estate / Van	bar	—
Front suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	0±1.0
Camber		-42'±20'
Castor		+1°55'±30'
King pin inclination		—
Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	20'±10'
Camber		-1°30'±10'

Torque wrench settings Toledo 1.8i 16V 1991 to 1992


Cylinder head - stage 1	Nm	40
- stage 2	Nm	60
- stage 3	Nm	+ 90°
- stage 4	Nm	+ 90°
Big-end bearings	Nm	30 + 90°
Main bearings	Nm	65
Clutch cover	Nm	20
Flywheel [driveplate]	Nm	60 + 90° N
Front hubs	Nm	260
Rear hubs	Nm	WSM
Wheel nuts / bolts	Nm	110
Spark plugs	Nm	30

Capacities Toledo 1.8i 16V 1991 to 1992


Engine oil & filter	litres	4.0
Gearbox - 4-speed [5-speed]	litres	2.0
Automatic transmission - refill	litres	—
Final drive	litres	WT
Cooling system	litres	6.2
Fuel tank	litres	55

Notes and Illustrations


1: Idle speed 2: CO / Mixture




1781 cm³, DOHC 16V



1781 cm³, 16V



K-Jetronic



K-Jetronic