

Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system Corolla 1.6 Exec. (AE92) 1987 to 1992

Type		4A-F (DOHC 16V)
Capacity (cm ³) / number of cylinders		1587 / 4
Compression ratio / pressure	bar	9.5 / ≥9.8
Oil pressure	bar	[2.5 to 5.0]
Oil temperature	°C	80
Valve clearance - inlet	mm	0.15 to 0.25
- exhaust	mm	0.20 to 0.30
Firing order		1-3-4-2
No 1 cylinder position		TBE
Thermostat opening temperature	°C	80 to 84
Radiator cap pressure	bar	0.74 to 1.03

Fuel system Corolla 1.6 Exec. (AE92) 1987 to 1992

Idle speed - manual [auto]	rpm	800 [800. PAS: 900]
Fast idle speed - manual [auto]	rpm	3000±200
CO @ idle speed [3000 rpm] - see page VI	%	1.0 to 2.5. 90 ▶: 1.0 to 2.0
HC @ idle speed [3000 rpm] - see page VI	ppm	≤1200
CO ₂ @ idle speed [3000 rpm] - see page VI	%	—
O ₂ @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		Aisan
Type / ref		2V, 21100-16300
Main jet / needle		—
Injection pressure	bar	—
Pump pressure	bar	—
Octane rating	RON	95[E 95 RON]

Ignition system Corolla 1.6 Exec. (AE92) 1987 to 1992

Type		Electronic
Ignition coil		—
Primary resistance	ohms	1.3 to 1.5
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor		—
Points gap (air gap)	mm	[0.20 to 0.40]
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		—
Ignition timing - basic [static	° Crankshaft @ rpm	10 BTDC @ 900
V = Vacuum NV = No Vacuum		NV
Total ignition advance	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	0 to 3 @ 1600 ¹
	° Crankshaft @ rpm	11.4 to 14.4 @ 3300 ¹
	° Crankshaft @ rpm	19.4 to 23.4 @ 6600 ¹
Vacuum range check	mbar	133 to 560 ²
Maximum vacuum advance	° Crankshaft	13 to 17 ²
Spark plugs		NGK/Champion
Type		BCRE 527Y / RC9YCC
Electrode gap	mm	0.80

Electrical system Corolla 1.6 Exec. (AE92) 1987 to 1992

Battery	V / CC / RC	12 / 50Ah
Alternator voltage / full load current / engine rpm		13.5 to 15.1 / _ / 3000
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	—

Running gear Corolla 1.6 Exec. (AE92) 1987 to 1992

Brakes -		
Front (min. friction material thickness)	mm	1.0
Rear (min. friction material thickness)	mm	1.0

Tyres		
Saloon	Size	175/70x13
Estate / Van	Size	—
Pressure - front / rear - Saloon	bar	1.8 / 1.8
- Estate / Van	bar	—

Front suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	+1.0±1.0 ³
Camber		-10'±45'
Castor		+1°20±45'
King pin inclination		+12°40'±45'

Rear suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	+4.0±1.0 ⁴
Camber		-35'±45'

Torque wrench settings Corolla 1.6 Exec. (AE92) 1987 to 1992

Cylinder head - stage 1	Nm	60 in several stages
- stage 2	Nm	—
- stage 3	Nm	—
- stage 4	Nm	—
Big-end bearings	Nm	49
Main bearings	Nm	60
Clutch cover	Nm	19
Flywheel [driveplate]	Nm	78 [64]
Front hubs	Nm	186 ⁵
Rear hubs	Nm	WSM
Wheel nuts / bolts	Nm	103
Spark plugs	Nm	18

Capacities Corolla 1.6 Exec. (AE92) 1987 to 1992

Engine oil & filter	litres	3.3
Gearbox - 4-speed [5-speed]	litres	2.6
Automatic transmission - refill	litres	2.5
Final drive	litres	AT: 1.4
Cooling system	litres	5.2 [AT: 5.5]
Fuel tank	litres	50

Notes and Illustrations

¹Distributor 19020-16110: 0.4 to 3.4 @ 1800, 16 to 19 @ 3700, 26.4 to 30.4 @ 6600


²Distributor 19020-16110: 133 to 573 @ 20 to 24°

³90 ▶: +1.0±2.0


⁴90 ▶: +4.0±2.0

⁵If noisy, retighten to 273


1: Idle speed 2: CO / Mixture



1587 cm³, 16V, to 1992



1587 cm³, 4A-F



Aisan 2V