


Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system Corolla 1.6 4x4 (AE95) 1988 to 1991

Type	4A-F (DOHC 16V)	
Capacity (cm ³) / number of cylinders	1587 / 4	
Compression ratio / pressure	bar	9.5 / ≥9.8
Oil pressure	bar	[2.5 to 5.0]
Oil temperature	°C	80
Valve clearance - inlet	mm	0.15 to 0.25
- exhaust	mm	0.20 to 0.30
Firing order	1-3-4-2	
No 1 cylinder position	TBE	
Thermostat opening temperature	°C	80 to 84
Radiator cap pressure	bar	0.74 to 1.03

Fuel system Corolla 1.6 4x4 (AE95) 1988 to 1991

Idle speed - manual [auto]	rpm	800
Fast idle speed - manual [auto]	rpm	3000±200
CO @ idle speed [3000 rpm] - see page VI	%	1.0 to 2.0
HC @ idle speed [3000 rpm] - see page VI	ppm	≤1200
CO ₂ @ idle speed [3000 rpm] - see page VI	%	-
O ₂ @ idle speed [3000 rpm] - see page VI	%	-
Carburettor / fuel injection	Aisan	
Type / ref	2V, 21100-16300	
Main jet / needle	-	
Injection pressure	bar	-
Pump pressure	bar	-
Octane rating	RON	95[E 95 RON]

Ignition system Corolla 1.6 4x4 (AE95) 1988 to 1991

Type	Electronic	
Ignition coil	-	
Primary resistance	ohms	1.3 to 1.5
Ballast resistor	ohms	-
Voltage - Tmnl 15(+) to earth	V	-
Distributor	-	
Points gap (air gap)	mm	[0.20 to 0.40]
Dwell angle	° (%)	-
Condenser capacity	µF	-
Rotation	-	
Ignition timing - basic [static	° Crankshaft @ rpm	10 BTDC @ 900
V = Vacuum NV = No Vacuum	NV	
Total ignition advance	° Crankshaft @ rpm	-
	° Crankshaft @ rpm	-
	° Crankshaft @ rpm	-
Centrifugal check.	° Crankshaft @ rpm	0 to 3 @ 1600 ¹
	° Crankshaft @ rpm	11.4 to 14.4 @ 3300 ¹
	° Crankshaft @ rpm	19.4 to 23.4 @ 6600 ¹
Vacuum range check	mbar	133 to 560 ²
Maximum vacuum advance	° Crankshaft	13 to 17 ²
Spark plugs	NGK/Champion	
Type	BCRE 527Y / RC9YCC	
Electrode gap	mm	0.80

Electrical system Corolla 1.6 4x4 (AE95) 1988 to 1991

Battery	V / CC / RC	12 / 50Ah
Alternator voltage / full load current / engine rpm	13.5 to 15.1 / _ / 3000	
Starter motor current / voltage - cranking	A / V	-
- locked	A / V	-

Running gear Corolla 1.6 4x4 (AE95) 1988 to 1991

Brakes -		
Front (min. friction material thickness)	mm	1.0
Rear (min. friction material thickness)	mm	1.0

Tyres		
Saloon	Size	-
Estate / Van	Size	165x13: 185/70x13
Pressure - front / rear - Saloon	bar	-
- Estate / Van	bar	1.9 / 1.9

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	+1.0±2.0
Camber	+10'±30'	
Castor	+1°15±30'	
King pin inclination	+12°05'±30'	

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	+1.0±1.0
Camber	-	

Torque wrench settings Corolla 1.6 4x4 (AE95) 1988 to 1991

Cylinder head - stage 1	Nm	60 in several stages
- stage 2	Nm	-
- stage 3	Nm	-
- stage 4	Nm	-
Big-end bearings	Nm	49
Main bearings	Nm	60
Clutch cover	Nm	19
Flywheel [driveplate]	Nm	78
Front hubs	Nm	186 ³
Rear hubs	Nm	WSM
Wheel nuts / bolts	Nm	103
Spark plugs	Nm	18

Capacities Corolla 1.6 4x4 (AE95) 1988 to 1991

Engine oil & filter	litres	3.3
Gearbox - 4-speed [5-speed]	litres	5.0 ⁴
Automatic transmission - refill	litres	-
Final drive	litres	Rear: 1.1
Cooling system	litres	6.2
Fuel tank	litres	50

Notes and Illustrations


¹Distributor 19020-16110: 0.4 to 3.4 @ 1800, 16 to 19 @ 3700, 26.4 to 30.4 @ 6600

²Distributor 19020-16110: 133 to 573 @ 20 to 24°


³If noisy, retighten to 273

⁴Transfer box: 0.7


1: Idle speed 2: CO / Mixture



1587 cm³, 16V



1587 cm³, 4A-F



Aisan 2V