


Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system Vectra-B 2.0i 16V 1995 to 1997

Type		X20XE 16V 100kW 94/12/EC
Capacity (cm ³) / number of cylinders		1998 / 4
Compression ratio / pressure	bar	10.8 / 12.0 to 15.0
Oil pressure	bar	1.5
Oil temperature	°C	80
Valve clearance - inlet	mm	0: Hyd.
Valve clearance - exhaust	mm	0: Hyd.
Firing order		1-3-4-2
No 1 cylinder position		TBE
Thermostat opening temperature	°C	92
Radiator cap pressure	bar	1.2 to 1.5

Fuel system Vectra-B 2.0i 16V 1995 to 1997

Idle speed - manual [auto]	rpm	670 to 1030 N/A
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	≤0.3 WSM
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO ₂ @ idle speed [3000 rpm] - see page VI	%	—
O ₂ @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		_GM
Type / ref		Simtec 56.5 MPI
Main jet / needle		—
Injection pressure	bar	—
Pump pressure	bar	3.0
Octane rating	RON	95[U]

Ignition system Vectra-B 2.0i 16V 1995 to 1997

Type		DIS
Ignition coil		—
Primary resistance	ohms	—
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor		—
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		—
Ignition timing - basic [static V = Vacuum NV = No Vacuum]	° Crankshaft @ rpm	Computer control WSM
Total ignition advance	° Crankshaft @ rpm	Computer control
Centrifugal check.	° Crankshaft @ rpm	Computer control
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs		_/Champion
Type		RC9YCC
Electrode gap	mm	0.7 to 0.8

Electrical system Vectra-B 2.0i 16V 1995 to 1997

Battery	V / CC / RC	12 / 44Ah
Alternator voltage / full load current / engine rpm		70A
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	—

Running gear Vectra-B 2.0i 16V 1995 to 1997

Brakes -		
Front (min. friction material thickness)	mm	7.0 with backing
Rear (min. friction material thickness)	mm	7.0 with backing
Tyres		
Saloon	Size	195/65x15: 205/60x15
Estate / Van	Size	195/65x15: 205/60x15
Pressure - front / rear - Saloon	bar	2.0 / 2.2
- Estate / Van	bar	Refer to vehicle
Front suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	(-3°50'±1°)
Camber		-1°05'±45'
Castor		—
King pin inclination		—
Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	(0°16'±10°)
Camber		-1°10'±35'

Torque wrench settings Vectra-B 2.0i 16V 1995 to 1997


Cylinder head - stage 1	Nm	25 N
- stage 2	Nm	+90°
Cylinder head - stage 3	Nm	+90°
- stage 4	Nm	+90°
Big-end bearings	Nm	35 +45°+15° N
Main bearings	Nm	30 +45° +15° N
Clutch cover	Nm	15
Flywheel [driveplate]	Nm	65 +30° +15° N (60)
Front hubs	Nm	WSM
Rear hubs	Nm	WSM
Wheel nuts / bolts	Nm	110
Spark plugs	Nm	25

Capacities Vectra-B 2.0i 16V 1995 to 1997

Engine oil & filter	litres	5.0
Gearbox - 4-speed [5-speed]	litres	1.9
Automatic transmission - refill	litres	3.0
Final drive	litres	WT
Cooling system	litres	7.2
Fuel tank	litres	60

Notes and Illustrations

—



1998 cm³, 16V