


Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system S40 1.8 1996 to 1997

Type	B4184S 16V 85kW	
Capacity (cm ³) / number of cylinders	1731 / 4	
Compression ratio / pressure	bar	10.5 / 11.0 to 13.0
Oil pressure	bar	1.0 [3.5]
Oil temperature	°C	80
Valve clearance - inlet	mm	0: Hyd.
- exhaust	mm	0: Hyd.
Firing order	1-3-4-2	
No 1 cylinder position	-	
Thermostat opening temperature	°C	90
Radiator cap pressure	bar	1.20 to 1.50

Fuel system S40 1.8 1996 to 1997

Idle speed - manual [auto]	rpm	750 N/A
Fast idle speed - manual [auto]	rpm	-
CO @ idle speed [3000 rpm] - see page VI	%	≤0.3
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO ₂ @ idle speed [3000 rpm] - see page VI	%	-
O ₂ @ idle speed [3000 rpm] - see page VI	%	-
Carburettor / fuel injection	_Siemens Bendix	
Type / ref	Fenix 5.1 MPI	
Main jet / needle	-	
Injection pressure	bar	3.0
Pump pressure	bar	-
Octane rating	RON	95[U]

Ignition system S40 1.8 1996 to 1997

Type	Direct electronic	
Ignition coil	-	
Primary resistance	ohms	-
Ballast resistor	ohms	-
Voltage - Tmnl 15(+) to earth	V	-
Distributor	-	
Points gap (air gap)	mm	-
Dwell angle	° (%)	-
Condenser capacity	µF	-
Rotation	-	
Ignition timing - basic [static V = Vacuum NV = No Vacuum]	° Crankshaft @ rpm	5° to 3° BTDC @ 750 WSM
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	-
	° Crankshaft @ rpm	-
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	-
	° Crankshaft @ rpm	-
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	-
Spark plugs	-	
Type	-	
Electrode gap	mm	-

Electrical system S40 1.8 1996 to 1997

Battery	V / CC / RC	12 / 62Ah
Alternator voltage / full load current / engine rpm	/ 100, 80 /	
Starter motor current / voltage - cranking	A / V	≤300 / 8.1
- locked	A / V	≤600 / 6.5

Running gear S40 1.8 1996 to 1997

Brakes -		
Front (min. friction material thickness)	mm	2.0
Rear (min. friction material thickness)	mm	2.0
Tyres		
Saloon	Size	185/65x14:195/55x15:205/50x15
Estate / Van	Size	-
Pressure - front / rear - Saloon	bar	2.2 / 2.0
- Estate / Van	bar	-
Front suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	[0°3'±6']
Camber		0°±1°
Castor		2°12'±1°
King pin inclination		12°41'±1°
Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	[0°6'+9'-3']
Camber		-0°40'±30'

Torque wrench settings S40 1.8 1996 to 1997


Cylinder head - stage 1	Nm	20 ¹
- stage 2	Nm	60
- stage 3	Nm	+130°
- stage 4	Nm	-
Big-end bearings	Nm	20 +90°
Main bearings	Nm	WSM
Clutch cover	Nm	25
Flywheel [driveplate]	Nm	45 +65° (45 +50°) oiled N
Front hubs	Nm	240
Rear hubs	Nm	175
Wheel nuts / bolts	Nm	110
Spark plugs	Nm	25

Capacities S40 1.8 1996 to 1997

Engine oil & filter	litres	5.3
Gearbox - 4-speed [5-speed]	litres	3.4
Automatic transmission - refill	litres	6.5
Final drive	litres	WT
Cooling system	litres	4.5 to 5.0
Fuel tank	litres	60

Notes and Illustrations

¹Bolt shank length: ≤158 mm



1731 cm³, 16V