

IBM BladeCenter
Management Module
BladeCenter T Management Module
Advanced Management Module
BladeCenter T Advanced Management Module



Command-Line Interface Reference Guide

IBM BladeCenter
Management Module
BladeCenter T Management Module
Advanced Management Module
BladeCenter T Advanced Management Module



Command-Line Interface Reference Guide

Note: Before using this information and the product it supports, read the general information in Appendix A, "Getting help and technical assistance," on page 107 and Appendix B, "Notices," on page 109.

Fifth Edition (January 2006)

© Copyright International Business Machines Corporation 2006. All rights reserved.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Chapter 1. Introduction	1
Before you begin	2
Chapter 2. Using the command-line interface	3
Command-line interface guidelines	3
Selecting the command target	4
Commands and user authority	5
Cabling the management module	9
Networked connection	10
Direct connection	10
Serial connection (advanced management module only)	10
Starting the command-line interface	10
Telnet connection	11
Serial connection	11
Secure Shell (SSH) connection	12
BladeCenter unit configuration	12
Configuring the management module	13
Starting an SOL session	14
Ending an SOL session	15
Chapter 3. Command reference	17
Built-in commands	18
env (environment) command	18
help command	20
history command	21
list (system physical configuration) command	22
Common commands	23
health command	23
identify (location LED) command	25
info (configuration information) command	26
update (update firmware) command	27
Configuration commands	30
alertentries command	30
clear command	36
dhcpinfo command	37
display command (advanced management module only)	38
dns command	38
ifconfig command	40
portcfg command (advanced management module only)	44
read command (advanced management module only)	45
service command (advanced management module only)	45
smtp command	46
snmp command	47
sol (serial over LAN) command	52
tcpcmdmode command	55
telnetcfg (Telnet configuration) command	56
uplink (management module failover) command	57
users (management-module users) command	59
write command (advanced management module only)	69
Event-log commands	69
clearlog command	69
displaylog command	70
Power-control commands	71

boot command	71
fuelg command	72
power command	75
reset command	77
Session commands	79
console command	79
exit command	80
System management commands (for BladeCenter T only)	81
alarm command	81
Chapter 4. Error messages	87
Common errors	88
alarm command errors	89
alertentries command errors	90
boot command errors	90
clear command errors	90
clearlog command errors	91
console command errors	91
dhcpinfo command errors	91
displaylog command errors	91
displaysd command errors	92
dns command errors	92
fuelg command errors	92
health command errors	93
identify command errors	93
ifconfig command errors	93
info command errors	95
list command errors	96
power command errors	96
portcfg command errors	96
read command errors	96
reset command errors	97
service command errors	97
smtp command errors	97
snmp command errors	97
sol command errors	98
tpcmdmode command errors	99
telnetcfg command errors	100
update command errors	100
uplink command errors	102
users command errors	102
write command errors	105
Appendix A. Getting help and technical assistance	107
Before you call	107
Using the documentation	107
Getting help and information from the World Wide Web	107
Software service and support	108
Hardware service and support	108
Appendix B. Notices	109
Edition notice	109
Trademarks	110
Important notes	110
Product recycling and disposal	111
Battery return program	112

Electronic emission notices	113
Federal Communications Commission (FCC) statement	113
Industry Canada Class A emission compliance statement	113
Australia and New Zealand Class A statement	113
United Kingdom telecommunications safety requirement	113
European Union EMC Directive conformance statement	113
Taiwanese Class A warning statement	114
Chinese Class A warning statement	114
Japanese Voluntary Control Council for Interference (VCCI) statement	114
Index	115

Chapter 1. Introduction

The IBM® BladeCenter® management-module command-line interface (CLI) provides direct access to BladeCenter management functions as an alternative to using the Web-based user interface. Using the command-line interface, you can issue commands to control the power and configuration of the management module and other components that are in a BladeCenter unit.

All IBM BladeCenter units are referred to throughout this document as the BladeCenter unit. All management modules are referred to throughout this document as the management module. Unless otherwise noted, all commands can be run on all management module and BladeCenter unit types.

The command-line interface also provides access to the text-console command prompt on each blade server through a serial over LAN (SOL) connection. See the *IBM BladeCenter Serial Over LAN Setup Guide* for information about SOL and setup instructions.

You access the management-module CLI by establishing a Telnet connection to the IP address of the management module or through a Secure Shell (SSH) connection. You can initiate connections from the client computer using standard remote communication software; no special programs are required. Users are authenticated by the management module before they can issue commands. You enter commands one at a time; however, you can use command scripting to enter multiple commands. The interface does not support keyboard shortcuts, except for the special key sequence (pressing “Esc” then “”) that terminates an SOL session.

The most recent versions of all BladeCenter documentation are available from the IBM Web site at <http://www.ibm.com/support/>.

Before you begin

Hardware and software required for the command-line interface are as follows:

Hardware:

No special hardware is required to use the management-module command-line interface.

To use the SOL feature, an Ethernet I/O module that supports SOL must be installed in I/O-module bay 1. You can use the console command to control a blade server through SOL only on blade server types that support SOL functionality and have an integrated system management processor firmware level of version 1.00 or later. See the *IBM BladeCenter Serial Over LAN Setup Guide* for information.

Firmware:

Make sure you are using the latest versions of device drivers, firmware, and BIOS code for your blade server, management module, and other BladeCenter components. Go to the IBM Support Web site, <http://www.ibm.com/support/> for the latest information about upgrading the device drivers, firmware, and BIOS code for BladeCenter components. The latest instructions are in the documentation that comes with the updates.

The management-module CLI is supported by BladeCenter management-module firmware level version 1.08 or later. All versions of BladeCenter T management-module firmware support the command-line interface. The SOL feature has additional firmware requirements. See the *IBM BladeCenter Serial Over LAN Setup Guide* for information.

Chapter 2. Using the command-line interface

The IBM management-module command-line interface (CLI) provides a convenient method for entering commands that manage and monitor BladeCenter components. This chapter contains the following information about using the command-line interface:

- “Command-line interface guidelines”
- “Selecting the command target” on page 4
- “Commands and user authority” on page 5
- “Cabling the management module” on page 9
- “Starting the command-line interface” on page 10
- “BladeCenter unit configuration” on page 12
- “Configuring the management module” on page 13
- “Starting an SOL session” on page 14
- “Ending an SOL session” on page 15

See Chapter 3, “Command reference,” on page 17 for detailed information about commands that are used to monitor and control BladeCenter components. Command-line interface error messages are in Chapter 4, “Error messages,” on page 87. See the *IBM BladeCenter Serial Over LAN Setup Guide* for SOL setup instructions and the documentation for your operating system for information about commands you can enter through an SOL connection.

Command-line interface guidelines

All commands have the following basic structure:

command -option parameter

Some commands do not require options and some command options do not require parameters. You can add multiple options to a command on one line to avoid repeating the same command. Options that display a value and options that set a value must not be used together in the same command. Some examples of valid command option syntax are:

- *command*
- *command -option_set*
- *command -option_set parameter*
- *command -option1_set parameter -option2_set parameter*

For example, `telnetcfg -t 360`.

The information for each option is returned in the order in which it was entered and is displayed on separate lines.

Observe the following general guidelines when using the command-line interface:


- Case sensitivity
All commands, command options, and pre-defined command option parameters are case sensitive.

Note: If you receive a Command not found error, make sure that you are typing the commands in the correct case; they are case sensitive. For a list of valid commands, type `help` or `?`.

- Data types
 - The `ip_address` data type uses a predefined formatted string of `xxx.xxx.xxx.xxx`, where `xxx` is a number from 0 to 255
- Delimiters
 - Options are delimited with a minus sign.
 - In a command that requires parameters, a single space is expected between the option and the parameter. Any additional spaces are ignored.
- Output format
 - Failed commands generate failure messages.
 - Successful commands are indicated by the message OK, or by the display of command results.
- Strings
 - Strings containing spaces should be enclosed in quotation marks, such as in `snmp -cn "John B. Doe"`.
 - String parameters can be mixed case.
- The `help` command lists all commands and a brief description of each command. You can also issue the help command by typing `?`. Adding the `-h` parameter to any command displays its syntax.
- You can use the up arrow and down arrow keys in the command-line interface to access the last eight commands that were entered.

Selecting the command target

You can use the command-line interface to target commands to the management module or to other devices installed in the BladeCenter unit. The command-line prompt indicates the persistent command environment: the environment where commands are entered unless otherwise redirected. When a command-line interface session is started, the persistent command environment is “system”; this indicates that commands are being directed to the BladeCenter unit. Command targets are specified hierarchically, as shown in the following illustration.



You can change the persistent command environment for the remainder of a command-line interface session by using the `env` command (see “`env` (environment) command” on page 18). When you list the target as a command attribute using the `-T` option, you change the target environment for the command that you are

entering, temporarily overriding the persistent command environment. Target environments can be specified using the full path name, or using a partial path name based on the persistent command environment. Full path names always begin with “system”. The levels in a path name are divided using a colon “:”.

For example:

- Use the `-T system:mm[1]` option to redirect a command to the management module in bay 1.
- Use the `-T system:switch[1]` option to redirect a command to the I/O (switch) module in I/O (switch) module bay 1.
- Use the `-T sp` option to redirect a command to the integrated system management processor (service processor) of the blade server in blade bay 3, when the persistent command environment is set to the blade server in blade bay 3.

Most management-module commands must be directed to the primary management module. If only one management module is installed in the BladeCenter unit, it will always act as the primary management module. Either management module can function as the primary management module; however, only one management module can be primary at one time. You can determine which management module is acting as the primary management module using the `list` command (see “list (system physical configuration) command” on page 22).

Commands and user authority

Some commands in the command-line interface can only be successfully executed by users who are assigned a required level of authority. Users with “Supervisor” command authority can successfully execute all commands. Commands that display information do not require any special command authority; however, users can be assigned restricted read-only access, as follows:

- Users with “Operator” command authority can successfully execute all commands that display information.
- Users with “Chassis Operator” custom command authority can successfully execute commands that display information about the common BladeCenter unit components.
- Users with “Blade Operator” custom command authority can successfully execute commands that display information about the blade servers.
- Users with “Switch Operator” custom command authority can successfully execute commands that display information about the I/O modules.

Table 1 on page 6 shows the command-line interface commands and their required authority levels. To use the table, observe the following guidelines:

- The commands listed in this table only apply to the command variants that set values or cause an action: display variants of the commands do not require any special command authority.
- When only one command authority at a time is required to execute a command, this is indicated by a “•” entry in a table row.
- When a command has several rows associated with it, each row indicates one of the valid user command authorities needed to successfully execute the command. For example, the `clearlog` command is available to users with the “Supervisor” command authority or to users with the “Chassis Log Administration” command authority.

- When a combination of two or more command authorities at a time is required to execute a command, this is indicated by multiple “◇” entries in a table row. The user must be assigned both of these command authorities to successfully execute the command. For example, one available authority combination for the power -on -c command is the “Blade Server Remote Presence” command authority and the “Blade Administration” command authority.

Important: Command authority definitions might change between firmware versions. Make sure that the command authority level set for each user is correct after updating management-module firmware.

Table 1. Command authority relationships

Command	Authority									
	Supervisor	Chassis User Account Management	Blade Server Remote Presence	Chassis Administration	Blade Administration	I/O Module Administration	Chassis Log Administration	Chassis Configuration	Blade Configuration	I/O Module Configuration
alarm -c, -r, -s	•									
								•		
									•	•
alarm -q -g	•									
			•		•					
alertentries	•									
								•		
boot	•									
					•					
boot -c	•									
			◇		◇					
boot -p	•									
					•					
clear -config	•									
								•		•
clearlog	•									
							•			

Table 1. Command authority relationships (continued)

Command	Authority										
	Supervisor	Chassis User Account Management	Blade Server Remote Presence	Chassis Administration	Blade Administration	I/O Module Administration	Chassis Log Administration	Chassis Configuration	Blade Configuration	I/O Module Configuration	
console	•		•								
console -o	•		•								
dns	•							•			
fuelg	•							•			
identify	•							•	•		
ifconfig	•							•	•	•	
portcfg	•							•			
power -on, -off, -cycle	•				•	•					
power -on -c, -cycle -c	•		◇		◇						
read -config	•							•			
reset (blade server or ISMP)	•				•						
reset (I/O module)	•					•					
reset (management module)	•			•							

Table 1. Command authority relationships (continued)

Command	Authority										
	Supervisor	Chassis User Account Management	Blade Server Remote Presence	Chassis Administration	Blade Administration	I/O Module Administration	Chassis Log Administration	Chassis Configuration	Blade Configuration	I/O Module Configuration	
reset -c (blade server or ISMP)	•		◇		◇						
reset -clr, -dg, -ddg, -sft (blade server)	•				•						
reset -exd, -full , -std (I/O module)	•					•					
reset -f (management module)	•			•							
service	•							•			
smtp	•							•			
snmp	•							•			
sol	•							•			
tcpcmdmode	•							•	•		
telnetcfg	•							•			
update	•			•	•	•					
uplink -del, -off, -on	•							•			
users	•	•									

Table 1. Command authority relationships (continued)

Command	Authority									
	Supervisor	Chassis User Account Management	Blade Server Remote Presence	Chassis Administration	Blade Administration	I/O Module Administration	Chassis Log Administration	Chassis Configuration	Blade Configuration	I/O Module Configuration
write -config	•							•		

Cabling the management module

You must connect a client computer to the management module to configure and manage operation of the BladeCenter unit. All management modules support a remote management and console (Ethernet) connection. The advanced management module also supports connection through the serial management port.

You can manage the BladeCenter unit by using the command-line interface that you access through Telnet or through the serial management port (advanced management module only). You can also use the graphical user interface that is provided by the management-module Web interface to manage the BladeCenter unit and blade servers that support KVM. Management connections to blade servers that do not support KVM are made using an SOL session through the management-module command-line interface. To connect to the management-module command-line interface, you need the following equipment and information:

- A computer with Ethernet or serial connection capability. To facilitate connections at multiple locations, you can use a notebook computer.
- The management-module MAC address (listed on the label on the management module).
- For networked connection to the management module, you need the following equipment:
 - A standard Ethernet cable
 - A local Ethernet network port (facility connection)
- For direct connection of a computer to the management-module remote management and console (Ethernet) connector, an Ethernet crossover cable. The advanced management module can use either a standard Ethernet cable or an Ethernet crossover cable to make this connection.
- For serial connection of a computer to the advanced management-module serial connector, you need a serial cable. See the *Installation Guide* for your management module for cabling information and instructions.

For information about accessing the management-module Web interface, see the *BladeCenter Management Module User's Guide*.

The following sections describe how to cable to the management module to perform initial configuration of the BladeCenter unit. See the *Installation Guide* for your management module for specific cabling instructions.

Networked connection

Connect one end of a Category 5 or higher Ethernet cable to the remote management and console (Ethernet) connector on the management module. Connect the other end of the Ethernet cable to the facility network.

Direct connection

Connect one end of a Category 5 or higher Ethernet cable (advanced management module only) or a Category 5 or higher Ethernet crossover cable (management module and advanced management module) to the remote management and console (Ethernet) connector on the management module. Connect the other end of the cable to the Ethernet connector on the client computer.

Serial connection (advanced management module only)

Connect one end of a serial cable to the serial connector on the management module. Connect the other end of the serial cable to the serial connector on the client computer. See the *Installation Guide* for your management module for cabling information and instructions.

Starting the command-line interface

Access the management-module command-line interface from a client computer by establishing a Telnet connection to the IP address of the management module or by establishing a Secure Shell (SSH) connection. For the advanced management module, you can also access the command-line interface using a serial connection. You can establish up to 20 separate Telnet, serial, or SSH sessions to the BladeCenter management module, giving you the ability to have 20 command-line interface sessions active at the same time.

Although a remote network administrator can access the management-module command-line interface through Telnet, this method does not provide a secure connection. As a secure alternative to using Telnet to access the command-line interface, use a serial or SSH connection. SSH ensures that all data that is sent over the network is encrypted and secure.

The following SSH clients are available. While some SSH clients have been tested, support or non-support of any particular SSH client is not implied.

- The SSH clients distributed with operating systems such as Linux[®], AIX[®], and UNIX[®] (see your operating-system documentation for information). The SSH client of Red Hat Linux 8.0 Professional was used to test the command-line interface.
- The SSH client of cygwin (see <http://www.cygwin.com> for information)
- Putty (see <http://www.chiark.greenend.org.uk/~sgtatham/putty> for information)

The following table shows the types of encryption algorithms that are supported, based on the client software version that is being used.

Algorithm	SSH version 1.5 clients	SSH version 2.0 clients
Public key exchange	SSH 1-key exchange algorithm	Diffie-Hellman-group 1-sha-1
Host key type	RSA (1024-bit)	DSA (1024-bit)

Algorithm	SSH version 1.5 clients	SSH version 2.0 clients
Bulk cipher algorithms	3-des	3-des-cbc or blowfish-cbc
MAC algorithms	32-bit crc	Hmac-sha1

The following sections describe how to connect to the management module to perform initial configuration of the BladeCenter unit. The management module has the following default settings:

- IP address: 192.168.70.125
- Subnet: 255.255.255.0
- User ID: USERID (all capital letters)
- Password: PASSWORD (note the number zero, not the letter O, in PASSWORD)

The computer that you are connecting to the management module must be configured to operate on the same subnet as the BladeCenter management module. If the IP address of the management module is outside of your local domain, you must change the Internet protocol properties on the computer that you are connecting.

Telnet connection

To log on to the management module using Telnet, complete the following steps:

1. From a command-line prompt on the network-management workstation, type `telnet 192.168.70.125`, and press Enter. The IP address 192.168.70.125 is the default IP address of the management module; if a new IP address has been assigned to the management module, use that one instead.
2. At the login prompt, type the management-module user ID. At the password prompt, type the management-module password. The user ID and password are case sensitive and are the same as those that are used for management-module Web access. The default management-module user name is USERID and the default password is PASSWORD (note the number zero, not the letter O, in PASSWORD).

The CLI command prompt is displayed. You can now enter commands for the management module.

Serial connection

After connecting a serial cable from the management module to the client computer, complete the following steps:

1. Open a terminal session on the client computer, and make sure that the serial port settings for the client computer match the settings for the serial port on the management module. The default management-module serial port settings are as follows:
 - Baud rate: 57600
 - Parity: no parity
 - Stop bits: 1
2. Remove the management module from the BladeCenter unit; then, reinsert it.
3. At the login prompt, type the management-module user ID. At the password prompt, type the management-module password. The user ID and password are case sensitive and are the same as those that are used for management-module Web access. The default management-module user name is USERID and the default password is PASSWORD (note the number zero, not the letter O, in PASSWORD).

The CLI command prompt is displayed. You can now enter commands for the management module.

Secure Shell (SSH) connection

To log on to the management module using SSH, complete the following steps:

1. Make sure that the SSH service on the network-management workstation is enabled. See your operating-system documentation for instructions.
2. Make sure that the SSH server on the BladeCenter management module is enabled. See the *IBM BladeCenter Management Module User's Guide* for instructions.
3. Start an SSH session to the management module using the SSH client of your choice. For example, if you are using the cygwin client, from a command-line prompt on the network-management workstation, type `ssh 192.168.70.125`, and press Enter. The IP address 192.168.70.125 is the default IP address of the management module; if a new IP address has been assigned to the management module, use that one instead.
4. Type the management-module user ID when prompted. At the password prompt, type the management-module password. The user ID and password are case sensitive and are the same as those that are used for management-module Web access. The default management-module user name is USERID and the default password is PASSWORD (note the number zero, not the letter O, in PASSWORD).

The CLI command prompt is displayed. You can now enter commands for the management module.

BladeCenter unit configuration

The BladeCenter unit automatically detects the modules and blade servers that are installed and stores the vital product data (VPD). When the BladeCenter unit is started, the management module automatically configures the remote management port of the management module, so that you can configure and manage BladeCenter components. You configure and manage BladeCenter components remotely using the management-module command-line interface (CLI) or the management-module Web interface.

To communicate with network resources and with the I/O modules in the BladeCenter unit, you must configure IP addresses for the management module and I/O modules. Management-module IP addresses can be configured using the Web interface or command-line interface. There are several ways to configure the I/O modules: through the management-module Web interface, or through an external I/O-module port enabled through the management module, using a Telnet interface, serial connection (advanced management module only), or a Web browser. See the documentation that comes with each I/O module for information and instructions.

To communicate with the blade servers for functions such as deploying an operating system or application program over a network, you must also configure at least one external (in-band) port on an Ethernet switch module in I/O-module bay 1 or 2.

Note: If a pass-thru module is installed in I/O-module bay 1 or 2 (instead of an Ethernet I/O module), you will need to configure the network switch that the pass-thru module is connected to; see the documentation that comes with the network switch for instructions.

Configuring the management module

You configure only the primary (active) management module. The redundant management module, if present, receives the configuration and status information automatically from the primary management module when necessary. The configuration information in this section applies to the primary management module, which might be the only management module in the BladeCenter unit.

If the management module that you installed is a replacement for the only management module in the BladeCenter unit, and you saved the configuration file before replacing the management module, you can apply the saved configuration file to the replacement management module. See “read command (advanced management module only)” on page 45 for information about applying a saved configuration file. Other management modules must have their configurations restored using the management-module Web interface (see the *BladeCenter Management Module User's Guide* for information).

For the active management module to communicate, you must configure the IP addresses for the following internal and external ports:

- The external Ethernet (remote management) port (eth0) of the management module. The initial automatic management module configuration enables a remote console to connect to the management module to configure the port completely and to configure the rest of the BladeCenter unit.
- The internal Ethernet port (eth1) on the management module for communication with the I/O modules. Internal Ethernet ports for the advanced management module cannot be configured.

After you connect the active management module to the network, the Ethernet port connection is configured in one of the following ways. Either of these actions enables the Ethernet connection on the active management module.

- If you have an accessible, active, and configured dynamic host configuration protocol (DHCP) server on the network, IP address, gateway address, subnet mask, and DNS server IP address are set automatically. The host name is set to the management-module MAC address by default, and the domain server cannot change it.
- If the DHCP server does not respond within 3 minutes after the port is connected, the management module uses the factory-defined static IP address and default subnet address.

Important: You can not connect to the management module using the factory-defined static IP address and default subnet address until after this 3-minute period passes.

Note: If the IP configuration is assigned by the DHCP server, the network administrator can use the MAC address of the management-module network interface to find out what IP address is assigned.

To configure the management-module internal and external Ethernet ports, complete the following steps:

1. Connect to the management-module command-line interface (see “Starting the command-line interface” on page 10 for more information).
2. Configure the external Ethernet interface (eth0), using the ifconfig command (see “ifconfig command” on page 40 for instructions).

3. For management modules other than the advanced management module, configure the internal Ethernet interface (eth1), using the ifconfig command (see “ifconfig command” on page 40 for instructions).

Notes:

- a. The internal Ethernet management port on each I/O module provides for communication with the management module. You configure this port by configuring the IP address for the I/O module (see the *BladeCenter Management Module User's Guide* and the *User's Guide* for your I/O module type for information and instructions). Some types of I/O modules, such as the pass-thru module, have no management port. See the documentation that comes with each I/O module to determine what else you must configure in the I/O module.
- b. For I/O module communication with a remote management station, such as the IBM Director server, through the management-module external Ethernet port, the I/O module internal network interface and the management-module internal and external interfaces must be on the same subnet.
- c. To communicate with the blade servers for functions such as deploying an operating system or application program, you also will need to configure at least one external (in-band) port on an Ethernet I/O module.

Starting an SOL session

Note: Serial over LAN (SOL) must be enabled for both the BladeCenter unit and the blade server before you can start an SOL session with the blade server. See “sol (serial over LAN) command” on page 52 and the *BladeCenter Serial over LAN Setup Guide* for information about setting up and enabling SOL.

After you start a Telnet or SSH session to the BladeCenter management module, you can start an SOL session to any individual blade server that supports SOL. Since you can start up to 20 separate Web interface, Telnet, serial (advanced management module only), or SSH sessions to the BladeCenter management module, this gives you the ability to have simultaneous SOL sessions active for each blade server installed in the BladeCenter unit.

Start an SOL session using the `console` command, from the command line, indicating the target blade server. For example, to start an SOL connection to the blade server in blade bay 6, type

```
console -T system:blade[6]
```

Note: A blade server assembly that occupies more than one blade bay is identified by the lowest bay number that it occupies.

Once an SOL session is started, all commands are sent to the blade server specified by the `console` command until the SOL session is ended, regardless of the persistent command target that was in effect before the SOL session.

See “sol (serial over LAN) command” on page 52 and the *IBM BladeCenter Serial over LAN Setup Guide* for information about configuring a blade server for SOL. See your operating-system documentation for information about SOL commands that you can enter using the command-line interface.

Ending an SOL session

To end an SOL session, press Esc followed by an open parenthesis:

Esc (

When the SOL session ends, the command-line interface will return to the persistent command target that was in effect before the SOL session. If you want to end the Telnet or SSH command-line session, type `exit`.

Note: Exiting an SOL session does not stop the flow of serial data.

Chapter 3. Command reference

This section contains command function, usage information, and examples. It is divided into the following subsections:

- “Built-in commands” on page 18
 - env (environment) command
 - help command
 - history command
 - list (system physical configuration) command
- “Common commands” on page 23
 - health command
 - identify (location LED) command
 - info (configuration information) command
 - update (update firmware) command
- “Configuration commands” on page 30
 - alertentries command
 - clear command
 - dhcpinfo command
 - displaysd command (advanced management module only)
 - dns command
 - ifconfig command
 - portcfg command (advanced management module only)
 - read command (advanced management module only)
 - service command (advanced management module only)
 - smtp command
 - snmp command
 - sol (serial over LAN) command
 - tcpcmdmode command
 - telnetcfg (Telnet configuration) command
 - uplink (management module failover) command
 - users (management-module users) command
 - write command (advanced management module only)
- “Event-log commands” on page 69
 - clearlog command
 - displaylog command
- “Power-control commands” on page 71
 - boot command
 - fuelg command
 - power command
 - reset command
- “Session commands” on page 79
 - console command
 - exit command
- “System management commands (for BladeCenter T only)” on page 81
 - alarm command

Adding a `-h`, `-help`, or `?` option to a command displays syntax help for that command. For example, to display help for the environment command, type one of the following commands:

- `env -h`
- `env -help`
- `env ?`

You can target a command to a device other than the one that is set as the default by adding a `-T` option to a command. See “Selecting the command target” on page 4 for information.

Built-in commands

Use these commands to perform top-level functions within the command-line interface:

- `env` (environment) command
- `help` command
- `history` command
- `list` (system physical configuration) command

env (environment) command

This command sets the persistent environment for commands that are entered during the remainder of the current session. The persistent command environment is indicated by the command prompt. When you start the command-line interface, the persistent command environment is the BladeCenter unit, denoted as “system” by the command prompt. You can target a single command to an environment other than the one that is set as the default by adding a `-T` option to the command that includes a valid target destination (see “Selecting the command target” on page 4 for information). Target environments can be specified using the full path name, or using a partial path name based on the persistent command environment. Full path names always begin with “system”. The levels in a path name are divided using a colon “.”.

Table 2. `env` (environment) command

Function	What it does	Command	Valid targets
Set BladeCenter unit as command target	Sets the BladeCenter unit as the persistent target for commands during the current session. This is the persistent command environment you are in at the beginning of each command-line interface session, indicated by the <code>system></code> prompt.	<code>env</code> <code>env -T system</code>	The <code>env</code> command can be directed to any installed device.
Set management module as command target	Sets the management module as the persistent target for commands during the current session.	<code>env -T system:mm[x]</code> where <code>x</code> is the bay (1 or 2) that identifies the management module.	The <code>env</code> command can be directed to any installed device, in this case <code>-T system:mm[x]</code> where <code>x</code> is the management-module bay number.
Set blade server as command target	Sets the specified blade server as the persistent target for commands during the current session.	<code>env -T system:blade[x]</code> where <code>x</code> is the blade bay that identifies the blade server. A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies.	The <code>env</code> command can be directed to any installed device, in this case <code>-T system:blade[x]</code> where <code>x</code> is the blade bay that identifies the blade server.

Table 2. env (environment) command (continued)

Function	What it does	Command	Valid targets
Set blade server integrated system management processor as command target	Sets the integrated system management processor on the specified blade server as the persistent target for commands during the current session.	env -T system:blade[x]:sp where x is the blade bay that identifies the blade server on which the integrated system management processor is installed. A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies.	The env command can be directed to any installed device, in this case -T system:blade[x]:sp where x is the blade bay that identifies the blade server on which the integrated system management processor is installed.
Set I/O (switch) module as command target	Sets the specified I/O (switch) module as the persistent target for commands during the current session.	env -T system:switch[x] where x is the I/O (switch) module bay where the I/O (switch) module is installed.	The env command can be directed to any installed device, in this case -T system:switch[x] where x is the I/O (switch) module bay where the I/O (switch) module is installed.

Example:

To set the persistent target of commands to the service processor on the blade server in blade bay 5, while the BladeCenter unit is set as the default command target, at the system> prompt, type

```
env -T system:blade[5]:sp
```

The following example shows the information that is returned:

```
system> env -T system:blade[5]:sp
OK
system:blade[5]:sp>
```

To set the persistent target of commands to the service processor on the blade server in blade bay 5, while the BladeCenter unit is set as the default command target, at the system> prompt, you can also type

```
env -T blade[5]:sp
```

The following example shows the information that is returned:

```
system> env -T blade[5]:sp
OK
system:blade[5]:sp>
```

To issue the reset command on the blade server in blade bay 5, while the management module is set as the default command target, at the system:mm[x]> prompt, type

```
reset -T system:blade[5]
```

help command

This command displays a list of all commands that are available in the command-line interface with a brief description of each command. You can also issue the help command by typing ?. Adding a -h, -help, or ? option to a command displays syntax help for the command.

Table 3. help command

Function	What it does	Command	Valid targets
Help	Displays a list of commands and a brief description of each command.	help	Any installed device.
		?	Any installed device.

Example:

To display a list of commands, while management module 1 is set as the default command target, at the system:mm[1]> prompt, type

```
help
```

The following example shows the information that is returned:

```
system:mm[1]> help
?- Display commands
alertentries- View/edit remote alert recipients
boot- Boot target
clear- Clear the config
clearlog- Clear the event log
console- Start SOL session to a blade
dhcpinfo- View DHCP server assigned settings
displaylog- Display event log entries
displaysd- Display service data
dns- View/edit DNS config
env- Set persistent command target
exit- Log off
health- View system health status
help- Display command list
history- Display command history
identify- Control target location LED
ifconfig- View/edit network interface config
info- Display identity and config of target
list- Display installed targets
portcfg- Serial port configuration
power- Control target power
read- Restore configuration from chassis
reset- Reset target
service- Enable debugging by service personnel
shutdown- Shutdown target
smtp- View/edit SMTP config
snmp- View/edit SNMP config
sol- View SOL status and view/edit SOL config
tcpcmdmode- View/edit TCP command mode config
telnetcfg- View/edit telnet config
update- Update firmware from TFTP server
users- View/edit user login profiles
alarm- Manage Telco System Management alarm(s)
write- Save configuration to chassis
```

Type "<command> -h" for individual command syntax help.

[] is used for indexing (by bay number)
 < > denotes a variable
 { } denotes optional arguments
 | denotes choice
 system:mm[1]>

To obtain help about the env command, type one of the following commands:

- env -h
- env -help
- env ?

history command

This command displays the last eight commands that were entered, allowing the user to choose and re-enter one of these commands. You choose the command to re-enter from the displayed list by typing an exclamation point (!) followed immediately by the numeric designation the command is assigned in the list. You can also recall one of the past eight previously entered commands using the up-arrow and down-arrow keys.

Table 4. history command

Function	What it does	Command	Valid targets
Command history	Displays the last eight commands that were entered.	history	Any installed device.
Re-enter previous command using numeric designation	Re-enters a numerically-specified command from the command history.	!x where x is the number of the command (0 - 7) to re-enter from the command history list.	Any installed device.

Example:

To display a list of the last eight commands entered, while management module 1 is set as the default command target, at the system:mm[1]> prompt, type
 history

To re-enter the command designated by “2” in the command history, type
 !2

The following example shows the information that is returned from these two commands:

```
system:mm[1]> history
0 dns
1 dns -on
2 dns
3 dns -i1 192.168.70.29
4 dns
5 dns -i1 192.168.70.29 -on
6 dns
7 history
system:mm[1]> !2
Enabled
-i1 192.168.70.29
-i2 0.0.0.0
-i3 0.0.0.0
```

```
system:mm[1]>
```

list (system physical configuration) command

This command displays a list of devices present within the command target. It can be used to determine how many management modules are installed in the BladeCenter unit and which management module is set as primary.

Table 5. list (system physical configuration) command

Function	What it does	Command	Valid targets
View command target	Displays the current command target. If a management-module bay is the current command target, it will be identified as primary or redundant.	list	Any installed device.
View system configuration tree	Displays the tree structure of devices present in the BladeCenter unit, starting at the command target level. If management-module bays are part of the tree, they will be identified as primary or redundant.	list -l <i>depth</i> where <i>depth</i> is "all" or "a" for full tree display, starting at the command target level. Specifying a <i>depth</i> of "1" displays the current command target. Specifying a <i>depth</i> of "2" displays the content of the current command target plus one level below it.	Any installed device.

Example:

To display a list of devices installed in the BladeCenter unit, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

```
list -l a
```

(This is the command syntax that can be used to determine the primary management module.)

The following example shows the information that is returned:

```
system> list -l a
system
    mm[1]    primary
    power[4]
    blower[1]
    blower[2]
    blade[1]
        sp
        dtr[1]
    blade[5]
        sp
    blade[6]
        sp
    blade[7]
        sp
    blade[8]
        sp
    mt
```

system>

Common commands

Use these commands to monitor and control operation of BladeCenter components using the command-line interface:

- health command
- identify (location LED) command
- info (configuration information) command
- update (update firmware) command

health command

This command displays the current health status of the command target. It can also be used to display the alerts that are active for the command target. You can only specify one command target each time you run the health command.

Table 6. health command

Function	What it does	Command	Valid targets
Display health status	Displays the current health status of the command target. Return values are different for the BladeCenter and BladeCenter T configurations. <ul style="list-style-type: none">• Possible return values for the BladeCenter configuration are:<ul style="list-style-type: none">– ok– warning– critical• Possible return values for the BladeCenter T configurations are:<ul style="list-style-type: none">– ok– minor– major– critical	health	-T system -T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.
Display health status for tree	Displays the current health status of the tree structure of devices present in the BladeCenter unit, starting at the command target level. If management-module bays are part of the tree, they will be identified as primary or redundant. Return values are different for the BladeCenter and BladeCenter T configurations. <ul style="list-style-type: none">• Possible return values for the BladeCenter configuration are:<ul style="list-style-type: none">– ok– warning– critical• Possible return values for the BladeCenter T configurations are:<ul style="list-style-type: none">– ok– minor– major– critical	health -l <i>depth</i> where <i>depth</i> is “2”, “all”, or “a” for full tree display, starting at the command target level. Specifying a <i>depth</i> of “1” displays health status of the current command target.	-T system -T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.

Table 6. health command (continued)

Function	What it does	Command	Valid targets
Display health status and alerts	<p>Displays the current health status and active alerts for the command target. Return values are different for the BladeCenter and BladeCenter T configurations.</p> <ul style="list-style-type: none"> • Possible return values for the health status of the BladeCenter configuration are: <ul style="list-style-type: none"> – ok – warning – critical • Possible return values for the health status of the BladeCenter T configurations are: <ul style="list-style-type: none"> – ok – minor – major – critical • Active alert information provides short text descriptions of alerts that are active for each monitored component. <p>The total amount of information returned from the health -f command is limited to 1024 bytes.</p>	health -f	<ul style="list-style-type: none"> -T system -T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] <p>where x is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.</p>

Example:

To display the overall health status of the BladeCenter T unit, while the BladeCenter T unit is set as the default command target, at the system> prompt, type

```
health
```

To display the health status of all components installed in the BladeCenter T unit, that are valid command targets, while the BladeCenter T unit is set as the default command target, at the system> prompt, type

```
health -l a
```

To display the health status of the blade server installed in blade bay 5, while the BladeCenter T unit is set as the default command target, at the system> prompt, type

```
health -T system:blade[5]
```

To display the health status and alerts for all components installed in the BladeCenter T unit, that are valid command targets, while the BladeCenter T unit is set as the default command target, at the system> prompt, type

```
health -l a -f
```

The following example shows the information that is returned from these commands:

```
system> health
system:major
system> health -l a
system:major
mm[1]:ok
```



```

blade[1]:ok
blade[3]:ok
blade[5]:minor
power[1]:ok
power[2]:minor
blower[1]:ok
blower[2]:ok
blower[3]:ok
blower[4]:ok
switch[1]:major
system> health -T system:blade[5]
blade[5]:minor
health -l a -f
system:major
  blade[5]:minor
    5V over voltage
    CPU1 temperature warning
  power[2]:minor
    5V over voltage
  switch[1]:major
    temperature fault
system>

```

identify (location LED) command

This command controls operation of the location LED in a blade server or in the BladeCenter unit. It can also be used to display the state of a location LED.

Table 7. identify (location LED) command

Function	What it does	Command	Valid targets
Display location LED state	Displays the current state of the location LED in the command target. Possible LED states are: <ul style="list-style-type: none"> • off • on • blink 	identify	-T system -T system:blade[x] where x is the blade bay number.
Set location LED state	Sets the state of the location LED in the command target.	identify -s <i>state</i> where <i>state</i> is “on”, “off”, or “blink”. Command use restricted (see “Commands and user authority” on page 5).	-T system -T system:blade[x] where x is the blade bay number.
Turn on BladeCenter unit location LED for specified period of time	Turns on the location LED in the BladeCenter unit for a specified period of time before turning it off automatically.	identify -s on -d <i>time</i> where <i>time</i> is the number of seconds the location LED will remain lit. Command use restricted (see “Commands and user authority” on page 5).	-T system

Example:

To display the status of the location LED in the blade server in blade bay 4, while the BladeCenter unit is set as the persistent command environment, at the `system>` prompt, type

```
identify -T system:blade[4]
```

To light the location LED in the blade server in blade bay 4, while the BladeCenter unit is set as the persistent command environment, at the `system>` prompt, type

```
identify -s on -T system:blade[4]
```

The following example shows the information that is returned from a series of `identify` commands:

```
system> identify -T system:blade[4]
-s off
system> identify -s on -T system:blade[4]
OK
system> identify -T system:blade[4]
-s on
system>
```

info (configuration information) command

This command displays information about BladeCenter components and their configuration.

Table 8. *info (configuration information) command*

Function	What it does	Command	Valid targets
Display component information	Displays identification and configuration information for the command target.	info Note: Only one target at a time can be viewed with the <code>info</code> command.	-T system:mm[x] -T system:blade[x] -T system:blade[x]:dtr[x] -T system:blade[x]:sp -T system:blade[x]:be -T system:switch[x] -T system:power[x] -T system:mt where <i>x</i> is the management-module bay number, blade server bay number, I/O (switch) module bay number, power module bay number, or daughter-card number.

Note: The command target `-T system:blade[x]:dtr[x]` is shown with a line break before `:dtr[x]`. When this command target is entered, the entire entry must all be on one line.

Example:

To view the information about the management module in management-module bay 1, while this management module is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
info
```

The following example shows the information that is returned from the info command:

```

system:mm[1]> info
UUID: 0000 0000 0000 0000 0000 0000 0000 0000
Manuf ID: SLRM
Mach type/model: Management Module
Mach serial number: n/a
Manuf date: 4102
Part no.: 02R1606
FRU no.: 59P6622
FRU serial no.: J1P702A511F
Main application
  Build ID:      DVETXX-
  File name:    CNETMNUS.PKT
  Rel date:     05-27-04
  Rev:          16
Boot ROM
  Build ID:      BRBR14-
  File name:    CNETBRUS.PKT
  Rel date:     09-12-02
  Rev:          16
Remote control
  Build ID:      BRRG14-
  File name:    CNETRGUS.PKT
  Rel date:     09-12-02
  Rev:          16
system:mm[1]>

```

update (update firmware) command

This command updates firmware using a Trivial File Transfer Protocol (TFTP) server and displays information about firmware installed in BladeCenter components.

Table 9. update (update firmware) command

Function	What it does	Command	Valid targets
Display update command help	Displays information about using the update command.	update	-T system:mm[x] -T system:blade[x]:sp -T system:switch[x] where x is the primary management-module, blade server bay number, or I/O (switch) module bay number.
Display firmware attributes	Displays attributes of the firmware installed in the command target. Return values are: <ul style="list-style-type: none"> • Firmware type • Build ID • Filename • Release date • Revision level 	update -a	-T system:mm[x] -T system:blade[x]:sp -T system:switch[x] where x is the primary management-module, blade server bay number, or I/O (switch) module bay number.

Table 9. update (update firmware) command (continued)

Function	What it does	Command	Valid targets
Update firmware	Update firmware for the command target. Important: Command authority definitions might change between firmware versions. Make sure that the command authority level set for each user is correct after updating management-module firmware.	update -i <i>ip_address</i> -l <i>filelocation</i> where: <ul style="list-style-type: none"> <i>ip_address</i> is the IP address of TFTP server. <i>filelocation</i> is the location of the firmware update file. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] -T system:blade[x]:sp -T system:switch[x] where x is the primary management-module, blade server bay number, or I/O (switch) module bay number.
Update firmware (verbose)	Update firmware for the command target, showing details of the firmware download and flash operations. The detailed information is not shown until the update is complete, which might take several minutes. Important: Command authority definitions might change between firmware versions. Make sure that the command authority level set for each user is correct after updating management-module firmware.	update -i <i>ip_address</i> -l <i>filelocation</i> -v where: <ul style="list-style-type: none"> <i>ip_address</i> is the IP address of TFTP server. <i>filelocation</i> is the location of the firmware update file. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] -T system:blade[x]:sp -T system:switch[x] where x is the primary management-module, blade server bay number, or I/O (switch) module bay number.

Example:

To update the firmware and display update details for the management module in management-module bay 1, while this management module is set as the persistent command environment, type the following command at the system:mm[1]> prompt. For this example, the IP address of the TFTP server is 192.168.70.120 and the firmware file containing the update is named dev_mm.pkt.

```
update -v -i 192.168.70.120 -l dev_mm.pkt
```

To display information about firmware installed in the management module in management-module bay 1, while this management module is set as the persistent command environment, at the system:mm[1]> prompt, type

```
update -a
```

To update the service-processor firmware in the blade server in blade bay 8 (not using verbose mode), while the management module in management-module bay 1 is set as the persistent command environment, type the following command at the system:mm[1]> prompt. For this example, the IP address of the TFTP server is 192.168.70.120 and the firmware file containing the update is named h8.pkt.

```
update -i 192.168.70.120 -l h8.pkt -T system:blade[8]:sp
```

The following example shows the information that is returned from these three update commands:

```
system:mm[1]> update -v -i 192.168.70.120 -l dev_mm.pkt
TFTP file upload successful 1517829.
Starting flash packet preparation.
Flash preparation - packet percent complete 24.
```

```
Flash preparation - packet percent complete 48.
Flash preparation - packet percent complete 72.
Flash preparation - packet percent complete 96.
Flash preparation - packet percent complete 100.
Flash operation phase starting.
Flashing - packet percent complete 34.
Flashing - packet percent complete 38.
Flashing - packet percent complete 50.
Flashing - packet percent complete 55.
Flashing - packet percent complete 80.
Flashing - packet percent complete 90.
Flash operation complete. The new firmware will become active after the next
reset of the MM.
OK
system:mm[1]> update -a
Bay 1 Name 1
Firmware type: Main application
Build ID: BRETkd+
Filename: CNETMNUS.PKT
Released: 11-17-03
Revision: 16
Firmware type: Boot ROM
Build ID: BRBR1B+
Filename: CNETBRUS.PKT
Released: 10-27-03
Revision: 16
Firmware type: Remote control
Build ID: BRRG1B+
Filename: CNETRGUS.PKT
Released: 10-27-03
Revision: 16
OK
system:mm[1]> update -i 192.168.70.120 -l h8.pkt -T system:blade[8]:sp
OK
system:mm[1]>
```

Configuration commands

Use these commands to view and configure network settings and Ethernet interfaces:

- alertentries command
- clear command
- dhcpinfo command
- displaysd command (advanced management module only)
- dns command
- ifconfig command
- service command (advanced management module only)
- smtp command
- snmp command
- sol (serial over LAN) command
- tcpcmdmode command
- telnetcfg (Telnet configuration) command
- uplink (management module failover) command
- users (management-module users) command

alertentries command

This command manages the recipients of alerts generated by the primary management module.

Table 10. alertentries command

Function	What it does	Command	Valid targets
Display alert properties for all recipients	Displays alert properties for all management-module alert recipients. Returned values for each alert recipient are: <ul style="list-style-type: none"> • recipient name • notification method (E-Mail over LAN/Director comp./SNMP over LAN) • type of alerts received (Receives critical alerts only/Receives all alerts/Disabled) 	alertentries	-T system:mm[x] where x is the primary management-module bay number.
Display alert properties for alert recipients	Displays alert properties for the specified management-module alert recipient profile. Returned values are: <ul style="list-style-type: none"> • -status <i>alert_recipient_status</i> (on/off) • -n <i>alert_recipient_name</i> • -f <i>alert_type</i> (critical/none) • -t <i>notification_method</i> (email/director/snmp) • -e <i>email_address</i> (used for e-mail notifications) • -i <i>static_IP_addr/hostname</i> (used for IBM Director notifications) 	alertentries - <i>recip_number</i> where <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list.	-T system:mm[x] where x is the primary management-module bay number.

Table 10. alertentries command (continued)

Function	What it does	Command	Valid targets
Delete alert recipient	Delete the specified alert recipient.	<p>alertentries -<i>recip_number</i> -del</p> <p>where <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the “Display alert properties for all recipients” list. It is possible to delete an empty alert recipient.</p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[<i>x</i>]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 10. alertentries command (continued)

Function	What it does	Command	Valid targets
Create alert recipient	<p>Create the specified alert recipient.</p> <p>All fields must be specified when creating an alert recipient.</p>	<pre> alertentries -recip_number -n recip_name -status alert_status -f filter_type -t notification_method -e email_addr -i ip_addr/hostname </pre> <p>where:</p> <ul style="list-style-type: none"> • <i>recip_number</i> is a number from 1 to 12 that corresponds to an unused recipient number in the "Display alert properties for all recipients" list. • <i>recip_name</i> is a alphanumeric string up to 31 characters in length containing any character, including spaces, except for angle brackets (< and >). If the string includes spaces it must be enclosed in double-quotes. • <i>alert_status</i> is on or off for receipt of alerts. • <i>filter_type</i> filters the alert types received: critical (receive critical alerts only) or none (receive all alerts). • <i>notification_method</i> is email, director (IBM Director) or snmp. <ul style="list-style-type: none"> – For e-mail, you must specify an e-mail address (-e argument). – For director, you must specify an IP address (-i argument). – If snmp is selected, the -e and -i arguments are not needed. • <i>email_addr</i> is a valid e-mail address string up to 63 characters in length. <p>(continued on next page)</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>

Table 10. alertentries command (continued)

Function	What it does	Command	Valid targets
Create alert recipient (continued)		<ul style="list-style-type: none"> <i>ip_addr/hostname</i> is a valid static IP address or an alphanumeric hostname string for the recipient that is up to 49 characters in length that can include periods (.), hyphens (-), and underscores (_). <p>Command use restricted (see “Commands and user authority” on page 5).</p>	
Set alert recipient name	Sets a name for the specified alert recipient.	<p>alertentries <i>-recip_number</i> <i>-n recip_name</i></p> <p>where:</p> <ul style="list-style-type: none"> <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the “Display alert properties for all recipients” list. <i>recip_name</i> is a alphanumeric string up to 31 characters in length that can include any character, including spaces, except for angle brackets (< and >). If the name includes spaces it must be enclosed in double-quotes. <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>
Set alert recipient status	Sets status for the specified alert recipient. The status determines if a recipient will receive alarm notifications.	<p>alertentries <i>-recip_number</i> <i>-status alert_status</i></p> <p>where:</p> <ul style="list-style-type: none"> <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the “Display alert properties for all recipients” list. <i>alert_status</i> is on or off. <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>

Table 10. alertentries command (continued)

Function	What it does	Command	Valid targets
Set alert types received	Filters the types of alert that are received by the specified alert recipient.	<p>alertentries <i>-recip_number</i> <i>-f filter_type</i></p> <p>where:</p> <ul style="list-style-type: none"> <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the “Display alert properties for all recipients” list. <i>alert_type</i> filters the alert types received: critical (receive critical alerts only) or none (receive all alerts). <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>
Set alert notification method	Sets the alert notification method for the specified alert recipient.	<p>alertentries <i>-recip_number</i> <i>-t notification_method</i></p> <p>where:</p> <ul style="list-style-type: none"> <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the “Display alert properties for all recipients” list. <i>notification_method</i> is email, director (IBM Director) or snmp. <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>
Set alert recipient e-mail address	<p>Sets the e-mail address for the specified alert recipient. This e-mail address is used to send alerts to the recipient via e-mail.</p> <p>The e-mail address can be set only if the alert notification method (-t option) is set to email. The -t and -e options can be combined within the same command.</p>	<p>alertentries <i>-recip_number</i> <i>-e email_addr</i></p> <p>where:</p> <ul style="list-style-type: none"> <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the “Display alert properties for all recipients” list. <i>email_addr</i> is a valid e-mail address string up to 63 characters in length. <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>

Table 10. alertentries command (continued)

Function	What it does	Command	Valid targets
Set alert recipient IP address or hostname	<p>Sets the IP address or hostname used to send alert notifications to the specified alert recipient using IBM Director.</p> <p>The IP address or hostname used to send alert notifications can be set only if the alert notification method (-t option) is set to director (IBM Director). The -t and -i options can be combined within the same command.</p>	<p>alertentries -<i>recip_number</i> -i <i>ip_addr/hostname</i></p> <p>where:</p> <ul style="list-style-type: none"> <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the “Display alert properties for all recipients” list. <i>ip_addr/hostname</i> is a valid static IP address or an alphanumeric hostname string up to 49 characters in length that can include periods (.), hyphens (-), and underscores (_). <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>

Example:

To view the configuration for alert recipient 1, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
alertentries -1
```

To configure alert recipient 2 to receive only critical alert notifications by e-mail, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
alertentries -2 -n test2 -status on -f critical -t email -e test2@us.ibm.com
```

To configure alert recipient 3 to receive all alert notifications through IBM Director, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
alertentries -3 -n test3 -status on -f none -t director -i 192.168.70.140
```

To configure alert recipient 4 to receive all alert notifications through SNMP, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
alertentries -4 -n test4 -status on -f none -t snmp
```

The following example shows the information that is returned from these commands:

```
system:mm[1]> alertentries -1
-status on
-n test1
-f critical
-t email
-e test1@us.ibm.com
system:mm[1]> alertentries -2 -n test2 -status on -f critical -t email
-e test2@us.ibm.com
```

```

OK
system:mm[1]> alertentries -3 -n test3 -status on -f none -t director
-i 192.168.70.140
OK
system:mm[1]> alertentries -4 -n test4 -status on -f none -t snmp
OK
system:mm[1]>

```

clear command

This command restores the primary management module configuration or an I/O (switch) module configuration to the default settings. The command must always include the `-config` option.

Table 11. *clear* command

Function	What it does	Command	Valid targets
Restore default configuration of primary management module	<p>Restores the default configuration of the primary management module; then, resets the management module.</p> <p>No results are returned from this command because it resets the management module.</p> <p>When you restore the management-module configuration, the Ethernet configuration method is set to a value of <code>dthens</code>. After the management module resets, this causes the management module to try <code>dhcp</code> configuration and then default to the static IP configuration, which might cause the management module to remain offline for longer than normal. See the “<code>ifconfig</code> command” on page 40 for information.</p>	<p><code>clear -config</code></p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p><code>-T system:mm[x]</code></p> <p>where <i>x</i> is the primary management-module bay number.</p>
Restore default configuration of I/O (switch) module	<p>Restores the configuration of the specified I/O (switch) module to the default settings.</p>	<p><code>clear -config</code></p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p><code>-T system:switch[x]</code></p> <p>where <i>x</i> is the I/O (switch) module bay number.</p>

Example:

To restore the primary management-module configuration to default settings, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
clear -config
```

No results are returned from this command. After the management module resets, you will need to start a new command-line session.

dhcpcinfo command

This command displays the IP configuration that is assigned to the primary management module by the DHCP server.

Note: The `dhcpcinfo` command does not apply to `eth1`, which always uses a static IP configuration.

Table 12. `dhcpcinfo` command

Function	What it does	Command	Valid targets
Display Ethernet channel 0 DHCP configuration	<p>If the IP configuration for <code>eth0</code> is assigned by a DHCP server, the configuration that is assigned by the DHCP server and DHCP server information is displayed. If the IP configuration for <code>eth0</code> is <i>not</i> assigned by a DHCP server, an error message is displayed. Possible configuration values returned are:</p> <ul style="list-style-type: none">• <code>-server dhcp_ip_address</code>• <code>-n hostname</code>• <code>-i ip_address</code>• <code>-g gateway_address</code>• <code>-s subnet_mask</code>• <code>-d domainname</code>• <code>-dns1 primary_dns_ip_address</code>• <code>-dns2 secondary_dns_ip_address</code>• <code>-dns3 tertiary_dns_ip_1address</code>	<code>dhcpcinfo -eth0</code>	<p><code>-T system:mm[x]</code></p> <p>where <code>x</code> is the primary management-module bay number.</p>

Example:

To display the DHCP server assigned network settings for Ethernet channel 0, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
dhcpcinfo -eth0
```

The following example shows the information that is returned:

```
system:mm[1]> dhcpcinfo -eth0
-server 192.168.70.29
-n MM00096BCA0C80
-i 192.168.70.183
-g 192.168.70.29
-s 255.255.255.0
-d linux-sp.raleigh.ibm.com
-dns1 192.168.70.29
-dns2 0.0.0.0
-dns3 0.0.0.0
system:mm[1]>
```

displaysd command (advanced management module only)

This command captures and displays service information. Service information includes BladeCenter VPD, the management-module event log, and self-test results from the primary management module. If multiple user interface sessions issue the displaysd command, the commands will be processed in the order that they are received.

Table 13. displaysd command

Function	What it does	Command	Valid targets
Display service information	Display service information on screen from last service information capture.	displaysd	-T system
Capture and display service information	Capture and display service information on screen.	displaysd -c	-T system

Example:

To capture service information, while the chassis is set as the persistent command environment, at the system> prompt, type

```
displaysd -c
```

The following example shows the information that is returned:

```
system> displaysd -c
SPAPP Capture Available
Time: 10/04/2005 21:47:43
UUID: Not Available
.
.
.
system:mm[1]>
```

Note: If a large amount of service information is available, display could exceed the capacity of your command prompt window, resulting in loss of information displayed at the start of the data set. If this happens, you will need to clear the management-module event log to reduce the amount of information being captured.

dns command

This command configures and displays the management-module DNS settings.

Table 14. dns command

Function	What it does	Command	Valid targets
Display DNS configuration of management module	Displays the current DNS configuration of the management module. Possible return values are: <ul style="list-style-type: none"> • enabled • disabled • -i1 <i>first ip_address</i> • -i2 <i>second ip_address</i> • -i3 <i>third ip_address</i> 	dns	-T system:mm[x] where x is the primary management-module bay number.
DNS - enable	Enables the management-module DNS configuration.	dns -on Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.

Table 14. dns command (continued)

Function	What it does	Command	Valid targets
DNS - disable	Disables the management-module DNS configuration.	dns -off Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
DNS first IP address - set	Checks syntax and sets the first IP address.	dns -i1 <i>ip_address</i> where <i>ip_address</i> is the first IP address. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
DNS second IP address - set	Checks syntax and sets the second IP address.	dns -i2 <i>ip_address</i> where <i>ip_address</i> is the second IP address. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
DNS third IP address - set	Checks syntax and sets the third IP address.	dns -i3 <i>ip_address</i> where <i>ip_address</i> is the third IP address. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.

Example:

To set the first IP address of the management-module DNS server to 192.168.70.29 and enable DNS on the primary management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
dns -i1 192.168.70.29 -on
```

To display the DNS status of the primary management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
dns
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> dns -i1 192.168.70.29 -on
Changes to the network settings will take effect after the next reset of the MM.
system:mm[1]> dns
Enabled
-i1 192.168.70.29
-i2 0.0.0.0
-i3 0.0.0.0
system:mm[1]>
```

ifconfig command

This command configures and displays the network interface settings for the management-module Ethernet interface and the blade server integrated system management processors.

Table 15. *ifconfig* command

Function	What it does	Command	Valid targets
Display Ethernet channel 0 configuration	Displays the current configuration of Ethernet channel 0. Possible return values are: <ul style="list-style-type: none"> • enabled • disabled • -i <i>static_ip_address</i> • -g <i>gateway_address</i> • -s <i>subnet_mask</i> • -n <i>hostname</i> • -c <i>config_method</i> • -r <i>data_rate</i> • -d <i>duplex_mode</i> • -m <i>mtu</i> • -l <i>locally_administered_mac_addr</i> • -b <i>burnedin_mac_address</i> 	ifconfig -eth0	-T system:mm[x] where x is the primary management-module bay number.
Set Ethernet channel 0 static IP address	Checks syntax and sets the static IP address for Ethernet channel 0.	ifconfig -eth0 -i <i>ip_address</i> where <i>ip_address</i> is the static IP address for Ethernet channel 0. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
Set Ethernet channel 0 gateway IP address	Checks syntax and sets the gateway IP address for Ethernet channel 0.	ifconfig -eth0 -g <i>ip_address</i> where <i>ip_address</i> is the gateway IP address for Ethernet channel 0. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
Set Ethernet channel 0 subnet mask	Checks syntax and sets the subnet mask for Ethernet channel 0.	ifconfig -eth0 -s <i>sub_mask</i> where <i>sub_mask</i> is the subnet mask for Ethernet channel 0. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
Set Ethernet channel 0 hostname	Checks syntax and sets the host name for Ethernet channel 0.	ifconfig -eth0 -n <i>hostname</i> where <i>hostname</i> is the host name for Ethernet channel 0. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.

Table 15. *ifconfig* command (continued)

Function	What it does	Command	Valid targets
Set Ethernet channel 0 configuration method	Checks syntax and sets the configuration method for Ethernet channel 0. A value of <i>dthens</i> will try the dhcp configuration and default to the static IP configuration if dhcp is unsuccessful.	<code>ifconfig -eth0 -c <i>config_method</i></code> where <i>config_method</i> is <i>dhcp</i> , <i>static</i> , or <i>dthens</i> . Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set Ethernet channel 0 data rate	Checks syntax and sets the data rate for Ethernet channel 0.	<code>ifconfig -eth0 -r <i>data_rate</i></code> where <i>data_rate</i> is <i>auto</i> , <i>10</i> , or <i>100</i> . Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set Ethernet channel 0 duplex mode	Checks syntax and sets the duplex mode for Ethernet channel 0.	<code>ifconfig -eth0 -d <i>duplex_mode</i></code> where <i>duplex_mode</i> is <i>auto</i> , <i>half</i> , or <i>full</i> . Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set Ethernet channel 0 MTU	Checks syntax and sets the MTU (maximum transmission unit) for Ethernet channel 0.	<code>ifconfig -eth0 -m <i>mtu</i></code> where <i>mtu</i> is between 60 and 1500, inclusive. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set Ethernet channel 0 static MAC address (locally administered)	Checks syntax and sets the locally administered MAC address to the specified MAC address for Ethernet channel 0.	<code>ifconfig -eth0 -l <i>address</i></code> where <i>address</i> is the locally administered MAC address for Ethernet channel 0. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Display Ethernet channel 1 configuration <i>(this command is not available for the advanced management module)</i>	Displays the current configuration of Ethernet channel 1. Possible return values are: <ul style="list-style-type: none"> • enabled • disabled • -i <i>static_ip_address</i> • -g <i>gateway_address</i> • -s <i>subnet_mask</i> • -r <i>data_rate</i> • -d <i>duplex_mode</i> • -m <i>mtu</i> • -l <i>locally_administered_mac_addr</i> • -b <i>burnedin_mac_address</i> 	<code>ifconfig -eth1</code>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 15. *ifconfig* command (continued)

Function	What it does	Command	Valid targets
<p>Set Ethernet channel 1 static IP address</p> <p><i>(this command is not available for the advanced management module)</i></p>	Checks syntax and sets the static IP address for Ethernet channel 1.	<p><code>ifconfig -eth1 -i <i>ip_address</i></code></p> <p>where <i>ip_address</i> is the static IP address for Ethernet channel 1.</p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<p>Set Ethernet channel 1 gateway IP address</p> <p><i>(this command is not available for the advanced management module)</i></p>	Checks syntax and sets the gateway IP address for Ethernet channel 1.	<p><code>ifconfig -eth1 -g <i>ip_address</i></code></p> <p>where <i>ip_address</i> is the gateway IP address for Ethernet channel 1.</p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<p>Set Ethernet channel 1 subnet mask</p> <p><i>(this command is not available for the advanced management module)</i></p>	Checks syntax and sets the subnet mask for Ethernet channel 1.	<p><code>ifconfig -eth1 -s <i>sub_mask</i></code></p> <p>where <i>sub_mask</i> is the subnet mask for Ethernet channel 1.</p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<p>Set Ethernet channel 1 static MAC address (locally administered)</p> <p><i>(this command is not available for the advanced management module)</i></p>	Checks syntax and sets the locally administered MAC address to the specified MAC address for Ethernet channel 1.	<p><code>ifconfig -eth1 -l <i>address</i></code></p> <p>where <i>address</i> is the locally administered MAC address for Ethernet channel 1.</p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<p>Enable Ethernet channel 1</p> <p><i>(this command is not available for the advanced management module)</i></p>	Enables Ethernet channel 1.	<p><code>ifconfig -eth1 -up</code></p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<p>Disable Ethernet channel 1</p> <p><i>(this command is not available for the advanced management module)</i></p>	Disables Ethernet channel 1.	<p><code>ifconfig -eth1 -down</code></p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 15. *ifconfig* command (continued)

Function	What it does	Command	Valid targets
Set starting IP address for blade server integrated system management processor	Sets the starting point of the integrated system management processor IP addresses for blade servers that are installed in the BladeCenter unit.	<code>ifconfig -i <i>ip_address</i></code> where <i>ip_address</i> is the starting IP address for all blade servers that are installed in the BladeCenter unit. Command use restricted (see “Commands and user authority” on page 5).	-T system:blade[1]:sp

Example:

To display the configuration for Ethernet channel 0, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type `ifconfig -eth0`

To set the static IP address for Ethernet channel 0 to 192.168.70.133, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type `ifconfig -eth0 -i 192.168.70.133 -c static`

The following example shows the information that is returned from these two commands:

```
system:mm[1]> ifconfig -eth0
Enabled
-i 10.10.10.10
-g 0.0.0.0
-s 255.255.255.0
-n MM00096BCA0C80
-c Try DHCP server. If it fails, use static IP config.
-r Auto
-d Auto
-m 1500
-l 00:00:00:00:00:00
-b 00:09:6B:CA:0C:80
system:mm[1]> ifconfig -eth0 -i 192.168.70.133 -c static
Changes to the network settings will take effect after the next reset of the MM.
system:mm[1]>
```

portcfg command (advanced management module only)

This command configures and displays the settings for the advanced management-module serial port.

Table 16. portcfg command

Function	What it does	Command	Valid targets
Display management-module serial port configuration	Displays the current configuration of the management-module serial port. Possible return values are: <ul style="list-style-type: none"> -b <i>baud_rate</i> -p <i>parity</i> -s <i>stop_bits</i> 	portcfg -com1	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set management-module serial port baud rate	Checks syntax and sets the baud (communications) rate of the management-module serial port.	portcfg -com1 -b <i>baud_rate</i> where <i>baud_rate</i> is 2400, 4800, 9600, 19200, 38400, 57600, or 115200. Command use restricted (see "Commands and user authority" on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set management-module serial port parity	Checks syntax and sets the parity of the management-module serial port.	portcfg -com1 -p <i>parity</i> where <i>parity</i> is none, odd, even, mark, or space. Command use restricted (see "Commands and user authority" on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set management-module serial port stop bits	Checks syntax and sets the number of stop bits for the management-module serial port.	portcfg -com1 -s <i>stop_bits</i> where <i>stop_bits</i> is 1 or 2. Command use restricted (see "Commands and user authority" on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example:

To display the configuration for the management-module serial port, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
portcfg -com1
```

To set the baud rate for the management-module serial port to 9600, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
portcfg -com1 -b 9600
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> portcfg -com1
-b 2400
-p odd
-s 1
```

```

system:mm[1]> portcfg -com1 -b 9600
OK
system:mm[1]>

```

read command (advanced management module only)

This command restores the management-module configuration that was previously saved to the BladeCenter unit chassis using the write command (advanced management module only).

Table 17. read command

Function	What it does	Command	Valid targets
Restore management-module configuration	Restores the management-module configuration from an image that was previously saved to the BladeCenter unit chassis.	read -config chassis Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.

Example:

To restore the management-module configuration from an image previously saved to the BladeCenter unit chassis, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type `read -config chassis`

The following example shows the information that is returned from this command:

```

system:mm[1]> read -config chassis
OK
Configuration restore from the chassis was successful
Restart the MM for the new settings to take effect
system:mm[1]>

```

service command (advanced management module only)

This command configures and displays the management-module service setting.

Table 18. service command

Function	What it does	Command	Valid targets
Display service setting	Displays the service setting for technician debug (enable or disable).	service	-T system:mm[x] where x is the primary management-module bay number.
Enable technician debug	Configure service setting to enable technician debug of the advanced management module.	service -enable Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
Disable technician debug	Configure service setting to disable (default setting) technician debug of the advanced management module.	service -disable Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.

Example:

To enable technician debug of the advanced management module, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
service -enable
```

To display the service setting of the advanced management module, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
service
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> service -enable
OK
system:mm[1]> service
Service by support personnel: Enabled
system:mm[1]>
```

smtp command

This command configures and displays the management-module SMTP settings.

Table 19. *smtp* command

Function	What it does	Command	Valid targets
Display SMTP server host name or IP address	Displays the SMTP server host name or IP address.	smtp	-T system:mm[x] where x is the primary management-module bay number.
Server host name or IP address - set	Checks syntax and sets the server host name or IP address.	smtp -s <i>hostname/ip_address</i> where <i>hostname/ip_address</i> is the host name or IP address of the server. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.

Example:

To set the SMTP server host name to `us.ibm.com`, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
smtp -s us.ibm.com
```

To display the SMTP configuration, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
smtp
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> smtp -s us.ibm.com
```

```

OK
system:mm[1]> snmp
-s us.ibm.com
system:mm[1]>

```

snmp command

This command configures and displays the management-module SNMP settings.

Table 20. snmp command

Function	What it does	Command	Valid targets
Display SNMP configuration of management module	<p>Displays the current SNMP configuration of the management module. Possible return values are:</p> <ul style="list-style-type: none"> • -a enabled/disabled • -t enabled/disabled • -c1 <i>community1_name</i> • -c1i1 <i>community1_ipaddr1_or_hostname</i> • -c1i2 <i>community1_ipaddr2_or_hostname</i> • -c1i3 <i>community1_ipaddr3_or_hostname</i> • -c2 <i>community2_name</i> • -c2i1 <i>community2_ipaddr1_or_hostname</i> • -c2i2 <i>community2_ipaddr2_or_hostname</i> • -c2i3 <i>community2_ipaddr3_or_hostname</i> • -c3 <i>community3_name</i> • -c3i1 <i>community3_ipaddr1_or_hostname</i> • -c3i2 <i>community3_ipaddr2_or_hostname</i> • -c3i3 <i>community3_ipaddr3_or_hostname</i> • -cn <i>contact_name</i> • -l <i>location</i> 	snmp	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>
SNMPv1 agent - enable	<p>Enables the management-module SNMPv1 agent.</p> <p>Note: SNMPv1 community setup required (see the snmp -cx commands, starting on page 48, for information).</p>	<p>snmp -a -on</p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>
SNMPv1 agent - disable	<p>Disables the management-module SNMPv1 agent.</p>	<p>snmp -a -off</p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>
SNMPv3 agent - enable	<p>Enables the management-module SNMPv3 agent.</p> <p>Note: SNMPv3 user setup required (see the users command, on page 60, for information).</p>	<p>snmp -a3 -on</p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>

Table 20. snmp command (continued)

Function	What it does	Command	Valid targets
SNMPv3 agent - disable	Disables the management-module SNMPv3 agent.	snmp -a3 -off Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
SNMP traps - enable	Enables the management-module SNMP traps.	snmp -t -on Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
SNMP traps - disable	Disables the management-module SNMP traps.	snmp -t -off Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
SNMP community 1 name - set	Sets the name of community 1.	snmp -c1 <i>name</i> where <i>name</i> is a descriptive name of community 1. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
SNMP community 1 first host name or IP address - set	Checks syntax and sets the first host name or IP address of community 1.	snmp -c1i1 <i>hostname/ip_address</i> where <i>hostname/ip_address</i> is the first host name or IP address of community 1. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
SNMP community 1 second host name or IP address - set	Checks syntax and sets the second host name or IP address of community 1.	snmp -c1i2 <i>hostname/ip_address</i> where <i>hostname/ip_address</i> is the second host name or IP address of community 1. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.

Table 20. *snmp* command (continued)

Function	What it does	Command	Valid targets
SNMP community 1 third host name or IP address - set	Checks syntax and sets the third host name or IP address of community 1.	snmp -c1i3 <i>hostname/ip_address</i> where <i>hostname/ip_address</i> is the third host name or IP address of community 1. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
SNMPv3 community 1 view type - set	Sets the SNMPv3 view type for community 1.	snmp -ca1 <i>type</i> where <i>type</i> is get, set, or trap. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
SNMP community 2 name - set	Sets the name of community 2.	snmp -c2 <i>name</i> where <i>name</i> is a descriptive name of community 2. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
SNMP community 2 first host name or IP address - set	Checks syntax and sets the first host name or IP address of community 2.	snmp -c2i1 <i>hostname/ip_address</i> where <i>hostname/ip_address</i> is the first host name or IP address of community 2. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
SNMP community 2 second host name or IP address - set	Checks syntax and sets the second host name or IP address of community 2.	snmp -c2i2 <i>hostname/ip_address</i> where <i>hostname/ip_address</i> is the second host name or IP address of community 2. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 20. snmp command (continued)

Function	What it does	Command	Valid targets
SNMP community 2 third host name or IP address - set	Checks syntax and sets the third host name or IP address of community 2.	snmp -c2i3 <i>hostname/ip_address</i> where <i>hostname/ip_address</i> is the third host name or IP address of community 2. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
SNMPv3 community 2 view type - set	Sets the SNMPv3 view type for community 2.	snmp -ca2 <i>type</i> where <i>type</i> is get, set, or trap. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
SNMP community 3 name - set	Sets the name of community 3.	snmp -c3 <i>name</i> where <i>name</i> is a descriptive name of community 3. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
SNMP community 3 first host name or IP address - set	Checks syntax and sets the first host name or IP address of community 3.	snmp -c3i1 <i>hostname/ip_address</i> where <i>hostname/ip_address</i> is the first host name or IP address of community 3. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
SNMP community 3 second host name or IP address - set	Checks syntax and sets the second host name or IP address of community 3.	snmp -c3i2 <i>hostname/ip_address</i> where <i>hostname/ip_address</i> is the second host name or IP address of community 3. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 20. snmp command (continued)

Function	What it does	Command	Valid targets
SNMP community 3 third host name or IP address - set	Checks syntax and sets the third host name or IP address of community 3.	snmp -c3i3 <i>hostname/ip_address</i> where <i>hostname/ip_address</i> is the third host name or IP address of community 3. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
SNMPv3 community 3 view type - set	Sets the SNMPv3 view type for community 3.	snmp -ca3 <i>type</i> where <i>type</i> is get, set, or trap. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
SNMP contact name - set	Sets the contact name.	snmp -cn <i>contact_name</i> Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
SNMP location - set	Sets the location.	snmp -l <i>hostname/ip_address</i> Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.

Example:

To view the SNMP configuration, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
snmp
```

To enable the SNMP agent and SNMP traps, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
snmp -a -on -t -on
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> snmp
-a Disabled
-t Disabled
-l No Location Configured
-cn No Contact Configured
-c1 com1
-c1i1 1.2.3.4
-c1i2
-c1i3
-c2 com2
-c2i1 1.2.3.4
-c2i2
```

```

-c2i3
-c3
-c3i1
-c3i2
-c3i3
system:mm[1]> snmp -a -on -t -on
Changes to the network settings will take effect after the next reset of the MM.
system:mm[1]>

```

sol (serial over LAN) command

This command configures SOL functions and indicates SOL status.

Table 21. sol (serial over LAN) command

Function	What it does	Command	Valid targets
Display SOL status	<p>Displays the SOL status for the targeted device:</p> <ul style="list-style-type: none"> When the command target is the primary management module, it displays the following values: <ul style="list-style-type: none"> -status <i>on/off</i> (global SOL status) -c <i>retry_count</i> -e <i>CLI_key_sequence</i> -i <i>retry_interval</i> -r <i>reset_blade_key_seq</i> -s <i>send_threshold</i> -t <i>accumulate_timeout</i> -v <i>VLAN_id</i> When the command target is a blade server, it displays the following: <ul style="list-style-type: none"> -status <i>on/off</i> (SOL status for the blade server) Status of any SOL sessions for that blade server: <ul style="list-style-type: none"> - There is no SOL session opening for that blade. - There is an SOL session opening for that blade. - There is an SOL session opening and it is connected to a telnet session. 	sol	-T system:mm[x] -T system:blade[x] where x is the primary management-module or blade server bay number.
SOL retry interval - set	Sets the SOL retry interval to the input value.	sol -i <i>value</i> where <i>value</i> is from 10 ms to 2550 ms, inclusive, in 10 ms increments. If you enter a value less than 10 ms, the retry interval will be set to 10 ms. If you enter a value greater than 2550 ms, the retry interval will be set to 2550 ms. Command use restricted (see "Commands and user authority" on page 5).	-T system:mm[x] where x is the primary management-module bay number.

Table 21. sol (serial over LAN) command (continued)

Function	What it does	Command	Valid targets
SOL retry count - set	Sets the SOL retry count to the input value.	sol -c <i>value</i> where <i>value</i> is from 0 to 7, inclusive. If you enter a value of 0, no retries will be attempted. If you enter a value greater than 7, an error will be displayed. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
SOL send threshold - set	Sets the SOL send threshold to the input value. Setting the threshold value to 1 causes the blade server integrated system management processor to send an SOL packet as soon as the first character is received.	sol -s <i>value</i> where <i>value</i> is from 1 to 251, inclusive. If you enter a value outside this range, an error will be displayed. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
SOL accumulate timeout - set	Sets the SOL accumulate timeout to the input value.	sol -t <i>value</i> where <i>value</i> is from 5 ms to 1275 ms, inclusive. If you enter a value less than 5 ms, the accumulate timeout will be set to 5 ms. If you enter a value greater than 1275 ms, an error will be displayed. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
SOL enable - global	Enables SOL globally for the BladeCenter unit. The global SOL enable command does not affect the SOL session status for each blade server.	sol -status on Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
SOL enable - blade server	Enables SOL for the specified blade server.	sol -status on Command use restricted (see “Commands and user authority” on page 5).	-T system:blade[x] where x is the blade server bay number.
SOL disable - global	Disables SOL globally for the BladeCenter unit. The global SOL disable command does not affect the SOL session status for each blade server.	sol -status off Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
SOL disable - blade server	Disables SOL for the specified blade server.	sol -status off Command use restricted (see “Commands and user authority” on page 5).	-T system:blade[x] where x is the blade server bay number.

Table 21. sol (serial over LAN) command (continued)

Function	What it does	Command	Valid targets
SOL VLAN ID - set	Sets the SOL VLAN ID to the input value.	sol -v <i>value</i> where <i>value</i> is from 1 to 4095, inclusive. If you enter a value outside this range, an error will be displayed. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
CLI key sequence - set	Sets the key sequence that is used to enter the CLI while a Telnet session in SOL mode.	sol -e <i>value</i> where <i>value</i> is the key sequence. In this sequence, a ^ (the carat symbol) indicates a Ctrl that maps to control-key sequences; for example: <ul style="list-style-type: none"> • ^[(the carat symbol followed by a left bracket) means Esc • ^M (the carat symbol followed by a capitol M) means carriage return. Refer to an ASCII-to-key conversion table for a complete listing of control-key sequences. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Reset blade server key sequence - set	Sets the key sequence that will reset a blade server while a Telnet session in SOL mode.	sol -r <i>value</i> where <i>value</i> is the key sequence. In this sequence, a ^ (the carat symbol) indicates a Ctrl that maps to control-key sequences; for example: <ul style="list-style-type: none"> • ^[(the carat symbol followed by a left bracket) means Esc • ^M (the carat symbol followed by a capitol M) means carriage return. Refer to an ASCII-to-key conversion table for a complete listing of control-key sequences. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example:

To set the SOL accumulate timeout to 25 ms, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
sol -t 25
```

To set the reset blade server key sequence to Esc R Esc r Esc R, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
sol -r ^[R^[r^[R
```

To display the SOL settings, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
sol
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> sol -t 25
OK
system:mm[1]> sol
-status on
-c 0
-e ^[(
-i 250
-r ^[R^[r^[R
-s 250
-t 25
-v 4095
system:mm[1]>
```

tcpcmdmode command

This command displays and changes the timeout of the TCP command-mode sessions that are used by *IBM Director* software for out-of-band communication with the management module. This command is also used to enable or disable the TCP command-mode sessions.

Table 22. *tcpcmdmode* command

Function	What it does	Command	Valid targets
Display TCP command-mode session status and timeout	Displays the TCP command-mode session status (on or off) and timeout.	<code>tcpcmdmode</code>	<code>-T system:mm[x]</code> where <i>x</i> is the primary management-module bay number.
Set TCP command-mode session timeout	Sets the TCP command-mode session timeout value.	<code>tcpcmdmode -t <i>timeout</i></code> where <i>timeout</i> is from 0 seconds (no timeout) to 4294967295 seconds, inclusive. If you enter a value outside this range, an error will be displayed. Command use restricted (see “Commands and user authority” on page 5).	<code>-T system:mm[x]</code> where <i>x</i> is the primary management-module bay number.

Table 22. *tcpcmdmode* command (continued)

Function	What it does	Command	Valid targets
Enable TCP command-mode sessions	Enables TCP command-mode sessions that are used by <i>IBM Director</i> software for out-of-band communication with the management module.	<code>tcpcmdmode -status on</code> Command use restricted (see “Commands and user authority” on page 5).	<code>-T system:mm[x]</code> where <i>x</i> is the primary management-module bay number.
Disable TCP command-mode sessions	Disables TCP command-mode sessions that are used by <i>IBM Director</i> software for out-of-band communication with the management module.	<code>tcpcmdmode -status off</code> Command use restricted (see “Commands and user authority” on page 5).	<code>-T system:mm[x]</code> where <i>x</i> is the primary management-module bay number.

Example:

To enable a TCP command-mode session for the primary management module, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
tcpcmdmode -status on
```

To set the TCP command-mode session timeout for the primary management module to 6 minutes, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
tcpcmdmode -t 360
```

To display the TCP command-mode session status and timeout for the primary management module, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
tcpcmdmode
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> tcpcmdmode -status on
OK
system:mm[1]> tcpcmdmode -t 360
OK
system:mm[1]> tcpcmdmode
-status on
-t 360
system:mm[1]>
```

telnetcfg (Telnet configuration) command

This command displays and configures the Telnet parameters of the primary management module.

Table 23. *telnetcfg* (Telnet configuration) command

Function	What it does	Command	Valid targets
Display telnet configuration	Displays the telnet configuration of the primary management module.	<code>telnetcfg</code>	<code>-T system:mm[x]</code> where <i>x</i> is the primary management-module bay number.

Table 23. *telnetcfg* (Telnet configuration) command (continued)

Function	What it does	Command	Valid targets
Display telnet timeout	Displays the telnet timeout value, in seconds, of the primary management module.	telnetcfg -t	-T system:mm[x] where x is the primary management-module bay number.
Set telnet timeout for primary management module	Sets the telnet timeout value for the primary management module.	telnetcfg -t <i>timeout</i> where <i>timeout</i> is from 0 seconds (no timeout) to 4294967295 seconds, inclusive. If you enter a value outside this range, an error will be displayed. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.

Example:

To set the telnet timeout for the primary management module to 6 minutes, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
telnetcfg -t 360
```

To display the telnet configuration for the primary management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
telnetcfg
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> telnetcfg -t 360
OK
system:mm[1]> telnetcfg
-t 360
system:mm[1]>
```

uplink (management module failover) command

This command displays and configures the management-module uplink failover feature. If the external network interface of the primary management module fails, this feature forces a failover to the redundant management module, if one is installed.

Table 24. *uplink* command

Function	What it does	Command	Valid targets
Display uplink failover status	Displays the management-module uplink failover status (enabled or disabled) and the failover delay.	uplink	-T system:mm[x] where x is the primary management-module bay number.

Table 24. uplink command (continued)

Function	What it does	Command	Valid targets
Set network uplink failover delay	Sets the amount of time between detection of a management-module uplink failure and failover to the redundant management module.	uplink -del <i>delay</i> where <i>delay</i> is from 1 to 255 minutes, inclusive. If you enter a value outside this range, an error will be displayed. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
Enable uplink failover	Enables failover to the redundant management module if the external network interface of the primary management module fails.	uplink -on Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
Disable uplink failover	Disables failover to the redundant management module if the external network interface of the primary management module fails.	uplink -off Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.

Example:

To enable failover to the redundant management module if the external network interface of the primary management module fails, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
uplink -on
```

To set the uplink failover delay to 3 minutes, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
uplink -del 3
```

To display the uplink failover configuration, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
uplink
```

The following example shows the information that is returned from these three commands:

```
system:mm[1]> uplink -on
OK
system:mm[1]> uplink -del 3
Uplink delay set to 3 minute(s).
OK
system:mm[1]> uplink
Failover on network uplink loss is enabled.
Uplink delay: 3 minute(s)
system:mm[1]>
```

users (management-module users) command

This command displays and configures user accounts, also called user profiles, of the primary management module.

Important: Command authority definitions might change between firmware versions. Make sure that the command authority level set for each user is correct after updating management-module firmware.

Table 25. users (management-module users) command

Function	What it does	Command	Valid targets
Display all user profiles	Displays all 12 management-module user profiles. Returned values are: <ul style="list-style-type: none"> • User name • Authority level 	users	-T system:mm[x] where x is the primary management-module bay number.
Display single user profile	Displays the specified management-module user profile. Returned values are: <ul style="list-style-type: none"> • User name • Authority level • Context name • Authentication protocol • Privacy protocol • Access type • Hostname/IP address 	users -user_number where user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list.	-T system:mm[x] where x is the primary management-module bay number.
Delete user profile	Delete the specified management-module user profile.	users -user_number -clear where user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. It is possible to delete an empty user profile. Command use restricted (see "Commands and user authority" on page 5).	-T system:mm[x] where x is the primary management-module bay number.

Table 25. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Create user profile	<p>Create the specified management-module user profile.</p> <p>All fields must be specified when creating a user profile for the BladeCenter T management module.</p> <p>For management modules other than those installed in a BladeCenter T unit, only the following user-profile fields are required:</p> <ul style="list-style-type: none"> • -user_number • -n user_name • -a user_authority • -p user_password 	<pre>users -user_number -n user_name -p user_password -a user_authority -cn context_name -ap auth_protocol -pp privacy_protocol -ppw privacy_pwd -at access_type -i ip_addr/hostname</pre> <p>where:</p> <ul style="list-style-type: none"> • user_number is a number from 1 to 12 that corresponds to an unused user number in the “Display all user profiles” list. • user_name is a alphanumeric string up to 15 characters in length that can include periods (.) and underscores (_). Each of the 12 user names must be unique. • user_password can be blank or an alphanumeric string up to 15 characters in length that can include periods (.) and underscores (_), and must include at least one alphabetic and one non-alphabetic character. • user_authority is one of the following: <ul style="list-style-type: none"> – operator (read-only) – rbs (see “Set user authority level” on page 65 for more information) for scripting on management modules other than the advanced management module, user_authority is one of the following: <ul style="list-style-type: none"> – super (Supervisor) – custom (see “Set user authority level” on page 63 for more information) – ro (read-only) <p>(continued on next page)</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>

Table 25. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
<p>Create user profile <i>(continued)</i></p>		<ul style="list-style-type: none"> • <i>context_name</i> is a string for SNMPv3 context that is up to 31 characters in length. Each of the 12 context names must be unique. • <i>auth_protocol</i> is an SNMPv3 authentication protocol of sha, md5, or blank (no entry) for none. • <i>privacy_protocol</i> is an SNMPv3 privacy protocol of des or blank (no entry) for none. If the privacy protocol is set to none, no -ppw command option (privacy password) is required. • <i>privacy_pwd</i> is an SNMPv3 privacy password string of up to 31 characters in length. If the privacy protocol is set to none, the -ppw command option does not need to be used unless a privacy password is required. • <i>access_type</i> is an SNMPv3 access type of read, write, or traps. • <i>ip_addr/hostname</i> is a valid SNMPv3 static IP address or an alphanumeric hostname string up to 63 characters in length. <p>Command use restricted (see “Commands and user authority” on page 5).</p>	

Table 25. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Set user name	Sets a user name in the specified management-module user profile.	<p>users -<i>user_number</i> -n <i>user_name</i></p> <p>where:</p> <ul style="list-style-type: none"> • <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the “Display all user profiles” list. • <i>user_name</i> is a alphanumeric string up to 15 characters in length that can include periods (.) and underscores (_). Each of the 12 user names must be unique. <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
Set user password	Sets a user password in the specified management-module user profile.	<p>users -<i>user_number</i> -p <i>user_password</i></p> <p>where:</p> <ul style="list-style-type: none"> • <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the “Display all user profiles” list. • <i>user_password</i> can be blank or an alphanumeric string up to 15 characters in length that can include periods (.) and underscores (_), and must include at least one alphabetic and one non-alphabetic character. <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 25. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Set user authority level	Sets a user authority level in the specified management-module user profile.	<p>users -<i>user_number</i> -a <i>user_authority</i></p> <p>where:</p> <ul style="list-style-type: none"> • <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the “Display all user profiles” list. • <i>user_authority</i> is one of the following: <ul style="list-style-type: none"> – operator (read-only) – rbs (custom) <p>The custom authority level parameter is specified using the following syntax:</p> <p>rbs:<i>levels</i>:<i>devices</i></p> <p>where the <i>levels</i> are one or more of the following authority levels, separated by a vertical bar ():</p> <ul style="list-style-type: none"> • super (Supervisor) • cam (Chassis User Account Management) • clm (Chassis Log Management) • co (Chassis Operator) • cc (Chassis Configuration) • ca (Chassis Administration) • bo (Blade Operator) • brp (Blade Remote Present) • bc (Blade Configuration) • ba (Blade Administration) • so (I/O Module Operator) • sc (I/O Module Configuration) • sa (I/O Module Administration) <p>(continued on next page)</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>

Table 25. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
<p>Set user authority level <i>(continued)</i></p>		<p>where the <i>devices</i> are one or more of the following devices, separated by a vertical bar (). Ranges of devices are separated by a dash (-).</p> <ul style="list-style-type: none"> • <i>cn</i> (Chassis <i>n</i>, where <i>n</i> is a valid chassis number. Use c1 for single-chassis environments.) • <i>bn</i> (Blade <i>n</i>, where <i>n</i> is a valid blade bay number in the chassis) • <i>sn</i> (I/O module <i>n</i>, where <i>n</i> is a valid I/O module bay number in the chassis) <p>Command use restricted (see “Commands and user authority” on page 5).</p>	

Table 25. *users* (management-module users) command (continued)

Function	What it does	Command	Valid targets
<p>Set user authority level</p> <p>(These are the previous version of authority levels that are used only for backward compatibility with scripts.)</p>	<p>Sets a user authority level in the specified management-module user profile.</p>	<p><code>users -user_number -a user_authority</code></p> <p>where:</p> <ul style="list-style-type: none"> • <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the “Display all user profiles” list. • <i>user_authority</i> is one of the following: <ul style="list-style-type: none"> – ro (read-only) – super (Supervisor) – custom <p>The custom authority level parameter is specified using the following syntax:</p> <p><code>custom:level1 level2</code></p> <p>where the <i>levels</i> are one or more of the following authority levels, separated by a vertical bar (): <ul style="list-style-type: none"> • am (User Account Management Access) • rca (Blade Server Remote Console Access) • rcvma (Remote Console and Virtual Media Access) • pr (Blade and I/O Power Restart Access) • cel (Ability to Clear Event Logs) • bc (Basic Configuration Permission) • nsc (Network and Security Configuration Permission) • ac (Advanced Configuration) </p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 25. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Set SNMPv3 user context name	<p>Sets an SNMPv3 context name in the specified management-module user profile.</p> <p>The context name defines the context the SNMPv3 user is working in. A context name can be shared by multiple users.</p>	<p>users <i>-user_number</i> -cn <i>context_name</i></p> <p>where:</p> <ul style="list-style-type: none"> <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the “Display all user profiles” list. <i>context_name</i> is a string up to 31 characters in length. Each of the 12 context names must be unique. <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>
Set SNMPv3 user authentication protocol	<p>Sets the SNMPv3 authentication protocol to be used for the specified management-module user profile.</p>	<p>users <i>-user_number</i> -ap <i>auth_protocol</i></p> <p>where:</p> <ul style="list-style-type: none"> <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the “Display all user profiles” list. <i>auth_protocol</i> is sha, md5, or blank (no entry) for none. <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>
Set SNMPv3 user privacy protocol	<p>Sets the SNMPv3 privacy protocol to be used for the specified management-module user profile.</p> <p>If the privacy protocol is set to none, no -ppw command option (privacy password) is required.</p>	<p>users <i>-user_number</i> -pp <i>privacy_protocol</i></p> <p>where:</p> <ul style="list-style-type: none"> <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the “Display all user profiles” list. <i>privacy_protocol</i> is des or blank (no entry) for none. <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>

Table 25. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Set privacy password for SNMPv3 user	Sets an SNMPv3 privacy password in the specified management-module user profile.	users - <i>user_number</i> -ppw <i>privacy_pwd</i> where: <ul style="list-style-type: none"> • <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the “Display all user profiles” list. • <i>privacy_pwd</i> is a string up to 31 characters in length. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set access type for SNMPv3 user	Sets an SNMPv3 access type for the specified management-module user profile. This command supports the following access types: <ul style="list-style-type: none"> • read: the user can query Management Information Base (MIB) objects and receive traps. • write: the user can query and set MIB objects and receive traps. • traps: the user can only receive traps. 	users - <i>user_number</i> -at <i>access_type</i> where: <ul style="list-style-type: none"> • <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the “Display all user profiles” list. • <i>access_type</i> is read, write, or traps. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set IP address or hostname for SNMPv3 trap receiver	Sets the IP address or hostname that will receive SNMPv3 traps for the specified management-module user profile.	users - <i>user_number</i> -i <i>ip_addr/hostname</i> where: <ul style="list-style-type: none"> • <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the “Display all user profiles” list. • <i>ip_addr/hostname</i> is a valid static IP address or an alphanumeric hostname string up to 63 characters in length. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example:

To create user number 3 with a user name of user3 who has supervisor rights to all BladeCenter components, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
users -3 -n user3 -p passwd -a rbs:super:c1|b1-b14|s1-s4 -cn joe -ap md5 -pp des
-ppw passwd -at read -I 192.168.70.129
```

Note: The entry beginning with users -3 -n... is shown with a line break after -pp des. When this command is entered, the entire entry must all be on one line.

To set the command authority for an existing user number 4 to Blade Operator for blade 1, blade 2, and blade 3 and Chassis Log Management, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
users -4 -rbs:bo|clm:b1-b3|c1
```

To display all users, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
users
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> users -3 -n user3 -p passwd -a rbs:super:c1|b1-b14|s1-s4
-cn joe -ap md5 -ppw passwd -at read -I 192.168.70.129
OK
system:mm[1]> users -4 -rbs:bo|clm:b1-b3|c1
OK
system:mm[1]> users
1. USERID
   Role:supervisor
   Blades:1|2|3|4|5|6|7|8|9|10|11|12|13|14
   Chassis:1
   Switches:1|2|3|4
2. <not used>
3. user3
   Role:supervisor
   Blades:1|2|3|4|5|6|7|8|9|10|11|12|13|14
   Chassis:1
   Switches:1|2|3|4
4. user4
   Role:blade operator|chassis log management
   Blades:1|2|3
   Chassis:1
   Switches:N/A
5. <not used>
6. <not used>
7. <not used>
8. <not used>
9. <not used>
10. <not used>
11. <not used>
12. <not used>
system:mm[1]>
```

Note: The entry beginning with users -3 -n... is shown with a line break after -a rbs:super:c1|b1-b14|s1-s4. When this command is entered, the entire entry must all be on one line.

write command (advanced management module only)

This command saves the management-module configuration to the chassis of the BladeCenter unit.

Table 26. write command

Function	What it does	Command	Valid targets
Save management-module configuration	Saves an image of the management-module configuration to the BladeCenter unit chassis.	write -config chassis Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.

Example:

To save the management-module configuration to an image on the BladeCenter chassis, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
write -config chassis
```

The following example shows the information that is returned from this command:

```
system:mm[1]> write -config chassis
OK
Configuration settings were successfully saved to the chassis
system:mm[1]>
```

Event-log commands

Use these commands to view and clear primary management-module event log entries:

- clearlog command
- displaylog command

clearlog command

This command clears the management-module event log.

Table 27. clearlog (clear management-module event log) command

Function	What it does	Command	Valid targets
Clear management-module event log	Clears the management-module event log and displays a message confirming that the event log was cleared.	clearlog Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.

Example:

To clear the management-module event log, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
clearlog
```

The following example shows the information that is returned:

```
system:mm[1]> clearlog
OK
system:mm[1]>
```

displaylog command

This command displays management-module event log entries.

Table 28. *displaylog (display management-module event log) command*

Function	What it does	Command	Valid targets
Display management-module event log entries	Displays five entries from the management-module event log. The first time the command is executed, the five most recent log entries are displayed. Each subsequent time the command is issued, the next five entries in the log display.	displaylog	-T system:mm[x] where x is the primary management-module bay number.
Display management-module event log entries (reset counter)	Resets the counter and displays the first five entries in the management-module event log.	displaylog -f	-T system:mm[x] where x is the primary management-module bay number.

Example:

To display the first five primary management-module event log entries, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
displaylog -f
```

To display the next five management-module event log entries, type (a second time)

```
displaylog
```

To display the next five management-module event log entries, type

```
displaylog
```

The following example shows the information that is returned from these three commands:

```
system:mm[1]> displaylog -f
1      I      SERVPROC      10/27/03      19:45:57      Remote
Login Successful. Login ID:''USERID' CLI authenticated from
192.168.70.231 (Telnet).'
2      E      SERVPROC      10/27/03      19:42:58      Failure
reading I2C device. Check devices on bus 4.
3      E      SERVPROC      10/27/03      19:42:58      Failure
reading I2C device. Check devices on bus 3.
4      E      SERVPROC      10/27/03      19:42:58      Failure
reading I2C device. Check devices on bus 2.
5      I      SERVPROC      10/27/03      19:41:54      Remote
Login Successful. Login ID:''USERID' from WEB browser at
IP@=192.168.70.231'
system:mm[1]> displaylog
6      E      SERVPROC      10/27/03      19:41:53      Blower 2
Fault Multiple blower failures
```

```

7      E      SERVPROC      10/27/03      19:41:53      Blower 1
Fault Single blower failure
8      I      SERVPROC      10/27/03      19:41:48
Ethernet[1] Link Established at 100Mb, Full Duplex.
9      I      SERVPROC      10/27/03      19:41:48
Ethernet[1] configured to do 100Mb/Full Duplex.
10     I      SERVPROC      10/27/03      19:41:48
Ethernet[1] MAC Address currently being used: 0x00-09-6B-CA-0C-81
system:mm[1]> displaylog
11     I      SERVPROC      10/27/03      19:41:48
Ethernet[0] Link Established at 100Mb, Full Duplex.
12     I      SERVPROC      10/27/03      19:41:48
Ethernet[0] configured to do Auto Speed/Auto Duplex.
13     I      SERVPROC      10/27/03      19:41:48
Ethernet[0] MAC Address currently being used: 0x00-09-6B-CA-0C-80
14     I      SERVPROC      10/27/03      19:41:48
Management Module Network Initialization Complete.
15     I      SERVPROC      10/27/03      19:41:46      ENET[1]
IP-Cfg:HstName=MM00096BCA0C81, IP0=192.168.70.126 ,GW0=0.0.0.0,
NetMsk=255.255.255.0
system:mm[1]>

```

The following example shows the information that is returned if the displaylog command is run after the event log is cleared:

```

system:mm[1]> displaylog -f
1      I      SERVPROC      10/27/03      19:53:02      System
log cleared.
(There are no more entries in the event log.)
system:mm[1]>

```

Power-control commands

Use these commands to control operation of the BladeCenter unit, blade servers, and I/O (switch) modules:

- boot command
- fuelg command
- power command
- reset command

boot command

This command resets blade servers with several different restart options.

Table 29. boot command

Function	What it does	Command	Valid targets
Reset blade server	Performs an immediate reset and restart of the specified blade server. This command will start a blade server that is turned off.	boot Command use restricted (see “Commands and user authority” on page 5).	-T system:blade[x] where x is the blade server bay number.

Table 29. boot command (continued)

Function	What it does	Command	Valid targets
Reset blade server to command console	Resets the specified blade server, causing it to open a command console with an SOL session when it restarts. This command will start a blade server that is turned off.	boot -c Command use restricted (see “Commands and user authority” on page 5).	-T system:blade[x] where x is the blade server bay number.
Power cycle	Cycles power for the specified blade server. If the blade server is off, it will turn on. If the blade server is on, it will turn off and then turn on.	boot -p powercycle Command use restricted (see “Commands and user authority” on page 5).	-T system:blade[x] where x is the blade server bay number.
Reset blade server	Performs an immediate reset and restart of the specified blade server. This command will start a blade server that is turned off.	boot -p reset Command use restricted (see “Commands and user authority” on page 5).	-T system:blade[x] where x is the blade server bay number.

Example:

To boot the blade server in blade bay 3, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type
boot -T system:blade[3]

The following example shows the information that is returned:

```
system:mm[1]> boot -T system:blade[3]
OK
system:mm[1]>
```

fuelg command

This command displays power domain information, listing the power modules that are installed in the BladeCenter unit and information about how the power in each domain is used. This command also configures the power domain policies for oversubscription and quiet mode

Table 30. fuelg command

Function	What it does	Command	Valid targets
Display power domain status overview	Displays health status and total power usage information for all power domains	fuelg	-T system
Display detailed power domain status	Displays detailed status and usage information for the specified power domains	fuelg <i>domain</i> where <i>domain</i> is “pd1” for power domain 1 and “pd2” for power domain 2. If no <i>domain</i> is specified, a status overview for all power domains displays.	-T system

Table 30. *fuelg* command (continued)

Function	What it does	Command	Valid targets
Set power domain redundancy loss policy	Sets how the BladeCenter unit responds to a condition that could cause a loss of redundant power.	<p><i>fuelg domain -os policy</i></p> <p>where:</p> <ul style="list-style-type: none"> • <i>domain</i> is “pd1” for power domain 1 and “pd2” for power domain 2. If no <i>domain</i> is specified, the <i>policy</i> is applied to all power domains. • <i>policy</i> of: <ul style="list-style-type: none"> – “none” (default) allows loss of redundancy. – “nonrecov” prevents components from turning on that will cause loss of power redundancy. – “recov” power throttles components to maintain power redundancy and prevents components from turning on that will cause loss of power redundancy. <p>Command use restricted (see “Commands and user authority” on page 5).</p>	-T system
Thermal event response (quiet mode)	Sets how the BladeCenter unit blowers respond to thermal events.	<p><i>fuelg -qm setting</i></p> <p>where the quiet-mode <i>setting</i> of:</p> <ul style="list-style-type: none"> • “off” (default) allows blowers to increase speed to provide additional cooling. • “on” keeps blowers at a fixed speed and power throttles BladeCenter components to reduce power consumption (only for BladeCenter components that support power throttling). <p>Command use restricted (see “Commands and user authority” on page 5).</p>	-T system

Example:

To view a power domain status overview, while the BladeCenter unit is set as the persistent command environment, at the `system>` prompt, type `fuelg`

To turn on quiet mode for all power domains, while the BladeCenter unit is set as the persistent command environment, at the `system>` prompt, type

```
fuelg -qm on
```

To view the detailed power domain status for power domain 1, while the BladeCenter unit is set as the persistent command environment, at the `system>` prompt, type

```
fuelg pd1
```

The following example shows the information that is returned when the `fuelg` command is run on a management module. Results that are returned for other management modules, such as an advanced management module, might have different categories and values.

```
system> fuelg
```

Note: All power values are displayed in Watts.

```
Power Domain 1
```

```
-----
```

```
Status: Power domain status is good.
```

```
Modules:
```

```
Bay 1: 2000
```

```
Bay 2: 2000
```

```
Power Budget: 3200
```

```
Reserved Power: 400
```

```
Remaining Power: 2800
```

```
Power in Use: 400
```

```
Power Domain 2
```

```
-----
```

```
Status: Power domain status is good.
```

```
Modules:
```

```
Bay 3: 1800
```

```
Bay 4: 1800
```

```
Power Budget: 2880
```

```
Reserved Power: 0
```

```
Remaining Power: 2880
```

```
Power in Use: 0
```

```
-qm off
```

```
system> fuelg -qm on
```

```
OK
```

```
system> fuelg pd1
```

Bay(s)	Module	Power State	Current	Allocated Max	Power Min
Chassis Components					
	Midplane	0n	10	10	10
no media tray					
Blowers					
1	Blower 1 (NP)	0n	120	120	120
2	Blower 2 (NP)	0n	120	120	120
Management Modules					
1	WMN315619689	0n	25	25	25
2	Backup MM (NP)		25	25	25
I/O Modules					
1	I/O Module 2 (NP)		45	45	45

2 I/O Module 2 (NP) 45 45 45

Domain totals:
Allocated Power 390 390 390

Note: (T) means "throttled", (U) means "unable to power up",
* means "the blade may throttle", (NP) means "the module is not present", (D) means "discovering", (C) means "comm error", SB means "Standby"

-os none
system>

power command

This command turns on and turns off blade servers and I/O (switch) modules.

Table 31. power command

Function	What it does	Command	Valid targets
Power on	Turns on the specified blade server or I/O (switch) module.	power -on Command use restricted (see "Commands and user authority" on page 5).	-T system:blade[x] -T system:switch[x] where x is the blade server or I/O (switch) module bay number.
Power on to command console	Opens a command console with an SOL session when the specified blade server is turned on.	power -on -c Command use restricted (see "Commands and user authority" on page 5).	-T system:blade[x] where x is the blade server bay number.
Power off	Turns off the specified blade server or I/O (switch) module.	power -off Command use restricted (see "Commands and user authority" on page 5).	-T system:blade[x] -T system:switch[x] where x is the blade server or I/O (switch) module bay number.
Power cycle	Cycles power for the specified blade server or I/O (switch) module. If the blade server or I/O (switch) module is off, it will turn on. If the blade server or I/O (switch) module is on, it will turn off and then turn on.	power -cycle Command use restricted (see "Commands and user authority" on page 5).	-T system:blade[x] -T system:switch[x] where x is the blade server or I/O (switch) module bay number.
Power cycle to command console	Cycles power for the specified blade server. If the blade server is off, it opens a command console with an SOL session when it is turned on. If the blade server is on, it will turn off and then turn on.	power -cycle -c Command use restricted (see "Commands and user authority" on page 5).	-T system:blade[x] where x is the blade server bay number.
Display power state	Displays the current power state for the specified blade server or I/O (switch) module. Possible return values are on and off.	power -state	-T system:blade[x] -T system:switch[x] where x is the blade server or I/O (switch) module bay number.

Table 31. power command (continued)

Function	What it does	Command	Valid targets
Display POST status for I/O (switch) module	<p>Displays the POST status for the specified I/O (switch) module. If the command is run while POST is in progress, it returns the level of POST that is currently in process. If the command is run after POST is complete, it displays one of the following return values:</p> <ul style="list-style-type: none"> • The POST results could not be read. message displays if there was an internal error during POST. • The POST results not complete: hex_code message displays if POST results are not available after POST completes. • If POST returns valid results, one of the following messages displays: <ul style="list-style-type: none"> – hex_code: Base internal function failure detected. – hex_code: Internal interface failure detected. – hex_code: External interface failure detected. – hex_code: Module completed POST successfully. – hex_code: Cannot decode POST result code. • The Invalid POST results. message displays if none of the above conditions is true. <p>Where <i>hex_code</i> is a hexadecimal code. See the documentation that comes with your I/O module for information.</p> <p>Note: This command option is not supported for serial concentrator I/O (switch) modules.</p>	power -state -post	<p>-T system:switch[x]</p> <p>where x is the I/O (switch) module bay number.</p>

Example:

To display the power state for the blade server in blade bay 5, while this blade server is set as the persistent command environment, at the system:blade[5]> prompt, type

```
power -state
```

To turn on the blade server in blade bay 5, while this blade server is set as the persistent command environment, at the system:blade[5]> prompt, type

```
power -on
```

To display the power state for the blade server in blade bay 5 again, while this blade server is set as the persistent command environment, at the `system:blade[5]>` prompt, type

```
power -state
```

The following example shows the information that is returned from these three commands:

```
system:blade[5]> power -state
Off
system:blade[5]> power -on
OK
system:blade[5]> power -state
On
system:blade[5]>
```

reset command

This command resets blade servers, blade server integrated system management processors (service processors), I/O (switch) modules, or the primary management module.

Table 32. *reset* command

Function	What it does	Command	Valid targets
Reset	Performs an immediate reset and restart of the specified device.	reset Command use restricted (see “Commands and user authority” on page 5).	-T system:blade[x] -T system:switch[x] -T system:blade[x]:sp -T system:mm[x] where x is the blade server, I/O (switch) module, or primary management-module bay number.
Reset blade server to command console	Opens a command console with an SOL session when the specified blade server is reset.	reset -c Command use restricted (see “Commands and user authority” on page 5).	-T system:blade[x] -T system:blade[x]:sp where x is the blade server bay number.
Reset management module with failover	Resets the primary management module, enabling failover if a redundant management module is present. An error message is displayed if you try to enable failover when a redundant management module is not installed.	reset -f Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] where x is the primary management-module bay number.
Reset I/O (switch) module with standard diagnostics	Performs an immediate reset and restart of the specified device, running standard diagnostics on the I/O (switch) module after it restarts. Running the reset -std command gives the same result as running the reset command on a I/O (switch) module.	reset -std Command use restricted (see “Commands and user authority” on page 5).	-T system:switch[x] where x is the I/O (switch) module bay number.

Table 32. reset command (continued)

Function	What it does	Command	Valid targets
Reset I/O (switch) module with extended diagnostics	Performs an immediate reset and restart of the specified device, running extended diagnostics on the I/O (switch) module after it restarts.	reset -exd Command use restricted (see “Commands and user authority” on page 5).	-T system:switch[x] where x is the I/O (switch) module bay number.
Reset I/O (switch) module with full diagnostics	Performs an immediate reset and restart of the specified device, running full diagnostics on the I/O (switch) module after it restarts.	reset -full Command use restricted (see “Commands and user authority” on page 5).	-T system:switch[x] where x is the I/O (switch) module bay number.
Restart blade server with NMI	Command results depend on the blade server model that is specified: <ul style="list-style-type: none"> • For a JS20 blade server, the command performs an immediate reset and restart of the specified blade server with non-maskable interrupt (NMI). • For all other blade servers, the command performs an immediate reset and restart of the specified blade server. 	reset -sft Command use restricted (see “Commands and user authority” on page 5).	-T system:blade[x] where x is the blade server bay number.
Restart blade server and clear NVRAM	Command results depend on the blade server model that is specified: <ul style="list-style-type: none"> • For a JS20 blade server, the command performs an immediate reset and restart of the specified JS20 blade server and clears all settings stored in non-volatile memory (NVRAM). • For all other blade servers, the command performs an immediate reset and restart of the specified blade server. 	reset -clr Command use restricted (see “Commands and user authority” on page 5).	-T system:blade[x] where x is the blade server bay number.
Restart blade server and run diagnostics	Command results depend on the blade server model that is specified: <ul style="list-style-type: none"> • For a JS20 blade server, the command performs an immediate reset and restart of the specified JS20 blade server and runs diagnostics. • For all other blade servers, the command performs an immediate reset and restart of the specified blade server. 	reset -dg Command use restricted (see “Commands and user authority” on page 5).	-T system:blade[x] where x is the blade server bay number.

Table 32. *reset* command (continued)

Function	What it does	Command	Valid targets
Restart blade server and run diagnostics using default boot sequence	<p>Command results depend on the blade server model that is specified:</p> <ul style="list-style-type: none"> For a JS20 blade server, the command performs an immediate reset and restart of the specified JS20 blade server and runs diagnostics using the default boot sequence configured for the blade server. For all other blade servers, the command performs an immediate reset and restart of the specified blade server. 	<p>reset -ddg</p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:blade[x]</p> <p>where x is the blade server bay number.</p>

Example:

To reset the service processor on the blade server in blade bay 5, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

```
reset
```

The following example shows the information that is returned:

```
system> reset -T blade[5]:sp
OK
system>
```

Session commands

Use these commands to start an SOL connection to the command console of a specific blade server or to end a command console session:

- console command
- exit command

console command

This command sets up a serial over LAN connection to the command console of a blade server.

To end an SOL session, press Esc followed by an open parenthesis:

```
Esc (
```

Table 33. *console* command

Function	What it does	Command	Valid targets
Create SOL session with blade server	Creates an SOL connection to the specified blade server.	<p>console</p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:blade[x]</p> <p>where x is the blade server bay number.</p>

Table 33. console command (continued)

Function	What it does	Command	Valid targets
Create override SOL session with blade server	Creates an SOL connection to the specified blade server, with the override option enabled. This enables you to end an existing SOL session to that blade server and start a new one.	console -o Command use restricted (see “Commands and user authority” on page 5).	-T system:blade[x] where x is the blade server bay number.

Example:

To start an SOL connection to the blade server in blade bay 14, while this blade server is set as the persistent command environment, at the system:mm[x]> prompt, type

```
sol -T system:blade[14]
```

exit command

This command exits the command-line interface, terminating the current session.

Table 34. exit command

Function	What it does	Command	Valid targets
Exit	Terminates the current command-line interface session.	exit	Any installed device.

Example:

To terminate the current command-line interface session, type

```
exit
```


System management commands (for BladeCenter T only)

Use these commands to manage alarms for monitored parameters of the BladeCenter T unit:

- alarm command

alarm command

This command displays alarm information, acknowledges alarms, and clears alarms for the specified command target.

Table 35. alarm command

Function	What it does	Command	Valid targets
Display all alarms	<p>Display all alerts generated by the target component. When directed to the BladeCenter unit, the command returns a summary of alarms for all BladeCenter components. When directed to a component installed in the BladeCenter unit, the command returns a detailed alarm listing for that component.</p> <p>Detailed alarm listings include an alarm key that can be used to acknowledge or clear an alarm.</p>	alarm	<p>-T system -T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]</p> <p>where x is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.</p>
Display power alarms	<p>Display all power related alerts generated by the target component. When directed to the BladeCenter unit, the command returns a summary of alarms for all BladeCenter components. When directed to a component installed in the BladeCenter unit, the command returns a detailed alarm listing for that component.</p> <p>Detailed alarm listings include an alarm key that can be used to acknowledge or clear an alarm.</p>	alarm -p	<p>-T system -T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]</p> <p>where x is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.</p>
Display alarm information (specified by alarm generator ID)	<p>Display information for alarm specified by the generator ID.</p>	<p>alarm -q -g <i>value</i></p> <p>where <i>value</i> is the generator ID.</p> <p>Command use restricted (see “Commands and user authority” on page 5).</p>	<p>-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]</p> <p>where x is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.</p>

Table 35. alarm command (continued)

Function	What it does	Command	Valid targets
Display alarm information (specified by alarm ID)	Display information for alarm specified by the alarm ID.	alarm -q -a <i>value</i> where <i>value</i> is the alarm ID.	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where <i>x</i> is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.
Display detailed alarm information (specified by generator information)	Display detailed information for alarm specified by the alarm generator information. Information returned includes the alarm description that is shown by the management-module Web interface and other information such as the alarm severity, power source, software indicator, and an alarm key.	alarm -q -o <i>value</i> where <i>value</i> is the generator information.	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where <i>x</i> is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.
Display alarm information (specified by complete alarm key)	Display information for alarm specified by the complete alarm key.	alarm -q -k <i>m:g:o:a</i> where <i>m:g:o:a</i> is the complete alarm key: <ul style="list-style-type: none"> • <i>m</i> is the module ID • <i>g</i> is the generator ID • <i>o</i> is the generator information • <i>a</i> is the alarm ID 	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where <i>x</i> is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.
Acknowledge alarm (specified by alarm generator ID)	Acknowledge the alarm specified by the generator ID.	alarm -r -g <i>value</i> where <i>value</i> is the generator ID. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where <i>x</i> is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.

Table 35. alarm command (continued)

Function	What it does	Command	Valid targets
Acknowledge alarm (specified by generator information)	Acknowledge the alarm specified by the generator information.	alarm -r -o <i>value</i> where <i>value</i> is the generator information. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where <i>x</i> is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.
Acknowledge alarm (specified by alarm ID)	Acknowledge the alarm specified by the alarm ID.	alarm -r -a <i>value</i> where <i>value</i> is the alarm ID. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where <i>x</i> is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.
Acknowledge alarm (specified by complete alarm key)	Acknowledge the alarm specified by the complete alarm key.	alarm -r -k <i>m:g:o:a</i> where <i>m:g:o:a</i> is the complete alarm key: <ul style="list-style-type: none"> • <i>m</i> is the module ID • <i>g</i> is the generator ID • <i>o</i> is the generator information • <i>a</i> is the alarm ID Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where <i>x</i> is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.
Clear alarm (specified by alarm generator ID)	Clear the alarm specified by the generator ID.	alarm -c -g <i>value</i> where <i>value</i> is the generator ID. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where <i>x</i> is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.

Table 35. alarm command (continued)

Function	What it does	Command	Valid targets
Clear alarm (specified by generator information)	Clear the alarm specified by the generator information.	alarm -c -o <i>value</i> where <i>value</i> is the generator information. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where <i>x</i> is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.
Clear alarm (specified by alarm ID)	Clear the alarm specified by the alarm ID.	alarm -c -a <i>value</i> where <i>value</i> is the alarm ID. Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where <i>x</i> is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.
Clear alarm (specified by complete alarm key)	Clear the alarm specified by the complete alarm key.	alarm -c -k <i>m:g:o:a</i> where <i>m:g:o:a</i> is the complete alarm key: <ul style="list-style-type: none"> • <i>m</i> is the module ID • <i>g</i> is the generator ID • <i>o</i> is the generator information • <i>a</i> is the alarm ID Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where <i>x</i> is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.
Set alarm	Set an alarm for the specified target, including severity level and description.	alarm -s -l <i>level desc</i> where <ul style="list-style-type: none"> • <i>level</i> is the severity level: <ul style="list-style-type: none"> – CRT (critical) – MJR (major) – MNR (minor) • <i>desc</i> is a short text description of the alarm Command use restricted (see “Commands and user authority” on page 5).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where <i>x</i> is the primary management-module, blade server, I/O (switch) module, power module, or blower bay number.

Example:

To display the alarm status for the BladeCenter T unit, while the BladeCenter T unit is set as the persistent command environment, at the `system>` prompt, type
`alarm`

To display the power alarm status for the BladeCenter T unit, while the BladeCenter T unit is set as the persistent command environment, at the `system>` prompt, type
`alarm -p`

To display detailed power alarm status for the power module in power bay 2, while the BladeCenter T unit is set as the persistent command environment, at the `system>` prompt, type
`alarm -T system:power[2]`

The following example shows the information that is returned from a series of alarm commands. This example assumes that the blade server in blade bay 3 has a major over-temperature fault and that the power module in power bay 2 has a critical fault.

```
system> alarm
Alarms Summary List
Module   Severity   Power   S/W
power[2] CRT        Yes    No
blade[3] MJR        No     No
system> alarm -p
Alarms Summary List
Module   Severity   Power   S/W
power[2] CRT        Yes    No
system> alarm -T system:power[2]
Alarms Detailed List
Severity   Power   S/W   Description      Key
CRT        Yes    No    Under Voltage   2:1:3:2
system> alarm -c -k 2:1:3:2 -T system:power[2]
Alarm Cleared
system> alarm -T system:power[2]
No Active Alarms
system> alarm
Alarms Summary List
Module   Severity   Power   S/W
blade[3] MJR        No     No
system> alarm -T system:blade[3]
Alarms Detailed List
Severity   Power   S/W   Description      Key
MJR        No     No    Over temperature  3:3:1:3
system> alarm -s -l CRT
OK
system> alarm -s -l MNR -p Investigate Watts -T system:blade[2]
OK
system> alarm -s -l CRT -p Under Voltage -T system:blade[2]
Failed. AlarmID is being used
system>
```

Chapter 4. Error messages

The command-line interface provides error messages specific to each command. The following topics list the common error messages that apply to all commands and command-specific error messages, along with their definitions.

- “Common errors” on page 88
- “alarm command errors” on page 89
- “alertentries command errors” on page 90
- “boot command errors” on page 90
- “clear command errors” on page 90
- “clearlog command errors” on page 91
- “console command errors” on page 91
- “dhcpinfo command errors” on page 91
- “displaylog command errors” on page 91
- “displaysd command errors” on page 92
- “dns command errors” on page 92
- “fuelg command errors” on page 92
- “health command errors” on page 93
- “identify command errors” on page 93
- “ifconfig command errors” on page 93
- “info command errors” on page 95
- “list command errors” on page 96
- “power command errors” on page 96
- “portcfg command errors” on page 96
- “read command errors” on page 96
- “reset command errors” on page 97
- “service command errors” on page 97
- “smtp command errors” on page 97
- “snmp command errors” on page 97
- “sol command errors” on page 98
- “tcpcmdmode command errors” on page 99
- “telnetcfg command errors” on page 100
- “update command errors” on page 100
- “uplink command errors” on page 102
- “users command errors” on page 102
- “write command errors” on page 105

Common errors

The following table lists error messages that apply to all commands. Each command that has unique errors will also have a list of command-specific error messages.

Table 36. Common errors

Error message	Definition
Command line contains extraneous arguments	Displays when extra command arguments are entered.
Duplicate option: <i>option</i> where <i>option</i> identifies the command option that was entered more than once.	Displays when a user tries to enter the same command option in a single command multiple times. For example, <code>dns -i 192.168.70.29 -i</code>
Each option can only be used once per command.	Displays when a user tries to enter the same command option in a single command multiple times. For example, <code>env -T system:blade[4] -T system:blade[5]</code> .
Error writing data for option <i>option</i> where <i>option</i> identifies the command option that is returning an error.	Displays when an internal error occurs while writing a command option value.
Illegal option: <i>option</i> where <i>option</i> identifies the illegal short command option that was entered.	Displays when an illegal short command option is entered.
Integer argument out of range (<i>range - range</i>) for <i>option: argument</i> where: <ul style="list-style-type: none"> • <i>range</i> identifies the range limits • <i>option</i> identifies the command option • <i>argument</i> identifies the integer that is out of range 	Displays when an integer is entered that is out of range.
Invalid integer argument for <i>option: argument</i> where: <ul style="list-style-type: none"> • <i>option</i> identifies the command option • <i>argument</i> identifies the invalid argument 	Displays when an invalid integer is entered.
Invalid option	Displays when an invalid command option is entered.
Invalid option argument for <i>option: argument</i> where: <ul style="list-style-type: none"> • <i>option</i> identifies the command option • <i>argument</i> identifies the invalid argument 	Displays when an invalid argument for a command option is entered.
Invalid target path	Displays when a user tries to issue a command to a target that is not valid.
Long option <i>option</i> requires an argument where <i>option</i> identifies the long command option that is missing an argument.	Displays when a long command option is entered without a required argument.
Missing option name	Displays when a dash (-) is entered with out a command option name.
Read/write command error	Displays when an internal error occurs while executing the command.

Table 36. Common errors (continued)

Error message	Definition
Short option <i>option</i> requires an argument where <i>option</i> identifies the short command option that is missing an argument.	Displays when a short command option is entered without a required argument.
The target bay is empty.	Displays when the user tries to issue a command to an empty blade bay, blower bay, I/O-module bay, management-module bay, or power bay.
The target bay is out of range.	Displays when a user tries to issue a command to a target that is out of range for that target. For example, the <code>env -T system:blade[15]</code> command is out of range because the BladeCenter unit has only 14 blade bays.
Unrecognized long option: <i>option</i> where <i>option</i> identifies the illegal long command option that was entered.	Displays when an illegal long command option is entered.
User does not have the authority to issue this command	Displays when a user lacks the authority level necessary to execute a command.

alarm command errors

The following table lists error messages for the alarm command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 37. alarm command errors

Error message	Definition
Alarm Description must be provided for setting an alarm.	Displays when the user tries to set an alarm without providing an alarm description.
Alarm ID must be from 1 to 255.	Displays when an invalid alarm ID is entered.
Generator ID must be from 1 to 255.	Displays when an invalid generator ID is entered.
Generator ID must be provided.	Displays when a generator information ID is provided without a generator ID.
Module ID must be from 1 to 255.	Displays when an invalid module ID is entered.
No active alarm.	Displays when no active alarm is found for the command target.
No matching alarm.	Displays when no matching alarm is found for the command target.
Severity level must be provided for setting an alarm.	Displays when the user tries to set an alarm without specifying the severity level.
Software Generator ID must be from 1 to 255.	Displays when an invalid generator information is entered.
The entered Alarm Key is not in proper format.	Displays when an invalid alarm key is entered.
Unable to acknowledge the requested alarm.	Displays when an internal error occurs while acknowledging an alarm.
Unable to clear the requested alarm.	Displays when an internal error occurs while clearing an alarm.
Unable to set the requested alarm.	Displays when an internal error occurs while setting an alarm.

alertentries command errors

The following table lists error messages for the alertentries command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 38. alertentries command errors

Error message	Definition
An entry cannot be modified and deleted in the same command.	Displays when a user tries to modify an entry and delete it in the same command.
Arguments containing spaces must be enclosed in quotation marks.	Displays when a user tries to enter a string containing spaces that has an opening quotation mark without a closing quotation mark.
Invalid input. Angle brackets are not allowed in the name field.	Displays when a user tries to enter a string parameter containing < or > for the -n (name) command option.
Invalid option	Displays when an invalid command option is entered. This includes numeric options for the alert recipient that are not from 1 through 12.
Invalid parameter. Input must be numeric.	Displays when a user tries to enter a parameter value containing non-numeric characters for a command option requiring numeric input.
Syntax error. -e can only be used in conjunction with the email argument.	Displays when a user tries to enter an invalid e-mail address for the -e command option.
Syntax error. -i can only be used in conjunction with the director argument.	Displays when a user tries to enter an invalid IP address for the -i command option.
Syntax error. Type alertentries -h for help.	Displays when an alert entry number is entered without the leading dash (-).
The name must be less than 32 characters long.	Displays when a user tries to enter too many characters in an input field.
When creating a new entry, all options are required.	Displays when a required command option is missing when creating a user.

boot command errors

There are no unique errors for the boot command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

clear command errors

The following table lists error messages for the clear command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 39. clear command errors

Error message	Definition
Firmware update is in progress. Try again later.	Displays when the user tries to reset the management module to its default configuration during a firmware update. The error message displays and the management-module configuration does not reset.
Internal error resetting to defaults.	Displays when an internal error occurs while resetting the management module to its default configuration. The error message displays and the management-module configuration does not reset.

clearlog command errors

The following table lists error messages for the clearlog command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 40. clearlog command errors

Error message	Definition
Error clearing the event log.	Displays when an internal error occurs while clearing the event log.

console command errors

The following table lists error messages for the console command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 41. console command errors

Error message	Definition
Error entering console mode.	Displays when an internal error occurs while trying to establish an SOL connection.
Global SOL is not enabled	Displays when SOL is not enabled globally.
Internal Error	Displays when an internal error occurs while processing the command.
SOL is not ready	Displays when the blade server is not available, or when a socket needed to establish a connection to the blade server is not available.
SOL on blade is not enabled	Displays when SOL is not enabled on the blade server where the user is trying to start an SOL session.
SOL session is already active	Displays when the user cannot start an SOL session with a blade server because an SOL session with that blade server is already in progress.

dhcpcinfo command errors

There are no unique errors for the dhcpcinfo command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

displaylog command errors

The following table lists error messages for the displaylog command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 42. displaylog command errors

Error message	Definition
(There are no more entries in the event log.)	Displays when there are no more event log entries to display.

displaysd command errors

There are no unique errors for the displaysd command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

dns command errors

The following table lists error messages for the dns command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 43. dns command errors

Error message	Definition
At least one address is required to enable DNS.	Displays when a user tries to enable DNS without configuring at least one address.
Invalid ip address	Displays when a user tries to set an invalid IP address.
-on and -off cannot both be used in the same command.	Displays when a user tries to enable and disable DNS in the same command.

fuelg command errors

The following table lists error messages for the fuelg command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 44. fuelg command errors

Error message	Definition
A power module failure in domain <i>domain_number</i> can result in an immediate shutdown. where <i>domain_number</i> identifies the power domain.	Displays when a power module fails and the domain in which it is installed loses redundancy. The BladeCenter unit might turn itself off, based on the power management configuration.
Blade <i>blade_number</i> is not allowed to power on because of insufficient power. where <i>blade_number</i> identifies the blade server.	Displays when there is insufficient power available in the power domain to turn on this blade server.
Blade <i>blade_number</i> is throttled. where <i>blade_number</i> identifies the blade server.	Displays when the specified blade server has reduced power (power throttling) in response to a thermal event or oversubscription condition.
Blade <i>blade_number</i> was instructed to power off due to power budget restrictions. where <i>blade_number</i> identifies the blade server.	Displays when BladeCenter power management turns off a blade server that is already on in response to a oversubscription condition.
Demand exceeds a single power module. Throttling can occur in power domain <i>domain_number</i> . where <i>domain_number</i> identifies the power domain.	Displays when the power requirements of components installed in a power domain exceed the level required for redundant operation. Power throttling of BladeCenter components might be able to correct the problem.
There are mismatched power modules in power domain <i>domain_number</i> . where <i>domain_number</i> identifies the power domain.	Displays when the power modules installed in a power domain have different ratings.

health command errors

There are no unique errors for the health command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

identify command errors

The following table lists error messages for the identify command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 45. *identify* command errors

Error message	Definition
Delay value must be less than 60	Displays when a user tries to enter a -d value that is greater than 60 seconds.
Identify: Error accessing remote LED	Displays when an internal error occurs while processing the command.
Identify: error getting LED status	Displays when an internal error occurs while processing the command.
Identify: error setting Management Module LED	Displays when an internal error occurs while processing the command.
Identify: Error unknown command	Displays when an internal error occurs while processing the command.
Identify: LED status not supported	Displays when the user tries to get the status of an LED that is not supported by a blade server.
Identify: unknown LED state <i>state</i> where <i>state</i> identifies the LED state that was returned.	Displays when an LED state other than on, off, or blinking is returned.
Identify: Unknown return status <i>status</i> where the <i>status</i> value varies based on the problem that was encountered.	Displays when an internal error occurs while processing the command.
Syntax error.	Displays when the user tries to enter an invalid command option. Type <code>identify -h</code> for command help.

ifconfig command errors

The following table lists error messages for the ifconfig command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 46. *ifconfig* command errors

Error message	Definition
Error reading gateway address.	Displays when an internal error occurs while reading the gateway address of a network interface (eth0 or eth1).
Error reading IP Address.	Displays when an internal error occurred while reading the IP address of the integrated system management processor on a blade server, or while reading the IP address of a network interface (eth0 or eth1).
Error reading the burned-in MAC address.	Displays when an internal error occurs while reading the burned-in MAC address of a network interface (eth0 or eth1).
Error reading the data rate.	Displays when an internal error occurs while reading the data rate setting of a network interface (eth0 or eth1).

Table 46. *ifconfig* command errors (continued)

Error message	Definition
Error reading the DHCP configuration.	Displays when an internal error occurs while reading the DHCP setting of a network interface (eth0).
Error reading the duplex setting.	Displays when an internal error occurs while reading the duplex setting of a network interface (eth0 or eth1).
Error reading the hostname.	Displays when an internal error occurs while reading the host name of a network interface (eth0).
Error reading the locally administered MAC address.	Displays when an internal error occurs while reading the locally administered MAC address of a network interface (eth0 or eth1).
Error reading the maximum transmission unit.	Displays when an internal error occurs while reading the maximum transmission unit (MTU) setting of a network interface (eth0 or eth1).
Error reading the subnet mask.	Displays when an internal error occurs while reading the subnet mask of a network interface (eth0 or eth1).
Error writing IP Address.	Displays when an internal error occurs while setting the IP address of the integrated system management processor on a blade server.
Invalid IP arg for <i>option: ip_address</i> . Each byte has to be in the range (0-255) where: • <i>option</i> identifies the command option • <i>ip_address</i> identifies the invalid IP address argument	Displays when the user tries to enter an IP address that is out of range. IP addresses must follow the standard format: xxx.xxx.xxx.xxx, where each xxx is a number from 0 to 255.
Invalid IP arg for <i>option: ip_address</i> . Enter 4 bytes separated by 3 dots where: • <i>option</i> identifies the command option • <i>ip_address</i> identifies the invalid IP address argument	Displays when the user tries to enter an IP address that is too long. IP addresses must follow the standard format: xxx.xxx.xxx.xxx, where each xxx is a number from 0 to 255.
Invalid IP arg for <i>option: ip_address</i> . Too few bytes where: • <i>option</i> identifies the command option • <i>ip_address</i> identifies the invalid IP address argument	Displays when the user tries to enter an IP address with too few bytes. IP addresses must follow the standard format: xxx.xxx.xxx.xxx, where each xxx is a number from 0 to 255.
Invalid IP arg for <i>option: ip_address</i> . Too many bytes where: • <i>option</i> identifies the command option • <i>ip_address</i> identifies the invalid IP address argument	Displays when the user tries to enter an IP address with too many bytes. IP addresses must follow the standard format: xxx.xxx.xxx.xxx, where each xxx is a number from 0 to 255.
Invalid hostname arg for <i>option: hostname</i> . Consecutive dots where: • <i>option</i> identifies the command option • <i>hostname</i> identifies the invalid hostname argument	Displays when the user tries to enter consecutive periods (.) as part of a hostname.
Invalid hostname arg for <i>option: hostname</i> . Length has to be < 64 characters where: • <i>option</i> identifies the command option • <i>hostname</i> identifies the invalid hostname argument	Displays when the user tries to enter a hostname longer than 63 characters.

Table 46. *ifconfig* command errors (continued)

Error message	Definition
Invalid hostname arg for <i>option</i> : <i>hostname</i> . Only alphanumeric chars and <code>._-</code> allowed where: <ul style="list-style-type: none"> <i>option</i> identifies the command option <i>hostname</i> identifies the invalid hostname argument 	Displays when the user tries to enter a hostname that contains invalid characters. Valid characters that can be used in a hostname are letters, numbers, periods (<code>.</code>), dashes (<code>-</code>), and underscores (<code>_</code>).
Invalid ip address.	Displays for one of the following errors: <ul style="list-style-type: none"> A user tries to set the IP address of <code>system:blade[1]:sp</code> either to an invalid IP address, or an IP address whose last part is greater than 255 (the max number of blade servers). A user tries to enter an invalid IP address for the <code>-i</code> (static IP address) command option.
Invalid MAC arg for <i>option</i> : <i>address</i> . Invalid syntax where: <ul style="list-style-type: none"> <i>option</i> identifies the command option <i>address</i> identifies the invalid MAC address argument 	Displays when the user tries to enter an invalid MAC address.
Invalid MAC arg for <i>option</i> : <i>address</i> . Multicast addresses not allowed where: <ul style="list-style-type: none"> <i>option</i> identifies the command option <i>address</i> identifies the invalid MAC address argument 	Displays when the user tries to enter a multicast address.
Invalid MAC arg for <i>option</i> : <i>address</i> . Too few bytes where: <ul style="list-style-type: none"> <i>option</i> identifies the command option <i>address</i> identifies the invalid MAC address argument 	Displays when the user tries to enter a MAC address with too few bytes.
Invalid MAC arg for <i>option</i> : <i>address</i> . Too many bytes where: <ul style="list-style-type: none"> <i>option</i> identifies the command option <i>address</i> identifies the invalid MAC address argument 	Displays when the user tries to enter a MAC address with too many bytes.
Invalid parameter. Valid values for <code>-c</code> are <code>dhcp</code> , <code>static</code> , or <code>dthens</code> .	Displays when a user tries to enter an invalid parameter for the <code>-c</code> (Ethernet configuration method) command option.
The target must be <code>system:blade[1]:sp</code> for this command	Displays when a user tries to issue the <code>ifconfig -i <ip address> -T system:blade[x]:sp</code> to a blade server other than <code>blade[1]</code> .

info command errors

The following table lists error messages for the `info` command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 47. *info* command errors

Error message	Definition
Device not found	Displays when no VPD is available for the targeted device.
Unknown device type.	Displays when the command is targeted to an unknown device type.

list command errors

The following table lists error messages for the list command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 48. list command errors

Error message	Definition
The level must be non-zero.	Displays when the user tries to enter a level of depth for tree-structure display of 0.

power command errors

The following table lists error messages for the power command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 49. power command errors

Error message	Definition
Invalid POST results.	Displays when the POST results are not valid.
POST results could not be read.	Displays when an internal error occurs during POST.
POST results not complete: <i>hex_code</i> where the <i>hex_code</i> value varies based on the problem that was encountered.	Displays when the POST results are not available. See the documentation that comes with the device that failed to respond correctly to the power command for information about the <i>hex_code</i> value.

portcfg command errors

There are no unique errors for the portcfg command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

read command errors

The following table lists error messages for the read command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 50. read command errors

Error message	Definition
Firmware update is in progress. Try again later.	Displays when a user tries to restore the management-module configuration from the BladeCenter unit midplane while the management-module firmware is updating.
Configuration restore from the chassis failed: operation not supported.	Displays when an internal error occurs while restoring the management-module configuration from the BladeCenter unit midplane due to a failed system check.
Configuration restore from the chassis failed: i2c bus read error	Displays when an internal error occurs while restoring the management-module configuration from the BladeCenter unit midplane due to an i2ct read error.
Configuration restore from the chassis failed: NVRAM compression error	Displays when an internal error occurs while restoring the management-module configuration from the BladeCenter unit midplane due to an EEPROM compression error.
Configuration restore from the chassis failed: unsupported midplane data format	Displays when an internal error occurs while restoring the management-module configuration from the BladeCenter unit midplane due to an unsupported EEPROM format.

reset command errors

The following table lists error messages for the reset command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 51. reset command errors

Error message	Definition
An error occurred while disabling failover.	Displays when an internal error occurs while disabling failover.
An error occurred while enabling failover.	Displays when an internal error occurs while enabling failover.
Firmware update is in progress. Try again later.	Displays when the user tries to reset the management module during a firmware update. The error message displays and the management module does not reset.
There is no backup management module installed.	Displays when a user tries to enable failover on a management-module reset and there is no back-up management module.

service command errors

There are no unique errors for the service command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

smtp command errors

The following table lists error messages for the smtp command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 52. smtp command errors

Error message	Definition
Input length is greater than the maximum characters allowed.	Displays when a user tries to enter too many characters in an input field.
Invalid host name or ip address	Displays when a user tries to set the SMTP host name or IP address to an invalid value.
SMTP server host name or IP address is not set	Displays when a user tries to view the SMTP host name or IP address and the values are not set.

snmp command errors

The following table lists error messages for the snmp command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 53. snmp command errors

Error message	Definition
Arguments containing spaces must be enclosed in quotation marks	Displays when a user tries to enter a string containing spaces that has an opening quotation mark without a closing quotation mark.
At least one configured community is required to enable SNMP.	Displays when a user tries to enable SNMP without configuring at least one community name.

Table 53. snmp command errors (continued)

Error message	Definition
Input length is greater than the maximum characters allowed.	Displays when a user tries to enter too many characters in an input field.
Invalid community name	Displays when a user tries to set a community name to an invalid value.
Invalid host name or ip address	Displays when a user tries to set the SNMP host name or IP address to an invalid value.

sol command errors

The following table lists error messages for the sol command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 54. sol command errors

Error message	Definition
An error occurred while disabling SOL globally	Displays when an internal error occurs while disabling SOL globally.
An error occurred while disabling SOL on that blade	Displays when an internal error occurs while disabling SOL on a blade server.
An error occurred while enabling SOL globally	Displays when an internal error occurs while enabling SOL globally
An error occurred while enabling SOL on that blade	Displays when an internal error occurs while enabling SOL on a blade server.
An error occurred while reading the global SOL status	Displays when an internal error occurs while reading the global SOL status.
An error occurred while reading the SOL accumulate timeout	Displays when an internal error occurs while reading the SOL accumulate timeout.
An error occurred while reading the SOL retry count	Displays when an internal error occurs while reading the SOL retry count.
An error occurred while reading the SOL retry interval	Displays when an internal error occurs while reading the SOL retry interval.
An error occurred while reading the SOL send threshold	Displays when an internal error occurs while reading the SOL send threshold.
An error occurred while reading the SOL session status on that blade	Displays when an internal error occurs while reading the SOL session status on a blade server.
An error occurred while reading the SOL VLAN ID	Displays when an internal error occurs while reading the SOL VLAN ID.
An error occurred while setting the SOL accumulate timeout	Displays when an internal error occurs while setting the SOL accumulate timeout.
An error occurred while setting the SOL blade reset sequence	Displays when an internal error occurs while processing the command.
An error occurred while setting the SOL escape sequence	Displays when an internal error occurs while processing the command.
An error occurred while setting the SOL retry count	Displays when an internal error occurs while setting the SOL retry count.
An error occurred while setting the SOL retry interval	Displays when an internal error occurs while setting the SOL retry interval.

Table 54. sol command errors (continued)

Error message	Definition
An error occurred while setting the SOL send threshold	Displays when an internal error occurs while setting the SOL send threshold.
An error occurred while setting the SOL vlan id	Displays when an internal error occurs while processing the command.
Invalid arg for -status. Must be on or off.	Displays if a user tries to enter an invalid argument for the -status command option.
Invalid parameter. The accumulate timeout must be between 1 and 1275 inclusive.	Displays when a user tries to enter a accumulate timeout that is outside of the valid range.
Invalid parameter. The retry count must be between 0 and 7, inclusive.	Displays when a user tries to enter a retry count that is outside of the valid range.
Invalid parameter. The send threshold must be between 1 and 251 inclusive.	Displays when a user tries to enter a send threshold that is outside of the valid range.
Invalid parameter. The vlan id must be between 1 and 4095 inclusive.	Displayed if a user tries to enter a VLAN ID that is out of range.
Retry interval range is too large. Setting to 250.	Displays when a user tries to enter a retry interval that is greater than 250 ms. If the user tries to enter a retry interval greater than 250 ms, the retry interval will be set to 250 ms.
This blade does not support SOL	Displays if a user tries to issue the SOL command to a blade server that does not support SOL.

tcpcmdmode command errors

The following table lists error messages for the tcpcmdmode command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 55. tcpcmdmode command errors

Error message	Definition
Error disabling tcpcmdmode	Displays when an internal error occurs while disabling TCP command mode.
Error enabling TCP command mode	Displays when an internal error occurs while enabling TCP command mode.
Invalid parameter. Input must be numeric.	Displays when a user tries to enter a parameter value for the -t (timeout) command option containing non-numeric characters. For example, tcpcmdmode -t 200m.
Invalid parameter. The timeout must be between 0 and 4294967295 seconds.	Displays when a user tries to enter a parameter value for the -t (timeout) command option that is outside of the valid range.

telnetcfg command errors

The following table lists error messages for the telnetcfg command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 56. telnetcfg command errors

Error message	Definition
Invalid parameter. Input must be numeric.	Displays when a user tries to enter a Telnet timeout value containing non-numeric characters. For example, telnetcfg -t 200w.
Invalid parameter. The timeout must be between 0 and 4294967295 seconds.	Displays when a user tries to enter a Telnet timeout value that is out of range.

update command errors

The following table lists error messages for the update command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 57. update command errors

Error message	Definition
Flash operation failed.	Displays when an internal error occurs during flash firmware update.
Flash operation failed status <i>percentage</i> where the <i>percentage</i> value varies based on when the problem was encountered.	Displays when an internal error occurs during flash firmware update.
Flash operation not in process or status unavailable.	Displays when an internal error occurs during flash firmware update.
Flash operation timed out <i>percentage</i> where the <i>percentage</i> value varies based on when the problem was encountered.	Displays when an internal error occurs during flash firmware update.
Flash preparation - error sending packet file <i>filename</i> where the <i>filename</i> value varies based on the file being updated.	Displays when an internal error occurs during flash firmware update.
Flash preparation error.Packet percent complete <i>percentage</i> . Flash percent complete <i>percentage</i> . where the <i>percentage</i> value varies based on when the problem was encountered.	Displays when an internal error occurs during flash firmware update.
Flash preparation error.Timeout on packet preparation operation <i>percentage</i> where the <i>percentage</i> value varies based on when the problem was encountered.	Displays when an internal error occurs during flash firmware update.
Flashing not supported on this target	Displays when a user targets the command to a I/O module that does not support flash firmware updates.

Table 57. update command errors (continued)

Error message	Definition
Invalid option	<p>Displays when an invalid command option is entered. For the update command, invalid command option errors include:</p> <ul style="list-style-type: none"> • the -i (IP address) command option does not have an IP address parameter • the -i (IP address) command option specifies an invalid IP address • attempting to enter the -i (IP address) command option without the -n (filename) command option • the -n (filename) command option does not have a file name parameter • attempting to enter the -n (filename) command option without the -i (IP address) command option • attempting to enter the -v (verbose) command option without the -i (IP address) command option and -n (filename) command option • attempting to enter the -v (verbose) command option with the -a command option
Management Module <i>bay_number</i> is not installed. where the <i>bay_number</i> value varies based on the problem that was encountered.	Displays when the command is targeted to a management-module bay where no management module is installed.
TFTP Error <i>error_code</i> where the <i>error_code</i> value varies based on the problem that was encountered.	Displays when an internal error occurs for the TFTP connection.
TFTP Error. Access violation.	Displays when an internal error occurs for the TFTP connection.
TFTP Error. Connection failure.	Displays when an internal error occurs for the TFTP connection.
TFTP Error. Disk full or allocation exceeded.	Displays when an internal error occurs for the TFTP connection.
TFTP Error. File already exists.	Displays when an internal error occurs for the TFTP connection.
TFTP Error. File error.	Displays when an internal error occurs for the TFTP connection.
TFTP Error. File not found.	Displays when an internal error occurs for the TFTP connection.
TFTP Error. Illegal option negotiation.	Displays when an internal error occurs for the TFTP connection.
TFTP Error. Illegal TFTP operation.	Displays when an internal error occurs for the TFTP connection.
TFTP Error. Unable to allocate memory.	Displays when an internal error occurs for the TFTP connection.
TFTP Error. Unknown transfer ID.	Displays when an internal error occurs for the TFTP connection.
TFTP Error. Unknown user.	Displays when an internal error occurs for the TFTP connection.
Unable to read blade server VPD bay <i>bay_number name</i> . where the <i>bay_number</i> and <i>name</i> values vary based on the problem that was encountered.	Displays when the command is specifies an empty bay or if an internal error occurs when reading the VPD.

Table 57. update command errors (continued)

Error message	Definition
Unable to read MM VPD bay <i>bay_number name</i> . where the <i>bay_number</i> and <i>name</i> values vary based on the problem that was encountered.	Displays when the command is specifies an empty bay or if an internal error occurs when reading the VPD.
Unable to read I/O Module VPD bay <i>bay_number name</i> . where the <i>bay_number</i> and <i>name</i> values vary based on the problem that was encountered.	Displays when the command is specifies an empty bay or if an internal error occurs when reading the VPD.
Unknown device type.	Displays when the command is targeted to an unknown device type.
Update error. Invalid destination.	Displays when a user tries to issue a command to a target that is not valid.

uplink command errors

The following table lists error messages for the uplink command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 58. uplink command errors

Error message	Definition
Invalid uplink delay value	Displays when a user tries to enter a delay value that is less than 1 or greater than 255. For example, <code>uplink -del 0</code> .

users command errors

The following table lists error messages for the users command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 59. users command errors

Error message	Definition
An entry cannot be modified and deleted in the same command.	Displays when a user tries to modify and delete a user in the same command.
Arguments containing spaces must be enclosed in quotation marks.	Displays when a user tries to enter a context name containing spaces that does not have opening and closing quotation marks.
Error: the RBS permissions capability is not enabled.	Displays when attempting to run use the <code>-a rbs:</code> command option on management-module firmware that does not support this option. (The <code>-a rbs:</code> command option is not supported for the advanced management module.)
Error converting RBS permissions	Displays when an internal error occurs while converting permissions data to role-based security (RBS) format.
Error creating user	Displays when an internal error occurs while creating a user.
Error setting the access type	Displays when an internal error occurs while setting the access type.
Error setting the authentication protocol	Displays when an internal error occurs while setting the authentication protocol.

Table 59. users command errors (continued)

Error message	Definition
Error setting the authority level	Displays when an internal error occurs while setting the authority level.
Error setting the context name	Displays when an internal error occurs while setting the context name.
Error setting the hostname/IP address	Displays when an internal error occurs while setting the hostname or IP address.
Error setting the password	Displays when an internal error occurs while setting the password.
Error setting the privacy password	Displays when an internal error occurs while setting the privacy password.
Error setting the privacy protocol	Displays when an internal error occurs while setting the privacy protocol.
Error setting the username	Displays when an internal error occurs while setting the username.
Incorrect login permission option: <i>permission</i> where the <i>permission</i> value varies based on the problem that was encountered.	Displays when a user tries to specify an invalid login permission for the -a command option.
Invalid argument. Valid arguments for -at are read, write, and traps.	Displays when a user tries to set an invalid argument for the -at command option.
Invalid argument. Valid choices are des or <none>.	Displays when a user tries to set an invalid argument for the -pp command option.
Invalid argument. Valid choices are md5, sha, or <none>.	Displays when a user tries to set an invalid argument for the -ap command option.
Invalid authority level.	Displays for one of the following errors: <ul style="list-style-type: none"> • A user tries to set an authority level that is invalid. • A user tries to set a custom authority level without specifying any customization information.
Invalid device number (first number must be smaller): <i>device_A-device_B</i> . where <i>device_A</i> and <i>device_B</i> identify the ends of the invalid device range being specified.	Displays when a user specifies an invalid device range while trying to create or modify a user.
Invalid device number: <i>device_number</i> . where <i>device_number</i> identifies the device number that is invalid.	Displays when a user provides a device number that is out of range while trying to create or modify a user.
Invalid hostname or ip address.	Displays when a user tries to set an invalid host name or IP address for the -i command option.
Invalid rbs device: <i>device</i> . where <i>device</i> identifies the device that is invalid.	Displays when a user specifies an invalid device while trying to create or modify a user.
Invalid rbs device: Must specify device number	Displays when a user specifies an invalid device number while trying to create or modify a user.
Invalid rbs device list.	Displays when a user does not specify a device list while trying to create or modify a user.
Invalid rbs device (must be same device): <i>device</i> . where <i>device</i> identifies the device that is invalid.	Displays when a user specifies an invalid device while trying to create or modify a user.

Table 59. users command errors (continued)

Error message	Definition
Invalid rbs role: <i>role</i> . where <i>role</i> identifies the role that is invalid.	Displays when a user specifies an invalid role while trying to create or modify a user.
Invalid username. The username can only contain numbers, letters, dots, and underscores.	Displays when the user tries to enter an username that contains invalid characters. Valid characters that can be used in a username are letters, numbers, periods (.), and underscores (_).
Syntax error. -a option must have an argument.	Displays when a user tries to attempt to enter the command with a -a command option that has no argument.
Syntax error. -at option must have an argument.	Displays when a user tries to attempt to enter the command with a -at command option that has no argument.
Syntax error. -cn option must have an argument.	Displays when a user tries to attempt to enter the command with a -cn command option that has no argument.
Syntax error. -i option must have an argument.	Displays when a user tries to attempt to enter the command with a -i command option that has no argument.
Syntax error. -n option must have an argument.	Displays when a user tries to attempt to enter the command with a -n command option that has no argument.
Syntax error. -ppw option must have an argument.	Displays when a user tries to attempt to enter the command with a -ppw command option that has no argument.
Syntax error. Multiple -a options found.	Displays when a user tries to enter the -a command option in a single command multiple times.
Syntax error. Multiple -ap options found.	Displays when a user tries to enter the -ap option flag in a single command multiple times.
Syntax error. Multiple -at options found.	Displays when a user tries to enter the -at option flag in a single command multiple times.
Syntax error. Multiple -cn options found.	Displays when a user tries to enter the -cn option flag in a single command multiple times.
Syntax error. Type users -h for help.	Displays when a user tries to set an invalid value for a command option.
Syntax error. Multiple -i options found.	Displays when a user tries to enter the -i option flag in a single command multiple times.
Syntax error. Multiple -n options found.	Displays when a user tries to enter the -n option flag in a single command multiple times.
Syntax error. Multiple -p options found.	Displays when a user tries to enter the -p option flag in a single command multiple times.
Syntax error. Multiple -pp options found.	Displays when a user tries to enter the -pp option flag in a single command multiple times.
Syntax error. Multiple -ppw options found.	Displays when a user tries to enter the -ppw option flag in a single command multiple times.
The context name must be less than 32 characters long.	Displays when a user tries to set a context name that is longer than 31 characters.
The password must be at least 5 characters long, but no more than 15 characters long.	Displays when the user tries to enter a password that is too short or too long.

Table 59. users command errors (continued)

Error message	Definition
The password must contain at least one alphabetic and one non-alphabetic character.	Displays when the user tries to enter a password that does not have at least one alphabetic and one non-alphabetic character.
The privacy password must also be set when setting the privacy protocol.	Displays if the user tries to set the privacy protocol to des without a specifying a privacy password (-ppw command option).
The privacy password must be less than 32 characters long.	Displays when a user tries to set a privacy password that is longer than 31 characters.
The username cannot be longer than 15 characters.	Displays when a user tries to set a user name that is longer than 15 characters.
When creating a new user, all options are required.	Displays when a user tries to create a new user without defining all command options and arguments.

write command errors

The following table lists error messages for the write command. See “Common errors” on page 88 for a list of error messages that apply to all commands.

Table 60. write command errors

Error message	Definition
Failed to save configuration settings to the chassis.	Displays when an internal error occurs while saving the management-module configuration to the BladeCenter unit midplane.
Firmware update is in progress. Try again later.	Displays when a user tries to save the management-module configuration to the BladeCenter unit midplane while the management-module firmware is updating.

Appendix A. Getting help and technical assistance

If you need help, service, or technical assistance or just want more information about IBM products, you will find a wide variety of sources available from IBM to assist you. This appendix contains information about where to go for additional information about IBM and IBM products, what to do if you experience a problem with your BladeCenter® product or optional device, and whom to call for service, if it is necessary.

Before you call

Before you call, make sure that you have taken these steps to try to solve the problem yourself:

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system and any optional devices are turned on.
- Use the troubleshooting information in your system documentation, and use the diagnostic tools that come with your system. Information about diagnostic tools is in the *Hardware Maintenance Manual and Troubleshooting Guide* or *Problem Determination and Service Guide* on the IBM Documentation CD that comes with your system.
- Go to <http://www.ibm.com/bladecenter/> and click **Support** to check for information to help you solve the problem.

You can solve many problems without outside assistance by following the troubleshooting procedures that IBM provides in the online help or in the documentation that is provided with your IBM product. The documentation that comes with BladeCenter systems also describes the diagnostic tests that you can perform. Most BladeCenter systems, operating systems, and programs come with documentation that contains troubleshooting procedures and explanations of error messages and error codes. If you suspect a software problem, see the documentation for the software.

Using the documentation

Information about your IBM BladeCenter system and preinstalled software, if any, or optional device is available in the documentation that comes with the product. That documentation can include printed documents, online documents, readme files, and help files. See the troubleshooting information in your system documentation for instructions for using the diagnostic programs. The troubleshooting information or the diagnostic programs might tell you that you need additional or updated device drivers or other software. IBM maintains pages on the World Wide Web where you can get the latest technical information and download device drivers and updates. To access these pages, go to <http://www.ibm.com/bladecenter/>, click **Support**, and follow the instructions. Also, some documents are available through the IBM Publications Center at <http://www.ibm.com/shop/publications/order/>.

Getting help and information from the World Wide Web

On the World Wide Web, the IBM Web site has up-to-date information about IBM BladeCenter systems, optional devices, services, and support at <http://www.ibm.com/bladecenter/>. For service information, click **Support**.

Software service and support

Through IBM Support Line, you can get telephone assistance, for a fee, with usage, configuration, and software problems with BladeCenter products. For information about which products are supported by Support Line in your country or region, see <http://www.ibm.com/services/sl/products/>.

For more information about Support Line and other IBM services, see <http://www.ibm.com/services/>, or see <http://www.ibm.com/planetwide/> for support telephone numbers. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

Hardware service and support

You can receive hardware service through IBM Services or through your IBM reseller, if your reseller is authorized by IBM to provide warranty service. See <http://www.ibm.com/planetwide/> for support telephone numbers, or in the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

In the U.S. and Canada, hardware service and support is available 24 hours a day, 7 days a week. In the U.K., these services are available Monday through Friday, from 9 a.m. to 6 p.m.

Appendix B. Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

*IBM Director of Licensing
IBM Corporation
North Castle Drive
Armonk, NY 10504-1785
U.S.A.*

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this IBM product, and use of those Web sites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Edition notice

© Copyright International Business Machines Corporation 2006. All rights reserved.

U.S. Government Users Restricted Rights — Use, duplication, or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Trademarks

The following terms are trademarks of International Business Machines Corporation in the United States, other countries, or both:

Active Memory	IBM (logo)	Tivoli
Active PCI	IntelliStation	Tivoli Enterprise
Active PCI-X	NetBAY	Update Connector
Alert on LAN	Netfinity	Wake on LAN
BladeCenter	Predictive Failure Analysis	XA-32
Chipkill	ServeRAID	XA-64
e-business logo	ServerGuide	X-Architecture
@server	ServerProven	XpandOnDemand
FlashCopy	TechConnect	xSeries
IBM		

Intel, Intel Xeon, Itanium, and Pentium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Java and all Java-based trademarks and logos are trademarks of Sun Microsystems, Inc. in the United States, other countries, or both.

Adaptec and HostRAID are trademarks of Adaptec, Inc., in the United States, other countries, or both.

Linux is a trademark of Linus Torvalds in the United States, other countries, or both.

Red Hat, the Red Hat "Shadow Man" logo, and all Red Hat-based trademarks and logos are trademarks or registered trademarks of Red Hat, Inc., in the United States and other countries.

Other company, product, or service names may be trademarks or service marks of others.

Important notes

Processor speeds indicate the internal clock speed of the microprocessor; other factors also affect application performance.

CD drive speeds list the variable read rate. Actual speeds vary and are often less than the maximum possible.

When referring to processor storage, real and virtual storage, or channel volume, KB stands for approximately 1000 bytes, MB stands for approximately 1 000 000 bytes, and GB stands for approximately 1 000 000 000 bytes.

When referring to hard disk drive capacity or communications volume, MB stands for 1 000 000 bytes, and GB stands for 1 000 000 000 bytes. Total user-accessible capacity may vary depending on operating environments.

Maximum internal hard disk drive capacities assume the replacement of any standard hard disk drives and population of all hard disk drive bays with the largest currently supported drives available from IBM.

Maximum memory may require replacement of the standard memory with an optional memory module.


IBM makes no representation or warranties regarding non-IBM products and services that are ServerProven[®], including but not limited to the implied warranties of merchantability and fitness for a particular purpose. These products are offered and warranted solely by third parties.

IBM makes no representations or warranties with respect to non-IBM products. Support (if any) for the non-IBM products is provided by the third party, not IBM.

Some software may differ from its retail version (if available), and may not include user manuals or all program functionality.

Product recycling and disposal

This unit must be recycled or discarded according to applicable local and national regulations. IBM encourages owners of information technology (IT) equipment to responsibly recycle their equipment when it is no longer needed. IBM offers a variety of product return programs and services in several countries to assist equipment owners in recycling their IT products. Information on IBM product recycling offerings can be found on IBM's Internet site at <http://www.ibm.com/ibm/environment/products/prp.shtml>.



Notice: This mark applies only to countries within the European Union (EU) and Norway.

This appliance is labeled in accordance with European Directive 2002/96/EC concerning waste electrical and electronic equipment (WEEE). The Directive determines the framework for the return and recycling of used appliances as applicable throughout the European Union. This label is applied to various products to indicate that the product is not to be thrown away, but rather reclaimed upon end of life per this Directive.

注意: このマークは EU 諸国およびノルウェーにおいてのみ適用されます。

この機器には、EU 諸国に対する廃電気電子機器指令 2002/96/EC(WEEE) のラベルが貼られています。この指令は、EU 諸国に適用する使用済み機器の回収とリサイクルの骨子を定めています。このラベルは、使用済みになった時に指令に従って適正な処理をする必要があることを知らせるために種々の製品に貼られています。

Remarque : Cette marque s'applique uniquement aux pays de l'Union Européenne et à la Norvège.

L'étiquette du système respecte la Directive européenne 2002/96/EC en matière de Déchets des Equipements Electriques et Electroniques (DEEE), qui détermine les dispositions de retour et de recyclage applicables aux systèmes utilisés à travers l'Union européenne. Conformément à la directive, ladite étiquette précise que le produit sur lequel elle est apposée ne doit pas être jeté mais être récupéré en fin de vie.

In accordance with the European WEEE Directive, electrical and electronic equipment (EEE) is to be collected separately and to be reused, recycled, or recovered at end of life. Users of EEE with the WEEE marking per Annex IV of the WEEE Directive, as shown above, must not dispose of end of life EEE as unsorted municipal waste, but use the collection framework available to customers for the return, recycling, and recovery of WEEE. Customer participation is important to minimize any potential effects of EEE on the environment and human health due to the potential presence of hazardous substances in EEE. For proper collection and treatment, contact your local IBM representative.

Battery return program

This product may contain a sealed lead acid, nickel cadmium, nickel metal hydride, lithium, or lithium ion battery. Consult your user manual or service manual for specific battery information. The battery must be recycled or disposed of properly. Recycling facilities may not be available in your area. For information on disposal of batteries outside the United States, go to <http://www.ibm.com/ibm/environment/products/batteryrecycle.shtml> or contact your local waste disposal facility.

In the United States, IBM has established a return process for reuse, recycling, or proper disposal of used IBM sealed lead acid, nickel cadmium, nickel metal hydride, and battery packs from IBM equipment. For information on proper disposal of these batteries, contact IBM at 1-800-426-4333. Have the IBM part number listed on the battery available prior to your call.

In the Netherlands, the following applies.



For Taiwan: Please recycle batteries.



Electronic emission notices

Federal Communications Commission (FCC) statement

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Industry Canada Class A emission compliance statement

This Class A digital apparatus complies with Canadian ICES-003.

Avis de conformité à la réglementation d'Industrie Canada

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

Australia and New Zealand Class A statement

Attention: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

United Kingdom telecommunications safety requirement

Notice to Customers

This apparatus is approved under approval number NS/G/1234/J/100003 for indirect connection to public telecommunication systems in the United Kingdom.

European Union EMC Directive conformance statement

This product is in conformity with the protection requirements of EU Council Directive 89/336/EEC on the approximation of the laws of the Member States relating to electromagnetic compatibility. IBM cannot accept responsibility for any failure to satisfy the protection requirements resulting from a nonrecommended modification of the product, including the fitting of non-IBM option cards.

This product has been tested and found to comply with the limits for Class A Information Technology Equipment according to CISPR 22/European Standard EN

55022. The limits for Class A equipment were derived for commercial and industrial environments to provide reasonable protection against interference with licensed communication equipment.

Attention: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Taiwanese Class A warning statement

警告使用者：
這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

Chinese Class A warning statement

聲 明
此為 A 級產品。在生活環境中，該產品可能會造成無線電干擾。在這種情況下，可能需要用戶對其干擾採取切实可行的措施。

Japanese Voluntary Control Council for Interference (VCCI) statement

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

Index

Special characters

! 21
? 20

A

accumulate timeout
 set for SOL 53
acknowledge alarms
 alarm ID 83
 complete alarm key 83
 generator ID 82
 generator information 83
advanced management module commands
 portcfg 44
 read 45
 write 69
alarm 81
 acknowledge (alarm ID) 83
 acknowledge (complete alarm key) 83
 acknowledge (generator ID) 82
 acknowledge (generator information) 83
 clear (alarm ID) 84
 clear (complete alarm key) 84
 clear (generator ID) 83
 clear (generator information) 84
 display (alarm ID) 82
 display (all) 81
 display (complete alarm key) 82
 display (generator ID) 81
 display (generator information) 82
 display (power) 81
 options
 c, a 84
 c, g 83
 c, k 84
 c, o 84
 p 81
 q, a 82
 q, g 81
 q, k 82
 q, o 82
 r, a 83
 r, g 82
 r, k 83
 r, o 83
 s, l 84
 set 84
alarm command 81
alarm command errors 89
alarm commands
 example 85
alert notification method, set 34
alert recipient, create 32, 33
alert recipient, delete 31
alert recipient, set email address 34
alert recipient, set hostname for alerts 35

alert recipient, set IP address for alerts 35
alert recipient, set name 33
alert recipient, set status 33
alert recipients, manage 30
alert type, filter 34
alert type, set 34
alertentries 30
 options
 1 through 12 30
 create (n, status, f, t, e, i) 32
 del 31
 e 34
 f 34
 i 35
 n 33
 status 33
 t 34
alertentries command 30
alertentries command errors 90
alertentries commands
 example 35
alerts, display 24
algorithms, encryption 10
attributes, display for firmware 27
authority, command 5

B

baud rate
 set for serial port of management module 44
blade server
 boot 71, 72
 boot (to console) 72
 command target 18
 cycle power 72, 75
 display power state 75
 power off 75
 power on 75
 power on (to console) 75
 reset 71, 72, 77
 reset (clear NVRAM) 78
 reset (run diagnostics with boot sequence) 79
 reset (run diagnostics) 78
 reset (to console) 72, 77
 reset (with NMI) 78
 turn off 75
 turn on 75
 turn on (to console) 75
blade servers
 set starting IP address 43
BladeCenter T specific commands 81, 87
BladeCenter unit
 command target 18
 configuring 12
blink location LED 25
boot 71
 blade server 71, 72

- boot (*continued*)
 - options
 - p powercycle 72
 - p reset 72
 - c 72
- boot (to console)
 - blade server 72
- boot command errors 90
- boot commands 71
 - example 72
- built-in commands 18, 23

C

- capture service information 38
- change command environment 18
- Class A electronic emission notice 113
- clear
 - options
 - config 36
- clear alarms
 - alarm ID 84
 - complete alarm key 84
 - generator ID 83
 - generator information 84
- clear command 36
- clear command errors 90
- clear commands
 - example 36
- clear event log
 - management module 69
- clear management module event log commands 69
 - example 69
- clearlog
 - example 69
- clearlog command errors 91
- clearlog commands 69
 - example 69
- CLI key sequence
 - set for SOL 54
- command
 - health 23, 24
 - system physical configuration 22
- command authority 5
- command environment selecting 4
- command history 21
- command redirect 18
- command target 18
 - blade server 18
 - BladeCenter unit 18
 - I/O module 19
 - integrated system management processor 19
 - management module 18
 - switch module 19
 - temporary 4
 - view 22
- command target selection 4
- command-line interface
 - guidelines 3
 - case sensitivity 3
 - command history 4

- command-line interface (*continued*)
 - guidelines (*continued*)
 - data types 4
 - delimiters 4
 - help 4
 - options 3
 - output format 4
 - strings 4
 - starting 10
 - using 3, 17
 - commands
 - alarm 81, 85
 - alertentries 30, 35
 - boot 71, 72
 - built-in 18, 23
 - clear 36
 - clear management module event log 69
 - clearlog 69
 - commands
 - management module failover 58
 - common 23, 29
 - configuration 30, 69
 - console 79, 80
 - dhcpinfo 37
 - display management module event log 70
 - displaylog 70
 - displaysd 38
 - dns 38, 39
 - environment 18, 19
 - event log, clear for management module 69
 - event log, display for management module 70
 - examples
 - alarm 85
 - alertentries 35
 - boot 72
 - clear 36
 - clear management module event log 69
 - clearlog 69
 - console 80
 - DHCP settings for management module 37
 - dhcpinfo 37
 - display management module event log 70
 - displaylog 70
 - displaysd 38
 - DNS 39
 - env 19
 - environment 19
 - environment redirect 19
 - Ethernet network settings for management module 43
 - exit 80
 - fuelg 73
 - health 24
 - help 20
 - history 21
 - identify 26
 - ifconfig 43
 - info 26
 - list 22
 - management module DHCP settings 37
 - management module DNS 39

commands *(continued)*
 examples *(continued)*
 management module Ethernet network settings 43
 management module event log clear 69
 management module event log display 70
 management module restore configuration 45
 management module save configuration 69
 management module serial port settings 44
 management module service 46
 management module SMTP settings 46
 management module SNMP settings 51
 management module telnet configuration 57
 management module uplink failover 58
 portcfg 44
 power 76
 read 45
 reset 79
 restore configuration for management module 45
 save configuration for management module 69
 Serial Over LAN 55
 serial port settings for management module 44
 service 46
 smtp 46
 SMTP settings for management module 46
 snmp 51
 SNMP settings for management module 51
 sol 55
 syntax help 20
 tcpcmdmode 56
 telnetcfg 57
 update 28
 uplink 58
 users 68
 write 69
 exit 80
 fuelg 72, 73
 help 20
 history 21
 identify 25, 26
 ifconfig 40, 43
 info 26
 list 22
 management module event log 69, 71
 management module failover 57
 portcfg 44
 power 75, 76
 power control 71, 79
 read 45
 reset 77, 79
 reset command 71, 79
 Serial Over LAN 52, 55
 service 45, 46
 session command 79, 80
 smtp 46
 snmp 47, 51
 SOL 52, 55
 system management command 81, 87
 tcpcmdmode 55, 56
 telnet configuration 56, 57
 telnetcfg 56, 57

commands *(continued)*
 update 27, 28
 uplink 57, 58
 users 59, 68
 write 69
 common commands 23, 29
 common errors 88
 communicating with IBM Director 55
 communication
 out-of-band 55
 communication rate
 set for serial port of management module 44
 component information 26
 component information display 26
 configuration
 restore for management module 45
 save for management module 69
 view for management module 22
 view tree for system 22
 configuration commands 30, 69
 configuration method
 set for channel 0 of management module 41
 console 79
 create override SOL session 80
 create SOL session 79
 options
 o 80
 console command 79
 console command errors 91
 console commands
 example 80
 create alert recipient 32, 33
 create override SOL session 80
 create SOL session 79
 create user 60, 61
 cycle power
 blade server 72, 75
 I/O module 75
 switch module 75

D

data rate
 set for channel 0 of management module 41
 default IP address 11
 delete alert recipient 31
 delete user 59
 DHCP settings for management module commands
 example 37
 dhcpinfo
 options
 eth0 37
 dhcpinfo command errors 91
 dhcpinfo commands 37
 example 37
 disable
 TCP command mode 56
 disable DNS
 management module 39
 disable power domain quiet mode 73

- disable SNMP agent
 - management module (SNMPv1) 47
 - management module (SNMPv3) 48
- disable SNMP traps
 - management module 48
- disable SOL
 - global 53
- disable technician debug
 - management module 45
- disable uplink failover
 - management module 58
- display
 - TCP command-mode session status 55
 - TCP command-mode session timeout 55
- display (reset counter) event log
 - management module 70
- display alarms
 - alarm ID 82
 - all 81
 - complete alarm key 82
 - generator ID 81
 - generator information 82
 - power 81
- display alert properties (all recipients) 30
- display alert properties (single recipient) 30
- display alerts 24
- display all users 59
- display component information 26
- display DNS configuration
 - management module 38
- display Ethernet channel 0 configuration
 - management module 40
- display Ethernet channel 0 DHCP configuration
 - management module 37
- display Ethernet channel 1 configuration
 - management module 41
- display event log
 - management module 70
- display failover configuration
 - management module 57
- display firmware attributes 27
- display health status 23, 24
- display health status (tree) 23
- display management module event log commands 70
 - example 70
- display POST status
 - I/O module 76
 - switch module 76
- display power domain information details 72
- display power domain information overview 72
- display power state
 - blade server 75
 - I/O module 75
 - switch module 75
- display serial port configuration
 - management module 44
- display service data command 38
- display service information 38
- display service setting
 - management module 45
- display single user 59
- display SMTP server host name
 - management module 46
- display SMTP server IP address
 - management module 46
- display SNMP configuration
 - management module 47
- display state
 - location LED 25
- display telnet configuration
 - management module 56
- display telnet timeout
 - management module 57
- display uplink configuration
 - management module 57
- displaylog 70
 - options
 - f 70
- displaylog command errors 91
- displaylog commands 70
 - example 70
- displaysd 38
 - options
 - c 38
- displaysd command errors 92
- displaysd commands 38
 - example 38
- dns 38
 - options
 - i1 39
 - i2 39
 - i3 39
 - off 39
 - on 38
- DNS
 - disable for management module 39
 - enable for management module 38
- dns command errors 92
- dns commands 38
 - example 39
- DNS configuration
 - display for management module 38
- DNS first IP address
 - set for management module 39
- DNS second IP address
 - set for management module 39
- DNS third IP address
 - set for management module 39
- duplex mode
 - set for channel 0 of management module 41

E

- electronic emission Class A notice 113
- enable
 - TCP command mode 56
- enable DNS
 - management module 38
- enable power domain quiet mode 73
- enable SNMP agent
 - management module (SNMPv1) 47
 - management module (SNMPv3) 47

- enable SNMP traps
 - management module 48
- enable SOL
 - global 53
- enable technician debug
 - management module 45
- enable uplink failover
 - management module 58
- encryption algorithms 10
- end session 80
- ending an SOL session 15, 79
- env 18
 - options
 - blade 18, 19
 - switch 19
 - system (management module) 18
- env command errors 88
- env commands
 - example 19
- environment
 - blade server 18
 - BladeCenter unit 18
 - I/O module 19
 - integrated system management processor 19
 - management module 18
 - switch module 19
- environment commands 18
 - example 19
- errors
 - alarm command 89
 - alertentries command 90
 - boot command 90
 - clear command 90
 - clearlog command 91
 - common 88
 - console command 91
 - dhcinfo command 91
 - displaylog command 91
 - displaysd command 92
 - dns command 92
 - env command 88
 - exit command 88
 - fuelg command 92
 - health command 93
 - help command 88
 - history command 88
 - identify command 93
 - ifconfig command 93
 - info command 95
 - list command 96
 - portcfg command 96
 - power command 96
 - read command 96
 - reset command 97
 - service command 97
 - smtp command 97
 - snmp command 97
 - sol command 98
 - tcpcmdmode command 99
 - telnetcfg command 100
 - update command 100
- errors (*continued*)
 - uplink command 102
 - users command 102
 - write command 105
- Ethernet
 - configuring remote connection 13
- Ethernet channel 0 configuration
 - display for management module 40
- Ethernet channel 0 configuration method
 - set for management module 41
- Ethernet channel 0 data rate
 - set for management module 41
- Ethernet channel 0 DHCP configuration
 - display for management module 37
- Ethernet channel 0 duplex mode
 - set for management module 41
- Ethernet channel 0 gateway IP address
 - set for management module 40
- Ethernet channel 0 hostname
 - set for management module 40
- Ethernet channel 0 MAC address
 - set for management module 41
- Ethernet channel 0 MTU
 - set for management module 41
- Ethernet channel 0 static IP address
 - set for management module 40
- Ethernet channel 0 subnet mask
 - set for management module 40
- Ethernet channel 1
 - disable for management module 42
 - enable for management module 42
- Ethernet channel 1 configuration
 - display for management module 41
- Ethernet channel 1 gateway IP address
 - set for management module 42
- Ethernet channel 1 MAC address
 - set for management module 42
- Ethernet channel 1 static IP address
 - set for management module 42
- Ethernet channel 1 subnet mask
 - set for management module 42
- Ethernet network settings for management module
 - commands
 - example 43
- event log
 - clear for management module 69
 - display (reset counter) for management module 70
 - display for management module 70
- event log, clear for management module
 - commands 69
- event log, display for management module
 - commands 70
- exit 80
- exit command 80
- exit command errors 88
- exit commands
 - example 80

F

- failover configuration
 - display for management module 57
- FCC Class A notice 113
- filter alert type 34
- firmware
 - display attributes 27
 - update 28
 - update (verbose) 28
- firmware requirements 2
- firmware update 27
- flash location LED 25
- fuelg 72
 - options
 - os 73
 - qm 73
- fuelg command errors 92
- fuelg commands 72
 - example 73

G

- gateway IP address
 - set for channel 0 of management module 40
 - set for channel 1 of management module 42
- global disable
 - SOL 53
- global enable
 - SOL 53
- guidelines
 - case sensitivity 3
 - command history 4
 - data types 4
 - delimiters 4
 - help 4
 - options 3
 - output format 4
 - overview of 3
 - strings 4

H

- hardware requirements 2
- health 23
 - display status 23
 - display status (tree) 23
 - display status and alerts 24
 - options
 - f 24
 - l 23
- health command 23, 24
 - example 24
- health command errors 93
- help 17, 20
- help command 20
- help command errors 88
- help commands
 - example 20
- help for update command 27
- history 21

- history command 21
- history command errors 88
- history commands
 - example 21
- host name
 - set for channel 0 of management module 40

I

- I/O module
 - command target 19
 - cycle power 75
 - display POST status 76
 - display power state 75
 - power off 75
 - power on 75
 - reset 77
 - reset (extended diagnostics) 78
 - reset (full diagnostics) 78
 - reset (standard diagnostics) 77
 - reset configuration 36
 - turn off 75
 - turn on 75
- IBM Director
 - communication 55
- identify 25
 - options
 - s 25
 - s, d 25
- identify command 25
- identify command errors 93
- identify commands
 - example 26
- ifconfig
 - options
 - eth0 40
 - eth0, c 41
 - eth0, d 41
 - eth0, g 40
 - eth0, i 40
 - eth0, l 41
 - eth0, m 41
 - eth0, n 40
 - eth0, r 41
 - eth0, s 40
 - eth1 41
 - eth1, down 42
 - eth1, g 42
 - eth1, i 42
 - eth1, l 42
 - eth1, s 42
 - eth1, up 42
 - i 43
- ifconfig command errors 93
- ifconfig commands 40
 - example 43
- info 26
- info command 26
- info command errors 95
- info commands
 - example 26

- information about components 26
- information display, component 26
- information display, power domain (detailed) 72
- information display, power domain (overview) 72
- integrated system management processor
 - command target 19
- IP address
 - set for management module 40
 - set starting for blade servers 43
- IP address, default 11
- ISMP
 - reset 77

J

- JS20 blade server commands
 - reset (clear NVRAM) 78
 - reset (run diagnostics with boot sequence) 79
 - reset (run diagnostics) 78
 - reset (with NMI) 78

L

- LED (location), control 25
- light location LED 25
- light location LED (BladeCenter unit)
 - time period 25
- list 22
 - options
 - l 22
- list command
 - example 22
- list command errors 96
- location LED
 - blink 25
 - display state 25
 - flash 25
 - light 25
 - light (BladeCenter unit)
 - time period 25
 - turn off 25
- location LED control 25

M

- MAC address
 - set for channel 0 of management module 41
 - set for channel 1 of management module 42
- manage alert recipients 30
- management module
 - clear event log 69
 - clear event log commands
 - example 69
 - command target 18
 - create alert recipient 32, 33
 - create user 60, 61
 - default IP address 11
 - delete alert recipient 31
 - delete user 59
 - DHCP settings commands
 - example 37

- management module (*continued*)
 - dhcpinfo commands 37
 - disable DNS 39
 - disable Ethernet channel 1 42
 - disable SNMP agent (SNMPv1) 47
 - disable SNMP agent (SNMPv3) 48
 - disable SNMP traps 48
 - disable technician debug 45
 - disable uplink failover 58
 - display (reset counter) event log 70
 - display alert properties (all recipients) 30
 - display alert properties (single recipient) 30
 - display all users 59
 - display DNS configuration 38
 - display Ethernet channel 0 configuration 40
 - display Ethernet channel 0 DHCP configuration 37
 - display Ethernet channel 1 configuration 41
 - display event log 70
 - display event log commands
 - example 70
 - display serial port configuration 44
 - display service setting 45
 - display single user 59
 - display SMTP server host name 46
 - display SMTP server IP address 46
 - display SNMP configuration 47
 - dns commands 38, 39
 - example 39
 - enable DNS 38
 - enable Ethernet channel 1 42
 - enable SNMP agent (SNMPv1) 47
 - enable SNMP agent (SNMPv3) 47
 - enable SNMP traps 48
 - enable technician debug 45
 - enable uplink failover 58
 - Ethernet network settings commands
 - example 43
 - failover configuration 57
 - filter alert type 34
 - IBM Director communication 55
 - ifconfig commands 40, 43
 - portcfg commands 44
 - read command 45
 - example 45
 - reset 77
 - reset (failover) 77
 - reset configuration 36
 - restore configuration 45
 - save configuration 69
 - serial port settings commands
 - example 44
 - service command 46
 - example 46
 - service commands 45
 - set alert notification method 34
 - set alert recipient email address 34
 - set alert recipient name 33
 - set alert recipient status 33
 - set alert type 34
 - set DNS first IP address 39
 - set DNS second IP address 39

management module (*continued*)

- set DNS third IP address 39
- set Ethernet channel 0 configuration method 41
- set Ethernet channel 0 data rate 41
- set Ethernet channel 0 duplex mode 41
- set Ethernet channel 0 gateway IP address 40
- set Ethernet channel 0 hostname 40
- set Ethernet channel 0 MAC address 41
- set Ethernet channel 0 MTU 41
- set Ethernet channel 0 static IP address 40
- set Ethernet channel 0 subnet mask 40
- set Ethernet channel 1 gateway IP address 42
- set Ethernet channel 1 MAC address 42
- set Ethernet channel 1 static IP address 42
- set Ethernet channel 1 subnet mask 42
- set hostname for alerts 35
- set IP address 40
- set IP address for alerts 35
- set privacy password (SNMPv3) 67
- set serial port baud rate 44
- set serial port communication rate 44
- set serial port parity 44
- set serial port stop bits 44
- set server host name 46
- set server IP address 46
- set SNMP community 1 first host name 48
- set SNMP community 1 IP address (first host) 48
- set SNMP community 1 IP address (second host) 48
- set SNMP community 1 IP address (third host) 49
- set SNMP community 1 name 48
- set SNMP community 1 second host name 48
- set SNMP community 1 third host name 49
- set SNMP community 1 view type (SNMPv3) 49
- set SNMP community 2 first host name 49
- set SNMP community 2 IP address (first host) 49
- set SNMP community 2 IP address (second host) 49
- set SNMP community 2 IP address (third host) 50
- set SNMP community 2 name 49
- set SNMP community 2 second host name 49
- set SNMP community 2 third host name 50
- set SNMP community 2 view type (SNMPv3) 50
- set SNMP community 3 first host name 50
- set SNMP community 3 IP address (first host) 50
- set SNMP community 3 IP address (second host) 50
- set SNMP community 3 IP address (third host) 51
- set SNMP community 3 name 50
- set SNMP community 3 second host name 50
- set SNMP community 3 third host name 51
- set SNMP community 3 view type (SNMPv3) 51
- set SNMP contact name 51
- set SNMP location 51
- set user access type (SNMPv3) 67
- set user authentication protocol (SNMPv3) 66
- set user authority level 63, 64, 65
- set user context name (SNMPv3) 66
- set user hostname (SNMPv3 traps) 67
- set user IP address (SNMPv3 traps) 67
- set user name 62

management module (*continued*)

- set user password 62
- set user privacy protocol (SNMPv3) 66
- smtp commands 46
- SMTP settings commands
 - example 46
- snmp commands 47, 51
- SNMP settings commands
 - example 51
- telnet configuration 56
- telnet timeout 57
- uplink configuration 57
- uplink failover delay 58
- view configuration 22
- write command 69
 - example 69
- management module event log commands 69, 71
- management module failover commands 57
- management module telnet configuration commands
 - example 57
- management module uplink failover commands
 - example 58
- management module, user accounts 59
- management-module firmware 2
- MTU
 - set for channel 0 of management module 41

N

- notes, important 110
- notices
 - electronic emission 113
 - FCC, Class A 113
- notification method, set for alerts 34

O

- online documentation 1
- out-of-band communication, IBM Director 55
- override persistent command environment 4

P

- parity
 - set for serial port of management module 44
- persistent command environment
 - override 4
- persistent command target 4
- portcfg
 - options
 - com1 44
 - com1, b 44
 - com1, p 44
 - com1, s 44
- portcfg command errors 96
- portcfg commands 44
 - example 44
- POST status
 - display for I/O module 76
 - display for switch module 76

- power
 - options
 - cycle 75
 - cycle, c 75
 - off 75
 - on 75
 - on, c 75
 - state 75
 - state, post 76
- power command errors 96
- power commands 75
 - example 76
- power control commands 71, 79
- power domain
 - disable quiet mode 73
 - enable quiet mode 73
- power domain information display (detailed) 72
- power domain information display (overview) 72
- power domain redundancy loss policy, set 73
- power off
 - blade server 75
 - I/O module 75
 - switch module 75
- power on
 - blade server 75
 - I/O module 75
 - switch module 75
- power on (to console)
 - blade server 75
- power state
 - display for blade server 75
 - display for I/O module 75
 - display for switch module 75
- primary management module 5

Q

- quiet mode, disable 73
- quiet mode, enable 73

R

- read
 - options
 - config 45
- read command 45
 - example 45
- read command errors 96
- redirect command 18
- redundancy loss policy, power domain (set) 73
- redundant management modules 5
- required, firmware 2
- required, hardware 2
- reset 77
 - blade server 71, 72, 77
 - I/O module 77
 - ISMP 77
 - management module 77
 - options
 - c 77
 - clr 78

- reset (*continued*)
 - options (*continued*)
 - ddg 79
 - dg 78
 - exd 78
 - f 77
 - full 78
 - sft 78
 - std 77
 - service processor 77
 - switch module 77
- reset (clear NVRAM)
 - blade server 78
- reset (extended diagnostics)
 - I/O module 78
 - switch module 78
- reset (failover)
 - management module 77
- reset (full diagnostics)
 - I/O module 78
 - switch module 78
- reset (run diagnostics with boot sequence)
 - blade server 79
- reset (run diagnostics)
 - blade server 78
- reset (standard diagnostics)
 - I/O module 77
 - switch module 77
- reset (to console)
 - blade server 72, 77
- reset (with NMI)
 - blade server 78
- reset blade server key sequence
 - set for SOL 54
- reset command 71, 79
- reset command errors 97
- reset commands 77
 - example 79
- reset configuration
 - I/O module 36
 - management module 36
 - switch module 36
- reset default configuration 36
- responding to thermal events 73
- restore configuration
 - management module 45
- restore management module configuration command
 - example 45
- retry count
 - set for SOL 53
- retry interval
 - set for SOL 52

S

- save configuration
 - management module 69
- save management module configuration command
 - example 69
- secure command-line interface 10
- Secure Shell connection clients 10

- security 10
- selecting command environment 4
- selecting command target 4
- send threshold
 - set for SOL 53
- Serial Over LAN 14
- Serial Over LAN commands 52
 - example 55
- serial port baud rate
 - set for management module 44
- serial port communication rate
 - set for management module 44
- serial port configuration
 - display for management module 44
- serial port parity
 - set for management module 44
- serial port settings for management module commands
 - example 44
- serial port stop bits
 - set for management module 44
- server host name
 - set for management module 46
- server IP address
 - set for management module 46
- service 45
 - options
 - disable 45
 - enable 45
- service command
 - example 46
- service command errors 97
- service commands 45
- service data
 - display command 38
- service information
 - capture 38
 - display 38
- service processor
 - reset 77
- service setting
 - display for management module 45
- session command 79, 80
- set
 - TCP command-mode session timeout 55
- set accumulate timeout
 - SOL 53
- set alarm 84
- set alert notification method 34
- set alert recipient email address 34
- set alert recipient name 33
- set alert recipient status 33
- set alert type 34
- set CLI key sequence
 - SOL 54
- set DNS first IP address
 - management module 39
- set DNS second IP address
 - management module 39
- set DNS third IP address
 - management module 39
- set Ethernet channel 0 configuration method
 - management module 41
- set Ethernet channel 0 data rate
 - management module 41
- set Ethernet channel 0 duplex mode
 - management module 41
- set Ethernet channel 0 gateway IP address
 - management module 40
- set Ethernet channel 0 hostname
 - management module 40
- set Ethernet channel 0 MAC address
 - management module 41
- set Ethernet channel 0 MTU
 - management module 41
- set Ethernet channel 0 static IP address
 - management module 40
- set Ethernet channel 0 subnet mask
 - management module 40
- set Ethernet channel 1 gateway IP address
 - management module 42
- set Ethernet channel 1 MAC address
 - management module 42
- set Ethernet channel 1 static IP address
 - management module 42
- set Ethernet channel 1 subnet mask
 - management module 42
- set hostname for alerts 35
- set IP address
 - management module 40
- set IP address for alerts 35
- set power domain redundancy loss policy 73
- set privacy password (SNMPv3) 67
- set reset blase server key sequence
 - SOL 54
- set retry count
 - SOL 53
- set retry interval
 - SOL 52
- set send threshold
 - SOL 53
- set serial port baud rate
 - management module 44
- set serial port communication rate
 - management module 44
- set serial port parity
 - management module 44
- set serial port stop bits
 - management module 44
- set server host name
 - management module 46
- set server IP address
 - management module 46
- set SNMP community 1 first host name
 - management module 48
- set SNMP community 1 IP address (first host)
 - management module 48
- set SNMP community 1 IP address (second host)
 - management module 48
- set SNMP community 1 IP address (third host)
 - management module 49

- set SNMP community 1 name
 - management module 48
- set SNMP community 1 second host name
 - management module 48
- set SNMP community 1 third host name
 - management module 49
- set SNMP community 1 view type (SNMPv3)
 - management module 49
- set SNMP community 2 first host name
 - management module 49
- set SNMP community 2 IP address (first host)
 - management module 49
- set SNMP community 2 IP address (second host)
 - management module 49
- set SNMP community 2 IP address (third host)
 - management module 50
- set SNMP community 2 name
 - management module 49
- set SNMP community 2 second host name
 - management module 49
- set SNMP community 2 third host name
 - management module 50
- set SNMP community 2 view type (SNMPv3)
 - management module 50
- set SNMP community 3 first host name
 - management module 50
- set SNMP community 3 IP address (first host)
 - management module 50
- set SNMP community 3 IP address (second host)
 - management module 50
- set SNMP community 3 IP address (third host)
 - management module 51
- set SNMP community 3 name
 - management module 50
- set SNMP community 3 second host name
 - management module 50
- set SNMP community 3 third host name
 - management module 51
- set SNMP community 3 view type (SNMPv3)
 - management module 51
- set SNMP contact name
 - management module 51
- set SNMP location
 - management module 51
- set starting IP address
 - blade servers 43
- set telnet timeout
 - management module 57
- set uplink failover delay
 - management module 58
- set user access type (SNMPv3) 67
- set user authentication protocol (SNMPv3) 66
- set user authority level 63, 64, 65
- set user context name (SNMPv3) 66
- set user hostname (SNMPv3 traps) 67
- set user IP address (SNMPv3 traps) 67
- set user name 62
- set user password 62
- set user privacy protocol (SNMPv3) 66
- set VLAN ID
 - SOL 54
- smtp 46
 - options
 - s 46
- smtp command errors 97
- smtp commands 46
 - example 46
- SMTP server host name
 - display for management module 46
- SMTP server IP address
 - display for management module 46
- SMTP settings for management module commands
 - example 46
- snmp 47
 - options
 - a, off 47
 - a, on 47
 - a3, off 48
 - a3, on 47
 - c1 48
 - c1i1 48
 - c1i2 48
 - c1i3 49
 - c2 49
 - c2i1 49
 - c2i2 49
 - c2i3 50
 - c3 50
 - c3i1 50
 - c3i2 50
 - c3i3 51
 - ca1 49
 - ca2 50
 - ca3 51
 - cn 51
 - l 51
 - t, off 48
 - t, on 48
- SNMP agent
 - disable for management module (SNMPv1)
 - SNMPv1 47
 - disable for management module (SNMPv3)
 - SNMPv3 48
 - enable for management module (SNMPv1)
 - SNMPv1 47
 - enable for management module (SNMPv3)
 - SNMPv3 47
- snmp command errors 97
- snmp commands 47
 - example 51
- SNMP community 1 first host name
 - set for management module 48
- SNMP community 1 IP address (first host)
 - set for management module 48
- SNMP community 1 IP address (second host)
 - set for management module 48
- SNMP community 1 IP address (third host)
 - set for management module 49
- SNMP community 1 name
 - set for management module 48
- SNMP community 1 second host name
 - set for management module 48

- SNMP community 1 third host name
 - set for management module 49
- SNMP community 1 view type
 - set for management module (SNMPv3) 49
- SNMP community 2 first host name
 - set for management module 49
- SNMP community 2 IP address (first host)
 - set for management module 49
- SNMP community 2 IP address (second host)
 - set for management module 49
- SNMP community 2 IP address (third host)
 - set for management module 50
- SNMP community 2 name
 - set for management module 49
- SNMP community 2 second host name
 - set for management module 49
- SNMP community 2 third host name
 - set for management module 50
- SNMP community 2 view type
 - set for management module (SNMPv3) 50
- SNMP community 3 first host name
 - set for management module 50
- SNMP community 3 IP address (first host)
 - set for management module 50
- SNMP community 3 IP address (second host)
 - set for management module 50
- SNMP community 3 IP address (third host)
 - set for management module 51
- SNMP community 3 name
 - set for management module 50
- SNMP community 3 second host name
 - set for management module 50
- SNMP community 3 third host name
 - set for management module 51
- SNMP community 3 view type
 - set for management module (SNMPv3) 51
- SNMP configuration
 - display for management module 47
- SNMP contact name
 - set for management module 51
- SNMP location
 - set for management module 51
- SNMP settings for management module commands
 - example 51
- SNMP traps
 - disable for management module 48
 - enable for management module 48
- SNMPv3
 - community 1 view type 49
 - community 2 view type 50
 - community 3 view type 51
 - privacy password 67
 - trap receiver IP address or hostname 67
 - user access type 67
 - user authentication protocol 66
 - user context name 66
 - user privacy protocol 66
- sol 52
 - options
 - c 53
 - e 54
- sol (*continued*)
 - options (*continued*)
 - i 52
 - r 54
 - s 53
 - status 53
 - t 53
 - v 54
- SOL 14, 15, 79
 - global disable 53
 - global enable 53
 - set accumulate timeout 53
 - set CLI key sequence 54
 - set reset base server key sequence 54
 - set retry count 53
 - set retry interval 52
 - set send threshold 53
 - set VLAN ID 54
 - status 52
- sol command errors 98
- sol commands
 - example 55
- SOL commands 52
- SOL session
 - ending 15, 79
 - starting 14
- SSH clients 10
- SSH connection 12
- starting a session using SSH 12
- starting a session using Telnet 11
- starting an SOL session 14
- starting command-line interface 10
- static IP address
 - set for channel 0 of management module 40
 - set for channel 1 of management module 42
- status
 - SOL 52
- stop bits
 - set for serial port of management module 44
- subnet mask
 - set for channel 0 of management module 40
 - set for channel 1 of management module 42
- switch module
 - command target 19
 - cycle power 75
 - display POST status 76
 - display power state 75
 - power off 75
 - power on 75
 - reset 77
 - reset (extended diagnostics) 78
 - reset (full diagnostics) 78
 - reset (standard diagnostics) 77
 - reset configuration 36
 - turn off 75
 - turn on 75
- syntax help 20
- syntax help commands
 - example 20
- system
 - view configuration tree 22

system management command 81, 87
system physical configuration command 22

T

target 18
TCP command mode
 disable 56
 enable 56
TCP command-mode session status
 display 55
TCP command-mode session timeout
 display 55
 set 55
tppcmdmode 55
 options
 off 56
 on 56
 t 55
tppcmdmode command errors 99
tppcmdmode commands 55
 example 56
technician debug
 disable for management module 45
 enable for management module 45
telnet configuration
 display for management module 56
telnet configuration commands 56
Telnet connection 10, 11
telnet timeout
 display for management module 57
 set for management module 57
telnetcfg 56
 options
 t 57
telnetcfg command errors 100
telnetcfg commands 56
 example 57
temporary command target 4
terminate session 80
thermal event response 73
trademarks 110
turn off
 blade server 75
 I/O module 75
 switch module 75
turn off location LED 25
turn on
 blade server 75
 I/O module 75
 switch module 75
turn on (to console)
 blade server 75

U

United States electronic emission Class A notice 113
United States FCC Class A notice 113
update 27
 options
 a 27

update (*continued*)
 options (*continued*)
 i, n 28
update command 27
update command errors 100
update command help 27
update commands
 example 28
update firmware 27, 28
update firmware (verbose) 28
uplink 57
 options
 del 58
 off 58
 on 58
uplink command errors 102
uplink commands 57
 example 58
uplink configuration
 display for management module 57
uplink failover
 disable for management module 58
 enable for management module 58
uplink failover delay
 set for management module 58
users 59
 options
 1 through 12 59
 a 63, 65
 ap 66
 at 67
 clear 59
 cn 66
 create (n, p, a, cn, ap, pp, ppw, at, i) 60
 i 67
 n 62
 p 62
 pp 66
 ppw 67
users command 59
users command errors 102
users commands
 example 68
users, create 60, 61
users, delete 59
users, display (all) 59
users, display (single) 59
users, management module 59
users, set access type (SNMPv3) 67
users, set authentication protocol (SNMPv3) 66
users, set authority level 63, 64, 65
users, set context name (SNMPv3) 66
users, set hostname (SNMPv3 traps) 67
users, set IP address (SNMPv3 traps) 67
users, set name 62
users, set password 62
users, set privacy password (SNMPv3) 67
users, set privacy protocol (SNMPv3) 66
using the command-line interface 3

V

- view command target 22
- VLAN ID
 - set for SOL 54

W

- write
 - options
 - config 69
 - write command 69
 - example 69
 - write command errors 105



Part Number: 24R9707

Printed in USA

(1P) P/N: 24R9707

