

D-3010-N **430-450 MHz POWER AMPLIFIER**

The MIRAGE D-3010-N represents the latest in 430-450 MHz amplifiers. It incorporates features that make it the most versatile and useful amplifier available today. The D-3010-N will amplify FM, SSB, and CW signals. It has variable SSB delay, remote Keying, over-temperature protection, and remote control operation when using the optional RC-1 Remote Head. The D-3010-N can be used on amateur television at a reduced output level.

SPECIFICATIONS

FREQUENCY RANGE	430-450 MHz
POWER.....	INPUT: 5-40 watts OUTPUT: 100 watts @ 30W input
MODES.....	FM, SSB, CW, ATV
DC POWER	13.6 VDC @ 15 amps nominal
FUSE.....	35 AMP (internally mounted)
IMPEDANCE.....	50 Ohm input and output
DUTY CYCLE.....	Intermittent; internal overtemp protection
SIZE.....	12" x 3" x 5-1/2"
WEIGHT	5 pounds

INSTALLATION

The D-3010-N may be mounted using the brackets which are available when requested with the return of the warranty card. The D-3010-N must have adequate ventilation for the finned heat-sink. Use #8 or larger wire to connect the D-3010-N to the battery is recommended. RG-8U, or the equivalent, should be used between the D-3010-N and the antenna. The antenna should be matched to better than 1.5:1 for best performance. Higher VWSR will not damage the amplifier, but it will degrade the system performance.

FRONT PANEL FUNCTIONS

POWER ON/OFF.....	This switch turns the power amplifier ON and OFF.
SSB/FM.....	Selects the relay time-delay for the mode of operation. In either the SSB or FM position, the amplifier is still biased for linear operation.
LED (Power/On)	This LED will go out if the amplifier overheats. It will come back on when the amplifier cools.
LED (Tx).....	This LED will light during transmitting periods.

REAR PANEL FUNCTIONS

- "RADIO" This connects to the transmitter or transceiver.
- "ANT" This connects to the antenna.
- RCA Jack This is for Remote Keying-Connect to ground to key the antenna relay.
- 6-Pin Remote Connector The RC-1 Remote Control Head connects here.

PRECAUTIONS

- OUTPUT POWER The D-3010-N puts out enough power to cause heating of the antenna coax. RG-8 or equivalent is recommended between the amplifier and antenna.
- HEAT SINK TEMPERATURE Along with high power output, comes the possibility of high heat sink temperatures. The D-3010-N must be mounted where air can circulate over the heat sink. The D-3010-N has a built-in thermostat that will not come back on until the temperature drops to 140 degrees F.
- INPUT POWER Input power should not exceed 40 watts. Higher power than this may cause failure of the input transistor. This will VOID ANY WARRANTY.
- SSB OPERATION The D-3010-N can be overdriven causing the SSB signal to be distorted. When using the D-3010-N on SSB, the drive level or the mic gain from the exciter should be adjusted for best "on the air" performance.

INTERNAL ADJUSTMENTS

- SSB DELAY This allows the relay to be adjusted to any desired delay. Access to this adjustment is through the hole in the left side of the cover, behind the front panel.
- RF ADJUSTMENTS There are no internal adjustments dealing with the RF amplifier board. Tuning of the RF amplifier is preset at the factory.
- FUSE A 35-amp fuse is located under the cover on the PC board. Should the fuse "blow," determine the cause and use the exact type in the unit as a replacement.
- "ATV MOD" Remove .1 mfd cap and 10 ohm resistor which crosses over both final power transistors and connects each base to its collect lead. These cap/resistor networks are designed to eliminate low frequency oscillations and will distort ATV signals.

IN CASE OF DIFFICULTY

1. Check for loose antenna or B+ connections.
2. Check SWR of antenna.
3. Look for bad or lossy coax.

TECHNICAL ASSISTANCE

If you have any problem with this unit first check the appropriate section of this manual. If the manual does not reference your problem or your problem is not solved by reading the manual you may call MIRAGE at 601-323-8287. You will be best helped if you have your unit, manual and all information on your station handy so you can answer any questions the technicians may ask.

You can also send questions by mail to MIRAGE, 921 HWY 25 South, Starkville, MS 39759 or by Fax to 601-323-6551. Send a complete description of your problem, an explanation of exactly how you are using your unit, and a complete description of your station.