


Cat. No. 19-1126

OWNER'S MANUAL

***HTX-242 TWO-METER MOBILE TRANS-
CEIVER***

Please read before using this transceiver.



Radio Shack

INTRODUCTION

Your HTX-242 Two-Meter Mobile Transceiver is an exciting addition to Radio Shack's growing line of high-quality amateur radio equipment. It offers some of the most advanced, and most requested, features available in a mobile transceiver. Be sure to read this entire manual to understand how to use all the radio's features.



You must have a Technician Class or higher Amateur Radio Operator's License and a call sign issued by the FCC to legally transmit using this transceiver. Transmitting without a license carries heavy penalties. Getting a license is easier than ever. Your local Radio Shack store has training materials for all classes of Amateur Radio Operator.

FEATURES

Auto Memory Store (AMS)—automatically searches for active frequencies and stores them in memory, including the appropriate repeater offset.

High (45 Watt) and Low (10 Watt) Power Settings—let you select the best power setting for effective communications.

True FM Modulation—provides a clear, natural-sounding signal.

41 Memory Channels—hold one calling frequency and 40 standard frequencies.

Priority Memory Channel 1—lets you set the HTX-242 to periodically check the frequency stored in Memory Channel 1 and alert you if there is activity on it.

Individually Programmable Repeater Offsets—let you program different repeater offset frequencies for each memory, and a default repeater offset for manually-tuned frequencies.

Subaudible Tone Transmit and Receive (CTCSS)—transmits the subaudible tones required to use some repeaters, and also lets you set a subaudible tone that your transceiver must receive to open squelch.

DTMF Page with Group Calling—lets you set a sequence of up to seven DTMF tones that your transceiver must receive to sound an alert tone and open squelch.

DTMF Transmit and Memory—lets you manually send DTMF tones or send DTMF sequences of up to 15 digits each from one of 10 DTMF memories to quickly access DTMF-access repeaters, autopatches, or other stations equipped with a DTMF page feature.

© 1996 Tandy Corporation.
All Rights Reserved.

Radio Shack is a registered trademark used by Tandy Corporation.

Programmable Frequency Step—lets you set the frequency step for tuning or scanning to 5, 10, 12.5, 20, 25, 50, or 100 kHz.

Extended Band Coverage—receives from 136 to 174 MHz and lets you extend transmit coverage to include 2-Meter ham, MARS (Military Amateur Radio Service), and CAP (Civil Air Patrol).

Dual VFO (Variable-Frequency Oscillator) and Duplex Modes—two independent VFOs let you quickly select between two directly-entered frequencies. You can also use one of the VFOs as a repeater input frequency and the other as a repeater output frequency for odd-split repeaters.

Using this Manual

To make this manual as easy to use as possible, we give you several ways to find information.

Contents—lists all sections in the order they appear in the manual.

Understanding the Display—lists all display indicators and gives a brief explanation and notes the sections where the indicator is fully explained.

Using the Menu—lists the options in the configuration menu and gives the page numbers where the options are discussed.

Quick Reference Card—gives brief instructions for most functions.

Type Conventions—make the references to keys and displays easier to find in the text:

- Keys are bold. For example, **VFO**.
- When a key has more than one marking (for example, **DTMF** and **ALM** refer to the same key), we refer to the key by the name appropriate to the task.
- Where you are instructed to press two keys at once, the keys are separated by a + symbol. For example, **F+DTMF**.
- Text and symbols that appear on the transceiver's display appear in a special typeface. For example, **144.940**.

Important notes in this manual have a large exclamation mark (!) in the margin. Warnings and cautions you should follow to prevent injury to a person or damage to the transceiver have a large lightning bolt (⚡) in the margin.

CONTENTS

Installation	6
Unpacking the Transceiver	6
Connecting the Microphone	6
Mounting the HTX-242 in a Vehicle	7
Connecting an Antenna	8
Connecting to your Vehicle's Power	9
Using the HTX-242 as a Base Station	10
Using the HTX-242 with Packet Radio	11
Connecting an External Speaker (Optional)	11
Understanding the HTX-242	12
Dual VFO Modes	12
DTMF (Touch-Tone) Features	12
Subaudible Tone (CTCSS) Features	13
Repeater Operation	13
Memory Channels	13
Understanding the Display	14
Basic Operation	16
Turning On/Off Your HTX-242	16
Resetting the HTX-242	16
Extending the Transmit Frequency Range	16
Setting Volume and Squelch	17
Using the Light	17
Setting the Power Level	17
Locking the Controls	17
Selecting a Frequency	18
Directly Entering a Frequency	18
Tuning to a Frequency	18
Scanning for a Frequency	19
Setting the Frequency Step	19
Setting the Scan Options	20
Storing Scan Skip Frequencies	20
Setting the Scan Resume Condition	20
Setting the Scan Resume Delay	21
Setting the Scanning Range	21
Receiving Transmissions	22
Transmitting	22
Manually Transmitting DTMF Tones	23
Transmitting DTMF Tones from Memory	23
Limiting Transmit Duration	24
Turning the Keytone Beep On and Off	24

Advanced Operation	25
Frequency Offset Defaults	25
Turning Auto Duplex On and Off	25
Changing the Default Offset	26
Reversing the Offset	26
Overriding the Duplex Offset	26
Using the Dual VFOs for Duplex Operation	27
Using Memory Channels	28
Storing a Frequency	28
Changing Stored Settings	28
Using Auto Memory Store (AMS)	29
Tuning to a Standard Memory Channel	30
Using the Calling-Frequency Memory	30
Checking Priority Channel 1	30
Scanning Memory Channels	31
Clearing a Memory Channel	31
Enabling/Disabling Scanning for Memory Channels	31
Using DTMF and Subaudible Tones	32
Storing a DTMF Sequence	32
Transmitting a DTMF Sequence	32
Using DTMF Page	33
Using Group Calling	33
Using Auto-Reply	34
Using DTMF Auto Send	35
Using Subaudible Tones	36
Valid Subaudible Tones	36
Setting the Subaudible Tones	36
Activating Subaudible Tone Transmit and Squelch	37
Setting the DTMF Page and Subaudible Tone Alert	37
Using the Menu	38
Troubleshooting	40
Error Codes	40
Common Problems and Solutions	40
Replacing the Fuse	41
Specifications	42
Schematics	44

INSTALLATION

Unpacking the Transceiver

As you unpack the transceiver, check to be sure you have all the items shown in this illustration.

Connecting the Microphone

Plug the microphone's connector into the microphone jack, secure the microphone holder to either the left or right side of the transceiver, then clip the microphone to the holder.

Mounting the HTX-242 in a Vehicle

When you select a mounting location for the HTX-242, be sure:

- You can easily reach it
- No wires or cables will interfere with the vehicle's operation
- It is not directly in front of heating vents
- All wires will reach their connection points

Cautions:



- To avoid damaging your vehicle's electronic systems, contact your vehicle's manufacturer before you install the HTX-242 to find out about the proper transceiver mounting locations, antenna locations, and power and antenna cable routing guidelines.
- Do not apply power to the transceiver until after you properly mount and connect an antenna.

Use the supplied screws, metal washers, bracket, rubber washers, and mounting knobs, as shown, to mount the transceiver.

Connecting an Antenna

You can connect a variety of antennas for both mobile and base-station use (see “Using the HTX-242 as a Base Station” on Page 10). Each type of antenna has its benefits. Choose one that best meets your needs.

When deciding on a mobile or base-station antenna and its location, consider the following:

- The antenna should be as high as possible on your vehicle or house.
- The antenna and antenna cable should be as far away as possible from sources of electrical noise (ignition systems, power cables, and so on).
- The antenna should be vertical.
- The antenna should have an SWR of less than 1.5:1. An SWR of 1.8:1 or greater can prevent the HTX-242 from performing to its specified ratings.

After you select an antenna, follow its mounting instructions. Then route the antenna cable from the antenna to the HTX-242 and connect it to the antenna connector.

Connect the antenna to your HTX-242 using 50-ohm coaxial cable. The cable should end in a PL-239 connector.

Cautions:



- To prevent damage to your HTX-242, you must connect an antenna to it before you operate it.
- Do not run the cable over sharp edges or moving parts that might damage the cable.
- Do not run the cable through the engine compartment or other areas that produce extreme heat.
- Check with your vehicle manufacturer for antenna cable routing guidelines.

Connecting to your Vehicle's Power

Follow these steps to power the HTX-242 in your vehicle.

1. Connect the black wire to your vehicle battery's negative (-) terminal or to a metal part of the vehicle's frame. Be sure the metal part is not insulated from the vehicle's frame by a plastic part.
2. Connect the red wire to a source of voltage that turns on and off with the ignition and that can handle the transceiver's 10-amp maximum power draw.

Or, if you do not want the HTX-242 to turn on and off with your vehicle's ignition, connect the red wire directly to the battery's positive (+) terminal.



Note: You might need to connect the red wire directly to the battery if you experience ignition noise.

Using the HTX-242 as a Base Station

Although we designed the HTX-242 primarily for use as a mobile transceiver, you can also use it as a base station. To do so, you need these items:

- 13.8-Volt DC regulated power supply that can supply at least 10 amps continuous power
- Base station antenna
- 50-ohm coaxial antenna cable and connectors

Follow these steps to connect the HTX-242 as a base station.

1. Mount the base station antenna according to its instructions.



Warning: For your safety, follow all cautions and warnings included with the base station antenna.

2. Connect the antenna cable to the antenna jack on the back of the HTX-242.
3. Connect the black power wire to the power supply's negative (-) terminal.
4. Connect the red power wire to the power supply's positive (+) terminal.
5. Connect the power supply to a source of power.

Using the HTX-242 with Packet Radio

You can connect your HTX-242 directly to a packet radio terminal node controller, as shown below.

Note: You can purchase an 8-pin plug that matches your HTX-242's MIC jack at your local Radio Shack store (Cat. No. 279-440).

Connecting an External Speaker (Optional)

You can connect an external speaker to your HTX-242.

Use an 8-ohm communications or PA speaker that can handle 5 or more watts of power (such as Radio Shack Cat. No. 21-549). The speaker's cable must end in a $\frac{1}{8}$ -inch plug. Simply plug the speaker cable into the HTX-242's EXT. SP jack.

If your vehicle has a cassette player, you can easily connect your transceiver to your vehicle's audio system using a CD-to-cassette adapter and a mono-to-stereo audio plug.

UNDERSTANDING THE HTX-242

This section explains some of the HTX-242's features. See "Basic Operation" on Page 16 for instructions about how to use these features.

Dual VFO Modes

The VFO (Variable-Frequency Oscillator) modes let you directly select a frequency anywhere within the HTX-242's operating range. Your HTX-242 has two VFOs: VFO-A and VFO-B. You typically use the VFOs to tune to frequencies you have not stored into one of the HTX-242's memory channels (see "Memory Channels" on Page 13).

A related feature of the HTX-242 lets you transmit on the frequency selected with one VFO and receive on the frequency selected with the other VFO. (See "Using the Dual VFOs for Duplex Operation" on Page 27.)

DTMF (Touch-Tone) Features

DTMF (Dual-Tone, Multiple Frequency) is another term for *touch-tones* (the tones a telephone produces when you press a digit). This standard set of tones is used by many different amateur radio systems for accessing programmable features and dialing through autopatches.

Your HTX-242 produces all 16 standard DTMF tones (0-9, *, #, A, B, C, and D). It has 10 DTMF memories which can each hold up to 15 digits for quick transmission. You can also set the HTX-242 to listen for a specific set of DTMF tones, and alert you when it detects them (this feature is called *DTMF Paging*). Until it hears the sequence, the HTX-242 does not pass any transmissions to the speaker.

Group Calling lets you DTMF page a single person or an entire group of people. To use group calling, every person in the group selects the same first three digits as their DTMF page sequence. They then select up to four additional digits unique to each person. To page an individual, you transmit their entire DTMF page sequence. To page the entire group, you transmit at least the first three digits of the sequence, followed by the DTMF tones for A, B, and C.



Note: Group Calling only works with the HTX-242 and other transceivers that support this feature.

Subaudible Tone (CTCSS) Features

Subaudible tones, also known as CTCSS (Continuous Tone-Coded Squelch System) are low-frequency tones that are mixed with a transmission. They are used by many repeaters to limit interference from other nearby radio transmitters. When a repeater uses a subaudible tone, it does not react to any transmission that does not include that tone.

Your HTX-242 includes all 38 standard subaudible tones. You can set your HTX-242 to include any of these tones with your transmissions. You can also set your HTX-242 to limit reception to only those transmissions that include the selected tone.

Repeater Operation

Operation through a repeater, where you transmit on one frequency and receive on another, is called *duplex* operation. Operation direct to another station where you transmit and receive on the same frequency is called *simplex* operation.

A repeater is a station that receives signals on one frequency (the *input* frequency) and then retransmits them on a different frequency (the *output* frequency). Repeater antennas are typically at the tops of tall buildings or on antenna towers, so a relatively low-power signal can reach the repeater. The repeater retransmits the signal at a higher power. This gives users of low-power transceivers the ability to communicate over a much greater range.

To use a repeater, you must know the repeater's input and output frequencies. Repeaters are usually identified by their output frequency. Thus, a repeater that has an output frequency of 146.94 is referred to as the 146.94 repeater. To determine the input frequency you must know the frequency *offset* (600 kHz for most of the 2-meter band) and the *offset direction* (+ if you add 600 kHz to the output, or - if you subtract 600 kHz from the output).

Your HTX-242 is programmed with the default 600 kHz frequency offset and direction for the 2-meter band. See "Frequency Offset Defaults" on Page 25. When you tune to a frequency that is normally assigned for repeater use, the HTX-242 automatically selects the correct input frequency if you turned on the AS option.

Memory Channels

Your HTX-242 has 41 memory channels (40 standard memory channels and one calling-frequency memory channel). Each memory channel can hold a transmit and receive frequency, subaudible transmit and receive tones, the transmit power level, and whether subaudible tone transmit and squelch are on or off. The HTX-242 can even scan a selected range and automatically store active frequencies in unused memory locations.

Understanding the Display

One or more of the following indicators appear when you turn on and use your HTX-242.

VFO-A or **VFO-B** — appears when you select one of the VFO modes. See “Dual VFO Modes” on Page 12.

VFO-A-T
VFO-B — appears when you select the DUP-A mode (transmit on VFO-A and receive on VFO-B). See “Using the Dual VFOs for Duplex Operation” on Page 27.

VFO-A
VFO-B-T — appears when you select the DUP-B mode (receive on VFO-A and transmit on VFO-B). See “Using the Dual VFOs for Duplex Operation” on Page 27.

BUSY — appears when the HTX-242 is receiving a transmission. See “Receiving Transmissions” on Page 22.

FUNC — appears after you press F. Flashes after you hold F for at least 1 second.

LOCK — appears when you lock the HTX-242’s functions. See “Locking the Controls” on Page 17.

T — appears when transmit subaudible tone is turned on. See “Using Subaudible Tones” on Page 36.

T-SQL — appears when both transmit subaudible tone and subaudible tone squelch are turned on. See “Using Subaudible Tones” on Page 36.


ALT — appears when you turn on the DTMF page/subaudible tone alert. See “Setting the DTMF Page and Subaudible Tone Alert” on Page 37.

+ or - — indicates the duplex offset direction. See “Overriding the Duplex Offset” on Page 26.

DTMF — appears when you turn on DTMF squelch. See “Using DTMF Page” on Page 33.

HIGH or LOW — indicates the transmit power level. See “Setting the Power Level” on Page 17.

ON-AIR — appears when you transmit. See “Transmitting” on Page 22.

 — appears when you turn on the Channel 1 alarm. Flashes when there is a transmission on Memory Channel 1 and the alarm is turned on. See “Checking Priority Channel 1” on Page 30.

M-CH — appears when you tune to a memory channel. See “Memory Channels” on Page 13.

BASIC OPERATION

Turning On/Off Your HTX-242

To turn your HTX-242 on or off, press **POWER**. When you turn it on, all display elements briefly turn on and the HTX-242 sounds five tones. Then it returns to the last-used settings.

Resetting the HTX-242

When you first use your HTX-242, if it displays **PLL Err** or **EEP Err**, or if you ever want to reset the HTX-242 to the factory defaults and clear all memory, follow these steps.



Important: This procedure clears all stored information.

1. Turn off the HTX-242.
2. While holding down **F+T-SQL**, turn on the HTX-242. All display elements stay on for about 1 second.

See “Extending the Transmit Frequency Range” (below) and “Using the Menu” on Page 38.

Extending the Transmit Frequency Range

The following are the HTX-242’s default frequency ranges:

Transmit: 144.000 – 148.000 MHz

Receive: 136.000 – 174.000 MHz



Important: Do not expand the transmit frequency coverage unless you are licensed to operate on MARS or CAP frequencies.

To expand the transmit frequency coverage, hold down **F+DTMF** while you turn on the HTX-242. The new frequency ranges are:

Transmit: 142.500 – 149.500 MHz

Receive: 136.000 – 174.000 MHz



Note: To return to the default frequency ranges, you must reset the transceiver. See “Resetting the HTX-242”.

Setting Volume and Squelch

SQUELCH sets the minimum signal level that must be present for the HTX-242 to amplify the signal through the speaker or to stop when scanning. Follow these steps to set the squelch.

1. Rotate **SQUELCH** fully counterclockwise.
2. Set **VOLUME** so you can hear the background hiss between transmissions.

Note: If you do not hear hissing, turn **TUNE/M-CH** to select a frequency that does not have communications in progress.

3. Slowly turn **SQUELCH** clockwise until the hissing stops.

If you turn **SQUELCH** too far clockwise, you might miss parts of transmissions. If you do not turn **SQUELCH** far enough clockwise, you hear hissing between transmissions and the HTX-242 might not scan properly.

Using the Light

Your HTX-242 has two display light levels. To switch between the two levels, press **F** then **DIM**.

Setting the Power Level

Your HTX-242 has two transmit power levels. Low is about 10 watts, and high is about 45 watts. To switch between the two power levels, press **LOW**. **LOW** or **HIGH** appears on the display. The power setting is saved when you store settings in memory.

Locking the Controls

To lock the controls on the microphone (except the push-to-talk button, **PTT**), slide **LOCK ON** to the right. This does not lock the HTX-242's front panel controls.

To lock all controls except **POWER**, **VOLUME**, **SQUELCH**, and the push-to-talk button, press **F** then **LOCK**. **LOCK** appears on the display.

To unlock the controls, press **F** then **LOCK** again.

Selecting a Frequency

You can select a frequency in any of three ways:

- Direct entry
- Tuning
- Scanning

Directly Entering a Frequency

1. Press **VFO** to select either **VFO-A** or **VFO-B**.
2. Enter the last five digits of the frequency. For example, to enter 145.050, simply press **45050**.

Notes:



- The HTX-242 rounds the last digit down to 5 or 0.
- The HTX-242 does not accept entries outside its range.
- If you have turned on the AS option, the HTX-242 automatically selects the correct duplex offset for frequencies normally assigned to repeaters and selects no offset for other frequencies. See “Turning Auto Duplex On and Off” on Page 25.

Tuning to a Frequency

1. Press **VFO** to select either **VFO-A** or **VFO-B**.
2. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to step through the frequencies.

Notes:



- You can set the HTX-242 to step in 5, 10, 12.5, 20, 25, 50, or 100 kHz increments. The default is 20 kHz. See “Setting the Frequency Step” on Page 19.
- To step in 1 MHz increments, press **MHz**. Press **MHz** again to return to the previous frequency step.
- If you have turned on the AS option, the HTX-242 automatically selects the correct duplex offset for frequencies normally assigned to repeaters and selects no offset for other frequencies. See “Turning Auto Duplex On and Off” on Page 25.

Scanning for a Frequency

1. Press **VFO** to select either **VFO-A** or **VFO-B**.
2. Press **F**. Then press **▲** to scan up or **▼** to scan down.

Notes:



- You can set the HTX-242 to scan in 5, 10, 12.5, 20, 25, 50, or 100 kHz steps. The default is 20 kHz. See “Setting the Frequency Step” on Page 19.
- You can program up to five frequencies for the HTX-242 to skip when scanning. See “Storing Scan Skip Frequencies” on Page 20.
- When the HTX-242 reaches one end of the scanning range, it starts over at the other end. To set the scanning range, see “Setting the Scanning Range” on Page 21.
- When the HTX-242 stops on a transmission, it either stops scanning, resumes scanning in 10 seconds even if the transmission continues, or stays on the frequency until the transmission ends. To select the scan resume option, see “Setting the Scan Resume Condition” on Page 20.
- If you set the HTX-242 to resume scanning after the transmission ends, it pauses to ensure you do not miss a reply. To set the scan delay, see “Setting the Scan Resume Delay” on Page 21.
- If you press PTT on the microphone, scanning stops.
- To resume scanning after the HTX-242 stops, press **MHz**.

Setting the Frequency Step

The factory default frequency step is 20 kHz. Each time you rotate **TUNE** one click, or press **UP** or **DOWN** on the microphone, the frequency changes by 20 kHz. When scanning, the HTX-242 scans up or down 20 kHz per step.

Follow these steps to change the frequency step.

1. Press **VFO**.
2. Press **F** then **STEP**. The HTX-242 displays **St** and the current frequency step.
3. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to select the desired frequency step (5, 10, 12.5, 20, 25, 50, or 100 kHz).
4. Press **MHz** or PTT to save the setting.

Setting the Scan Options

Storing Scan Skip Frequencies

You can store up to five frequencies for your HTX-242 to skip when scanning. This lets you prevent the HTX-242 from stopping on beacon or packet repeater frequencies.

1. Press **VFO**.
2. Hold **F** for at least 1 second. **FUNC** flashes.
3. Press **MR**. The HTX-242 displays **SC** and the current scan resume setting.
4. Repeatedly press **▲** until the HTX-242 displays **S1** and the first scan skip frequency (or **---.---** if no frequency is stored).
5. Select the first scan skip frequency by rotating **TUNE**, pressing **UP** or **DOWN** on the microphone, or directly entering the last five digits of the frequency.
6. Press **▲** for the next scan skip memory—**S2**, **S3**, **S4**, or **S5**.
7. Repeat Steps 5 and 6 for each scan skip frequency.
8. Press **MR** or **PTT** to save the setting.

Setting the Scan Resume Condition

When you scan VFO frequencies or frequencies you stored in memory, the HTX-242 stops at any signal strong enough to break squelch. The HTX-242 is preset to **ti**, meaning it resumes scanning in 10 seconds, even if the signal continues.

Follow these steps to change the scan resume condition.

1. Press **VFO**.
2. Hold **F** for at least 1 second. **FUNC** flashes.
3. Press **MR**. The HTX-242 displays **SC** and the current option.
 - ti** Resumes scanning in 10 seconds
 - cr** Resumes scanning after the carrier drops and the scan resume delay expires
 - SE** Does not resume scanning
4. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to select the desired option.
5. Press **MR** or **PTT** to save the setting.

Setting the Scan Resume Delay

When you set the scan resume condition to **cr** (carrier), the HTX-242 resumes scanning after the carrier drops. The scan resume delay option lets you set the HTX-242 to pause before resuming so you can hear replies. The factory default is 2 seconds.

Follow these steps to change the scan resume delay.

1. Press **VFO**.
2. Hold **F** for at least 1 second. **FUNC** flashes.
3. Press **MR**.
4. Repeatedly press **▲** until the HTX-242 displays **sd** and the current scan resume delay (0.5, 1, 2, or 4 seconds).
5. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to select the desired scan resume delay.
6. Press **MR** or **PTT** to save the setting.

Setting the Scanning Range

When you scan in a VFO mode, the HTX-242 scans frequencies within a selected range. The default range is 144.0 to 148.0 MHz.

Follow these steps to change the scanning range.

1. Press **VFO**.
2. Hold **F** for at least 1 second. **FUNC** flashes.
3. Press **MR**.
4. Repeatedly press **▲** until the HTX-242 displays **SL** and the lower scan limit.
5. Rotate **TUNE**, press **UP** or **DOWN** on the microphone, or directly enter the lower scan limit's last five digits on the microphone's keypad.
6. Press **▲**. The HTX-242 displays **SH** and the upper scan limit.
7. Rotate **TUNE**, press **UP** or **DOWN** on the microphone, or directly enter the upper scan limit's last five digits on the microphone's keypad.
8. Press **MR** or **PTT** to save the settings.



Note: The frequency gap between the lower and upper scan limits should be no less than two times the current frequency step. If the frequency gap is less than this, the HTX-242 does not scan.

Receiving Transmissions

To receive a transmission, turn on the HTX-242, adjust the volume and squelch, and tune to the frequency you want to monitor. The HTX-242 displays **BUSY**, and the signal-strength indicator shows the relative signal strength when it receives a signal.

Note: If **BUSY** appears but you hear nothing from the speaker, be sure the DTMF page and tone-squelch features are turned off and **SQUELCH** is set correctly. To turn off DTMF page, press **DTMF** once. To turn off tone squelch, press **T-SQL** until neither **T** nor **T-SQL** appears on the display. See “Activating Subaudible Tone Transmit and Squelch” on Page 37.

Transmitting



Caution: It is illegal to transmit if you do not have a Technician Class (or higher) license issued by the FCC.

1. Select the desired frequency.

Note: If you select a repeater frequency, the HTX-242 displays **+** or **-** to show the offset direction. To operate with no offset (simplex) on that frequency, press **SHIFT** until neither **+** nor **-** appears.

2. Press **LOW** so **LOW** appears on the display. This selects the low power (10 watt) setting.
3. Press the push-to-talk button (PTT) on the side of the microphone to transmit. The signal strength meter shows half-scale for low power (or full-scale for high power). Release PTT to listen for a reply.

Notes:



- If the other party advises you to improve your signal, press **LOW**. **HIGH** appears on the display, and the HTX-242 transmits at high power (about 45 watts). To return to low power, press **LOW** again.
- If you try to transmit outside the permitted range, the HTX-242 displays **tF Err** and beeps twice.

Manually Transmitting DTMF Tones

To transmit DTMF tones, follow the steps for transmitting. Then, while holding down PTT, press the digits on the microphone to transmit the tones.



Note: If auto-reply is turned on, you must hold down PTT while you transmit. If auto-reply is off, you can release PTT after you enter the first digit. The HTX-242 transmits for 1 second after you enter the last digit. See “Using Auto-Reply” on Page 34.

Transmitting DTMF Tones from Memory

1. Press **DTMF** so the HTX-242 displays **DTMF** and the current DTMF memory number.
2. To select a different DTMF memory, press and hold **F** for at least 1 second. Then press **DTMF**.
3. Rotate **TUNE** or press **▲** or **▼** to select the desired DTMF memory.
4. Press and hold **PTT**. Then press **DTMF** to send the current DTMF memory.



Notes:

- If you turn on the DTMF auto send option and turn on DTMF memory (**DTMF** appears on the display), the HTX-242 sends the DTMF sequence in the current memory every time you press PTT. See “Using DTMF Auto Send” on Page 35.
- To store DTMF sequences, see “Storing a DTMF Sequence” on Page 32.

Limiting Transmit Duration

When you communicate on the 2-meter band, you should keep your transmissions as brief as possible. Most repeaters have built-in timers that limit single transmissions to 3 minutes or less.

You can set the transceiver to stop transmitting and sound a beep if a single transmission exceeds the selected time (none, 1, 2, 3, 5, 7, 10, or 15 minutes). Follow these steps to select the transmission time-out setting.

1. Press **VFO**.
2. Hold **F** for at least 1 second. **FUNC** flashes.
3. Press **MR**.
4. Repeatedly press **▲** until the HTX-242 displays **to** and either the selected time (if the option is on) or **OFF** (if the option is off).
5. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to select the desired time-out time (to turn on the time out option) or **OFF** (to turn off the option).
6. Press **MR** or **PTT** to save the settings.

Turning the Keytone Beep On and Off

Your HTX-242 sounds a beep each time you press a button. Follow these steps to turn off this keytone beep.



Note: This does not affect the tone-alert beep, alarm scan beep, or the transmit limit beep.

1. Press **VFO**.
2. Hold **F** for at least 1 second. **FUNC** flashes.
3. Press **MR**.
4. Repeatedly press **▲** until the HTX-242 displays **bp** and either **on** (if the beep option is on) or **OFF** (if the option is off).
5. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to select **on** (to turn on the beep option) or **OFF** (to turn off the option).
6. Press **MR** or **PTT** to save the settings.

ADVANCED OPERATION

Frequency Offset Defaults

When you select a frequency, the HTX-242 defaults to the following frequency offsets if auto duplex is turned on:

Receive Frequency	Transmit Offset
Below 144.600 MHz	No offset (Simplex)
144.600 to 144.905 MHz	+ offset
144.910 to 145.205 MHz	No offset (Simplex)
145.210 to 145.505 MHz	- offset
145.510 to 146.005 MHz	No offset (Simplex)
146.010 to 146.375 MHz	+ offset
146.380 to 146.605 MHz	No offset (Simplex)
146.610 to 146.995 MHz	- offset
147.000 to 147.395 MHz	+ offset
147.400 to 147.595 MHz	No offset (Simplex)
147.600 to 147.995 MHz	- offset
148.000 MHz and above	No offset (Simplex)

The default offset is 600 kHz. For example, if you tune to receive 146.940 MHz, the HTX-242 automatically transmits at 146.340 MHz (600 kHz less than 146.940).



Note: Outside these ranges, the HTX-242 operates with no offset.

Turning Auto Duplex On and Off

The HTX-242 can automatically select the correct duplex offset for frequencies normally assigned to repeaters and selects no offset (simplex) for other frequencies. Follow these steps to turn this option on or off.

1. Press **VFO**.
2. Hold **F** for at least 1 second. **FUNC** flashes.
3. Press **MR**.
4. Repeatedly press **▲** or **▼** until the HTX-242 displays **AS** and either **on** (if the option is on) or **OFF** (if the option is off).
5. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to select **on** or **OFF**.
6. Press **MR** or **PTT** to save the setting.

Changing the Default Offset

Follow these steps to change the default offset for the VFO modes.

1. Press **VFO**.
2. Hold **F** for at least 1 second. **FUNC** flashes.
3. Press **SHIFT**. The HTX-242 displays **oS** and the current offset (in MHz).
4. Rotate **TUNE**, press **UP** or **DOWN** on the microphone, or directly enter the step using the microphone's keypad to select an offset default (from 0 to 38 MHz).
5. Press **SHIFT** or **PTT** to save the setting.



Note: This setting does not affect frequencies already stored in memory.

Reversing the Offset

To reverse the transmit and receive frequencies when you operate duplex, press **F** then **REV**. For example, if you tune to 146.940 (which has a - offset), pressing **F** then **REV** makes the transceiver receive on 146.340 and transmit on 146.940. The setting returns to the default if you change frequencies.

Overriding the Duplex Offset

When you tune to a frequency, the HTX-242 automatically selects either simplex operation, or duplex operation with the correct offset direction (if the auto duplex option is on). To override this setting, press **SHIFT**. Each time you press **SHIFT**, the offset switches between +, -, and no offset. The setting returns to the default if you change frequencies.

Using the Dual VFOs for Duplex Operation

Follow these steps to use one VFO to transmit and the other to receive.

1. Press **VFO** to select **VFO-A**.
2. Select a frequency.
3. Press **VFO** to select **VFO-B**.
4. Select a frequency.
5. Press **DUP**.

When the HTX-242 displays:

VFO-A-T
VFO-B

it transmits on the VFO-A frequency and receives on the VFO-B frequency.

When it displays:

VFO-A
VFO-B-T

it transmits on the VFO-B frequency and receives on the VFO-A frequency.

USING MEMORY CHANNELS

The HTX-242 has 40 standard memory channels and one calling-frequency memory, where you can store frequently-used frequencies, along with all settings, for quick access.

Storing a Frequency

1. Press **VFO** and tune to a frequency you want to store. Set all duplex and subaudible tone settings (see “Using Subaudible Tones” on Page 36), the transmit power setting, and the DTMF option.
2. **To store the frequency in the calling-frequency memory**, press and hold **F** for at least 1 second. **FUNC** flashes on the display. Then press **CALL**.

To store the frequency in a standard memory, press **F**. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, until the HTX-242 displays the desired memory number to the left of the frequency. Then press **MR**. The HTX-242 beeps twice and stores all settings into the selected memory channel.

Changing Stored Settings

To change the receive frequency, follow the steps under “Storing a Frequency.” To change the transmit frequency or a tone squelch option without changing the receive frequency, follow these steps.

1. To change the calling memory, press **CALL**.

To change a standard memory, press **MR**. Then rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to select the memory channel you want to change.

2. If you want to turn tone squelch on or off, repeatedly press **TSQL** to select the desired tone squelch mode. (See “Using Subaudible Tones” on Page 36.)
3. **For the calling-frequency memory**, press and hold **F** for one second. Then press **CALL**.

For a standard memory, press **F**, then press **MR**.

The HTX-242 displays **rF** and the receive frequency, and **M-CH** flashes.

4. Rotate **TUNE**, press **UP** or **DOWN** on the microphone, or enter the receive frequency using the microphone’s keypad.
5. Press **▲**. The HTX-242 displays **tF** and the transmit frequency.
6. Rotate **TUNE**, press **UP** or **DOWN** on the microphone, or enter the transmit frequency using the microphone’s keypad.

-
7. Press **▲**. The HTX-242 displays **rC** and the current receive subaudible tone.
 8. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to change the receive subaudible tone.
 9. Press **▲**. The HTX-242 displays **tC** and the current transmit subaudible tone.
 10. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to change the transmit subaudible tone.
 11. **For the calling-frequency memory**, press **CALL** to save all settings.

For a standard memory, press **▲**. The HTX-242 displays **Sn**. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to select whether the memory is included in a memory scan (**On**) or locked out of a memory scan (**Off**). Then press **MR** to save all settings.

Using Auto Memory Store (AMS)

Follow these steps to have the HTX-242 scan through a selected range and store active frequencies in memory.

1. Set the upper and lower scan limits (see “Setting the Scanning Range” on Page 21).
2. Set the scanning step (see “Setting the Frequency Step” on Page 19).
3. Set the squelch (see “Setting Volume and Squelch” on Page 17).
4. Hold **F** for at least 1 second. Then press **MHz**.

The HTX-242 scans between the lower and upper scan limits. When it detects a transmission, it checks all memories to see if that frequency is already stored. If the frequency is not in a memory, the HTX-242 stores the frequency in the lowest unused memory, then resumes scanning. The HTX-242 continues auto store until all memories are used.

5. To stop auto store before all memories are used, press **VFO**, **DUP**, **MR**, **CALL**, or **MHz**.



Notes:

- The HTX-242 turns off tone squelch during auto store.
- Auto store does not work if all memories are used.

Tuning to a Standard Memory Channel

1. Press **MR**.
2. Rotate **M-CH**, or press **UP** or **DOWN** on the microphone, to select the desired memory channel.

Using the Calling-Frequency Memory


Press **CALL**. The HTX-242 recalls all settings saved in the calling-frequency memory.

Notes:



- If you rotate **TUNE**, press **UP** or **DOWN**, or directly enter a frequency, the HTX-242 returns to the last-used VFO.
- To return to the mode selected before you used the calling-frequency memory, press **CALL** again.

Checking Priority Channel 1

To have the HTX-242 periodically “look back” at Memory Channel 1 to check for a transmission, press **F** then **ALM**.  appears on the display. The HTX-242 looks back at Memory Channel 1 every 4, 8, 12, or 16 seconds. If there is a transmission, the HTX-242 beeps to let you know to tune to it, if desired.

Follow these steps to change the look-back time.

1. Press **VFO**.
2. Hold **F** for at least 1 second. **FUNC** flashes. Then press **MR**.
3. Repeatedly press **▲** until the HTX-242 displays **Lb** and the current look-back time.
4. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to select the desired look-back time (4, 8, 12, or 16 seconds).
5. Press **MR** or **PTT** to save the setting.

Scanning Memory Channels

To set the HTX-242 to scan memory channels, press and release **MR**. Then press and hold **MR** for at least 1 second. **.** flashes, and the HTX-242 scans memories that have the scan option turned on (see “Enabling/Disabling Scanning for Memory Channels” on this page). The HTX-242 stops when it encounters a transmission. It resumes scanning according to the saved scan settings (see “Setting the Scan Options” on Page 20). To resume scanning immediately, press **MHz**.



Note: Scanning stops if you press **MR** or **PTT**.

Clearing a Memory Channel

You can clear any memory channel except Memory Channel 1 and the calling-frequency memory.

1. Tune to the memory channel you want to clear.
2. Hold **F** for at least 1 second. **FUNC** flashes.
3. Press **MR**. All settings are cleared from the memory channel.

Enabling/Disabling Scanning for Memory Channels

You can disable (lock out) individual memory channels, so the HTX-242 does not stop on them when you scan memory channels.

1. Tune to the memory channel you want to enable or disable for scanning.
2. Press **F**, then press **MR**.
3. Repeatedly press **▲** until the HTX-242 displays **Sn** and the scan setting.
4. To enable scanning for the current channel, rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to select **on**.

To disable scanning for the current channel, rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to select **OFF**.

5. Press **MR** or **PTT** to save the setting.

USING DTMF AND SUBAUDIBLE TONES

Your HTX-242 has 10 DTMF (Dual-Tone, Multiple Frequency—another name for *touch tones*) memories where you can store DTMF sequences. DTMF Memory 0 can hold a 7-digit DTMF paging sequence your HTX-242 must receive for DTMF paging. DTMF Memories 1-10 each hold 15 digits you can quickly transmit.

Storing a DTMF Sequence

1. Hold down **F** for at least 1 second. **FUNC** flashes.
2. Press **DTMF**. The HTX-242 displays the sequence stored in the currently selected memory.
3. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to select one of the 10 transmit DTMF memories (1-10) or the receive DTMF memory (0).

Note: **td** appears with transmit DTMF Memories 1-10, and **rd** appears with receive DTMF Memory 0.

4. Press **SHIFT**. Then use the keypad to enter the sequence you want to store.

Note: DTMF Memories 1-10 hold 15 digits each. DTMF Memory 0 holds 7 digits.

5. Repeat Steps 3 and 4 to store more DTMF sequences, or press **DTMF** or **PTT** to save all sequences and return to normal operation.



Note: To clear a DTMF sequence, repeat these steps but do not enter a frequency in Step 4 after you press **SHIFT**.

Transmitting a DTMF Sequence

1. Hold **F** for at least 1 second. **FUNC** flashes.
2. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to select the DTMF memory that contains the sequence you want to transmit.
3. Press the push-to-talk button. While holding down **PTT**, press **DTMF**. The HTX-242 transmits the stored sequence.



Note: If the DTMF auto send feature is turned on, the HTX-242 transmits the tones in the selected DTMF memory every time you press **PTT**.

Using DTMF Page

DTMF page lets other operators page you. To turn on DTMF page, press **DTMF** so **DTMF** appears. The HTX-242 does not pass transmissions to the speaker until it receives the sequence you stored in DTMF Memory 0. If DTMF Memory 0 is empty, DTMF page does not operate.

When you receive a DTMF page, the HTX-242 turns on the speaker and turns off DTMF page so all transmissions come through.

Notes:



- If you turn on auto-reply, the HTX-242 immediately sends the sequence in the currently selected DTMF memory when it receives the sequence you set. See “Using Auto-Reply” on Page 34.
- If you turn on tone-alert, the HTX-242 sounds four tones when it receives its DTMF sequence you set. See “Setting the DTMF Page and Subaudible Tone Alert” on Page 37.
- If you turn on DTMF auto send, the HTX-242 opens squelch only for transmissions that start with the sequence stored in DTMF Memory 0. After the transmission, DTMF squelch is still turned on. See “Using DTMF Auto Send” on Page 35.

Using Group Calling

Group calling lets you page several users at once. Each user must have a transceiver that has this feature. When the HTX-242 receives at least three DTMF tones followed by the sequence A-B-C, it compares the DTMF tones it received before the A-B-C with the sequence in DTMF Memory 0. If the tones match, it operates as if it received the entire sequence.

For example, if these sequences are assigned to a group:

Name	Assignment	DTMF Page Sequence
George	West Side	4654321
Bob	West Side	4654254
Doug	East Side	4651823
Bill	North Side	4652252
Cary	East Side	4651855
Paul	South Side	4653552
Kim	North Side	4652183
James	South Side	4653122
Beth	East Side	4651931

-
- Assuming all club members have DTMF page activated, to page everyone, transmit 465ABC.
 - To page West Side members, transmit 4654ABC.
 - To page Doug and Cary, transmit 46518ABC.
 - To page only one person, transmit the 7-digit sequence.

Using Auto-Reply

If you turn on the auto-reply feature, the HTX-242 automatically sends the sequence stored in the currently-selected DTMF memory when it receives a DTMF page.

Follow these steps to turn on auto-reply.

1. Press **VFO**.
2. Hold **F** for at least 1 second. **FUNC** flashes.
3. Press **MR**. The HTX-242 displays the first configuration menu item.
4. Repeatedly press **▲** to select the **Ar** option. Then rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to set the option to **on**.
5. Press **MR** or **PTT** to save the setting.

To turn off auto-reply, set the option to **OFF** in Step 4.

Using DTMF Auto Send

If you turn on the DTMF auto-send feature, the HTX-242 automatically sends the sequence stored in the currently-selected DTMF memory every time you press PTT.

Follow these steps to turn on auto send.

1. Press **VFO**.
2. Hold **F** for at least 1 second. **FUNC** flashes.
3. Press **MR**.
4. Repeatedly press **▲** to select the **dA** option. Then rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to set the option to **on**.
5. Press **MR** or **PTT** to save the setting.
6. Press **DTMF** so **DTMF** is on the display.

To temporarily turn off auto send, press **DTMF** so **DTMF** is not on the display. To turn off auto send, set the option to **oFF** in Step 4.

Notes:



- This feature works with the DTMF page feature. If you stored a sequence in DTMF Memory 0, the HTX-242 does not pass transmissions to the speaker until it receives that sequence. After the transmission, DTMF squelch is still turned on.
- If there is no sequence stored in DTMF Memory 0, the HTX-242 still transmits the currently selected DTMF memory sequence each time you press PTT, but passes all transmissions to the speaker.

Using Subaudible Tones

Some repeaters require you to transmit a subaudible tone to activate them. You can set your HTX-242 to transmit any of the 38 standard subaudible tones. You can also limit incoming reception by setting the HTX-242 to open the squelch only when someone transmits a subaudible tone you select.

Valid Subaudible Tones

Code	Freq. (Hz)	Code	Freq. (Hz)	Code	Freq. (Hz)
XZ	67.0	1B	107.2	6Z	167.9
XA	71.9	2E	110.9	6A	173.8
WA	74.4	2A	114.8	6B	179.9
XB	77.0	2B	118.8	7Z	186.2
WB	79.7	3Z	123.0	7A	192.8
YZ	82.5	3A	127.3	M1	203.5
YA	85.4	3B	131.8	M2	210.7
YB	88.5	4Z	136.5	M3	218.1
ZZ	91.5	4A	141.3	M4	225.7
ZA	94.8	4B	146.2	M5	233.6
ZB	97.4	5Z	151.4	M6	241.8
1Z	100.0	5A	156.7	M7	250.3
1A	103.5	5B	162.2		

Setting the Subaudible Tones

Some repeaters require you to transmit a subaudible tone with your transmission. You can also set a tone that must accompany transmissions for your HTX-242 to open squelch.

Follow these steps to set the subaudible tones for the VFO mode. After you set the tones, you must activate the function to turn it on. Changing this setting does not change the tones stored in any memory channel.

1. Press **VFO**.
2. Hold **F** for at least 1 second. **FUNC** flashes.
3. Press **T-SQL**. The HTX-242 displays **rC** and the currently set receive tone.
4. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to set a different receive tone. If you do not want a receive tone, select **OFF**.

-
5. Press **▲**. The HTX-242 displays **ⓉC** and the currently set transmit tone.
 6. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to set a different transmit tone. If you do not want a transmit tone, select **OFF**.
 7. Press **T-SQL** or **PTT** to save the settings.

Activating Subaudible Tone Transmit and Squelch

1. Press **T-SQL** once. **T** appears. The HTX-242 includes the selected transmit tone with your transmissions.
2. Press **T-SQL** again. **T-SQL** appears. The HTX-242 includes the selected transmit tone with your transmissions and requires the selected receive tone to open squelch.
3. Press **T-SQL** a third time to turn off both subaudible tone transmit and squelch. Neither **T** nor **T-SQL** appears on the display.

Setting the DTMF Page and Subaudible Tone Alert

When the alert function is turned on, the HTX-242 sounds a sequence of three tones when it receives a DTMF page (if DTMF page is activated) or a transmission that includes the correct subaudible tone (if tone squelch is activated).

To turn on the alert function, press **F** then **ALT**. **ALT** appears. To turn off the alert function, press **F** then **ALT** again. **ALT** disappears.

USING THE MENU

Your HTX-242 has a menu that lets you select how some functions work. The previous sections included procedures that access this menu—this section provides an overview. Follow these steps to use the menu:

1. Press **VFO**.
2. Hold **F** for at least 1 second. **FUNC** flashes.
3. Press **MR**. The first menu item appears. Then press ▲ or ▼ to select the desired menu option.
4. Rotate **TUNE**, or press **UP** or **DOWN** on the microphone, to select the setting. For options that require a frequency (such as scan skip), you can use the microphone keypad to directly enter the frequency's last five digits.
5. Press **MR** or **PTT** to save the settings.

Menu Item	Default Option	Explanation/Available Settings	Page #
SC	ti	Scan resume option. ti—time out in 10 seconds. Cr—resume after carrier drops. SE—do not resume scanning.	20
sd	2.0	Scan delay (delay before resume when SC is set to Cr). 0.5, 1, 2, or 4.	21
S1	---.---	Scan skip frequency 1 (frequency for HTX-242 to skip when scanning VFO).	20
S2	---.---	Scan skip frequency 2.	20
S3	---.---	Scan skip frequency 3.	20
S4	---.---	Scan skip frequency 4.	20
S5	---.---	Scan skip frequency 5.	20
Lb	4	Look-back time (how often the HTX-242 checks Priority Memory Channel 1 for a transmission when the alarm is activated). 4, 8, 12, or 16.	30
SL	144.000	Lower scan limit. With SH, determines the VFO scanning range.	21
SH	148.000	Upper scan limit.	21
Ar	oFF	Auto reply (controls whether the HTX-242 transmits a DTMF memory sequence when it is DTMF paged). oFF or on.	34
to	oFF	Time-out option (sets whether the HTX-242 limits transmissions). oFF, 1, 2, 3, 5, 7, 10, or 15.	24
bp	oN	Keytone beep option.	24
AS	on	Auto duplex/simplex option (controls whether the HTX-242 uses the standard repeater offsets). oFF or on.	25
dA	oFF	DTMF auto send (controls whether the HTX-242 transmits the contents of the currently-selected DTMF memory each time you press PTT). oFF or on.	35

TROUBLESHOOTING

Error Codes

Your HTX-242 has the following three built-in error codes.

tF Err—appears if you try to transmit outside the allowed range (see “Extending the Transmit Frequency Range” on Page 16).

PLL Err—appears if the HTX-242’s PLL (phase-locked loop) section malfunctions. If turning the HTX-242 off then back on does not correct this error, take it to your local Radio Shack store to arrange for service.

EEP Err—appears if the HTX-242’s EEPROM checksum fails. Try resetting the HTX-242 (see “Resetting the HTX-242” on Page 16). If this does not clear the error, take it to your local Radio Shack store to arrange for service.

Common Problems and Solutions

If your HTX-242 does not seem to be operating properly, check this section for a possible solution.

Problem	Possible Solutions
Signal strength meter shows a signal and BUSY appears, but no sound from speaker.	Be sure DTMF is not on the display. If it is, press DTMF to turn off DTMF page. Be sure T-SQL is not on the display. If it is, press T-SQL until neither T nor T-SQL appears. Be sure VOLUME and SQUELCH are properly adjusted. Be sure nothing is plugged into the EXT. SP jack.
No controls operate.	Be sure LOCK is not on the display. If it is, press F then LOCK to unlock the controls. Be sure LOCK on the microphone is set to its leftmost position.
Other party cannot hear your transmission.	Be sure the duplex offset is set correctly. Set the output power to high by pressing LOW so HIGH appears on the display.
The display does not light when you press POWER .	Check the power connections. Check the fuse (see “Replacing the Fuse” on Page 41).

Replacing the Fuse

Your HTX-242 (and vehicle) are protected by a 15-amp fuse in the HTX-242's positive (red) power wire. If the HTX-242 does not turn on, even when you are sure the power wire is properly connected to a 12V DC power source, check the fuse and replace it, if necessary.

1. Snap open the in-line fuse holder.
2. Remove the fuse from the holder, and slide the fuse out of the end connectors.
3. If the fuse's filament is no longer intact, replace the fuse with a 15-amp 1 1/4 × 1/4-inch fuse (Cat. No. 270-1073).



Caution: Use only a fuse of the recommended size and type. Using another type fuse, or defeating the fuse protection, could damage your vehicle or your HTX-242. If the fuse frequently blows, there is a problem with the HTX-242 or its wiring. Have that problem fixed as soon as possible.

4. Replace the fuse in the holder and snap it closed.

SPECIFICATIONS

General

Frequency Range (Factory)	
Transmit	144 – 148 MHz
Receive.	136.000 – 174.000 MHz
Frequency Step	5/10/12.5/20/25/50/100 kHz
Frequency Stability	±10 ppm
Antenna Impedance	50 Ohms
Speaker	8 Ohms
Microphone	Electret Condenser (1.2 kOhms)
Operating Temperature	14 to 140°F (-10 to 60°C)
Dimensions (HWD)	1 ⁵ / ₈ × 5 ⁹ / ₁₆ × 6 ³ / ₁₆ Inches (42 × 142 × 160 mm)
Supply Voltage	13.8 V DC (±15%)

Receiver

Intermediate Frequency	
1st IF	21.4 MHz
2nd IF	455 kHz
Sensitivity	
12 dB sinad	0.25 µV
20 dB nq.	0.39 µV
Squelch Sensitivity	
Threshold	0.1 µV
Tight.	10 dB above threshold
Spurious Response Attenuation	Better than 70 dB
Adjacent Channel Rejection	Better than 70 dB
Modulation Acceptance Bandwidth.	Better than 7.5 kHz
Hum and Noise	Better than 40 dB
Audio Output Power at 10% THD	Better than 2.0 W
Audio Distortion.	2%
Audio Response	-6 dB/Octave
Stand-by Current	500 mA
CTCSS Sensitivity.	0.15 µV
DTMF Squelch Sensitivity.	0.2 µV

Transmitter

RF Power Output	45 W (high)/10 W (Low)
Maximum Deviation	5 kHz
Hum and Noise	Better than 35 dB
Audio Distortion	3% (TX)
Audio Response	+6 dB/Oct
Spurious and Harmonic Emissions	Better than 60 dB
Frequency Error	±10 ppm
Microphone Sensitivity	4 mV rms
CTCSS Tone Deviation	0.75 kHz
DTMF Tone Deviation	3.5 kHz
Current Drain	Less than 8 A at 45 W Less than 4 A at 10 W

Specifications are typical; individual units might vary. Specifications are subject to change and improvement without notice.

SCHEMATICS

RF SCHEMATIC

DIGITAL SCHEMATIC

MICROPHONE SCHEMATIC

Radio Shack Limited Warranty

This product is warranted against defects for 1 year from date of purchase from Radio Shack company-owned stores and authorized Radio Shack franchisees and dealers. Within this period, we will repair it without charge for parts and labor. Simply **bring your Radio Shack sales slip** as proof of purchase date to any Radio Shack store. Warranty does not cover transportation costs. Nor does it cover a product subjected to misuse or accidental damage.

EXCEPT AS PROVIDED HEREIN, RADIO SHACK MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. Some states do not permit limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

We Service What We Sell

10/95

Radio Shack
A Division of Tandy Corporation
Fort Worth, Texas 76102

7A6

Printed in Korea