



**SGI® InfiniteStorage 16000 (IS16000)  
User's Guide**

007-5725-001

---

## COPYRIGHT

© 2010, 2011 SGI. All rights reserved; provided portions may be copyright in third parties, as indicated elsewhere herein. No permission is granted to copy, distribute, or create derivative works from the contents of this electronic documentation in any manner, in whole or in part, without the prior written permission of SGI.

---

## LIMITED RIGHTS LEGEND

The software described in this document is “commercial computer software” provided with restricted rights (except as to included open/free source) as specified in the FAR 52.227-19 and/or the DFAR 227.7202, or successive sections. Use beyond license provisions is a violation of worldwide intellectual property laws, treaties and conventions. This document is provided with limited rights as defined in 52.227-14.

The electronic (software) version of this document was developed at private expense; if acquired under an agreement with the USA government or any contractor thereto, it is acquired as “commercial computer software” subject to the provisions of its applicable license agreement, as specified in (a) 48 CFR 12.212 of the FAR; or, if acquired for Department of Defense units, (b) 48 CFR 227-7202 of the DoD FAR Supplement; or sections succeeding thereto. Contractor/manufacturer is SGI, 46600 Landing Parkway, Fremont, CA 94538.

---

## TRADEMARKS AND ATTRIBUTIONS

Silicon Graphics, SGI, the SGI logo, and Supportfolio are trademarks or registered trademarks of Silicon Graphics International Corp. or its subsidiaries in the United States and/or other countries worldwide.

Fusion-MPT, Integrated RAID, MegaRAID, and LSI Logic are trademarks or registered trademarks of LSI Logic Corporation. InfiniBand is a registered trademark of the InfiniBand Trade Association. Intel, Itanium, and Xeon are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries. Internet Explorer and MS-DOS are registered trademarks of Microsoft Corporation. Java and Java Virtual Machine are trademarks or registered trademarks of Sun Microsystems, Inc. Linux is a registered trademark of Linus Torvalds, used with permission by SGI. Novell and Novell Netware are registered trademarks of Novell Inc. PCIe and PCI-X are registered trademarks of PCI SIG. Phoenix and PhoenixBIOS are registered trademarks of Phoenix Technologies Ltd. Red Hat and all Red Hat-based trademarks are trademarks or registered trademarks of Red Hat, Inc. in the United States and other countries. Sharp is a registered trademark of Sharp corporation. SUSE LINUX and the SUSE logo are registered trademarks of Novell, Inc. UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company, Ltd.

All other trademarks mentioned herein are the property of their respective owners.

## ***Preface***

### **What is in this guide**

This user guide gives you step-by-step instructions on how to install and configure the SGI InfiniteStorage 16000 ( IS16000) system.

### ***Related Documentation***

You should also see the following documents:

- *SGI InfiniteStorage 16000 Quick Start Guide* (007-5689-xxx)
- *SGI InfiniteStorage 16000 and InfiniteStorage 6120 CLUI Command Reference* (007-5726-xxx)

You can find SGI customer documents on the SGI Technical Publications Library (<http://docs.sgi.com>).

### ***International Standards***

The IS16000 complies with the requirements of the following agencies and standards:

- CE
- UL
- CUL
- C-Tick
- FCC

### ***Potential for Radio Frequency Interference***

#### **USA Federal Communications Commission (FCC)**

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. The supplier is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### ***European Regulations***

This equipment complies with European Regulations EN 55022 Class A: Limits and Methods of Measurement of Radio Disturbance Characteristics of Information Technology Equipments and EN50082-1: Generic Immunity.

## Canadian Regulations

ICES-003 Class A Notice - Avis NMB-003, Classe A

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

## Safe Handling

- Do not lift the IS16000 by the handles at the front and on the power supply modules on the back; they are not designed to support the weight of the enclosure.

## Safety

---

**NOTE :** If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

---



---

**Caution !** Safety goggles should be worn when maintaining the equipment.

---



**The IS16000 *MUST* be grounded before applying power. Unplug the unit if you think that it has become damaged in any way and before you move it.**

---



---

**Caution !** To maintain proper airflow through the system, operate the system with the system top covers closed.

---

- Plug-in modules are part of the IS16000 and must only be removed when a replacement can be immediately installed. The system must not be run without all modules in place.
  - In order to comply with applicable safety, emission, and thermal requirements, the top covers should remain closed while running.
  - The IS16000 system must only be operated from a power supply input voltage range of 200 VAC to 240 VAC.
  - A faulty power supply or fan module must be replaced with a fully operational module within 24 hours.
- 



**WARNING:** To minimize the risk of electric shock, disconnect the power from the power supply, either by turning off the switch or by physically removing the power cable, prior to removing the PCM from the enclosure.

---

- Do not remove a faulty power supply or fan module unless you have a replacement module of the correct type ready for insertion.
- The power connection must always be disconnected prior to removal of the power supply from the IS16000.
- A safe electrical earth connection must be provided to the power cord.

- Provide a suitable power source with electrical overload protection to meet the requirements given in the technical specifications.



**Do not remove covers from the power supply module. Danger of electric shock inside. Return the module to your supplier for repair.**

---



**Operation of the IS16000 with ANY modules missing will disrupt the airflow and the components will not receive sufficient cooling. It is ESSENTIAL that all apertures are filled before operating the unit.**

---

### ***Recycling of Waste Electrical and Electronic Equipment (WEEE)***

At the end of the product's life, all scrap/ waste electrical and electronic equipment should be recycled in accordance with National regulations applicable to the handling of hazardous/ toxic electrical and electronic waste materials.

---

**NOTE :**Observe all applicable safety precautions, such as weight restrictions, handling batteries and lasers etc, detailed in the preceding paragraphs when dismantling and disposing of this equipment.

---

### ***ESD Precautions***

---

**Caution !** It is recommended that you check and fit a suitable anti-static wrist or ankle strap and observe all conventional ESD precautions when handling the IS16000 plug-in modules and components. Avoid contact with backplane components and module connectors.

---

### ***Data Security***

- **ALL** the supplied plug-in modules and blanking plates must be in place for the air to flow correctly around the enclosure and also to complete the internal circuitry.
- If the IS16000 is used with modules or blanking plates missing for more than a few minutes, the system can overheat, causing power failure and data loss. Such use may also invalidate the warranty.
- Do not abandon your backup routines. No system is completely foolproof.

## ***Product Support***

SGI provides a comprehensive product support and maintenance program for its products. SGI also offers services to implement and integrate Linux applications in your environment.

- Refer to <http://www.sgi.com/support/>
- If you are in North America, contact the Technical Assistance Center at +1 800 800 4SGI or contact your authorized service provider.
- If you are outside North America, contact the SGI subsidiary or authorized distributor in your country.

## ***Reader Comments***

If you have comments about the technical accuracy, content, or organization of this document, contact SGI. Be sure to include the title and document number of the manual with your comments. (Online, the document number is located in the front matter of the manual. In printed manuals, the document number is located at the bottom of each page.)

You can contact SGI in any of the following ways:

- Send e-mail to the following address: [techpubs@sgi.com](mailto:techpubs@sgi.com)
- Contact your customer service representative and ask that an incident be filed in the SGI incident tracking system.
- Send mail to the following address:
  - SGI
  - Technical Publications
  - 46600 Landing Parkway
  - Fremont, CA 94538

SGI values your comments and will respond to them promptly.

## Table of Contents

<b>Preface</b>	Related Documentation . . . . .	iii
	International Standards . . . . .	iii
	Potential for Radio Frequency Interference . . . . .	iii
	European Regulations . . . . .	iii
	Canadian Regulations . . . . .	iv
	Safe Handling . . . . .	iv
	Safety . . . . .	iv
	Recycling of Waste Electrical and Electronic Equipment (WEEE) . . . . .	v
	ESD Precautions . . . . .	v
	Data Security . . . . .	v
	Product Support . . . . .	vi
	Reader Comments . . . . .	vi
<b>Chapter 1</b>		
<b>Introduction</b>	<b>1.1 Introduction</b> . . . . .	3
	1.1.1 System Architecture . . . . .	3
	1.1.2 Product Variations . . . . .	3
	1.1.3 Features of the IS16000 . . . . .	4
	<b>1.2 The IS16000 System Hardware</b> . . . . .	7
	1.2.1 Controller . . . . .	7
	1.2.1.1 Status LED Indicators . . . . .	8
	1.2.1.2 Fan Module . . . . .	9
	1.2.1.3 Power Supply Module . . . . .	9
	1.2.1.4 Internal Disk Modules . . . . .	10
	1.2.1.5 RAID Processor . . . . .	10
	1.2.1.6 I/O Ports . . . . .	11
	1.2.2 Uninterruptible Power Supplies (UPS) . . . . .	13
	1.2.3 Disk Enclosures . . . . .	14
	1.2.3.1 Disk Enclosure Chassis . . . . .	15
	1.2.3.2 Front Panel Indicators . . . . .	16
	1.2.3.3 Disk Modules . . . . .	17
	1.2.3.4 Power Cooling Module (PCM) . . . . .	18
	1.2.3.5 I/O Module . . . . .	19
	1.2.3.6 Internal Indicators . . . . .	19
	1.2.3.7 Drive Expander Module (DEM) Card . . . . .	20
<b>Chapter 2</b>		
<b>Installation</b>	<b>2.1 Installation Overview</b> . . . . .	23
	<b>2.2 Site Preparation</b> . . . . .	24
	2.2.1 Delivery Route Verification . . . . .	24
	2.2.2 Rack Location, Air Flow, and Access . . . . .	25
	2.2.3 Floor Loading . . . . .	26
	2.2.4 Cooling Supply Planning . . . . .	26
	2.2.5 AC Power Supply Planning and Verification . . . . .	27
	<b>2.3 Unpacking the IS16000</b> . . . . .	28
	2.3.1 Packing List . . . . .	28

<b>2.4</b>	<b>Installing the Disk Modules</b>	29
<b>2.5</b>	<b>Verifying Zoning Configuration on Disk Enclosures</b>	30
<b>2.6</b>	<b>Cable Connections</b>	31
2.6.1	Couplet ICL Cabling	31
2.6.2	Disk Enclosure Cabling	32
2.6.3	Management Network Connection	36
2.6.4	Host Connections	36
2.6.5	RS-232 Console Connection	36
2.6.6	UPS Connection	37
2.6.6.1	UPS Battery	37
2.6.7	Power Connections	38
<b>2.7</b>	<b>Powering On the System</b>	39
<b>2.8</b>	<b>Configuring the IS16000</b>	40
2.8.1	Planning Your Setup and Configuration	40
2.8.1.1	Storage Pools and Spare Pools	40
2.8.1.2	Storage Pools and Virtual Disks	41
2.8.1.3	WWN Node Names for Controller Ports	41
2.8.2	Disk Module Layout	41
2.8.3	Serial Interface Configuration	42
2.8.4	Validate the Hardware	43
2.8.5	Clear System Configuration	44
2.8.6	Set System Time & Date (NTP)	44
2.8.7	Set the System Name	45
2.8.8	Configure Network Interface Settings	45
2.8.9	Create Storage Pools	46
2.8.10	Create Virtual Disks	48
2.8.11	Create and Assign Spare Pools	49
2.8.12	Present Virtual Disk to External Host	51
2.8.12.1	Special Considerations for MAC OS	53
2.8.12.2	Selective Presentation	53
2.8.13	Storage Pool Initialization	54
<b>Chapter 3</b>	<b>Administration</b>	
<b>3.1</b>	<b>Managing the IS16000</b>	57
3.1.1	Management Interface	57
3.1.2	User Logins	58
3.1.3	Available Commands	58
3.1.3.1	Basic Key Operations	59
<b>3.2</b>	<b>Configuration Management</b>	60
3.2.1	Disk Information	60
3.2.1.1	Disk States	61
3.2.1.2	Visual Indication	62
3.2.2	Storage Pool Management	63
3.2.2.1	Display Storage Pool Information	63
3.2.2.2	Creating a Storage Pool	64
3.2.2.3	Storage Pool Initialization	65
3.2.2.4	Initialization Job Failure	65
3.2.2.5	Verifying a Storage Pool	66
3.2.2.6	Naming a Storage Pool	66
3.2.2.7	Deleting a Storage Pool	66

3.2.2.8	Locate a Storage Pool . . . . .	66
3.2.3	Virtual Disk Management . . . . .	67
3.2.3.1	Display Virtual Disk Information . . . . .	67
3.2.3.2	Creating a Virtual Disk . . . . .	68
3.2.3.3	Naming a Virtual Disk . . . . .	68
3.2.3.4	Deleting a Virtual Disk . . . . .	68
3.2.3.5	Presentation to Hosts . . . . .	68
3.2.4	Spare Pool Management . . . . .	69
3.2.4.1	Display Spare Pool Information . . . . .	69
3.2.4.2	Creating a Spare Pool . . . . .	70
3.2.4.3	Naming a Spare Pool . . . . .	70
3.2.4.4	Deleting a Spare Pool . . . . .	70
3.2.5	Disk Rebuild . . . . .	71
3.2.5.1	Full and Partial Rebuilds . . . . .	71
3.2.5.2	Sparing Policy . . . . .	71
3.2.5.3	Manual Disk Replace/Rebuild . . . . .	72
3.2.5.4	Manual Fail/Rebuild of a Disk . . . . .	72
3.2.6	SATAssure . . . . .	73
3.2.7	Setting the System's Date and Time (NTP Mode) . . . . .	73
3.2.8	Restarting the IS16000 . . . . .	75
<b>3.3</b>	<b>Performance Management . . . . .</b>	<b>76</b>
3.3.1	Background Job Priority . . . . .	76
3.3.2	Right Side I/O . . . . .	77
3.3.3	Rebuild Policy Priority . . . . .	78
3.3.4	Cache Coherency . . . . .	79
3.3.4.1	Cache Protection . . . . .	79
<b>3.4</b>	<b>Presentations . . . . .</b>	<b>80</b>
3.4.1	Discovered Initiator Commands . . . . .	81
3.4.2	Host Commands . . . . .	81
3.4.3	Presentation Commands . . . . .	81
3.4.4	Configuration of Presentations of Virtual Disks to Hosts . . . . .	82
3.4.4.1	Host Object Creation Example . . . . .	83
3.4.4.2	Identifying Host FC Connections via Ports . . . . .	83
3.4.4.3	Presenting a Virtual Disk to a Host . . . . .	87
3.4.5	Additional Configuration Considerations for Macintosh Hosts . . . . .	89
<b>3.5</b>	<b>Firmware Update Management . . . . .</b>	<b>90</b>
3.5.1	Displaying Current Firmware Version . . . . .	91
3.5.2	Controller Firmware Update Procedure . . . . .	91
3.5.2.1	Linux Environment-Firmware Update from the Network . . . . .	92
3.5.2.2	Windows Environment-Firmware Update from the Network . . . . .	92
3.5.3	Disk Enclosure Firmware Update Procedure . . . . .	94
3.5.3.1	Linux Environment-Firmware Upload . . . . .	94
3.5.3.2	Windows Environment-Firmware Upload . . . . .	94
3.5.3.3	Disk Shelf Upgrade . . . . .	94
3.5.4	Physical Disk Firmware Update Procedure . . . . .	97
3.5.4.1	Linux Environment-Firmware Upload . . . . .	97
3.5.4.2	Windows Environment-Firmware Upload . . . . .	97
3.5.4.3	Physical Disk Upgrade . . . . .	97
<b>3.6</b>	<b>The System Logs . . . . .</b>	<b>99</b>
3.6.1	Displaying Event Logs . . . . .	99
3.6.2	Event Log Structure . . . . .	100

3.6.3	Special Terminology in the Log	100
<b>3.7</b>	<b>Remote Management of IS16000</b>	101
3.7.1	Network Connection	101
3.7.2	Display Network Interface Attributes	101
3.7.3	Change Network Interface Settings	101
3.7.4	Logins	102
3.7.5	Email and SNMP Notification Setup	102
3.7.5.1	Email Setup	102
3.7.5.2	SNMP Setup	103
3.7.5.3	Inquiry Items and Events	103
<b>Chapter 4</b>		
<b>Troubleshooting</b>		
<b>4.1</b>	<b>Troubleshooting</b>	109
4.1.1	“RAID[0]\$" Prompt is not shown correctly	109
4.1.2	Event Log	109
<b>4.2</b>	<b>Manual Intervention Required (MIR) States</b>	110
<b>4.3</b>	<b>Recovery from Disk Failure</b>	112
4.3.1	Automatic Rebuild	112
4.3.2	Disk Module Replacement	113
4.3.3	When a Spare is not available	113
4.3.4	Manual Rebuild	114
<b>4.4</b>	<b>Controller Component Failure</b>	115
4.4.1	Replacing a Power Supply Module	116
4.4.2	Replacing a Fan	117
4.4.3	Replacing Internal Disk Module	118
<b>4.5</b>	<b>Disk Enclosure Faults</b>	119
4.5.1	Front Panel Indicators	119
4.5.2	Thermal Alarm	120
4.5.3	System Faults	120
4.5.4	Power Supply/Cooling Faults	121
4.5.5	Replacing a Disk Module	123
4.5.6	Replacing a DEM (Drive Expander Module)	125
4.5.7	Replacing an I/O Module	127
<b>Chapter 5</b>		
<b>GUI Management Agent 5.1</b>	<b>Starting the GUI Management Agent</b>	131
5.1.1	Login	131
5.1.2	Initial Home Screen and Health Indicators	132
<b>5.2</b>	<b>Physical Disks</b>	133
5.2.1	Physical Disks Menu	133
5.2.2	Checking Status of Physical Disks	133
<b>5.3</b>	<b>Storage Pools</b>	134
5.3.1	Storage Pool Menu	134
5.3.2	Create a Storage Pool	135
5.3.3	Configure Storage Pool Attributes	136
5.3.4	Locate Storage Pools	137
5.3.5	Show Storage Pools	137
5.3.6	Show Unassigned Pools	137

5.3.7 Delete a Storage Pool ..... 137

5.3.8 Storage Pool Initialization ..... 138

**5.4 Virtual Disks** ..... 139

5.4.1 Virtual Disk Menu ..... 139

5.4.2 Show Virtual Disks ..... 139

5.4.3 Create a Virtual Disk ..... 140

5.4.4 Configure Disk Virtual Attributes ..... 140

5.4.5 Delete a Virtual Disk ..... 141

**5.5 Spare Pools** ..... 142

5.5.1 Spare Pool Menu ..... 142

5.5.2 Show Spare Pools ..... 142

5.5.3 Create a Spare Pool ..... 143

5.5.4 Set Spare Pool Attributes ..... 144

5.5.5 Locate Storage Pools ..... 144

5.5.6 Delete a Spare Pool ..... 144

**5.6 Presentations** ..... 145

5.6.1 Presentation Menu ..... 146

5.6.2 Show Presentations ..... 146

5.6.3 Set up a Presentation ..... 146

**5.7 Email and Critical Event Notification Setup** ..... 148

**5.8 NTP Mode** ..... 149

**Appendices**

**Appendix A. Technical Specifications** ..... 153

**Appendix B. Terminology** ..... 155

**Index** ..... 157



# CHAPTER 1

*Introduction*

---



## 1.1 Introduction

---

### 1.1.1 System Architecture

The IS16000 employs RAID, data integrity and data management software written from the ground up to take advantage of multi-core processors and modern bus architectures. Its highly threaded architecture allows performance to linearly scale with advances in underlying hardware. This same architecture allows the IS16000 to perform in the extreme range of both throughput and IOPS. Designed to house the most scalable unstructured file data, the system supports up to 600 disks of raw storage while enabling a combination of SAS, SATA or SSD disks.

### 1.1.2 Product Variations

Two couplet configurations (Figure 1) are available with the IS16000 to enable full system performance, capacity, and the highest levels of disk enclosure fault tolerance.

- 5 disk enclosures with up to 300 disk modules at 28U in one rack
- 10 disk enclosures with up to 600 disk modules at 48U in two racks

Figure 1. IS16000 Product Variations

**7-Enclosure System**  
( 2 Controllers & UPS )  
( 5 Disk Enclosures )



**12-Enclosure System**  
( 2 Controllers & UPS )  
( 10 Disk Enclosures )



### 1.1.3 Features of the IS16000

The IS16000 incorporates the following features:

- 8GB/s full-duplex cache link
- Internal SAS Switching (480Gb/s Internal SAS Storage Network)
- Up to 600 SAS, SATA, or SSD disks with full redundant paths
- **InfiniBand™ (IB) or Fibre Channel (FC) Connectivity**  
For IB option, the two IS16000 Controllers provide up to eight (8) QDR InfiniBand host port connections.  
For FC option, the two IS16000 Controllers provide up to sixteen (16) individual 8Gb/s Fibre Channel host port connections, including simultaneous access to the same data through multiple ports. Each FC host port supports point-to-point and switched fabric operation.
- **Active/Active Operation with Cache Coherency and Failover**  
This architecture implements an active/active host presentation model with routing-based data access and full cache coherency.
- **Data Protection**  
The IS16000 RAID stack provides protection against single physical disk failures with RAID 1 or RAID 5 data protection as well as double physical disk failures through the use of high-speed RAID 6 protection.
- **Configurable RAID Group Sizes**  
(5 or 9 disks/RAID5 group, 6 or 10 disks/RAID6 group, 2 disks/RAID1 group)  
This feature allows you to configure the system with the desired RAID and redundancy levels based on the importance of your data. Each RAID group is configured independently and any valid combination for the number of disks in the array is supported.
- **SAS/SATA Storage Pool**  
This feature allows in-box storage pooling, where high performance SAS disks are used for primary data and high capacity SATA disks are used for secondary data or active archiving. Flexible configurations along with intermix of SATA and SAS disks within the same enclosure is supported. Although for performance and reliability reasons, there are best practice guidelines.
- **SATAssure™ Data Protection**  
SATAssure technology (Silent Data Corruption Detection and Avoidance) is designed to improve the reliability of enterprise SATA disks and make sure that data integrity is always mentioned for all I/O operations.
- **Battery Backed Write Back Cache**  
The IS16000 provides a write back cache feature that is used to improve I/O performance. Write back cache data that has not been written to disk is preserved by maintaining power to the cache memory in the event of an AC mains failure long enough to copy the contents of the cache to stable storage. In addition, the IS16000 is designed to tolerate a simultaneous AC mains failure and RAID software failure.
- **Mirrored Write Back Cache**  
Currently, the IS16000 provides the ability to mirror all write back cache data such that the failure of a single controller will not result in data loss. A storage administrator can optionally turn off write back cache mirroring for a RAID set (for higher performance); however data protection is reduced for logical units within that RAID set.
- **Mirrored Transaction Journal**  
RAID write holes are prevented by executing stripe updates as ACID (Atomicity, Consistency,

Isolation, Durability) transactions. If the transactions are interrupted by a power failure, they can be recovered from the transaction journal implemented within the write back cache when power is restored. This journal is mirrored so that when a simultaneous power failure and controller hardware failure occurs, the surviving controller can recover the transactions.

- **Metadata Mirrored n-Ways**

The IS16000 stores a copy of storage system metadata on 18 physical disks to minimize the likelihood that its metadata is lost or corrupted.

- **Partial Rebuild**

This feature reduces rebuild times by updating only the data that has changed while the disk was down. The IS16000 tracks the changes made to a RAID set when a member physical disk becomes unavailable. If that member becomes available again within a user-definable timeout, then only the stripes that were modified while the member was missing are rebuilt. This minimizes the mean-time-to-repair for the RAID set and thus limits any performance impact of a disk repair.

- **Hot-Swappable and Redundant Components**

Adhering to enterprise RAS standard, almost all hardware components (such as physical disks, power supply modules, and fan module) are redundant and hot-swappable.

- **Hot Spares**

The IS16000 provides pools of spare physical disks that can be automatically used to replace failed physical disks. By replacing a failed RAID set member automatically, the mean-time-to-repair for the RAID set is minimized resulting in improved data reliability.

- **Management Options via RS-232 and Ethernet (SSH)**

A RS-232 port and Ethernet ports are included to provide local and remote management capabilities.




## 1.2 The IS16000 System Hardware

This section describes the hardware components of the IS16000.

### 1.2.1 Controller


The IS16000 Controller is a three-unit (3U), rack-mountable enclosure (Figure 2).

Figure 2. IS16000 Controller Chassis




At the front, there are four fan modules, three internal disk modules, control buttons and status LED indicators (Figure 3).

Figure 3. IS16000 Controller Front View without Bezel



At the back, there are two power supply modules and various I/O connectors (Figure 4).


Figure 4. IS16000 Controller Rear View



### 1.2.1.1 Status LED Indicators

Figure 5 below illustrates the positions of all the control buttons and LED indicators on the front panel. The LEDs are defined in Figure 6. The USB port can be used for downloading new firmware and BIOS to the Controller.

Figure 5. Controller Front Panel Control Buttons and Status LED Indicators



**NOTE :**Do NOT use the Power button under normal operation since doing so may cause data loss. Use the UPS power switch instead if you need to power down the Controller.

Figure 6. Controller Status LED Indicators

Description	Color	Status
Power	Green	ON - power is applied to Controller enclosure OFF - no power is applied to Controller enclosure
Locate	Blue	Flashing at a 2-second interval - receiving "Locate Enclosure" command OFF - NOT receiving "Locate Enclosure" command
Enclosure Fault	Amber	ON - a fan failure, power supply failure, or over temperature condition occurred. A service action is required. OFF - no detectable faults


Figure 6. Controller Status LED Indicators

Description	Color	Status
HDD	Green	Flashes - indicates HDD activity OFF - no HDD activity
Ethernet ICL	Green	Flashes - indicates the corresponding ICL link is up and both Controllers are running OFF - no ICL activity
Network Activity	Green	ON - good connection is established on the corresponding Ethernet port Flashes - indicates activity

### 1.2.1.2 Fan Module

Each Controller is equipped with four fan modules (Figure 7). These fan modules provide redundant cooling system for the unit. If one module fails, the other three will maintain sufficient cooling for the enclosure. The faulty module will still be providing proper air flow for the enclosure so do not remove it until a new module is available for replacement.

Figure 7. Controller Fan Module




### 1.2.1.3 Power Supply Module

Each Controller includes two power supply modules (Figure 8). These modules are redundant and hot-swappable. If one module fails, the other module will maintain sufficient power to the enclosure. The faulty module will still be providing proper air flow for the enclosure so do not remove it until a new module is available for replacement.

The LED mounted on the module indicates the status of the power supply. It is green when the module is operating normally and turns off when a fault occurs.

Figure 8. Controller Power Supply Module




### 1.2.1.4 Internal Disk Modules

The IS16000 Controller includes three internal hard disks. Disk A and Disk B are mirrored system disks to run the Controller. The information on these 2 disks includes the Linux OS, the Controller software, the event log, and Controller-specific configuration (not storage configuration). Disk C is used for a large trace log<sup>a</sup>.

Each disk module comprises a single low profile 1.0-inch high, 3.5-inch form factor hard disk mounted in a carrier. The module handle provides camming of the module into and out of disk bays and positive “spring loading” of the disk/baseplane connector (Figure 9). The handle is released by pressing the handle release button.

Figure 9. Controller Internal Disk Module



### 1.2.1.5 RAID Processor

The IS16000 has two parallel, multi-threaded RAID engines that work simultaneously in each Controller for a total of 4 RAID Processors across the redundant Controller pair.

The two Controllers are redundant and hot-swappable which provide the intelligence and active/active data protection features of the IS16000. If a Controller fails, the remaining Controller will assume its functionality and continue to provide data access, at a reduced performance level.


---

a. The mirrored system disk feature is not yet implemented in V1.3.0.4. Currently, Disk A is the system disk and Disks B and C are not used.

### 1.2.1.6 I/O Ports

Figure 10 below illustrates the I/O ports on the back of the Controller.

Figure 10. Controller I/O Ports



The InfiniBand ICL and Ethernet ICL ports provide connections for Mirrored Write Back Cache and control between the Controllers in a couplet configuration.

The Disk I/O Channels are used for disk enclosure connections.


The RS-232 connector provides local system monitoring and configuration capabilities. The VGA monitor and USB keyboard ports can be used as an alternative to the RS-232 console. However, the RS-232 console is recommended since its output can be logged and its connection can be longer.

The UPS port is used for UPS connection.

The Management Network Ethernet port provides remote monitoring and configuration capabilities.


The RP0 and RP1 host ports (client channels) provide 8 Fibre Channel or 4 InfiniBand host connections on each Controller. The LED color schemes are described in Figure 11 and Figure 12.

Figure 11. FC Host Port LED Color Scheme



Yellow LED (8 Gbps)	Green LED (4 Gbps)	Red LED (2 Gbps)	Status
Off	Off	Off	Power off
On	On	On	Power on (before firmware init)
Flashing	Flashing	Flashing	Power on (after firmware init)
Yellow, Green, and Red LEDs flashing alternatively			Firmware error
Off	Off	On/Flashing	Online, 2 Gbps link / I/O activity
Off	On/Flashing	Off	Online, 4 Gbps link / I/O activity
On/Flashing	Off	Off	Online, 8 Gbps link / I/O activity
Flashing	Off	Flashing	Locate

Figure 12. IB Host Port LED Color Scheme



Description	Color	Status
Physical link	Green	ON - good physical link Flashing - indicates a problem with the link
Data activity	Yellow	ON - no data transfer Flashing - indicates data activity

## 1.2.2 Uninterruptible Power Supplies (UPS)

Each Controller within the IS16000 system is paired with a UPS to provide battery backup power when the AC mains fail. The UPS is a rack-mountable 1U unit.

Figure 13 below illustrates the positions of all the control buttons and LED indicators on the front panel. The DIP switches on the back panel are set at the factory and should only be changed by the SGI field engineer (Figure 14).

Figure 13. UPS Front View





Figure 14. UPS Rear View




### 1.2.3 Disk Enclosures

The IS16000 disk enclosure is an ultra dense four-unit (4U) 60-disk enclosure based on 3.5 inch SAS or SATA Hard Disk Drives (HDD)(Figure 15).

The enclosure includes a set of plug-in modules and (*as supplied*) comprises:

- Enclosure Chassis with front panel LED status indicator
- Two (2) Power Cooling (PCM) plug-in modules
- Two Input/Output (I/O) modules
- Up to 60 top loadable hard disk modules in a 5×12 matrix
- Eight (8) SAS Drive Expander Modules (DEM)

Figure 15. Disk Enclosure—Front and Rear Views



### 1.2.3.1 Disk Enclosure Chassis

The chassis assembly contains 60 disk bays at the front, each of which accommodates a plug-in disk module capable of holding a 3.5-inch SAS or SATA Hard Disk Drive (HDD) or Solid State Disk (SSD). The 60 disk bays are arranged in five rows of twelve disk modules (5×12) (Figure 16). At the rear, the chassis assembly contains two (2) power cooling modules and two (2) I/O modules (Figure 17).

The chassis is fitted with 19-inch rack mounting features which enables it to be installed into 19-inch wide racks and uses four (4) EIA units of rack space. A mid-plane separates the front and back of the chassis and provides the interconnect system between the power cooling modules, I/O modules, and the baseboard.

Figure 16. Disk Enclosure—Top View





Figure 17. Disk Enclosure—Rear View



### 1.2.3.2 Front Panel Indicators

The front panel indicators show the aggregated status of all the modules (Figure 18). The LEDs are defined in Figure 19. The Disk Activity LEDs indicate disk presence and flash during data I/O.

Figure 18. Disk Enclosure—Front Panel LED Indicators




Figure 19. Front Panel LED Description

LED	Definition	Color	Status
	System Power	Green	ON - DC power is present OFF - DC power is not present LED does NOT flash under normal operating conditions
	System Fault	Amber	ON - one or more components within enclosure have failed. A service action is required. Exact failed component has its own amber fault LED lit. OFF - no detectable faults
	Shelf Identify	Blue	Flashing - receiving “Locate Enclosure” command OFF - NOT receiving “Locate Enclosure” command
	Cover Open	Amber	OFF - both cover pieces securely closed and latched in place ON - either of the cover pieces is NOT securely closed and latched in place
	DEM Fault	Amber	OFF - all DEMs operating correctly ON - at least one DEM has failed; service action required
	Disk Fault	Amber	ON - one or more HDDs are failed; SES must determine exact HDD OFF - no detectable disk faults
Individually numbered	Disk Activity	Green	ON - SAS HDD is present Flashing - indicates HDD activity OFF - no HDD activity

### 1.2.3.3 Disk Modules

The disk module comprises a hard disk mounted in a carrier (Figure 20). Each disk bay can house a single low profile 1.0-inch high, 3.5-inch form factor disk drive in its carrier. A fully loaded enclosure contains 60 disk modules.

The module handle provides the following functions:

- Camming of the module into and out of disk bays
- Positive “spring loading” of the disk/baseplane connector
- Disk Status LED incorporated in handle assembly


---

**NOTE :**The disk enclosure design allows for disk bays to be left empty without the need for fitting dummy disk modules.

---

The disk enclosure supports a SATA interposer card which allows simultaneous access to the SATA HDD from both I/O modules installed in the enclosure. *Note that a SATA interposer card is required to run SATA HDDs.*


Figure 20. Disk Module



### 1.2.3.4 Power Cooling Module (PCM)

Two (2) power cooling modules are supplied with the disk enclosure, installed in the rear of the chassis (Figure 21).

Figure 21. Disk Enclosure Power Cooling Module



The disk enclosure must always be operated with two PCM installed. Module replacement should only take a few minutes to perform but must be completed within 5 minutes from removal of the failed module. Four (4) LEDs mounted on the PCM indicate the status of the module and the fans (Figure 22). Figure 23 provides a description of the color and status of the LEDs.

Figure 22. Power Cooling Module LEDs





Figure 23. disk enclosure PCM LED Description

LED	Description	Color	Status
	PCM AC	Green	ON - AC input to PCM within tolerances OFF - PCM failed
	PCM DC	Green	ON - DC output of PCM within tolerances OFF - PCM failed
	PCM Fault	Amber	ON - PCM fault detected OFF - no detected PCM faults
	PCM ID	Blue	Flashing - this module is receiving "Locate Power Supply" or "Locate Fan" command OFF - NOT receiving "Locate Power Supply" or "Locate Fan" command

### 1.2.3.5 I/O Module

The disk enclosure includes two plug-in I/O modules (Figure 24). Processors housed on the I/O modules provide enclosure management and interface to devices on the backplane, PCM, and front display panel in order to monitor internal functions.

Figure 24. A Disk Enclosure I/O Module



The four I/O ports provide connections to the IS16000 Controllers. The various LED indicators are listed in Figure 25.

Figure 25. I/O Module LED Description

Description	Color	Status
I/O port SAS Link	Green	ON - valid SAS link established OFF - no valid link
I/O port SAS Link Fault	Amber	ON - fault is detected on port OFF - no fault detected
OK	Green	ON - I/O module is functioning properly OFF - internal fault detected
Fault	Amber	ON - a fault is detected on I/O module OFF - no fault detected
Identify	Blue	Flashing - this module is receiving "Locate Expander" command OFF - NOT receiving "Locate Expander" command

### 1.2.3.6 Internal Indicators

For some components, the failure LED is internal to the enclosure and visible only when the cover is open. The various internal indicators are listed in Figure 26.

Figure 26. Internal LED Description


Description	Location	Color	Status
DEM DC	DEM internal to enclosure	Green	ON - 1.2VDC regulator circuit correctly functioning OFF - faulty 1.2VDC regulator circuit
DEM ID	DEM internal to enclosure	Blue	Flashing - receiving "Locate Expander" command OFF - NOT receiving "Locate Expander" command
HDD ID	HDD internal to enclosure	Blue	Flashing - this slot is receiving "Locate Slot" or "Locate Physical_Disk" command ON - Controller has determined that the HDD in this slot has failed or requires attention OFF - NOT receiving "Locate Slot" or "Locate Physical_Disk" command and HDD is functioning correctly

### 1.2.3.7 Drive Expander Module (DEM) Card

The disk enclosure contains eight (8) top-loadable, hot-swappable DEMs (Figure 27). The DEMs provide the SAS connectivity between the I/O modules and the HDDs located with the enclosure.


The DEMs are organized into four module pairs, with each module pair controlling a bank of 15 disks. If a DEM card fails, its sister card will provide continuous operation of the unit until a replacement is inserted bringing the unit back to full redundancy.

Figure 27. DEM Card Locations (Viewing from Top)



Each DEM (Figure 28) connects to a single port of the HDD based on the location within the enclosure within which it is installed. Each card provides power control signals to each disk slot. It controls HDD identify/service LEDs and monitors the status from partner DEM. Each pair of DEMs supports 15 disk modules.

Figure 28. DEM Card



# CHAPTER 2

---

*Installation*



## **2.1**      ***Installation Overview***

---

Here is an overview of all the steps needed to be taken to complete an installation and configuration of an IS16000 system.

1. Site preparation.
2. Unpack the IS16000 system.
3. Install the disk modules into the disk enclosures.
4. Verify zoning configuration on disk enclosures.
5. Connect the cables.
6. Power up the system.
7. Validate the hardware.
8. Configure the network interface settings via the RS-232 console.
9. Configure the IS16000 storage (create Storage Pools, Virtual Disks, Spare Pools, and presentations).

## 2.2 Site Preparation

This section provides information on how to prepare a site prior to installing a IS16000 system. The site preparation steps include:

- Delivery route verification
- Rack location, air flow, and access
- Floor loading
- Cooling supply planning
- AC power supply planning and verification

### 2.2.1 Delivery Route Verification

Each IS16000 system consists of one to two 19" racks. Each of these racks is shipped in a large crate on a pallet that weighs between 1000 lbs (454.55kg) and 1500 lbs (681.82kg) and measures 53" × 40" × 100.5" (1346mm × 1016mm × 2553mm) (Figure 29).

Each crate includes a ramp that can be used to remove the rack from the crate. A pallet jack must be used to move the crate from the delivery vehicle to a flat location that is at least 5' × 12' (1.52m × 3.66m) where the ramp can be installed and the rack can be rolled out of the crate. Due to the weight of the crate, it is essential that either the delivery vehicle is equipped with a lift gate or the destination has a loading dock with a lift.

Once a rack has been removed from the crate, it can be rolled to its destination. Racks are either 42U or 45U. The 42U racks are 81.75" (2077mm) tall and the 45U racks are 87" (2210mm) tall. Both type of racks are 28" (712mm) wide and 45.75" (1162mm) deep including the front and rear doors.

Note that the physical disk modules are shipped separately from the disk enclosures. The disk modules are packaged in separate boxes that are strapped to pallets. These pallets can be moved to the installation site using a pallet jack.

#### To Do List:

- Plan the unpacking location where the delivery vehicle will deliver the crate.
- Verify that the route to the installation site does not involve any steps.
- Verify that any elevator that is part of the route has sufficient door height and load capacity.
- Verify that the size of all the doorways along the delivery route is big enough for the pallet jack with the crate to pass through.
- Verify that there is enough space at the unpacking location to set up the ramps and remove the racks from the crates.

Figure 29. Crate Containing One IS16000 Rack



## 2.2.2 Rack Location, Air Flow, and Access

The racks that comprise a single IS16000 storage subsystem must be installed adjacent to one another so that the disk enclosure cables can be properly routed and connected. The airflow through the racks is from front to back. The front of one rack should not be near the back of another rack.

---


**NOTE :**Racks with more than 5 disk enclosures have an anti-tip plate installed at the floor level and it is important that it does not cover a cold air grill.

---

Access to the equipment in the racks is from their fronts and the backs. Front access is for physical disk, disk enclosure, controller chassis, and UPS maintenance. Rear access is for power supply and I/O module maintenance plus cabling.

The recommended service clearances are 48" (1220mm) from the front of a rack and 30" (762mm) between the back of an enclosure and a wall or 30" (762mm) between the back of a IS16000 system and the back of another enclosure that is exhausting hot air (Figure 30). No service clearance is required on the side of the rack.

Figure 30. IS16000 Service Area and Dimensions




### To Do List:

- Plan the location of the racks so that they have sufficient access and proper airflow. A scale drawing is recommended.

The best way to accomplish this is to create rows of racks that are side-by-side where each rack draws cool air from a 60" (1524mm) walking isle and blows hot air into a 48" (1220mm) maintenance isle (Figure 31).

Figure 31. Rows of Racks with Walking Isles and Maintenance Isles



### 2.2.3 Floor Loading

The IS16000 racks are heavy and it is important to verify that the weight does not exceed the floor specifications. SGI will provide an estimate of the weight of each rack on request.

A full 45U IS16000 rack with ten disk enclosures can weigh up to 2570lbs (1166kg). This weight is relatively evenly distributed across the four castors and/or leveling feet, so each will be subject to a load of 645 lbs. While the load from such a rack is  $289\text{lb}/\text{ft}^2$  ( $2570\text{lb} / 8.9\text{ft}^2$ ) underneath the rack, the average load is less given the space for isles. With the minimum size isles (48" in the front and 30" in the back), the load is  $156\text{lb}/\text{ft}^2$  ( $289\text{lb}/\text{ft}^2 \times 45.75" / \{45.75" + 48"/2 + 30"/2\}$ ).

The more common 42U IS16000 racks for 5 and 10 disk enclosure subsystems weigh approximately 1600 lbs and so the point load is only 400lbs and the floor loading is  $180\text{lb}/\text{ft}^2$  ( $1600\text{lb} / 8.9\text{ft}^2$ ). Accounting for the minimum isle space the load is  $98\text{lb}/\text{ft}^2$ .

#### To Do List:

- Verify with the building structural engineer that the floor structure is sufficient to hold the weight of the IS16000 racks configured as planned in Section 2.2.2.

### 2.2.4 Cooling Supply Planning

Each IS16000 45U rack can draw up to 14.5KW and generate 50KBTU/hour of heat.

Each IS16000 42U racks can draw over 8KW and 25KBTU/hour of heat.

Sufficient air conditioning must be provided to cool this heat load to a nominal room temperature of 25°C. SGI will provide an estimate of power and heat for each rack on request.

#### To Do List:


- Verify that the rack locations will have sufficient cooling.

## 2.2.5 AC Power Supply Planning and Verification

Each IS16000 rack has four to eight power cords that are designed to connect to 208 VAC or 230 VAC. SGI will provide a count of the power cords for each rack on request.

Each AC power cable has a NEMA L6-30P connector (Figure 32). Before the IS16000 racks can be installed, sufficient L6-30R receptacles for these AC power cables must be installed by an electrician. Each L6-30R receptacle should be connected to a 30 Amp circuit breaker.

Figure 32. L6-30R Wiring Diagram



These power cords can either be connected to two separate AC power sources (for example, utility power and UPS power) or to a single AC power source. That is, half the power cords provide sufficient power to operate the system, however, all power cords must be plugged to take advantage of redundant DC power supplies.

Each IS16000 Controller has a UPS that is used to protect its cached data in the event of a power failure. These must be configured with firmware and switch settings depending on the AC voltage and how the site power is grounded. This configuration is best done at the SGI factory and so it is helpful to provide these measurements to SGI as part of the order.

### To Do List:

- Each UPS unit has two DIP switches on the back. During installation, verify that the switches are correctly set as described in Section 2.6.7.

## 2.3 *Unpacking the IS16000*

---

The IS16000 system components are already installed in the rack(s).



Warning

**Wear an ESD wrist strap or otherwise ground yourself when handling IS16000 modules and components. Electrostatic discharge can damage the circuit boards.**

---

Before you unpack your IS16000, inspect the shipping container(s) for damage. If you detect damage, report it to your carrier immediately. Retain all boxes and packing materials in case you need to store or ship the system in the future.

While removing the components from their boxes/containers, inspect the IS16000 chassis and all components for signs of damage. If you detect any problems, contact SGI Technical Support immediately.

### 2.3.1 *Packing List*

The IS16000 ships with the following:

- Installed in the rack(s):
  - Two (2) Controllers
  - Two (2) UPS units
  - Four (4) 1-meter Ethernet ICL cables
  - Two (2) 1-meter InfiniBand ICL cables
  - Two (2) USB cables
  - Twenty (20) SAS cables
  - Five (5) or ten (10) disk enclosures
- Disk modules
- Two (2) serial cables
- Two (2) Ethernet cables

## 2.4 Installing the Disk Modules

The disk modules are shipped separately from the disk enclosures. To create a more balanced configuration, evenly distribute the disk modules among the disk enclosures. If a mixture of disk technologies, such as SAS and SATA, will be populated into the enclosures, it is best to populate the SAS disks into the front slots and install the SATA disks in the rear slots.



Warning

**Wear an ESD wrist strap or otherwise ground yourself when handling the disk modules and components. Electrostatic discharge can damage the circuit boards.**

Follow these steps to install a disk module:


1. Slide the enclosure out from the rack by squeezing the tabs on both rack slides. Keep pulling until the enclosure locks and you hear a clicking sound.
2. Disengage both enclosure cover latches (Figure 33) and open the covers.

Figure 33. Disk Enclosure Cover Latch



3. On the disk module, slide the latch backward to release the handle (Figure 34).

Figure 34. Release Disk Module Handle



4. Insert the module into a disk bay. Cam the disk module home. The camming foot on the base of the module will engage into the slot in the enclosure.
5. When the module is fully inserted, close the handle. You should hear a click as the latch engages and holds the handle closed.
6. After you have installed all the disk modules in this enclosure, close the enclosure covers and engage both cover latches.
7. Squeeze the tabs on both rack slides and push the enclosure back into the rack.

## 2.5 Verifying Zoning Configuration on Disk Enclosures

The disk enclosures must be zoned correctly. The zoning configuration is determined by the piano switches located behind the front bezel of the enclosure. Follow these steps to verify the zoning configuration on each disk enclosure:


1. Slide the enclosure out from the rack by squeezing the tabs on both rack slides. Keep pulling until the enclosure locks and you hear a clicking sound.
2. Remove the front bezel by removing the four screws (Figure 35).

Figure 35. Removing Disk Enclosure Front Bezel



3. Once the front bezel is removed, it is possible to see the piano switches through the grey bezel (Figure 36). If the switches are hidden by a Mylar switch cover, remove the cover with a small pair of tweezers. If the switches are still not visible, remove the grey bezel. It is attached to the chassis with 32 small screws (18 on the front and 14 on the bottom).

Figure 36. Zoning Configuration Piano Switches Behind Bezel



Piano Switches

4. Verify that the piano switches are correctly set.
 

For system with 5 disk enclosures (zoning configuration 1), the left-most piano switch should be up and the rest down. This divides the disk slots into two logical enclosures.

For system with 10 disk enclosures (zoning configuration 0), all the piano switches should be down. This connects all disk slots into one logical enclosure.

If a change is needed, remove the Mylar switch cover with a small pair of tweezers and then use a dental tool to move the switches. The tweezers and dental tool can be inserted through the grey bezel air holes. If changing the switches with a dental tool proves to be too difficult, then the grey bezel can be removed.
5. Replace the front bezel (and the grey bezel, if previously removed).
6. Push the enclosure back into the rack.
7. Repeat the above steps on all disk enclosures.


## 2.6 Cable Connections

### 2.6.1 Couplet ICL Cabling

There are two sets of Inter-Controller Link (ICL) connections between the two Controllers.

1. Verify that the two InfiniBand cables are attached to the ICL ports on the two Controllers as shown in Figure 37.
2. Verify that the four short Ethernet cables are attached to the Ethernet ports on the two Controllers as shown in Figure 37.

Figure 37. Inter-Controller Link Connections on Controllers



## 2.6.2 Disk Enclosure Cabling

The IS16000 systems are shipped with the cables attached between the disk enclosures and Controller's I/O channels. Incorrect wiring can prevent the system from operating correctly or from operating at all.

Verify that the disk enclosures are correctly connected to the two Controllers and secured using [Figure 38](#), [Figure 39](#), [Figure 40](#), and [Figure 41](#). The cables are labeled by ports to which they will be connected. In the illustrations, the port numbers are colored to aid in locating matching cables.

<a href="#">Figure 38</a>	Five 60-bay disk enclosures containing <i>ALL</i> SAS disks
<a href="#">Figure 39</a>	Five 60-bay disk enclosures containing <i>ALL</i> SATA disks or a mixture of SAS and SATA disks
<a href="#">Figure 40</a>	Ten 60-bay disk enclosures containing <i>ALL</i> SAS disks
<a href="#">Figure 41</a>	Ten 60-bay disk enclosures containing <i>ALL</i> SATA disks or a mixture of SAS and SATA disks

Figure 38. Connecting 5 Disk Enclosures (with SAS Disks Only) to Controllers





Figure 39. Connecting 5 Disk Enclosures (with SATA and SAS Disks) to Controllers



*Note: Do NOT connect the cables to the ports that are not labeled.*

Figure 40. Connecting 10 Disk Enclosures (with SAS Disks Only) to Controllers





Figure 41. Connecting 10 Disk Enclosures (with SATA and SAS Disks) to Controllers




*Note: Do NOT connect the cables to the ports that are not labeled.*

### 2.6.3 Management Network Connection

You may remotely monitor the system over your Ethernet network. Connect the Controllers to your network using the Ethernet port as shown in Figure 42. The Ethernet management port supports 10, 100, and 1000BASE-T rates.

Figure 42. Ethernet Connections to Your Network



### 2.6.4 Host Connections


Connect the Controller host ports shown in Figure 43 either directly to your hosts or to a switch that connects your hosts. Depending on your IS16000 model, these connections may be Fibre Channel or InfiniBand.

---

**NOTE :**Do NOT use the unused Inter-Controller Link connectors to connect InfiniBand hosts or switches.

---


Figure 43. Host Ports on Controllers



### 2.6.5 RS-232 Console Connection

Connect a null modem cable between a PC and the RS-232 connector on the back of the Controller (Figure 44). The RS-232 console is used to configure the management network ports during initial configuration. However, it can also be used to log the console output and upgrade the BIOS/BMC/CONFIG firmware.


Figure 44. Connect RS-232 Console to Controller



## 2.6.6 UPS Connection

1. For each Controller, verify that a USB cable is attached to the port on the back of the Controller and its UPS as shown in [Figure 45](#).
2. For each Controller, verify that the two power cables are attached to the Controller's power supplies and its UPS as shown in [Figure 45](#).

Figure 45. Connect UPS to Controller




### 2.6.6.1 UPS Battery

The UPS units are shipped with the batteries disconnected. Follow these steps to connect the batteries:

1. Remove the front bezel of the unit.
2. Fasten the two connectors together ([Figure 46](#)). *Note that it is normal if you see a spark and hear a pop sound as you connect the battery.*
3. Replace the front bezel.
4. Repeat the above steps on the other UPS.

Figure 46. Connect UPS Battery



## 2.6.7 Power Connections


1. Verify your AC power source by measuring the AC voltage.
2. Refer to the illustrations in [Figure 47](#) and verify that the DIP switches on the back of the UPS units are correctly set. If the settings are incorrect, have an SGI field engineer correct them.

---

**NOTE** :Changing the voltage of the UPS requires more steps than just changing the DIP switches.

---

Figure 47. DIP Switch Settings on UPS Rear Panel




3. Verify that the power switches on all the power distribution units (PDUs) are set to OFF.
4. Connect the PDUs to your AC power source. For maximum redundancy, connect the PDUs to different AC circuits.

## 2.7 Powering On the System


1. Switch on all the PDUs.
2. Switch on the power supply modules on all the disk enclosures.
3. Press and hold the Power button for 2 seconds on the front panel of both UPS to turn on the units (Figure 48).

Figure 48. UPS Front Panel



4. Verify that the Power OK LED on both UPS units turns green and the Load Segment 1 LED turns yellow (Figure 48), indicating a successful power application.
5. Verify that the Power indicator on both Controllers turns green (Figure 49). If not, press the Power button once.
6. Verify that the Fault LED on both Controllers is off (Figure 49).

Figure 49. Controller Front Panel LEDs



You may now configure the system as described in Section 2.8 "Configuring the IS16000".

## 2.8 *Configuring the IS16000*

---

This section provides information on configuring your IS16000.

---

**NOTE :**The configuration examples provided here represent only a general guideline. These examples should not be used directly to configure your particular IS16000.

The CLUI (Command Line User Interface) commands used in these examples are fully documented in [Chapter 3](#)—however, exact commands may change depending on your firmware version. To access the most up-to-date commands, use the CLUI’s online HELP feature.

The CLUI commands are independent of case. Most of the keywords can be abbreviated and most of the punctuations are optional. For example, “SHOW VD 0 ALL” is adequate for “SHOW VIRTUAL\_DISK=0 ALL\_ATTRIBUTES”

---

### 2.8.1 *Planning Your Setup and Configuration*

Before proceeding to configure the storage settings for the IS16000, it is necessary to understand the basic organization of the system.

#### 2.8.1.1 **Storage Pools and Spare Pools**

The disks in the system are categorized into one of the following pools:

- Unassigned Pool - By default, all the disks or replacement disks are initially allocated to this pool. When a disk has failed or been released (from a Spare Pool, for example), it is also moved to this pool.
- Storage Pool (sometimes referred to as a RAID group) - A collection of 2 to 10 disks, ideally of the same capacity and type.
- Spare Pool - This type of pool contains disk(s) that can be used as spare disks in one or more Storage Pools.

### 2.8.1.2 Storage Pools and Virtual Disks

A Virtual Disk is the storage unit presented to any attached host. Virtual Disks allocate space in 8GiB increments. For example, 16GiB of storage space will be allocated when creating a Virtual Disk of 10GiB.

The IS16000 uses Storage Pools and Virtual Disks to configure disk storage for use by host systems. A Storage Pool (sometimes referred to as a RAID group) is a collection of 2 to 10 physical disks, ideally of the same capacity and type. In RAID5, the capacity of one disk is reserved for parity, allowing data recovery in the event of a single disk loss in the Storage Pool. In RAID6, the capacity of two disks is reserved for parity, allowing data recovery if either one or two disks are down in a Storage Pool. In RAID1, the capacity of one disk is used for data duplication.

A single RAID1 Storage Pool can be configured with 2 disks. A single RAID5 Storage Pool can be configured using 5 or 9 disks. A single RAID6 Storage Pool can be configured using 6 or 10 disks.

---

**NOTE** :Although a Storage Pool can be configured with disks of different capacity, in which case the IS16000 will use the lowest capacity for all disks, this is **NOT** recommended.

---

### 2.8.1.3 WWN Node Names for Controller Ports

If your SAN configuration requires unique world-wide name (WWN) node names on each controller port, set the controller channels (ports) to MAC mode. Use the following command:

**APPLICATION SET CHANNEL [0|1|2|3] MODE MAC**


See section 3.4.5, "Additional Configuration Considerations for Macintosh Hosts" and other Mac OS notes for details.

## 2.8.2 Disk Module Layout

Figure 50 shows the layout of disks in a disk enclosure. Disks are always referenced by enclosure ID and slot number as illustrated. The disk layout may also be found inside the covers of the enclosure.

The IS16000 supports any mix of SAS and SATA disks. For most efficient airflow and reduced vibrations, SAS disks should be placed in the front of the enclosure (lower slot numbers) while SATA disks should be placed in the rear of the enclosure (higher slot numbers).


Figure 50. Disk Enclosure Disk Module Layout



### 2.8.3 Serial Interface Configuration

1. Connect the supplied null modem cable between a PC and the RS-232 connector on the back of the Controller (Figure 51).

Figure 51. RS-232 Port on Controller



2. Load a serial console program (such as HyperTerminal, minicom, and screen) and use the following settings for the serial connection:
  - Bits per second: 115,200
  - Data bits: 8
  - Parity: None
  - Stop bits: 1
  - Flow control: None
3. Once connected, press the <Enter> key to bring up the login prompt. Enter the user name **user** and password **user**.

## 2.8.4

**Validate the Hardware**

1. Enter: **SHOW CONTROLLER \***  
Verify that both Controller can be seen (Figure 52).

Figure 52. Show Controller Status

```
RAID[0]$ show controller *
OID: 0x38000000 Index: 0000 Name: A LOCAL PRIMARY
OID: 0x38000001 Index: 0001 Name: B REMOTE SECONDARY
Total Controllers: 2
```

2. Enter: **SHOW ENCLOSURE \***  
Verify that all the disk enclosures can be seen and contain consistent firmware versions.
3. Enter: **SHOW FAN \***  
Verify that no fan faults are found.
4. Enter: **SHOW POWER \***  
Verify that the “AC Fail” and “DC Fail” states are false.
5. Enter: **SHOW TEMPERATURE \***  
Verify that all the temperature sensors do not report over temperature conditions.
6. Enter: **SHOW PHYSICAL\_DISK \***  
Verify that all the disks can be seen and are healthy (Figure 53).

Figure 53. Show Physical Disk Status

```
RAID[0]$ show pd *
                                     |Health|
Encl|Slot|Vendor| :::::::::::::::::::::State|Idx|State| ::::::
-----
  1   1 HITACHI ::::::::::::::::::::: GOOD   6 NORM  ::::::
  1   2 HITACHI ::::::::::::::::::::: GOOD   1 NORM  ::::::
  1   3 HITACHI ::::::::::::::::::::: GOOD   5 NORM  ::::::
::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::
Total Physical Disks:   300
Total Assigned Disks:   0
Total Unassigned Disks: 300
Total SAS Disks:        300
Total Member State Normal: 300
```

7. Enter: **SHOW UPS \***  
Verify that the UPS batteries are healthy. Also take note of the charge level as the battery may take several hours to fully charge.

## 2.8.5

**Clear System Configuration**

**Use of the CLEAR SUBSYSTEM CONFIGURATION command will destroy any existing data.**

To ensure that you are starting from a fresh/clean install, enter:

**CLEAR SUBSYSTEM CONFIGURATION**

Then enter **YES** twice to confirm deletion of current configuration (Figure 54).

Figure 54. Clear Subsystem Configuration

```
RAID[0]$ clear subsystem configuration
Are you sure you want to delete this configuration [No]? yes
Are you sure you want to delete this configuration?
All data will be lost [No]? yes
RAID SUBSYSTEM CONFIGURATION cleared STATUS='Success' (0x0)
```

## 2.8.6

**Set System Time & Date (NTP)**

NTP (Network Time Protocol) mode is available on the IS16000. You can enter up to four NTP addresses as the time servers.

To enable the NTP mode, enter the command:

**SET SUBSYSTEM NTP=[<ip address list, up to 4>|NONE]**

Specifying a list of NTP addresses will start the NTP mode on each Controller, using that list of NTP addresses as the time servers. Specifying **NONE** will turn off NTP mode.

To display the current settings, enter the command(Figure 55):

**SHOW SUBSYSTEM ALL\_ATTRIBUTES**

Figure 55. Show NTP Settings

```
RAID[0]$ show subsystem all
*****
*   Subsystem   *
*****
RP Subsystem Name:    co-test-8
UID:                  60001ff0800a3000000000030000000
Subsystem Time:      Mon Sep 27 17:08:59 2010
Locate Dwell Time:   120 seconds
Enabled Licenses:    RAID6 SATASSURE
Fast Timeout:        ON
Pool Verify Priority: 10%
NTP Mode:             ON
                    (10.32.16.24)
                    (10.32.16.25)
                    (10.32.16.26)
                    (10.32.16.27)
Mon Sep 27 17:08:59 2010
```

If you are not using NTP, you can set the time of both Controllers using the **SET SUBSYSTEM DATE\_AND\_TIME** command. However, once the time is set, the time on the two Controllers is free to drift independent of the other Controller. To change the date and time to March 1, 2010 2:15 pm, for example, type: **SET SUBSYSTEM DATE\_AND\_TIME=2010:3:1:14:15**

**NOTE** :If NTP mode is enabled, the **SET SUBSYSTEM DATE\_AND\_TIME** command will fail with a status of “Setting date/time while in NTP mode”.



## 2.8.9 Create Storage Pools

A Storage Pool on a IS16000 has the following attributes:

- **RAID Level (RAID)**  
Storage Pools can be configured to use either a RAID1, RAID5 or RAID6 parity scheme. In RAID1, the capacity of one disk is used for data duplication. In RAID5, the capacity of one disk is reserved for parity, allowing data recovery in the event of a single disk loss in the Storage Pool. In RAID6, the capacity of two disks is reserved for parity, allowing data recovery if either one or two disks are down in a Storage Pool. **For maximum data protection, use RAID6.**
- **Chunk Size (CHUNK)**  
The chunk size (in KiB blocks) defines the amount of data written to a single disk before proceeding to the next disk in the Storage Pool.

---

**NOTE :**RAID1 is a two member RAID set where the data is mirrored on each disk. There is no parity, hence, the chunk size is fixed.

---

- **Disk Count (NUMBER)**  
A RAID1 Storage Pool may consists of 2 physical disks. A RAID5 Storage Pool may consist of 5 or 9 physical disks. A RAID6 Storage Pool may consist of 6 or 10 physical disks. For maximum performance, select disks with the same characteristics (such as SAS/SATA, capacity, and RPM).

To create a Storage Pool, use the **CREATE POOL** command:

1. At the CLUI prompt, type:  

```
CREATE POOL RAID_LEVEL=[raid1|raid5|raid6]
CHUNK_SIZE=[32|64|128|256] {ASSIGN_POLICY=[SAS|SATA]
NUMBER=[2|5|6|9|10] or PHYSICAL_DISK=<list of disks>}
INIT_ALLOW=<initialization policy>
SATASSURE=[NONE|DATA_INTEGRITY_FIELD|PARITY]
where <list of disks>=index name of disks; <initialization policy>=Allow_IO, NO_IO,
Priority (1-99, where 99 puts all system resources on the initialization).
```

You may either explicitly select the disks for the pool by using “**PHYSICAL\_DISK=**” or specify the number of disks in the pool by using “**NUMBER=**” in which case the next available disks will be selected (Figure 59). You may disable the SATAssure feature or enable it to use either the data integrity field option or the parity check on read option.

Figure 59. Create Storage Pool Example (1)

```
RAID[0]$ create pool raid_level=raid5 chunk_size=64kb physical_disk=0x6c, 0x6d, 0x6e, 0x6f, 0x70
POOL 0 OID=0x19b60000 create STATUS='Success' (0x0)

RAID[0]$ create pool raid_level=raid6 chunk_size=128kb number=6
POOL 1 OID=0x19b80001 create STATUS='Success' (0x0)
```

If you specify the **ASSIGN\_POLICY** and **NUMBER** parameters together (Figure 60), only the selected type of disks will be used for the Storage Pool and you will not need to enter the individual disk name.

Figure 60. Create Storage Pool Example (2)

```
RAID[0]$ create pool raid_level=raid6 chunk_size=128kb number=6 assign_policy=sas
POOL 2 OID=0x19b80002 create STATUS='Success' (0x0)
```

- Use the **CREATE POOL** command to add more Storage Pools as needed.  
If you need to delete a Storage Pool, use the **DELETE POOL <pool-id>** command.

**NOTE :**Storage Pool initialization is a background process and multiple Storage Pools can be initialized simultaneously. However, Virtual Disks on a Storage Pool are NOT accessible until its initialization is complete.

You may assign a name to a Storage Pool using the command:  
**SET POOL=<pool-id> NAME=<pool name>**

To view the list of configured Storage Pools, enter the **SHOW POOL \***  command (Figure 61).

Figure 61. Show Pool Information Screen

```
RAID[0]$ show pool *
```

Idx	Name	State	Chunk	Raid	Faults	Total cap GB	Free cap GB	Max VD GB	Settings	Jobs	Disk T/O	Global spare pool	Spare Policy
0	pool-0	NORMAL	128	5		4104	0	0	W R F I		10	UNASSIGNED	AUTO
1	pool-1	NORMAL	128	5		4104	0	0	W R F I		10	UNASSIGNED	AUTO
2	pool-2	NORMAL	128	5		4104	0	0	W R F I		10	UNASSIGNED	AUTO
3	pool-3	NORMAL	128	5		6192	0	0	W R F I I		10	UNASSIGNED	AUTO

Total Storage Pools: 6

To display the detailed information of a Storage Pool, use the **SHOW POOL <id> ALL\_ATTRIBUTES** command (Figure 62).

Figure 62. Show Pool All\_Attributes Example Screen

```
RAID$ show pool=0 all
Index: 0
OID: 0x19e50000
Type: STORAGE
Name: pool-0
Chunk Size: 128KB (0x100 blocks)
Block Size: 512
RAID Type: RAID5
Free Raid5 Capacity: 0 GB
Max VD Size: 0 GB
Total Capacity: 600 GB
UUID: 6000000000000000000000000000180d0000
Global Spare Pool: UNASSIGNED
DiskTimeout(FRT): 10 minutes
Init Policy: ALLOW_IO
Init Priority: 50%
Full Rebuild Priority: 80%
Fractional Rebuild Priority: 90%
Sparing Policy: AUTOMATIC
Verify Policy: DISABLED
Assign Policy:
Device Type: SATA
Rotation Speed: NA
Raw Capacity: NA
SATAssure: None
Cache Settings:
ReACT: FALSE
IO Routing: TRUE
Mirroring: TRUE
Read Ahead: TRUE
Write Back: FALSE
Initializing: TRUE
Rebuilding: FALSE
Paused: FALSE
AutoWriteLock: FALSE
Critical: FALSE
Forced Write-Thru: FALSE
Current Home: 0x38000000 0x00000000 (LOCAL)
Future Home: 0xffffffff 0x00000000
Preferred Home: 0x38000000 0x00000000 (LOCAL)
BkgdJob OID: 0x28000003
BkgdJob Priority: 50%
Total Phy Disks: 5
State: NORMAL
Member Size: 120 GB
pID State UID
0x0001 NORM 0x5000cca215c56e47
0x0002 NORM 0x5000cca215c56456
0x0003 NORM 0x5000cca215c54c71
0x0004 NORM 0x5000cca215c5675c
0x0005 NORM 0x5000cca215c56e55
```

## 2.8.10 Create Virtual Disks

A Virtual Disk can be created to use all or a part of a Storage Pool.

To create a Virtual Disk, use the **CREATE VIRTUAL\_DISK** command:

- At the CLUI prompt, type:  
**CREATE VIRTUAL\_DISK POOL=<pool-id> CAPACITY=<capacity>**

where <pool-id> is the Storage Pool to be used by this Virtual Disk; <capacity> is the capacity of the Virtual Disk in GiB or type “max” to use all available capacity (Figure 63).

A message is displayed to indicate whether the Virtual Disk creation was successful.

Figure 63. CREATE VIRTUAL DISKS Example Screen

```
RAID[0]$ create virtual_disk pool=0 capacity=16
VIRTUAL_DISK 0 OID=0x89ba000 creation STATUS='Success' (0x0)

RAID[0]$ create virtual_disk capacity=32 pool=0
VIRTUAL_DISK 1 OID=0x89bb001 creation STATUS='Success' (0x0)
```

- Use the **CREATE VIRTUAL\_DISK** command to add more Virtual Disks as needed.

If you need to delete a Virtual Disk, use the **DELETE VIRTUAL\_DISK <virtual disk-id>** command.

You may assign a name to a Virtual Disk :

**SET VIRTUAL\_DISK=<virtual disk-id> NAME=<virtual disk name>**

To view the list of configured Virtual Disks, use the command **SHOW VIRTUAL\_DISK \*** (Figure 64).

Figure 64. Show Virtual Disk Information Screen

```
RAID[0]$ show virtual_disk *
```

Idx	Name	State	Pool	Raid	Cap GB	Settings	Jobs	Home			Background Job
								Current	Preferred	Future	
0	vd-0_0	READY	0	5	3632	W I		0(L) 0	0(L) 0	None	INACTIVE
1	vd-1_1	READY	1	5	3632	W I		0(L) 0	1(R) 0	1(R) 0	INACTIVE
2	vd-2_2	READY	2	5	3632	W I		0(L) 0	0(L) 0	None	INACTIVE
3	vd-3_3	NOT RDY	3	5	5480	W I I		0(L) 0	1(R) 0	1(R) 0	0x28000003

Total Virtual Disks: 4

To display the detailed information of a Virtual Disk, use the command:

**SHOW VIRTUAL\_DISK=<id> ALL\_ATTRIBUTES** (Figure 65).

Figure 65. Show Virtual\_Disk All\_Attributes Example Screen

```
RAID[0]$ show vd=0 all
Index:          0
OID:            0x880f0000
Name:           vd-0_0
Pool Index:     0
Pool OID:       0x180d0000
.
.
.
Current Home:   0x38000000 0x00000000 (LOCAL)
Future Home:    0xffffffff 0x00000000
Preferred Home: 0x38000000 0x00000000 (LOCAL)
BkgdJob OID:    INACTIVE
UUID:          600000000000000000000000000000880f0000
```

## 2.8.11 Create and Assign Spare Pools

The IS16000 supports the concept of Spare Pool. A Spare Pool contains physical disks that can be used as spare disks in one or more Storage Pools.

In the event of disk failure, a disk that is assigned to a Spare Pool is automatically swapped into the Storage Pool to replace the failed disk. A rebuild then occurs immediately, reducing the possibility of data loss due to additional disk failures.

Spare Pools can be shared by Storage Pools or dedicated to a particular Storage Pool in which case the spare disks will only be used by the designated Storage Pool. After a Spare Pool is created, you will need to select disk(s) from the Unassigned Pool and assign it to the Spare Pool.

Follow these steps to create a Spare Pool:

1. At the CLUI prompt, enter the command: **CREATE SPARE\_POOL** (Figure 66)

A message is displayed to indicate whether the new Spare Pool creation was successful.

Figure 66. Create Spare Pool Example Screen

```
RAID[0]$ create spare_pool
SPARE_POOL 6 OID=0x19bc0006 create STATUS='Success' (0x0)
```

2. Assign physical disk(s) to the Spare Pool. Enter the command: **ASSIGN PHYSICAL\_DISK=<disk-id> TO\_POOL=<pool-id>** where <disk-id> is the index name of the disk to be added and <pool-id> is the index name of the Spare Pool.

A message is displayed to indicate whether the disk has been added to the Spare Pool (Figure 67).

Figure 67. Assign Physical Disk to Spare Pool Example Screen

```
RAID[0]$ assign physical_disk=648 to_pool=6
PHYSICAL_DISK 648 OID=0x22b10288 assigned to POOL 6 OID=0x19bc0006STATUS='Success' (0x0)
```

To view the list of available disks, enter the command:

**SHOW UNASSIGNED\_POOL PHYSICAL\_DISK**

3. Use the **CREATE SPARE\_POOL** and **ASSIGN PHYSICAL\_DISK** commands to create more Spare Pools as needed.

If you need to delete a disk from the Spare Pool, enter the command:

**ASSIGN PHYSICAL\_DISK=<disk-id> TO\_POOL=0x1800ffff**

To delete a Spare Pool, enter the command:

**DELETE SPARE\_POOL=<pool-id>**

4. You may assign a name to a Spare Pool using the command: **SET SPARE=<spare pool-id> NAME=<name>**
5. To view the list of configured Spare Pool(s), enter the command: **SHOW SPARE\_POOL \*** (Figure 68).



## 2.8.12 Present Virtual Disk to External Host

Virtual Disks are only presented to the hosts that have been given authorized access. A Presentation on a IS16000 has the following components:

- **Discovered Initiators**  
A Discovered Initiator is defined as a Fibre Channel or InfiniBand initiator that has logged into the IS16000. This is normally a single port on a Fibre Channel or InfiniBand HBA in an external computer.
- **Host**  
A Host is an abstract client of a Virtual Disk that has all the access to all data within the Virtual Disk. This most commonly represents an external computer with one or more Fibre Channel or InfiniBand initiators. Host attributes are OS (operating system) of which you can select GENERIC, WINDOWS, LINUX or MAC\_OS. The OS attribute dictates the way the controller responds to certain Fibre Channel commands where appropriate. For example, Mac OS X expects a different response from an inquiry of LUN0 (the controller LUN) than a Windows host.
- **Channel**  
A Channel is one of the Fibre Channel or InfiniBand ports on the Controller. Channel attributes are MODE of which you can select either MAC\_OS or STANDARD. When MAC\_OS is selected, the port's node name will be set differently in order to be visible to a Macintosh system.
- **Stack**  
A Stack is the input side of the subsystem. In the case of the IS16000, the stack is defined as the Fibre Channel interface. In future versions of the product, different interface stacks may exist.
- **Presentation**  
A Presentation is the relationship between a Host and a Virtual Disk. A Presentation implies that the related Host has some sort of access to the Virtual Disk. Attributes of a Presentation are:
  - PORT: from which the host will see the Virtual Disk
  - READ\_ONLY: controls read only access
  - PRESENT\_HOME\_ONLY: presents the specified Virtual Disk from its designated home controller only
  - LUN: user-specified LUN number that the Virtual Disk will show to the host.

Follow these steps to set up a presentation:

1. To display the currently available initiators, enter the command (Figure 72):

**APPLICATION SHOW DISCOVERED\_INITIATORS \***

Figure 72. Display Available Initiators

```
RAID$ app show discovered_initiators *
```

Index	Type	ID	Initiator node	Identifier port	Controller 0		Controller 1	
					RP 0	RP 1	RP 0	RP 1
00001	FC	0x0000e8	0x2001001b32ae096c	0x2101001b32ae096c			3	
00002	FC	0x0000e8	0x2001001b32aeb580	0x2101001b32aeb580				0
00003	FC	0x0000e8	0x2001001b328e0280	0x2001001b328e0280			2	
00004	FC	0x0000e8	0x2001001b32ae176c	0x2001001b32ae176c				1
00005	FC	0x0000e8	0x2001001b328eb580	0x2001001b328eb580		0		
00006	FC	0x0000e8	0x2001001b32aeb280	0x2001001b32aeb280	2			
00007	FC	0x0000e8	0x2001001b328e176c	0x2001001b328e176c		1		
00008	FC	0x0000e8	0x2001001b328e096c	0x2101001b328e096c		3		

Total FC Initiators: 8

2. Create a host. Enter the command (Figure 73):  
**APPLICATION CREATE HOST NAME=<host name>**  
**OSTYPE=[ LINUX | WINDOWS | MAC\_OS | DEFAULT | GENERIC ]**  
 where <host name> is an assigned host name to help make mapping simpler for the user; <os type> is the mode which can be set to characteristics specific to an Operating System, especially for Mac OSX.

Use the **APPLICATION CREATE HOST** command to create more hosts as needed.

If you need to delete a host, use the **APPLICATION DELETE HOST=<host-id>** command.

To display the current settings, enter the command: **APP SHOW HOST \***

Figure 73. Create Host Examples

```
RAID$ app create host name=server1-port1 ostype=linux
HOST 0 OID=0x18d0000 creation STATUS='Success' (0x0)

RAID$ app create host name=server1-port2 ostype=linux
HOST 1 OID=0x18e0001 creation STATUS='Success' (0x0)

RAID$ app show host *
-----
Index|Host Name          |Stack| Host Mode Attributes |
      |                   |Index| OS Type |Characteristics|
-----|-----|-----|-----|-----
00000 server1-port1   |00000| LINUX  | 0x0000000000000001
00001 server1-port2   |00001| LINUX  | 0x0000000000000001
-----|-----|-----|-----|-----
Total Hosts: 2
```

3. Map a host to a discovered initiator. Enter the command (Figure 74):  
**APPLICATION IMPORT DISCOVERED\_INITIATOR=<initiator-id>**  
**HOST=<host-id>**  
 where <initiator-id> is the index name of the discovered initiator;  
 <host-id> is the index name of the host.

Figure 74. Map a Host to a Discovered Initiator

```
RAID$ app import discovered_initiator=6 host=0

INITIATOR 0 OID=0x280f0000 imported from DISCOVERED_INITIATOR 6 oid=0x30000006
STATUS='Success' (0x0)
```

Use the **APPLICATION IMPORT** command to map the other hosts to the initiators as needed.

To display the current mappings, enter the command (Figure 75):

**APPLICATION SHOW INITIATOR \***

Figure 75. Show Current Imported Initiators

```
RAID$ app show initiator *
-----
Index |Type|Host |          Initiator Identifier          |
      |    |Index| node | port |
-----|-----|-----|-----|-----
00000  FC  00000 0x2001001b32aeb280 0x2001001b32aeb280
-----|-----|-----|-----|-----
Total FC Initiators: 1
```

4. Present the Virtual Disks to the hosts. Enter the command (Figure 76):  
**APPLICATION CREATE PRESENTATION HOST=<host-id>**  
**VIRTUAL\_DISK=<vd-id> LUN=<LUN-id>**

where <host-id> is the index name of the host; <vd-id> is the Virtual Disk to be presented; <LUN-id> is the LUN that the specified Virtual Disk will be presented as or use the default value if it is not specified.

Figure 76. Create a Presentation

```
RAID$ app create presentation host=0 vd=0 lun=0
PRESENTATION 0 OID=0x0x20110000 creation STATUS='Success' (0x0)
```

To simply present the Virtual Disk to all host ports for both Controllers (promiscuous mode), use this command:

```
APPLICATION CREATE PRESENTATION VIRTUAL_DISK=<vd-id> HOST=ALL
```

Use the **APPLICATION CREATE PRESENTATION** command to configure other presentations as needed.

To display the current settings, enter the command (Figure 77):

```
APPLICATION SHOW PRESENTATION *
```

Figure 77. Show Current Presentations

```
RAID$ app show presentation *
Pres. | Host      Host | VD | Home | Read | Channel Mask
Index | Name      Index | Index | LUN | Only | Only | Controller 0 | Controller 1
      |          |      |      |     |      |      | RP 0 | RP 1 | RP 0 | RP 1
-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----
00000 server1-port1 00000 00000 000 OFF R/W f f f f
Total Presentations: 1
```

### 2.8.12.1 Special Considerations for MAC OS

Apple's Mac OS X Server does not adhere to the FC specification with regards to node naming. Apple expects the node name to vary from port to port while the FC specification calls for it to remain constant. A mode setting is provided to force the node name to be unique on a given client channel (Fibre Channel port). This mode can be set for one or more client channels. While the feature is aimed at Mac SANs, it can also be used for connections to heterogeneous client SANs.

When creating the host, specify the **OSTYPE** to be **MAC\_OS**:

```
APPLICATION CREATE HOST OSTYPE=MAC_OS
```

Refer to Section 3.4.5, "Additional Configuration Considerations for Macintosh Hosts" for more information.

### 2.8.12.2 Selective Presentation

By default, a LUN is accessible via all initiators/ports. You may mask a presentation and choose the specific port on which the initiator may have access to the LUN.

You may mask a presentation when you create it:

```
APPLICATION SET PRESENTATION HOST=<host-id> VIRTUAL_DISK=<vd-id>
LUN=<LUN-id> ENABLE=<mask option>
```

By selecting the **ENABLE** option, you are choosing the specific port on which the initiator may have access:

- Controller 0 RP0: **ENABLE=0**
- Controller 0 RP1: **ENABLE=1**
- Controller 1 RP0: **ENABLE=2**
- Controller 1 RP1: **ENABLE=3**

To mask a LUN to all ports, use **ENABLE=ALL**.

To change a mask, you must first reset it with **ENABLE=NONE**.

To mask a LUN to multiple ports, you must set one port at a time. For example, to mask the same LUN 4 to Controller 0, RP0 and Controller 1, RP1:

- APP SET PRESENTATION=4 ENABLE=0**
- APP SET PRESENTATION=4 ENABLE=3**

### 2.8.13 Storage Pool Initialization

When a Storage Pool is created, initialization begins automatically and will continue in the background until it is completed. While its Virtual Disk(s) can be accessed immediately, the performance of the virtual disks will be degraded while it continues to initialize.

To monitor the progress of a job, use the **SHOW JOB \* ALL\_ATTRIBUTES** command. It will display the type of job and the percentage of completion (Figure 78).

Figure 78. Show Job Example Screen

```
RAID[0]$ show job * all_attributes
OID:          0x2e040001 (Index:1)
Target:       POOL:0x1aa00001 (Index:1)
Sub-Target:   NA
Type:         INITIALIZE
State:        RUNNING
Completion Status:UNKNOWN
Priority:      50
Fraction Complete:71%
Time:         NA
```

You may also check if a Virtual Disk is ready for access using the **SHOW VIRTUAL\_DISK <id> ALL\_ATTRIBUTES** command (Figure 79).

Figure 79. Show Virtual Disk Example Screen

```
RAID[0]$ show virtual_disk 0 all_attributes
OID:          0x89ba0000
Name:         89ba0000
POOL OID:     0x19b40003
Capacity:     16384 MBs
Offset:       0x0
State:        READY
Raidlevel:   RAID5
IO ROUTING:  TRUE
WBC:         TRUE
MWBC:        FALSE
Initializing: FALSE
Paused:      FALSE
AutoWriteLock: FALSE
Data Lost:   FALSE
Present Home Only:FALSE
.
.
.
```

# CHAPTER 3

## *Administration*

---



## 3.1 Managing the IS16000

The IS16000 provides a set of tools that enable administrators to centrally manage the network storage and resources that handle business-critical data. These include Configuration Management, Performance Management, and Firmware Update Management.

---

**NOTE :**The command descriptions given in this User Guide are specific to Firmware Version 1.3.0.4.xxxx. To access the most up-to-date commands, use the CLUI's Online Help feature.

---

### 3.1.1 Management Interface


SAN management information for the IS16000 can be accessed locally through a serial interface, or remotely through SSH.

#### Locally via Serial Interface

Any RS-232 terminal or terminal emulator (such as Hyperterminal) can be used to configure and monitor the IS16000.

1. Connect the supplied serial cable to the RS-232 port on the Controller (Figure 80). Connect the other end of the cable to a serial port on a standard PC.

Figure 80. RS-232 Port on Controller



2. Load a serial console program (such as HyperTerminal, minicom, and screen) and use the following settings for the serial connection:
  - Bits per second: 115,200
  - Data bits: 8
  - Parity: None
  - Stop bits: 1
  - Flow control: None
3. Once connected, press the <Enter> key to bring up the login prompt. Enter the user name **user** and password **user**.

#### Remotely via SSH

To configure and monitor the IS16000 remotely, connect the system to your Ethernet network. Please refer to Section 3.7 for further information on how to set up the Controller's network interface.

### 3.1.2 User Logins

#### RS-232 Login

For a terminal session, press the <Enter> key to bring up the login prompt. Enter the user name **user** and password **user**.

#### Login via SSH

For a SSH session (Figure 81), enter the user name **user** and password **user**. Both are case sensitive.

Figure 81. SSH Login Screen

```
login as: user
user@10.23.23.16's password:

Linux (none) 2.6.25-sgi-016620-3 #2 SMP Mon Aug 16 10:38:29 MST 2010 x
SGI IS
```

#### Logout

To logout, enter the command **QUIT**. For SSH connection, the current session will be disconnected.

### 3.1.3 Available Commands

The CLUI commands are independent of case. Most of the keywords can be abbreviated and most of the punctuations are optional.

Entering the “?” character at the CLUI prompt will display the available commands within the IS16000 CLUI (Figure 82). To get help information on a command, type the command followed by a question mark.

For example, **ASSIGN ?**<Enter> will display help on “assign” options on the system.

Figure 82. Help Screen

```
RAID[0]$ ?
Select one of the following subjects for additional commands:
  APPLICATION    Selects the application processor as the subject
  RAID           Selects the raid processor as the subject
  UI             Selects the user interface as the subject

Additional commands:
  HELP          Provides information on how to use the user interface help
  QUIT         Exits the Command Line User Interface

Object class options available for default subject RAID:
Available keywords:
  ASSIGN       Assign raid object
  CLEAR       Clear raid object states
  CREATE      Create raid objects
  DELETE     Delete raid objects
  LOCATE     Locate raid objects
  MOVE_HOME  Locate raid objects
  PAUSE     Pause raid objects
  REPLACE   Replace raid objects
  RESUME    Resume raid objects
  SET       Set raid objects
  SHOW     Display raid objects
  SHUTDOWN Shutdown raid objects
  SYNCHRONIZE Synchronize raid objects
  UPDATE_FIRMWARE Update firmware on raid objects
  VERIFY   Start a Verify background job(s)
```

### 3.1.3.1 Basic Key Operations

The command line editing and history features support ANSI and VT-100 terminal modes. The command history buffer can hold up to 64 commands. The full command line editing and history only work on main CLI and SSH sessions when entering new commands. Basic Key Assignments are listed in Figure 83.

Simple, not full command, line editing only is supported when the:

- CLUI prompts the user for more information.
- alternate CLUI prompt is active. (The alternate CLUI is used on the RS-232 connection during an active SSH session.)

---

**NOTE :**Not all SSH programs support all the keys listed in Figure 83.

---

Figure 83. Basic Key Assignments

Key	ANSI CTRL or Escape Sequence	Description
Backspace	Ctrl-H	deletes preceding character
Delete	Del, or Esc [3~	deletes current character
Up Arrow	Esc [A	retrieves previous command in the history buffer
Down Arrow	Esc [B	retrieves next command in the history buffer
Right Arrow	Esc [C	moves cursor to the right by one character
Left Arrow	Esc [D	moves cursor to the left by one character
Home	Esc [H or Esc [1~	get the oldest command in the history buffer
End	Esc [K or Esc [4~	get the latest command in the history buffer
Insert	Esc [2~	toggles between insert mode and overtype mode
PgUp	Esc [5~	retrieves oldest command in the history buffer
PgDn	Esc [6~	retrieves latest command in the history buffer
Ctrl-U	Ctrl-U	delete to beginning of line
Ctrl-K	Ctrl-K	delete to end of line
Ctrl-A	Ctrl-A	move cursor to beginning of line
Ctrl-E	Ctrl-E	move cursor to end of line

## 3.2 Configuration Management

The disks in the system are categorized into one of the following pools:

- Unassigned Pool - By default, all the disks or replacement disks are initially allocated to this pool. When a disk has failed or been released (from a Spare Pool, for example), it is also moved to this pool.
- Storage Pool (sometimes referred to as a RAID group) - A collection of 2 to 10 disks, ideally of the same capacity and type.
- Spare Pool - This type of pool contains Physical Disks that can be used as spare disks in one or more Storage Pools.

### 3.2.1 Disk Information

To display the list of all the disks installed in the system, enter the command (Figure 84):

```
SHOW PHYSICAL_DISK *
```

Figure 84. Show Physical Disk List Example Screen

```
RAID[0]$ show pd *
```

Encl	Slot	Vendor	Product ID	Type	Cap GB	RPM	Revision	Serial Number	Pool	Status	Idx	State	Member	WWN
1	1	HITACHI	HDS725050KLA360	SATA	465	7K	K2A0AD1A	KRVN652AKA2LKH	UNAS	GOOD	57	READY	5000cca20def4516	
1	2	HITACHI	HDS725050KLA360	SATA	465	7K	K2A0AD1A	KRVN652AKNL79H	UNAS	GOOD	32	READY	5000cca20df3a263	
1	3	HITACHI	HDS725050KLA360	SATA	465	7K	K2A0AD1A	KRVP652AKD8Y5F	UNAS	GOOD	42	READY	5000cca20defdc87	
1	4	HITACHI	HDS725050KLA360	SATA	465	7K	K2A0AD1A	KRVN652AK72BLH	UNAS	GOOD	1	NORM	5000cca20ded7e05	
...														
Total Physical Disks:			120											
Total Assigned Disks:			104											
Total Unassigned Disks:			16											
Total SAS Disks:			60											
Total SATA Disks:			60											
Total Member State Normal:			104											

To display the list of unassigned disks, enter the command:

```
SHOW UNASSIGNED_POOL PHYSICAL_DISK
```

To retrieve information about a specific disk, enter the command:

```
SHOW PHYSICAL_DISK=<disk-id> ALL_ATTRIBUTES (Figure 85).
```

Figure 85. Physical Disk Information Example Screen

```
RAID[0]$ show pd 40 all
```

Index:	40
OID:	0x27000028
Pool Index:	UNASSIGNED
Pool OID:	UNASSIGNED
Capacity:	448 GB
Raw Capacity:	465 GB(Base 2)/500 GB(Base 10)
Block Size:	512
Enabled Disk Ch:	0xffff 0x21d0 0xffff 0x2054
Disk Slot:	46 (2:46)
Vendor ID:	HITACHI
Product ID:	HDS725050KLA360
Product Revision:	K2A0AD1A
Serial Number:	KRVN652BGB8MTF
Health State:	GOOD
Rotation Speed:	7200 RPM
Device Type:	SATA
Member State:	UNASSIGNED
Spare:	FALSE
Failed:	FALSE
UUID:	0x5000cca20ec52082

If there is a failed disk, use the **SHOW UNASSIGNED\_POOL FAILED ALL** command to display the failed disk's information (Figure 86).

Figure 86. Show Failed Disk Example Screen

```
RAID[0]$ show unassigned_pool failed all
OID:                0x20a7003f
Pool OID:           UNASSIGNED
Capacity:          704512 MBs (0x56000000 blocks)
Raw Capacity:      715404 MBs (0x575466f0 blocks)
Block Size:        512
Enabled Disk Ch:   0x27 0x22
Disk Slot:         1:42
Vendor ID:         Hitachi
Product ID:        Hitachi HUA721075KLA330
Product Revision:  GK80AB0A
Serial Number:     GTF200P8GBVPXF
Health State:      FAILED
Rotation Speed:    7200 RPM
Device Type:       SATA
Member State:      UNASSIGNED
State:             READY
Spare:             FALSE
Failed:            TRUE
UUID:             0x5000cca215c564560
```

### 3.2.1.1 Disk States

Listed below are the possible disk states:

**NORM:** Disk is in a normal or functional condition.

**AMIS:** Disk is Already MISsing. The disk in this state must return prior to the other disks. If the specific disk that is in this state never returns to the pool, the pool will remain inoperative. Replacing this disk to do a rebuild will do nothing.

**WTRB:** Disk is Waiting To ReBuild. A disk went missing then came back and is rebuilding (either partial or full). Then other disks in the Storage Pool went missing causing it to go inoperative, which halts the rebuild. Now waiting for other disks in the system to become active again.

**MNRB:** Disk is Missing with No ReBuild. This is the same as missing, but when the disk comes back, there is nothing to rebuild. This could happen when multiple disks fail at the same time making the Storage Pool inoperative. Reseating is an option here to see if the disk would come back. This is similar to the AMIS condition, but in this case it does not matter what order the MNRB disks become active.

**MISS:** Disk is MISSING. This is either not electrically active or seen, or only one Controller sees it in a couplet system. Reseating would be a first recommendation as a partial rebuild would happen if it then appears to both Controllers. Replacing would cause a full rebuild.

**FAIL:** Disk is FAILED and is unassigned. This means that the disk timeout has either expired or the disk had errors and had been failed. "FAIL" in the Storage Pool command means that it has been failed out of the Storage Pool, not necessarily the state of the disk. This is being renamed to EMPTY.

**RBLD:** Disk is ReBuiLDing.

**PRTRDY:** PaRTial ReaDY state is a condition where only one of the two Controllers is able to communicate with a drive.

### **3.2.1.2 Visual Indication**

**LOCATE PHYSICAL\_DISK=<id>** provides a visual indication of the specified disk. The status LED of the disk module will blink.

**LOCATE UNASSIGNED\_POOL** provides a visual indication of the disk modules that are unassigned. The status LED of the disk modules will blink.

**LOCATE UNASSIGNED\_POOL FAILED** provides a visual indication of the disk modules that have failed. The status LED of the disk modules will blink.

### 3.2.2 Storage Pool Management

The IS16000 creates centrally-managed and vendor-independent Storage Pooling. It enables different types of storage to be aggregated into a single logical storage resource from which virtual volumes (Virtual Disks) can be served up to multi-vendor host computers. The networked Storage Pools will provide the framework to manage the growth in storage demand from web-based applications, database growth, network data-intensive applications, and disaster tolerance capabilities.

#### 3.2.2.1 Display Storage Pool Information

You can add and remove Storage Pools without affecting system operations. Use the **SHOW POOL \*** command to display the current list of Storage Pools (Figure 87).

Figure 87. Show Storage Pool List Example Screen

```
RAID[0]$ show pool *
```

Idx	Name	State	Chunk	Raid	Faults	Total cap GB	Free cap GB	Max VD GB	Settings	Jobs	Disk T/O	Global spare pool	Spare Policy
0	pool-0	NORMAL	128	6		720	0	0	DWMRFI		1	UNASSIGNED	AUTO
1	pool-1	NORMAL	128	6		720	0	0	DWMRFI		1	UNASSIGNED	AUTO
2	pool-2	NORMAL	128	6		720	0	0	DWMRFI		1	UNASSIGNED	AUTO
3	pool-3	NORMAL	128	6		720	0	0	DWMRFI		1	UNASSIGNED	AUTO
4	pool-4	NORMAL	128	6		720	0	0	DWMRFI		1	UNASSIGNED	AUTO
5	pool-5	NORMAL	128	6		720	0	0	DWMRFI		1	UNASSIGNED	AUTO

Total Storage Pools: 5

**NOTE :** If you issue the command, **SHOW POOLS \***, and the pools indicate there is a fault, check the details of the pool. The pool will go into WR thru state on initial startup to allow the batteries the opportunity to charge. The WR Thru mode is necessary to allow for data integrity until battery redundancy on each controller is completed. If there is a battery issue, the system will indicate replacement is required and all VDs will remain in WR Thru mode until the issue is resolved.

The **SHOW POOL=<id> ALL\_ATTRIBUTES** command displays the detailed information of the specified Storage Pool (Figure 88).

Figure 88. Show Storage Pool Attributes Example Screen

```
RAID[0]$ show pool 0 all
```

Index:	0	
OID:	0x1a520000	
Type:	STORAGE	
Name:	pool-0	
Chunk Size:	128KB (0x100 blocks)	
Block Size:	512	
RAID Type:	RAID6	
Free Raid6 Capacity:	0 GB	
Max VD Size:	0 GB	
Total Capacity:	720 GB	
UUID:	60001ff0800a3000000000001a520000	
Global Spare Pool:	UNASSIGNED	
:	:	
:	:	
BkgdJob OID:	INACTIVE	
Total Phy Disks	6	
State:	NORMAL	
Member Size:	120 GB	
pID	State	UUID
0x01dd	NORM	0x5000cca00d273618
0x01df	NORM	0x5000cca00d32293c
0x0263	NORM	0x5000cca00d324438
0x01e3	NORM	0x5000cca00d2b4c48
0x01e1	NORM	0x5000cca005039324
0x01e7	NORM	0x5000cca00d103e94

Total Storage Pools: 1

The **SHOW POOL=<id> PHYSICAL\_DISK** command displays the list of disks associated with the specified Storage Pool (Figure 89).

Figure 89. Show Storage Pool Physical Disks Example Screen

```
RAID[0]$ RAID[0]$ show pool 0 pd
```

Encl Slot	Vendor	Product ID	Type Cap GB	RPM Revision	Serial Number	Pool Health	State	Idx State	WWN	
1 37	HITACHI	HUS153014VLS300	SAS 136	15K A410	JFVMMZNC5301	0 GOOD	611	NORM	5000cca00d324438	
1 39	HITACHI	HUS153014VLS300	SAS 136	15K A140	J4V1YYAA5301	0 GOOD	481	NORM	5000cca005039324	
1 51	HITACHI	HUS153014VLS300	SAS 136	15K A410	JFVWL5YC5301	0 GOOD	479	NORM	5000cca00d32293c	
2 1	HITACHI	HUS153014VLS300	SAS 136	15K A410	JFVSU5PC5301	0 GOOD	483	NORM	5000cca00d2b4c48	
2 3	HITACHI	HUS153014VLS300	SAS 136	15K A410	JFV8XYQC5301	0 GOOD	487	NORM	5000cca00d103e94	
2 42	HITACHI	HUS153014VLS300	SAS 136	15K A410	JFVFKHUC5301	0 GOOD	477	NORM	5000cca00d273618	
Total Physical Disks:		6								
Total Assigned Disks:		6								
Total Unassigned Disks:		0								
Total SAS Disks:		6								
Total Member State Normal:		6								

The **SHOW POOL=<id> VIRTUAL\_DISK** command displays the list of Virtual Disks associated with the specified Storage Pool (Figure 90).

Figure 90. Show Storage Pool Virtual Disks Example Screen

```
RAID[0]$ show pool 0 vd
```

Idx Name	State	Pool Raid	Cap GB Settings	Jobs	Current	Home Preferred	Background Job
0 vd-0_0	READY	0 5	3632 W I		0(L) 0	0(L) 0	INACTIVE
Total Virtual Disks:		1					

### 3.2.2.2 Creating a Storage Pool

To create a Storage Pool, enter the command:

```
CREATE POOL RAID_LEVEL=[1|5|6] CHUNK_SIZE=[32|64|128|256]
{ASSIGN_POLICY=[SAS|SATA] NUMBER=[2|5|6|9|10] or PHYSICAL_DISK=<list of disks>} INIT_ALLOW=<initialization policy>
SATASSURE=[NONE|DATA_INTEGRITY_FIELD|PARITY]
```

where <initialization policy>=Allow\_IO, NO\_IO, Priority (1-99, where 99 puts all system resources on the initialization).

You may either explicitly select the disks for the pool by using “**PHYSICAL\_DISK=**” or specify the number of disks in the pool by using “**NUMBER=**” in which case the next available disks will be selected. If you specify the **ASSIGN\_POLICY** and **NUMBER** parameters together, only the selected type of disks will be used for the Storage Pool and you will not need to enter the individual disk name. You may disable the SATAssure feature or enable it to use either the data integrity field option or the parity check on read option.

Examples:

- To use only the specified disks:  
**CREATE POOL RAID\_LEVEL=RAID5 CHUNK\_SIZE=64KB PHYSICAL\_DISK=62 63 64 65 66**
- To use the next available disks:  
**CREATE POOL RAID\_LEVEL=RAID6 CHUNK\_SIZE=128KB NUMBER=6**
- To use only the selected type of disks:  
**CREATE POOL RAID\_LEVEL=RAID6 CHUNK\_SIZE=128KB NUMBER=6  
 ASSIGN\_POLICY=SAS**

### 3.2.2.3 Storage Pool Initialization

When a Storage Pool is created, initialization begins automatically and will continue in the background until it is completed.

You may use the **SHOW POOL** command to check if the Storage Pool is being initialized (see Section 3.2.2.1, "Display Storage Pool Information" for more information).

You may monitor the initialization progress using the **SHOW JOB** command (see Section 3.3.1, "Background Job Priority" for more information).

### 3.2.2.4 Initialization Job Failure

Rarely, a job may fail to initialize. If so, the event will be reported as:

```
000737 2010-01-25 20:42:09:0684480 G=61 S=2 T=1 RP=0 VP=1
LOG_ST_SET_FAILED STATE VIRTUAL DISK SET FAILED CONDITION INDEX:00000003 POOL:00000000 INIT FAILED
```

If an initialization job fails, enter the command **VERIFY POOL <pool-id> FORCE** to restart the initialization.

#### Examples:

- **SHOW POOL \*** command under failed initialization conditions:

Idx	Name	State	Chunk	Raid	Faults	Total cap	Free cap	Max VD	Settings	Jobs	Disk T/O	Global spare pool	Spare Policy
0	pool-0	FAILED	128	6	I	720	0	0	DWMRFI		1	UNASSIGNED	AUTO
1	pool-1	NORMAL	128	6		720	0	0	DWMRFI		1	UNASSIGNED	AUTO

- **SHOW POOL 0 ALL** command under failed initialization conditions:

```
Index: 0
OID: 0x1a520000
Type: STORAGE
Name: pool-0
Chunk Size: 128KB (0x100 blocks)
Block Size: 512
RAID Type: RAID6
Free Raid6 Capacity: 0 GB
Max VD Size: 0 GB
Total Capacity: 720 GB
UUID: 60001ff0800a30000000000001a520000
Global Spare Pool: UNASSIGNED
DiskTimeout(FRT): 1 minute
Init Policy: ALLOW_IO
:
:
Initializing: FAILED
Rebuilding: FALSE
Paused: FALSE
:
:
```

- **SHOW VD \*** command under failed initialization conditions:

Idx	Name	State	Pool	Raid	Cap GB	Settings	Jobs	Home		Background Job
								Current	Preferred	
0	vd-0_0	FAILED	0	5	8	W M I		1(L) 0	1(L) 0	INACTIVE
1	vd-1_0	FAILED	0	5	8	W M I		1(L) 0	1(L) 0	INACTIVE
2	vd-2_0	FAILED	0	5	8	W M I		1(L) 0	1(L) 0	INACTIVE
3	vd-3_1	READY	1	5	8	W M I		1(L) 0	1(L) 0	INACTIVE

- **SHOW VD 3 ALL** command under failed initialization conditions:

```

Index:          0
OID:           0x8a680000
Name:          vd-0_0
Pool Index:    0
Pool OID:      0x1a520000
Capacity:     472 GB
Offset:       0x0
State:         FAILED_INITIALIZATION
Raidlevel:    RAID6
IO ROUTING:   TRUE
WBC:         TRUE
MIRRORED:    TRUE
Initializing: FAILED
Paused:      FALSE
AutoWriteLock: FALSE

```

### 3.2.2.5 Verifying a Storage Pool

Pool verification is a feature that goes with SATAssure. It allows you to run a background job that finds and fixes parity issues (when using the **FORCE** option). It is also automatically initiated when SATAssure encounters an error in an attempt to fix the errors.

To set this mode, use the command:

```
SET SUBSYSTEM VERIFY_POLICY=<0..99>
```

where the number range indicates the internal resources to use for the process. Zero is used to turn the feature OFF, any other number will turn the feature on.

To use the “one-time” verify function, use the command:

```
VERIFY POOL [<pool-id>|*] FORCE_CONSISTENCY
```

### 3.2.2.6 Naming a Storage Pool

The **SET POOL=<pool-id> NAME="<name>"** command lets you specify a name to identify the Storage Pool (Figure 91).

Figure 91. Set Pool Name Example Screen

```

RAID[0]$ set pool 0 name="RAID 5 Set"
POOL 0 OID: 0x19b40000 attributes set with STATUS='Success' (0x0)

```

### 3.2.2.7 Deleting a Storage Pool

The **DELETE POOL=<id>** command deletes the specified Storage Pool from the system.



Warning

**The DELETE POOL command erases all the data on the Storage Pool. You cannot delete a Storage Pool if there are Virtual Disks still present on the pool.**

### 3.2.2.8 Locate a Storage Pool

The **LOCATE POOL=<id>** command provides a visual indication of the specified Storage Pool. The status LED of the disk modules in the specified Storage Pool will blink.

### 3.2.3 Virtual Disk Management

A Virtual Disk is the storage unit presented to any attached host. A Virtual Disk can be created to use all or just a part of the capacity of a single Storage Pool. Virtual disks allocate space in 8GiB increments. For example, 16GiB of storage space will be allocated when creating a Virtual Disk of 10GiB.

#### 3.2.3.1 Display Virtual Disk Information

The **SHOW VIRTUAL\_DISK \*** command displays the list of configured Virtual Disks in the system (Figure 92).

Figure 92. Show Configured Virtual Disks Example Screen

```
RAID[0]$ show vd *
```

Idx Name	State	Pool Raid	Cap GB	Settings	Jobs	Current	Home Preferred	Background Job
0 vd-0_0	READY	0 5	3632	W I		0(L) 0	0(L) 0	INACTIVE
1 vd-1_1	READY	1 5	3632	W I		0(L) 0	1(R) 0	INACTIVE
2 vd-2_2	READY	2 5	3632	W I		0(L) 0	0(L) 0	INACTIVE
3 vd-3_3	READY	3 5	5480	W I		0(L) 0	1(R) 0	INACTIVE
4 vd-4_4	READY	4 5	5480	W I		0(L) 0	0(L) 0	INACTIVE
6 vd-6_5	READY	5 5	5480	W I		0(L) 0	1(R) 0	INACTIVE

Total Virtual Disks: 6

The **SHOW VIRTUAL\_DISK=<id> ALL\_ATTRIBUTES** command displays the detailed information of the specified Virtual Disk (Figure 93).

Figure 93. Show Virtual Disk Attributes Example Screen

```
RAID[0]$ show vd 0 all
```

```

Index:          0
OID:           0x8a680000
Name:          vd-0_0
Pool Index:    0
Pool OID:     0x1a520000
Capacity:     472 GB
Offset:       0x0
State:        READY
Raidlevel:   RAID6
IO ROUTING:  TRUE
WBC:         TRUE
MIRRORED:    TRUE
Initializing: FALSE
Paused:      FALSE
AutoWriteLock: FALSE
Critical:    FALSE
Forced Write-thru: FALSE
Current Home: 0x38000000 0x00000000 (LOCAL)
Future Home:  0xffffffff 0x00000000
Preferred Home: 0x38000000 0x00000000 (LOCAL)
Job OID:      INACTIVE
UUID:        60001ff0800a3000000000008a680000
Total Virtual Disks: 1

```

### 3.2.3.2 Creating a Virtual Disk

To create a Virtual Disk, enter the command:

```
CREATE VIRTUAL_DISK CAPACITY=<capacity> POOL=<pool-id>
```

where <capacity> is the capacity of the Virtual Disk in GiB or type “max” to use all available capacity; <pool-id> is the Storage Pool to be used by this Virtual Disk (Figure 94).

A message is displayed to indicate whether the Virtual Disk creation was successful.

Figure 94. Create Virtual Disks Example Screen

```
RAID[0]$ create virtual_disk capacity=16 pool=0
VIRTUAL_DISK 0 OID=0x89ba000 creation STATUS='Success' (0x0)
RAID[0]$ create virtual_disk capacity=32 pool=0
VIRTUAL_DISK 1 OID=0x89bb001 creation STATUS='Success' (0x0)
```

### 3.2.3.3 Naming a Virtual Disk

The **SET VIRTUAL\_DISK=<id> NAME=<name>** command lets you specify a name to identify the Virtual Disk (Figure 95).

Figure 95. Set Virtual Disk Name Example Screen

```
RAID[0]$ set vd 0 name=LUN "
VIRTUAL_DISK 0 OID=0x89ba000 attributes set with STATUS='Success' (0x0)
```

### 3.2.3.4 Deleting a Virtual Disk

The **DELETE VIRTUAL\_DISK=<id>** command deletes the specified Virtual Disk from the system. However, it does not delete presentations for that Virtual Disks. If a presentation is configured for a Virtual Disk, deleting the Virtual Disk will return an error. You must first delete all the presentations configured on that Virtual Disk (see Section 3.4.3, "Presentation Commands").



Warning

**When you delete a Virtual Disk, you lose access to all data that was stored on that Virtual Disk.**

### 3.2.3.5 Presentation to Hosts

Virtual Disks are only presented to the hosts that have been given authorized access. Refer to Section 2.8.12, "Present Virtual Disk to External Host" for detailed instructions on configuring Virtual Disk presentations to hosts. Refer to Section 3.4, "Presentations" for more information on commands related to presentation.

To display presentations associated with the specified application host, enter the command:

```
APPLICATION SHOW HOST=<host-id> PRESENTATIONS
```

To display the initiators associated with the specified application host, enter the command:

```
APPLICATION SHOW HOST=<host-id> INITIATORS
```

### 3.2.4 Spare Pool Management

The IS 16000 supports the concept of Spare Pool which contains Physical Disks that can be used as spare disks. Spare Pools can be shared by Storage Pools or dedicated to a particular Storage Pool in which case the spare disks will only be used by the designated Storage Pool. After a Spare Pool is created, you will need to select disk(s) from the Unassigned Pool and assign it the Spare Pool.

In the event of disk failure, a disk that is assigned to a Spare Pool is automatically swapped into the Storage Pool to replace the failed disk. A rebuild then occurs immediately, reducing the possibility of data loss due to additional disk failures.

---

**NOTE :**Each Storage Pool should have a Spare Pool assigned to it. If a Storage Pool's attributes show "Global Spare Pool: UNASSIGNED", no Spare Pool will serve this Storage Pool.

---

#### 3.2.4.1 Display Spare Pool Information

Use the **SHOW SPARE\_POOL \*** command to display the list of configured Spare Pool(s) (Figure 96).

Figure 96. Show Configured Spare Pools Example Screen

```
RAID[0]$ show spare_pool *
-----
Idx|Name          |Blocks|Disk T/O|Total|Total|Storage|
-----|-----|-----|-----|-----|-----|-----|
 6|spare_pool-6   |512   |10     |528  |2     |        |
 7|spare_pool-7   |512   |10     |528  |2     |        |
-----
Total Spare Pools: 2
```

To display the detailed information of the Spare Pool, enter the command:

**SHOW SPARE\_POOL=<id> ALL\_ATTRIBUTES** command (Figure 97).

Figure 97. Show Spare Pool Attributes Example Screen

```
RAID[0]$ show spare_pool 6 all
Index:          6
OID:            0x19bc0006
Type:           GLOBAL_SPARE
Name:           19bc0006
Block Size:     0x200
DiskTimeout(FRT): 10 minutes
Total Capacity: 1409024 MBs
UUID:           0x00
Total Phy Disks 2
```

To display the list of disks in the Spare Pool, enter the command (Figure 98):

**SHOW SPARE\_POOL=<id> PHYSICAL\_DISKS**

Figure 98. Show Spare Pool Physical Disks Example Screen

```
RAID[0]$ show spare_pool 6 pd
-----
Encl|Slot| Vendor | Product ID |Type|Cap GB| RPM|Revision| Serial Number |Health|
-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
 2 53 HITACHI HUS153030VLS300 SAS 279 15K A410 JHVXKUKC5303 14 SPARE 648 NORM 5000cca00d335c6b0
 2 58 HITACHI HUS153030VLS300 SAS 279 15K A410 JHVWU54C5303 14 SPARE 652 NORM 5000cca00d3291f4
-----
Total Physical Disks: 2
Total Assigned Disks: 2
Total Unassigned Disks: 0
Total SAS Disks: 2
Total Member State Normal: 2
```

### 3.2.4.2 Creating a Spare Pool

Use these commands to create a Spare Pool, add disk to the Spare Pool, and assign the Spare Pool to a Storage Pool:

- `CREATE SPARE_POOL`
- `ASSIGN PHYSICAL_DISK=<disk-id> TO_POOL <spare-pool-id>`
- `SET POOL=<pool-id> SPARE_POOL=<spare-pool-id>`  
where <pool-id> and <spare-pool-id> are the index names of the Storage Pool and Spare Pool respectively.

### 3.2.4.3 Naming a Spare Pool

The `SET SPARE_POOL=<pool-id> NAME="<name>"` command lets you specify a name to identify the Spare Pool.

### 3.2.4.4 Deleting a Spare Pool

To delete a disk from the Spare Pool, enter the command:

```
ASSIGN PHYSICAL_DISK=<disk-id> TO_POOL 0x1800ffff
```

To delete a Spare Pool, enter the command:

```
DELETE SPARE_POOL=<pool-id>
```

### 3.2.5 Disk Rebuild

The IS16000's automatic disk failure recovery procedures ensure that absolute data integrity is maintained while operating in degraded mode.

#### 3.2.5.1 Full and Partial Rebuilds

Both full and partial (fractional) rebuilds are supported in IS16000. Rebuilds are done at the Storage Pool level, not the Virtual Disk level. Partial rebuilds will reduce the time to return the Storage Pool to full redundancy and can be controlled by adjustable time limit for each Storage Pool. Permitted time limits are 0 (in which case partial rebuild is off) to 240 minutes. The timer will begin when a disk in the Storage Pool is declared missing. If the disk reappears prior to the expiration of the timer, a fractional rebuild will be done. Otherwise, the disk will be declared failed, replaced by a spare and a full rebuild will begin to return the Storage Pool to full redundancy. The default partial rebuild timer (Disk Timeout) setting is 10 minutes.

Under heavy write workloads, it is possible that the number of stripes that need to be rebuilt will exceed the system's internal limits prior to the timer expiration. When this happens, a full rebuild will be started automatically instead of waiting for the partial rebuild timeout.

Use the **SHOW POOL=<id> ALL\_ATTRIBUTES** command to display the current Disk Timeout setting (Figure 99).

Figure 99. Show Pool All Attributes

```
RAID[0]$ show pool 0 all
Index:          0
OID:           0x1a520000
Type:          STORAGE
Name:          pool-0
Chunk Size:    128KB (0x100 blocks)
Block Size:    512
RAID Type:     RAID6
Free Raid6 Capacity: 0 GB
Max VD Size:  0 GB
Total Capacity: 720 GB
UUID:         60001ff0800a30000000000001a520000
Global Spare Pool: 0x1aca000e (Index 14)
DiskTimeout(FRT): 1 minute
:
```

To change the disk timeout setting, use this command:

```
SET POOL=<id> DISK_TIMEOUT=<timeout>
```

where <timeout> is in the range of <0..240> minutes. The default setting is 10.

#### 3.2.5.2 Sparing Policy

Each Storage Pool has a sparing policy that determines what happens when a physical disk within the pool fails (or becomes inaccessible). In the event of a disk failure, the IS16000 will automatically initiate a disk rebuild if the sparing policy is set to automatic and a Spare Pool has been assigned to the Storage Pool.

Use the **SHOW POOL=<id> ALL\_ATTRIBUTES** command to display the current settings (Figure 100).

Figure 100. Show Pool All Attributes

```

RAID[0]$ show pool 0 all

Index:          0
OID:            0x1a520000
Type:           STORAGE
.
.
.
UUID:           0x00
Global Spare Pool: 0xlaca000e (Index 14)
DiskTimeout(FRT): 10 minutes
Init Policy:    ALLOW_IO
Init Priority:   50%
Full Rebuild Priority: 80%
Fractional Rebuild Priority: 90%
Sparing Policy: AUTOMATIC
.
.
.

```

To change the sparing policy setting, use this command:

```
SET POOL=<id> SPARING_POLICY=[AUTOMATIC|MANUAL]
```

The default setting is automatic which is recommended.

A rebuild operation can take up to several hours to complete, depending on the size of the disk and rate of rebuild. Refer to Section 3.3, "Performance Management" on page 76 for information on how to adjust the rate of rebuild.

### 3.2.5.3 Manual Disk Replace/Rebuild

If a Storage Pool does not have a Spare Pool assigned to it, it becomes necessary to manually add a disk to the Storage Pool to replace a failed disk.

To add a disk to a Storage Pool to replace a failed disk, use this command:

```
ASSIGN PHYSICAL_DISK=<disk-id> TO_POOL=<pool-id> SET_SPARE
```

The disk will be put into the Storage Pool as the spare disk and it will be used in the Storage Pool to replace the failed disk.

### 3.2.5.4 Manual Fail/Rebuild of a Disk

The **SET PHYSICAL\_DISK <disk-id> FAILED** command instructs the system to fail the specified disk. When a non-SPARE disk is specified and it is failing, the disk will not cause a multi-channel failure. The disk is marked as failed. An attempt is made to replace it with a spare disk. When a SPARE disk is specified, it is released, but marked as unhealthy and unavailable.

**CLEAR PHYSICAL\_DISK <disk-id> FAILED** changes the specified disk's "Failed" state to "FALSE". After clearing a disk, use the **ASSIGN PHYSICAL\_DISK <disk-id> TO\_POOL <pool-id> SET\_SPARE** command to add the disk back to the Storage Pool it was failed from. This command will also initiate a rebuild if a spare has not already been assigned to the Storage Pool.

### 3.2.6 SATAssure

You may enable SATAssure for a Storage Pool.

To display the current setting, enter the command (Figure 101):

```
SHOW POOL=<pool-id> ALL_ATTRIBUTES
```

Figure 101. Show Storage Pool Details Example Screen

```
RAID[0]$ show pool 0 all
Index:                0
OID:                  0x1a520000
Type:                 STORAGE
Name:                 pool-0
:
Assign Policy:
Device Type:          SAS
Rotation Speed:       NA
Raw Capacity:         136 GB
SATAssure:            NONE
:
:
```

To enable SATAssure, enter the command:

```
SET POOL=<pool-id> SATASSURE=[PARITY|DATA_INTEGRITY_FIELD]
```

where **PARITY** is the parity check on read option and **DATA\_INTEGRITY\_FIELD** is the integrity field option.

To disable SATAssure, enter the command: **SET POOL=<pool-id> SATASSURE=NONE**

### 3.2.7 Setting the System's Date and Time (NTP Mode)

NTP (Network Time Protocol) mode is available on the IS16000. It provides a means for the Controllers to synchronize their time across a network, usually within a small number of milliseconds over a long period of time. You can enter up to four NTP addresses as the time servers.

To enable the NTP mode, enter the command:

```
SET SUBSYSTEM NTP=[<ip address list, up to 4>|NONE]
```

Examples:

```
SET SUBSYSTEM NTP=1.2.3.4 1.2.3.5 3.4.5.6 6.5.7.8
```

```
SET SUBSYSTEM NTP=1.2.3.4
```

```
SET SUBSYSTEM NTP=NONE
```

Specifying a list of NTP addresses will start the NTP mode on each Controller, using that list of NTP addresses as the time servers. Specifying NONE will turn off NTP mode.

To display the current settings, enter the command (Figure 102):

```
SHOW SUBSYSTEM ALL_ATTRIBUTES
```

Figure 102. Show NTP Settings

```
RAID[0]$ show subsystem all
*****
*   Subsystem   *
*****
RP Subsystem Name:   co-test-8
UID:                 60001ff0800a30000000000030000000
Subsystem Time:      Mon Sep 27 17:08:59 2010
Locate Dwell Time:   120 seconds
Enabled Licenses:    RAID6 SATASSURE
Fast Timeout:        ON
Pool Verify Priority: 10%
NTP Mode:            ON
                    (10.32.16.24)
                    (10.32.16.25)
```

**When in NTP mode:**

- The time is set between the two Controllers under the following conditions:
  - when the Controllers boot and discover each other
  - when a **SET SUBSYSTEM** command is issued, whether it is setting the time or not
- Each Controller will attempt to synchronize with the specified NTP servers. If none of the servers are valid, the time on each Controller is free to drift independent of any other time source (and independent of the other Controller).
- The **SET SUBSYSTEM DATA\_AND\_TIME** command will fail with a status of “Setting date/time while in NTP mode”.
- Once the Clock code has finished calibration (100 seconds), NTP will be started. Both Controllers will have the same NTP settings, and so presumably will have synchronized time once NTP sets the time.
- Issuing a new **SET SUBSYSTEM NTP** command with a new set of IP addresses will stop and restart NTP.
- If NTP finds a time difference of more than 128 msec, it will “jump” the time to the correct time. This will result in a discontinuity in the event log, logdisk, syslog, and anywhere that records a timestamp.
- NTP will always set the Controllers to UTC (Coordinated Universal Time). There is no option to set time zones or otherwise change the offset from UTC.

**When not in NTP mode:**

- The master Controller uses its time to set the time on the other Controller.
- The **SET SUBSYSTEM DATE\_AND\_TIME** command is used to set the time of both Controllers together. The system records time using the military method, which records hours from 00 to 24, not in a.m. and p.m. increments of 1 to 12. Valid date settings are between years 2000 and 2104. Settings are automatically adjusted for leap years.

To change the system date and time to March 1, 2010 2:15:32 pm, for example, type:

**SET SUBSYSTEM DATE\_AND\_TIME=2010:3:1:14:15:32**

- Once the time is set, the time on the two Controllers is free to drift independent of the other Controller.

### 3.2.8 *Restarting the IS16000*

#### **System Restart**

The **SHUTDOWN CONTROLLER [LOCAL|REMOTE|0|1] RESTART** command performs a restart on the specified Controller.

The **SHUTDOWN SUBSYSTEM RESTART** command performs a restart on both Controllers.

These commands will prepare the system to be restarted. The system will halt all I/O requests and save the data to the disks before restarting. The restart process may take several minutes to complete.

#### **System Shutdown**

The **SHUTDOWN CONTROLLER [LOCAL|REMOTE|0|1]** command shuts down the specified Controller.

The **SHUTDOWN SUBSYSTEM** command shuts down both Controllers.

If you need to power down the IS16000, use **SHUTDOWN** prior to shutting off the power. This will cause the IS16000 to immediately flush its cache, abort all initialization and rebuild operations, and proceed with an orderly shutdown.

All hosts actively using the IS16000 should be safely shutdown and all users logged out before using this command. The IS16000 will halt all I/O requests and save the data to the disks. The unit can be safely turned off after using this command.

Once shut down is complete, all power supplies must be switched off or unplugged. Power must be removed from the system for at least 10 seconds before it will start up again.

---

**NOTE :**Use **SHUTDOWN** whenever you need to power down the IS16000 for maintenance. **SHUTDOWN** flushes any data left in the cache and prepares the IS16000 for an orderly shutdown.

---

## 3.3 Performance Management

Initialization and rebuild operations are background processes and their rates can be adjusted to minimize their impact on system performance.

### 3.3.1 Background Job Priority

To monitor all current jobs (Figure 103), enter command:

```
SHOW JOB * ALL_ATTRIBUTES
```

The type of job and percentage of completion are displayed.

Figure 103. Show Job Example Screen

```
RAID[0]$ show job * all
```

Idx	Type	Target	(Sub)	State	Fraction Complete	Priority	Status	Time
0	FULL REBUILD	POOL:0	(NA)	RUNNING	0%	80%		NA

```
Total Background Jobs: 1
```

You may specify the amount of system resources that should be devoted to a background job. The higher its priority value, the faster the background job will run and the more the background job will impact client I/O performance.

To set the job priority, enter the command:

```
SET JOB=<id> PRIORITY=<priority>
```

where <priority> is a number between 1 and 99. Note that PRIORITY is not a percentage or a mathematical fraction of the available resources. For example, two background jobs with priority values of 50 will not use 100% of the system resources. The IS16000 may or may not limit the number of background jobs to keep the total of their priorities below 100.

#### Pause/Resume a Job

You may pause a job at any time using the **PAUSE JOB=<id>** command (Figure 104).

Figure 104. Pause a Job

```
RAID[0]$ pause job 0
JOB 0 OID=0x2b010000 paused with STATUS='Janus Success' (0x0)

RAID[0]$ show job 0 all
OID:                0x2b010000 (Index:0)
Target:             POOL:0xa520000 (Index:0)
Sub-Target:         NA
Type:               REBUILD
Status:             PAUSED
Completion Status:  UNKNOWN
Priority:            50
Fraction Complete: 11%
Time:               NA
```

To resume the job, enter the command: **RESUME JOB=<id>** (Figure 105)

Figure 105. Resume a Job


```
RAID[0]$ resume job 0
JOB 0 OID=0x2b010000 resumed with STATUS='Janus Success' (0x0)

RAID[0]$ show job 0 all
OID:                0x2b010000 (Index:0)
Target:             POOL:0xa520000 (Index:0)
Sub-Target:         NA
Type:               REBUILD
Status:             RUNNING
Completion Status:  UNKNOWN
Priority:            50
Fraction Complete: 11%
Time:               NA
```

### 3.3.2 Right Side I/O

Access to Virtual Disks uses the notion of a preferred home or “homed” path. If a path to the VD utilizes the peer Controller, additional latency is incurred for every I/O as it must be processed first by the “non-homed” Controller and forwarded over the same communication path used by Mirrored Write Back Cache (Figure 106).

Figure 106. Path to VD Utilizes the Peer Controller



Properly configured and tested host side multi-path drivers will ensure right side I/O will occur. If poor performance is encountered, especially upon initial configuration, then verifying and correcting your primary path to disks is essential.

Verify by reviewing the Virtual Disk counters, enter the command (Figure 107):

```
SHOW VD * COUNTERS ALL
```

**NOTE :** You need to enter this command three times—first time to initiate the counters, second time to display the results, third time to reset the counters.

Controller 0’s results are displayed on the left and Controller 1’s results are displayed on the right. In Figure 107, if VD 102 is mastered by Controller 0, all of the I/O is passing through Controller 1, thus doing wrong side I/O.

Figure 107. Show Virtual Disk Counters Example Screen

```
RAID[0]$ show vd * counters
Virtual disk Counters: Elapsed time = 12.181 seconds
```

Idx	IOs/sec	KiB/sec	KiB/IO	Fwd IO/s	Fwd KiB/s	IOs/sec	KiB/sec	KiB/IO	Fwd IO/s	Fwd KiB/s
102	0	0	0	0	0	6580	109243	68	0	0
103	0	0	0	0	0	7005	116304	68	0	0
104	0	0	0	0	0	5158	186392	148	0	0
105	0	0	0	0	0	2825	102083	148	0	0
106	0	0	0	0	0	3481	210768	248	0	0
107	0	0	0	0	0	3641	220500	248	0	0
108	0	0	0	0	0	0	0	0	0	0
109	0	0	0	0	0	0	0	0	0	0
110	0	0	0	0	0	0	0	0	0	0
111	0	0	0	0	0	0	0	0	0	0
112	0	0	0	0	0	0	0	0	0	0
113	0	0	0	0	0	0	0	0	0	0
114	0	0	0	0	0	0	0	0	0	0
115	0	0	0	0	0	0	0	0	0	0
116	0	0	0	0	0	0	0	0	0	0
117	0	0	0	0	0	0	0	0	0	0
118	0	0	0	0	0	0	0	0	0	0
119	0	0	0	0	0	0	0	0	0	0

### 3.3.3 *Rebuild Policy Priority*

Each Storage Pool has its own rebuild policy settings. You may specify the priority values for full rebuild and partial (fractional) rebuild policies. To display the current settings, enter the command **SHOW POOL=<id> ALL\_ATTRIBUTES** (Figure 108).

Figure 108. Show Pool Information

```
RAID[0]$ show pool 3 all
Index:                0
OID:                  0x1a520000
Type:                 STORAGE
Name:                 pool-0
Chunk Size:           128KB (0x100 blocks)
Block Size:           512
RAID Type:            RAID6
Free Raid6 Capacity: 0 GB
Total Capacity:       720 GB
UUID:                 60001ff0800a30000000000001a520000
Global Spare Pool:   0x1aca000e (Index 14)
DiskTimeout(FRT):    10 minutes
Init Policy:          ALLOW_IO
Init Priority:         50%
Full Rebuild Priority: 80%
Fractional Rebuild Priority: 90%
Sparing Policy:       AUTOMATIC
.
.
.
```

#### **Full Rebuild Priority**

To change the full rebuild priority value (Figure 109), enter the command:

**SET POOL=<id> REBUILD\_FULL\_POLICY=<priority>**

where <priority> is an integer in the range of 1 to 99. The default value specifies a priority of 80%.

Figure 109. Set Full Rebuild Priority

```
RAID[0]$ set pool 3 rebuild_full_policy=70
POOL 3 OID=0x19b40003 attributes set with STATUS='Success' (0x0)
```

#### **Partial Rebuild Priority**

To change the partial rebuild priority value (Figure 110), enter the command:

**SET POOL=<id> REBUILD\_PARTIAL\_POLICY=<priority>**

where <priority> is an integer in the range of 1 to 99. The default value specifies a priority of 90%.

Figure 110. Set Partial Rebuild Priority

```
RAID[0]$ set pool 3 rebuild_partial_policy=80
POOL 3 OID=0x19b40003 attributes set with STATUS='Success' (0x0)
```

### 3.3.4 Cache Coherency

By default, the IS16000 runs in couplet mode, where both Controllers are running simultaneously, communicating through internal Ethernet and InfiniBand connections. This means that the IS16000 is always running with cache coherency enabled.

The cache settings are configurable for each Storage Pool. Available keywords are:

<b>FULL_STRIPE_WRITE_CACHING</b>	Specify full stripe write caching
<b>MIRRORED</b>	Specify cache data mirroring
<b>READ_AHEAD_CACHING</b>	Specify read ahead caching
<b>WRITE_BACK_CACHING</b>	Specify write back caching

To display the current settings, enter the command **SHOW POOL=<id> ALL\_ATTRIBUTES**.

To change the settings, use these commands:

```
SET POOL=<id> FULL_STRIPE_WRITE_CACHING=[TRUE|FALSE]
SET POOL=<id> MIRRORED=[TRUE|FALSE]
SET POOL=<id> READ_AHEAD_CACHING=[TRUE|FALSE]
SET POOL=<id> WRITE_BACK_CACHING=[TRUE|FALSE]
```

---

**NOTE** :Turning off mirroring may result in data integrity issues.

---

#### 3.3.4.1 Cache Protection

The IS16000 UPS serves as a battery, which allows the controller to flush the contents of cache to non-volatile storage (internal disk) during a power event. When cache has been completely flushed, the Controller will shut itself down. When power is restored, the flushed cache is replayed back from the non-volatile storage and committed to disk.

Mirrored Write Back Cache (MWBC) provides a mechanism of cache protection by copying, or mirroring, the contents of cache from one singlet to the peer singlet (and vice-versa). In the event of a singlet failure, the copy of cache sitting in the surviving peer can be committed to disk by the surviving peer. Although there is a latency involved in the cache mirroring process, it is recommended as additional protection of data.

## 3.4 Presentations

---

A Presentation on a IS16000 has the following components:

- **Discovered Initiators**  
A Discovered Initiator is defined as a Fibre Channel or InfiniBand initiator that has logged into the IS16000. This is normally a single port on a Fibre Channel or InfiniBand HCA in an external computer.
  - **Host**  
A Host is an abstract client of a Virtual Disk that has all the access to all data within the Virtual Disk. This most commonly represents an external computer with one or more Fibre Channel or InfiniBand initiators. Host attributes are OS (operating system) of which you can select **GENERIC**, **WINDOWS**, **LINUX** or **MAC\_OS**. The OS attribute dictates the way the controller responds to certain Fibre Channel commands where appropriate. For example, Mac OS X expects a different response from an inquiry of LUN0 (the controller LUN) than a Windows host.
    - **OSTYPE**: “Standard” uses current settings and “Custom” allows for requests for different adjustments from OEMs.
  - **Channel**  
A Channel is one of the Fibre Channel or InfiniBand ports on the Controller. Channel attributes are **MODE** of which you can select either **MAC\_OS** or **STANDARD**. When **MAC\_OS** is selected, the port’s node name will be set differently in order to be visible to a Macintosh system.
- 
- NOTE** :If your SAN configuration requires unique world-wide name (WWN) node names on each controller port, set the controller channels (ports) to MAC mode. Use the command **APPLICATION SET CHANNEL [0|1|2|3] MODE MAC**. See section 3.4.5, "Additional Configuration Considerations for Macintosh Hosts" and other Mac OS notes for details.
- 
- **Stack**  
A Stack is the input side of the subsystem. In the case of the IS16000, the stack is defined as the Fibre Channel interface. In future versions of the product, different interface stacks may exist.
  - **Presentation**  
A Presentation is the relationship between a Host and a Virtual Disk. A Presentation implies that the related Host has some sort of access to the Virtual Disk. Attributes of a Presentation are:
    - **PORT**: from which the host will see the Virtual Disk
    - **READ\_ONLY**: controls read only access
    - **PRESENT\_HOME\_ONLY**: presents the specified Virtual Disk from its designated home controller only
    - **LUN**: user-specified LUN number that the Virtual Disk will show to the host.

### 3.4.1 *Discovered Initiator Commands*

To map a host to a discovered initiator, use the command:

```
APPLICATION IMPORT DISCOVERED_INITIATOR=<initiator-id> HOST=<host-id>
```

To display the currently available initiators, use the command:

```
APPLICATION SHOW DISCOVERED_INITIATORS *
```

To display the attributes of a specified initiator, use the command:

```
APPLICATION SHOW DISCOVERED_INITIATORS=<initiator-id> [ALL ATTRIBUTES]
```

To create an application initiator for the specified host, use the command:

```
APPLICATION CREATE INITIATOR HOST=<host-id> WWPN=<integer>
```

To delete the specified initiator, use the command:

```
APPLICATION DELETE INITIATOR=<initiator-id>
```

### 3.4.2 *Host Commands*

To create a host, use the command:

```
APPLICATION CREATE HOST [OSTYPE=GENERIC|LINUX|MAC_OS|WINDOWS]
```

To delete the specified host, use the command:

```
APPLICATION DELETE HOST=<host-id>
```

To display the presentation associated with the specified application host, use the command:

```
APPLICATION SHOW HOST=<host-id> [PRESENTATIONS]
```

To display the initiators associated with the specified application host, use the command:

```
APPLICATION SHOW HOST=<host-id> [INITIATORS]
```

### 3.4.3 *Presentation Commands*

To present a Virtual Disk to the specified host, use the command:

```
APPLICATION CREATE PRESENTATION HOST=<host-id> VIRTUAL_DISK=<vd-id>  
LUN=<LUN-id>
```

To delete a presentation, use the command:

```
APPLICATION DELETE PRESENTATION HOST=<host-id> VIRTUAL_DISK=<vd-id>  
[FORCE]
```

Note the optional parameter of **FORCE** deletes without confirmation. The wildcard **\*** deletes all presentations.

To set the specified attribute to the specified value, use the command:

```
APPLICATION SET PRESENTATION=<object-id> [<attribute-name>=<value>]
```

Attributes are:

**ENABLE=ALL|NONE|<channel-id>** where the channel-id is the object -id of an Enabled Client Channel.

**LUN=<integer>** where the integer is a Logical Unit Number (LUN) that will be used to present the associated Virtual Disk to the associated Host. NOTE: Each LUN integer entered for a presentation is cumulative and does not replace the previous entry.

**HOME\_ONLY**=[TRUE|FALSE] which enables/disables the home\_only parameter.

**READ\_ONLY**=[TRUE|FALSE] which enables/disables the read\_only parameter.

### 3.4.4 Configuration of Presentations of Virtual Disks to Hosts

---

**NOTE** :If you are configuring a storage subsystem with any “MAC OSx presentations”, it is absolutely required that you read and understand Section 3.4.5, "[Additional Configuration Considerations for Macintosh Hosts](#)" prior to actually doing your configuration.

---

There are three objects/relationships that must be properly established in order to create a presentation of a LUN (Virtual Disk) to a host:

- **Establish a host object** for EACH host that wishes access to the IS16000 storage system Virtual Disk.

---

**NOTE** :On the storage subsystem you **ONLY** need to create a single host object for any/all Virtual Disk presentations to that host.

---

- **Import a discovered initiator** into an established relationship with a host object. An association between a discovered initiator FC Port/Node WWN (World Wide Name) to a host object is established in this operation. This association of host/port WWN to host object is maintained persistently within the subsystems configuration information along with all other information. If the host to controller association is subsequently disrupted and then re-established, the Controller is able to maintain this relationship until such time that the configuration in the storage Controller is cleared or that relationship is deleted.

---

**TIP** : Use of a host based HBA utility such as HBAnyware® or SANsurfer will allow you to examine the FC Port/Node WWNs on the host in the easiest manner.

---

- **Assign a Virtual Disk to a host object.**

---

**NOTE** :You may **ONLY** present a Virtual Disk **ONCE** to the same host object.

---



Warning

**You can present a Virtual Disk to multiple hosts; however, this is dangerous. If doing so, presenting them as Read-Only to the other hosts would be appropriate.**

---



---

**NOTE** :You may present a Virtual Disk to **ALL** hosts. This may be appropriate in some limited system environments; however, it is best practice to not **MIX** the presentations, where some VDs are selectively presented while others are presented all. Managing at the host end may become confusing.

---

To present a Virtual Disk to ALL hosts, use the command:

```
APPLICATION CREATE PRESENTATION VD=<VD-id> HOST=ALL
```

### 3.4.4.1 Host Object Creation Example

The following example demonstrates presenting 6 Virtual Disks to 3 separate hosts (2 Windows hosts and a Linux host) from a single storage subsystem. Although this configuration will have a FC Switch, the steps are identical.

---

**NOTE :**In the example below, the CLUI is operating in the RAID subject mode. The ASM (Application Stack Management) commands must be preceded by the subject application.

---

#### Examples:

```
RAID[1]$ application create host name=co-ls1 ostype=Linux
HOST 301 OID=0x1d5e012d creation STATUS='Success' (0x0)
```

```
RAID[1]$ application create host name=co-test-d10 ostype=windows
HOST 302 OID=0x1d5f012e creation STATUS='Success' (0x0)
```

```
RAID[1]$ app create host name=co-test-d08 ostype=windows
HOST 303 OID=0x1d60012f creation STATUS='Success' (0x0)
```

```
RAID[1]$ application show host *
```

Index	Host Name	Stack Index	Host Mode OS Type	Attributes Characteristics
00304	co-ls1	00000	LINUX	0x0000000000000001
00305	co-test-d10	00000	WINDOWS	0x0000000000000001
00306	co-test-d08	00000	WINDOWS	0x0000000000000001

```
Total Hosts: 3
```

#### Recommendations:

- When creating host objects, always include a descriptive “name” for the host objects that is easily recognizable. This benefits the storage administrator in managing storage connectivity issues.
- The **OS\_TYPE** determines the FC flow control mechanism for host I/O.
- The Linux OS type is currently appropriate for all versions/implementations of Linux and UNIX.
- The Windows OS type is currently appropriate for all versions of the Windows operating systems.
- It is imperative the **OS\_TYPE** for Apple/MAC hosts be appropriately set to MAC. The setup requirements involving MAC OSX hosts require additional steps and considerations. Please see Section 3.4.5, "[Additional Configuration Considerations for Macintosh Hosts](#)".

### 3.4.4.2 Identifying Host FC Connections via Ports

The host ports of the Controller dynamically acknowledge and log in any FC Host/Port WWN connection that it can sync up with. When you query the storage subsystem for the discovered initiators, the listing you get will be the current set of connections that are logged in. If a connection

is broken and then re-established, the re-discovered Port/Node WWN will be assigned a new host\_index number. This is inconsequential after a specific Port/Node WWN is directly associated with a specific host that is done in a subsequent step.

**Example of discovered initiators:**

```
RAID$ app show discovered_initiators *
```

Index	Type	ID	node	Initiator Identifier port	Controller 0		Controller 1	
					RP 0	RP 1	RP 0	RP 1
00003	FC	0x010600	0x20000000c9813cc9	0x20000000c9813cc9			3	0
00005	FC	0x010800	0x20000000c9813cc8	0x20000000c9813cc8			2	
00006	FC	0x010900	0x20000000c9813a47	0x20000000c9813a47				1
00007	FC	0x010a00	0x20000000c9813a46	0x20000000c9813a46				
00011	FC	0x010300	0x2000001b32827e95	0x2000001b32827e95	0			
00012	FC	0x010200	0x2000001b32a27e95	0x2000001b32a27e95	0			

Total FC Initiators: 6

In order to provide an association between a host and a Virtual Disk, you must identify the FC connection (its Node/Port WWN name to the host object). You may use the following techniques:

- Utilize the physical sticker tag information on the HBA.
- Connect a single host at a time (and all its FC connections to the subsystem) to the subsystem (direct connect or via a switch); identify their WWNs as a discovered initiator; then a proceed to plug in subsequent hosts, noting their WWNs.
- Utilize a host based FC Adapter utility such as HBAnyware (for Emulex HBAs) (Figure 111) or SANsurfer (for QLogic HBAs) (Figure 112).

Figure 111. HBAnyware Screen





Figure 112. SANsurfer FC HBA Manager Screen



**Example for Linux system with driver loaded (example of QLogic):**

```
# cd /proc/scsi/qla2xxx
# ls
1 2
# grep adapter-port 1
scsi-qla0-adapter-port=210000e08b9d6149;

bm-dell-09:/proc/scsi/qla2xxx # grep adapter-port 2
scsi-qla1-adapter-port=210100e08bbd6149;

# lsscsi -g | grep -i sgi
[1:0:0:1] disk SGI DD4A-FC008-6620 1.03 /dev/sdc /dev/sg2
[2:0:0:1] disk SGI DD6A-IS16K-10000 1.03 /dev/sdg /dev/sg6
```

**Example for Linux system without driver loaded:**

```
# cd /sys/class/fc_host
# ls -la
total 0
drwxr-xr-x 4 root root 0 Jul 15 11:47 .
drwxr-xr-x 43 root root 0 Jul 15 11:48 ..
drwxr-xr-x 3 root root 0 Jul 15 11:48 host3
drwxr-xr-x 3 root root 0 Jul 15 11:48 host4
# cd host3
# ls -la
total 0
drwxr-xr-x 3 root root 0 Jul 15 11:48 .
drwxr-xr-x 4 root root 0 Jul 15 11:47 ..
lrwxrwxrwx 1 root root 0 Jul 15 11:47 device ->
../../../../devices/pci0000:00/0000:00:04.0/0000:0a:00.0/host3
-r--r--r-- 1 root root 4096 Jul 17 15:31 fabric_name
--w----- 1 root root 4096 Jul 17 15:31 issue_lip
-r--r--r-- 1 root root 4096 Jul 17 15:31 node_name
-r--r--r-- 1 root root 4096 Jul 17 15:31 port_id
-r--r--r-- 1 root root 4096 Jul 17 15:31 port_name
-r--r--r-- 1 root root 4096 Jul 17 15:31 port_state
-r--r--r-- 1 root root 4096 Jul 17 15:31 port_type
-r--r--r-- 1 root root 4096 Jul 17 15:31 speed
drwxr-xr-x 2 root root 0 Jul 15 11:47 statistics
lrwxrwxrwx 1 root root 0 Jul 15 11:48 subsystem -> ../../../../class/fc_host
-r--r--r-- 1 root root 4096 Jul 17 15:31 supported_classes
-r--r--r-- 1 root root 4096 Jul 17 15:31 symbolic_name
-rw-r--r-- 1 root root 4096 Jul 17 15:31 system_hostname
-rw-r--r-- 1 root root 4096 Jul 17 15:31 tgtid_bind_type
--w----- 1 root root 4096 Jul 15 11:47 uevent
# cat port_name
0x2100001b3282dc50
```

---

**NOTE :**In switch environments you may disable/enable the ports on the switch to identify which physical connection you are dealing with.

---

Utilizing one or more of the techniques above, you can document an association between the physical host and the discovered initiators on the storage.

**Example of showing imported initiators:**

```
RAID[1]$ application show initiator *
```

Index	Type	Host Index	node	Initiator Identifier	port
00004	FC	0x010600	0x20000000c98107cb	0x10000000c98107cb	← co-test-d08
00006	FC	0x010900	0x20000000c9813a47	0x10000000c9813a47	← co-test-d10
00007	FC	0x010a00	0x20000000c9813a46	0x10000000c9813a46	← co-test-d10
00008	FC	0x010300	0x20000000c98107ca	0x10000000c98107ca	← co-test-d08
00011	FC	0x010200	0x2000001b32827e95	0x2100001b32827e95	← co-ls1
00012	FC	0x010800	0x2001001b32a27e95	0x2101001b32a27e95	← co-ls1

Now identify the WWN and the discovered initiator index number with the host and its index number and import the appropriate discovered initiator to an association with the appropriate host.

**Example of importing discovered initiators:**

```
RAID[1]$ application import discovered 11 host 304
INITIATOR 12 OID=0x2d66000c imported from DISCOVERED_INITIATOR 11 OID=0x3000000b
STATUS='Success' (0x0)
```

```
RAID[1]$ application import discovered 12 host 304
INITIATOR 13 OID=0x2d67000d imported from DISCOVERED_INITIATOR 12 OID=0x3000000c
STATUS='Success' (0x0)
```

```
RAID[1]$ application import discovered 4 host 306
INITIATOR 14 OID=0x2d68000e imported from DISCOVERED_INITIATOR 4 OID=0x30000004
STATUS='Success' (0x0)
```

```
RAID[1]$ application import discovered 8 host 306
INITIATOR 15 OID=0x2d69000f imported from DISCOVERED_INITIATOR 8 OID=0x30000008
STATUS='Success' (0x0)
```

```
RAID[1]$ app import discovered=6 host=305
INITIATOR 16 OID=0x2d6a0010 imported from DISCOVERED_INITIATOR 6 OID=0x30000006
STATUS='Success' (0x0)
```

```
RAID[1]$ app imp disc 7 host 305
INITIATOR 17 OID=0x2d6b0011 imported from DISCOVERED_INITIATOR 7 OID=0x30000007
STATUS='Success' (0x0)
```

```
RAID[1]$ application show initiator *
```

Index	Type	Host Index	node name	Initiator Identifier	port name
00012	FC	00304	0x2000001b32827e95	0x2100001b32827e95	
00013	FC	00304	0x2001001b32a27e95	0x2101001b32a27e95	
00014	FC	00306	0x20000000c98107cb	0x10000000c98107cb	
00015	FC	00306	0x20000000c98107ca	0x10000000c98107ca	
00016	FC	00305	0x20000000c9813a47	0x10000000c9813a47	
00017	FC	00305	0x20000000c9813a46	0x10000000c9813a46	

```
Total FC Initiators: 6
```

### 3.4.4.3 Presenting a Virtual Disk to a Host

From your list of Virtual Disks that have been created, identify the host that you wish to present this LUN to and create the presentation.

#### Recommendations:

- Commands entered through the CLI may take a shortened form of the unique word as demonstrated in the above examples
- Spaces may be used in place of “=” sign in command syntax

#### Example of list of candidate Virtual Disks for presentation:

```
RAID[1]$ show vd *
```

Idx	Name	State	Pool	Raid	Cap GB	Settings	Jobs	Home		Background
								Current	Preferred	Job
49	vd-49_29	READY	29	6	1400	W I		1(L) 0	1(L) 0	INACTIVE
50	vd-50_30	READY	30	6	1400	W I		0(R) 0	0(R) 0	INACTIVE
51	vd-51_31	READY	31	1	344	W I		1(L) 0	1(L) 0	INACTIVE
52	vd-52_32	READY	32	1	344	W I		0(R) 0	0(R) 0	INACTIVE
53	vd-53_33	READY	33	5	1400	W I		1(L) 0	1(L) 0	INACTIVE
54	vd-54_34	READY	34	5	1400	W I		0(R) 0	0(R) 0	INACTIVE
55	vd-55_35	READY	35	6	3608	W I		1(L) 0	1(L) 0	INACTIVE
56	vd-56_36	READY	36	6	3608	W I		0(R) 0	0(R) 0	INACTIVE
57	vd-57_37	READY	37	5	3608	W I		1(L) 0	1(L) 0	INACTIVE
58	vd-58_38	READY	38	5	3608	W I		0(R) 0	0(R) 0	INACTIVE
59	vd-59_39	READY	39	1	344	W I		1(L) 0	1(L) 0	INACTIVE
60	vd-60_41	READY	41	1	896	W I		1(L) 0	1(L) 0	INACTIVE

Total Virtual Disks: 12

#### Example of creating VD presentation to Windows host co-test-d10 (not specifying SCSI LUN\_ID):

The next two VDs are presented to a Windows host and the subsystem assigns the SCSI LUN\_ID.

```
RAID[1]$ application create presentation vd 51 host 305
PRESENTATION 2482 OID=0x256e09b2 creation STATUS='Success' (0x0)
```

```
RAID[1]$ application create presentation vd 52 host 305
PRESENTATION 2483 OID=0x256f09b3 creation STATUS='Success' (0x0)
```

```
RAID[1]$ application show presentation *
```

Pres. Index	Host Name	Host Index	VD Index	LUN	Home Only	Read Only	Channel Mask			
							Controller 0 0123	Controller 0 0123	Controller 1 0123	Controller 1 0123
02480	co-ls1	00304	00049	060	OFF	R/W	ffff	ffff	ffff	ffff
02481	co-ls1	00304	00050	061	OFF	R/W	ffff	ffff	ffff	ffff
02482	co-test-d10	00305	00051	000	OFF	R/W	ffff	ffff	ffff	ffff
02483	co-test-d10	00305	00052	001	OFF	R/W	ffff	ffff	ffff	ffff

Total Presentations: 4

---

**NOTE :**For Windows environments, you should let the subsystem specify the LUN\_ID for a Virtual Disk.

---

```
RAID[1]$ application create presentation vd 58 host 306 lun 10
PRESENTATION 2484 OID=0x257009b4 creation STATUS='Success' (0x0)
```

```
RAID[1]$ application create presentation vd 59 host 306 lun 12
PRESENTATION 2485 OID=0x257109b5 creation STATUS='Success' (0x0)
```

```
RAID[1]$ app show pres *
```

Pres. Index	Host Name	Host Index	VD Index	LUN	Home Only	Read Only	Channel Mask			
							Controller 0 0123	Controller 0 0123	Controller 1 0123	Controller 1 0123
02480	co-ls1	00304	00049	060	OFF	R/W	ffff	ffff	ffff	ffff
02481	co-ls1	00304	00050	061	OFF	R/W	ffff	ffff	ffff	ffff
02482	co-test-d10	00305	00051	000	OFF	R/W	ffff	ffff	ffff	ffff
02483	co-test-d10	00305	00052	001	OFF	R/W	ffff	ffff	ffff	ffff
02484	co-test-d08	00306	00058	010	OFF	R/W	ffff	ffff	ffff	ffff
02485	co-test-d08	00306	00059	012	OFF	R/W	ffff	ffff	ffff	ffff

Total Presentations: 6

**Recommendations:**

- At times some hosts may have device discovery issues if there are “gaps” in the SCSI LUN\_ID space. Letting the subsystem assign (as it will by default) the lowest SCSI\_ID it can from this subsystem, may be considered a best practice.
- Use of a host based HBA utility such as HBAnyware® or SANsurfer greatly enhances the ability to determine perceived connectivity issues between the storage subsystem and the host.
- Your hosts “multipath driver” must be enabled correctly to recognize the SGI Device/Hardware ID.
  - For Windows Server 2008, the Device/Hardware\_ID information must be entered into the MPIO stack as an 8-bit / 16-character space-padded field.
  - For Linux, the /etc/multipath.conf file must be edited, and the Device/Hardware\_ID is NOT padded with the space character.

```
Device Hardware_ID
SGI DD6A-IS16K-10000
```

### 3.4.5 *Additional Configuration Considerations for Macintosh Hosts*

Apple/Mac Operations systems handles Fibre Channels Port/Node WWNs uniquely. Apple hosts expect node names to be unique across all subsystem ports.

All other OS's expect the FC node names to be the same across all subsystem ports.

Because of this uniqueness, VD presentations must be uniquely set up when an Apple/Mac presentation is being made from a IS16000 subsystem.

---

**NOTE :** You MUST create the host object with **OSTYPE=MAC** for Mac hosts.

---

You must identify at least one Controller port (channel) (preferably one Controller port for each IS16000 Controller) on the storage subsystem as operating in the MAC mode:

```
APPLICATION SET CHANNEL [0|1|2|3] MODE MAC
```

---

**NOTE :** Setting/changing the mode of a “channel” will require a shutdown/restart of the Controller for the change to actually take place.

---

If a Mac presentation is being made from the subsystem, NO other VD from this subsystem should be presented to “ALL” hosts !

In a SAN and/or MIXED OS environment of MAC and other operating systems, create the presentations as follows:

```
APPLICATION CREATE PRESENTATION VD=<vd-id> HOST=<host_index> ENABLE=NONE
```

This will disable channels through which to make a presentation. Then you will next enable the specific channels through which you wish to make the presentation:

```
APPLICATION SET PRESENTATION <index> ENABLE {0|1|2|3}
```

To enable two channels, it is necessary to enter two separate commands.

In the current implementation, you can disable all channels, enable all channels, or enable one channel at a time through the CLUI. If you wish to have two channels enabled, use the following commands:

```
APPLICATION SET PRESENTATION <index> ENABLE 0  
APPLICATION SET PRESENTATION <index> ENABLE 2
```

Channel 0 is CORP0. Channel 1 is CORP1. These are the two RAID processors on Controller 0.

Channel 2 is C1RP0. Channel 3 is C1RP1. These are the two RAID processors on Controller 1.

If you have an existing storage configuration running Windows/Linux presentations and you wish to ADD a VD presentation for MAC:

- You will have to sustain a storage outage now so that you can disable “all” VD presentations thru any channel; and
- Re-enable the appropriate channels one at a time that will be serving VDs to the Windows/Linux hosts.
- You will then set up the appropriate channel(s) that will operate in MAC mode.
- At this point you can restart the storage subsystem, proceed in creating your MAC VD presentations and enable them through their separate channels.

## 3.5 Firmware Update Management

---

SGI periodically releases firmware updates to enhance features of the products. Please contact our Technical Support Department to obtain the latest firmware files.

Before performing any updates, please note the following:

- The **UPDATE ENCLOSURE** command starts a background operation so that the CLUI is free to do other operations during the **UPDATE**. The status that comes back from the **UPDATE ENCLOSURE** command only indicates whether the background operation was successfully started. **SHOW ENCLOSURE <id> UPDATE\_FIRMWARE\_PROGRESS** should be used immediately after the command and then subsequently periodically to check the status of the **UPDATE**.
- When you SCP the Consolidated Download File (.SGI) to the firmware directory, it must be copied to the PRIMARY Controller. Since the PRIMARY may change, it is probably best to copy it to BOTH Controllers. If **SHOW ENCLOSURE <id> UPDATE\_FIRMWARE\_PROGRESS** reports status **JS\_ES\_DL\_UCODE\_OPEN\_FAILED**, the most likely cause is that the file was not copied to the PRIMARY Controller.
- When the IS16000 is busy rebuilding, initializing, or doing host I/O, **UPDATE ENCLOSURE** operations may fail because the enclosure is too busy to service the UPDATE IOs in a timely fashion. Therefore, make sure that there are no rebuilds, initializations, or host I/O operations being done during the **UPDATE ENCLOSURE** operation.
- In order to cause the new enclosure firmware to start being used you must power cycle the enclosure. In the IS16000, it is best to do this by doing a **SHUTDOWN SUBSYSTEM** followed by power-cycling the enclosure. This is also required to recover from an **UPDATE ENCLOSURE** failure. These power cycles are required.
- The **UPDATE PD** command starts a background operation so that the CLUI is free to do other operations during the **UPDATE**. The status that comes back from the **UPDATE PD** command only indicates whether the background operation was successfully started. **SHOW PD \* UPDATE\_FIRMWARE\_PROGRESS** should be used immediately after the command and then subsequently periodically to check the status of the **UPDATE**.
- When you SCP the Consolidated Download File (.SGI) to the firmware directory, it must be copied to the PRIMARY Controller. Since the PRIMARY may change, it is probably best to copy it to BOTH Controllers. If **SHOW PD \* UPDATE\_FIRMWARE\_PROGRESS** reports status **JS\_ES\_PD\_DL\_UCODE\_OPEN\_FAILED** for a physical disk, the most likely cause is that the file was not copied to the PRIMARY Controller.
- Online physical disk firmware update is not currently supported. Therefore, make sure that there are no rebuilds, initializations, or host IO operations being done during the **UPDATE PD** operation. This is enforced by making sure the user has issued the **SET SUBSYSTEM OFFLINE** command before allowing an **UPDATE PD** command.
- In order to cause the new physical disk firmware to start being used you must power cycle the enclosure in which the physical disk is installed. In the IS16000, it is best to do this by doing a **SHUTDOWN SUBSYSTEM** followed by power-cycling the enclosure.

### 3.5.1 Displaying Current Firmware Version

The `SHOW CONTROLLER <id> ALL_ATTRIBUTES` command displays version information of the IS16000's hardware and firmware (Figure 113).

Figure 113. Show Controller Information Screen

```
RAID[0]$ show controller 0 all
Index:                0
OID:                  0x38000000
Firmware Version:
  Release:             1.3.0.4
  Source Version:      4476
  Fully Checked In:    Yes
  Private Build:       No
  Build Type:          Production
  Build Date and Time: 2010-10-02-22:10UTC
  Builder Username:    root
  Builder Hostname:    co-bs2
  Build for CPU Type:  AMD-64-bit
Hardware Version:     0000
State:                RUNNING
:
:
Name:                 A
Controller:           LOCAL (SECONDARY)
Controller ID:        0x0001ff0800a30000
Enclosure OID:        0x50000006 (Index 6)
Universal LAN Address: 0x00000001ff0800a3
MIR Reason:           None
```

Annotations:

- Blue arrow pointing to `1.3.0.4`: Firmware Release Version
- Blue arrow pointing to `4476`: Code Base Version
- Blue arrow pointing to `0x0001ff0800a30000`: ID used for Key Generation
- Blue arrow pointing to `None`: State of Controller ("None" is good!)

### 3.5.2 Controller Firmware Update Procedure

The firmware update procedure described here only applies to upgrades from firmware version 1.3.0.4.xxxx or later to a new version. Upgrades from an older version of firmware must be done by a trained technician.

---

**NOTE :**The IS16000 now supports an upgrade of the firmware while the system is still online. However, you must correctly follow the upgrade instructions to perform a successful online upgrade.

---

If you are upgrading from v1.3.0.4.xxxx or later, there are two methods that can be utilized:

- Copy the new firmware image over to the Controller via the network instead of using a USB flash disk for Linux.
- Copy the new firmware image over to the Controller via the network for Windows users.

---

**NOTE :**In the examples, the filename of the firmware image is `sgi-flash-2812-opt.tgz` and the IP address of the controller is `10.32.31.240`. Replace these parameters with the filename and IP address appropriate for your installation.

---

### 3.5.2.1 Linux Environment-Firmware Update from the Network

Follow these steps to update the firmware:

1. Copy the new firmware to both Controllers using an scp or sftp client. The user name is **firmware** and the password is **Firmware** (Note that entries are case-sensitive).

For example:

```
scp sgi-flash-2812-opt.tgz firmware@10.32.31.240:
```

2. At the CLUI prompt, enter command:

```
UPDATE_FIRMWARE CONTROLLER=LOCAL FILE="<file-specification>"
```

For example:

```
UPDATE_FIRMWARE CONTROLLER=LOCAL FILE="sgi-flash-2812-opt.tgz"
```

(Note that the file name must be enclosed with double quotation marks.)

3. Upon completion of reboot, login and enter the command:

```
SHOW CONTROLLER LOCAL ALL
```

Verify that the firmware version is correct.

---

**NOTE :**The pools may indicate there is a fault. Issue the command **SHOW POOLS \*** to check the details of the pool. The pools will go into WR thru state on initial startup to allow the batteries the opportunity to charge. The WR Thru mode is necessary to allow for data integrity until battery redundancy on each Controller is completed. If there is a battery issue, the system will indicate replacement is required and all VDs will remain in WR Thru mode until the issue is resolved.

---

For example:

```
CLUI unable to get RAID SUBSYSTEM NAME. STATUS='MIR:Firmware Version Mismatch'  
(0x30003f8)
```

---

**NOTE :**The firmware will be in MIR, firmware version mismatch state for the first Controller that is upgraded. You must ensure that you have a CLUI prompt from the newly upgraded Controller before moving to Step 4.

---

4. Upgrade the second Controller by repeating Steps 2-3 above on the other Controller.


### 3.5.2.2 Windows Environment-Firmware Update from the Network

This method requires a SFTP or SCP client, and involves two steps – copying the firmware image to both Controllers and launching the update.

1. Copy the new firmware to the Controller using an scp or sftp client. You must use an application that supports SFTP or SCP. WinSCP, a free SFTP and SCP client, is used in this example.
2. Launch WinSCP or other SFTP/SCP client. For hostname, use the IP address of your Controller. user name is **firmware** and password is **Firmware**. Both user name and password are case-sensitive.
3. Select Login .

At the login screen (Figure 114), use the user name **admin** with the password **password** to log into the system. User name and passwords are care sensitive.

Figure 114. Login Screen



4. Find the image file and drag this to the destination window and select copy. Copy operation commences.

#### To launch the update:

1. Login to the Controller via an SSH session with the user name **user** and password **user**.
2. At the CLI prompt, enter:  
`update_firmware controller=<controller-id> FILE="<file-specification>"`

For example:

```
update_firmware controller=LOCAL FILE= "sgi-flash-2812-opt.tgz"
```

---

**NOTE :**The quotes around the filename of the firmware image are required.

---

3. Upon completion of reboot, login and enter the command:  
**SHOW CONTROLLER LOCAL ALL**  
 Verify that the firmware version is correct.

---

**NOTE :**The pools may indicate there is a fault. Issue the command **SHOW POOLS \*** to check the details of the pool. The pools will go into WR thru state on initial startup to allow the batteries the opportunity to charge. The WR Thru mode is necessary to allow for data integrity until battery redundancy on each Controller is completed. If there is a battery issue, the system will indicate replacement is required and all VDs will remain in WR Thru mode until the issue is resolved.

---

For example:

```
CLUI unable to get RAID SUBSYSTEM NAME. STATUS='MIR:Firmware Version Mismatch'  
(0x30003f8)
```

---

**NOTE :**The firmware will be in MIR, firmware version mismatch state for the first controller that is upgraded. You must ensure that you have a CLUI prompt from the newly upgraded controller before moving to Step 4.

---

4. Upgrade the second Controller by repeating Steps 2-3 above on the other Controller.

### 3.5.3 Disk Enclosure Firmware Update Procedure




---

**Before starting this procedure, verify that a power cycle or any perturbations to the system is NOT required for the next two hours. This procedure requires that all host IO is shutdown prior to its use. Any outstanding formats or rebuilds must not be running. Check the status of any outstanding formats or rebuilds and verify that no disk IO activity is in process before updating your firmware.**

---

There are two (2) parts to update the enclosure firmware:

1. Upload the enclosure firmware to the enclosure using either Linux Environment or Windows.
2. Update Disk Shelf using CLUI commands.

#### 3.5.3.1 Linux Environment-Firmware Upload

Obtain the firmware from SGI. Firmware must be running on the IS16000 and must be connected to the enclosure to be upgraded.

1. Copy the new firmware to the Controller using an scp or sftp client. The user name is **firmware** and the password is **Firmware**. (Note that entries are case-sensitive.)  
Use the secured copy program (scp) to transfer the file to the expander with the command: **scp <firmware file name> firmware@<ip\_address\_of\_IS16000>:**

---

**NOTE :**Ensure the colon (:) is at the end of the above command.

---

2. Enter the password **Firmware**. (Note that entries are case-sensitive).

The file will be copied to the Controller.

#### 3.5.3.2 Windows Environment-Firmware Upload

Obtain the firmware from SGI. Firmware must be running on the IS16000 and must be connected to the enclosure to be upgraded.

1. Use the putty secured copy program (pscp) to transfer the file to the expander with the command: **pscp <firmware file name> firmware@<ip\_address\_of\_IS16000>:**

---

**NOTE :**Ensure the colon (:) is at the end of the above command.

---

2. Enter the password **Firmware**. (Note that entries are case-sensitive).

The file will be copied to the Controller.

#### 3.5.3.3 Disk Shelf Upgrade

Once the file is copied from either procedure above (Linux or Windows), follow the steps below to complete the upgrade:

1. Log onto the Controller.  
User name is **user**. Password is **user**.

- At the CLUI prompt, enter the command:  
**UPDATE ENCLOSURE <enclosure num> FILE=<file name uploaded>**

The upgrade will take approximately 2 hours. You can have multiple upgrades going simultaneously so that all disk enclosures can be upgraded at the same time to expedite the upgrade.

- To monitor the upgrade progress, enter the command:  
**SHOW ENCLOSURE 1 UPDATE\_FIRMWARE\_PROGRESS**

For example:

```
RAID[0]$ show enclosure 1 update_firmware_progress
ES download progress for enclosure 1.
  CDF file name      /tmp/janus_update//IS_D02_011.SGI
  CDF is for Vendor ID  SGI
  CDF is for Product ID IS OS
  CDF package version D02.011
  CDF release date    01-SEP-2010
  Download is in progress and 15 percent complete.
  Download consists of 2 images.
  Image 2 is in progress and 13 percent complete.
```

- When the download is complete, you must power-cycle the enclosure.
- To verify that the update was successful, enter the command:  
**SHOW ENCLOSURE 1 UPDATE\_FIRMWARE\_PROGRESS**

For example:

```
RAID[0]$ show enclosure 1 update_firmware_progress
ES download progress for enclosure 1.
  Download not in progress -- last download completed successfully.
```

- Verify that the upgrade was successful by using the command: **SHOW EXPANDER**

---

**NOTE :** The expanders are Sub Index 3 through 10. Ensure that the Firmware version and the Init String version are identical.

---

For example:

```
RAID[0]$ show expander 1 * all
Sub Index:      1
Sub OID:        0x78000001
Enclosure Index: 1
Enclosure OID:  0x50000001
Position:       1
SES Status:     OK
Present:        TRUE
Predicted Failure Ind: OFF
Locate Indicator: OFF
Firmware version: 0078

Sub Index:      2
Sub OID:        0x78000002
Enclosure Index: 1
Enclosure OID:  0x50000001
Position:       2
SES Status:     OK
Present:        TRUE
Predicted Failure Ind: OFF
Locate Indicator: OFF

Sub Index:      3
Sub OID:        0x78000003
Enclosure Index: 1
Enclosure OID:  0x50000001
Position:       3
SES Status:     OK
Present:        TRUE
Predicted Failure Ind: OFF
Locate Indicator: OFF
Part number:    TCA-00300-01-A
Serial number:  MXSCI00089HVD12B
Firmware version: D02.011
Init string version: D02.011
FPGA version:   7

Sub Index:      4
Sub OID:        0x78000004
Enclosure Index: 1
Enclosure OID:  0x50000001
```

Position: 4  
 SES Status: OK  
 Present: TRUE  
 Predicted Failure Ind: OFF  
 Locate Indicator: OFF  
 Part number: TCA-00300-01-A  
 Serial number: MXSCI00089HVD110  
 Firmware version: D02.011  
 Init string version: D02.011  
 FPGA version: 7

Sub Index: 5  
 Sub OID: 0x78000005  
 Enclosure Index: 1  
 Enclosure OID: 0x50000001  
 Position: 5  
 SES Status: OK  
 Present: TRUE  
 Predicted Failure Ind: OFF  
 Locate Indicator: OFF  
 Part number: TCA-00300-01-A  
 Serial number: MXSCI00085QVD2CB  
 Firmware version: D02.011  
 Init string version: D02.011  
 FPGA version: 7

Sub Index: 6  
 Sub OID: 0x78000006  
 Enclosure Index: 1  
 Enclosure OID: 0x50000001  
 Position: 6  
 SES Status: OK  
 Present: TRUE  
 Predicted Failure Ind: OFF  
 Locate Indicator: OFF  
 Part number: TCA-00300-01-A  
 Serial number: MXSCI00086QVD109  
 Firmware version: D02.011  
 Init string version: D02.011  
 FPGA version: 7

Sub Index: 7  
 Sub OID: 0x78000007  
 Enclosure Index: 1  
 Enclosure OID: 0x50000001  
 Position: 7  
 SES Status: OK  
 Present: TRUE  
 Predicted Failure Ind: OFF  
 Locate Indicator: OFF  
 Part number: TCA-00300-01-A  
 Serial number: MXSCI000893VD19D  
 Firmware version: D02.011  
 Init string version: D02.011  
 FPGA version: 7

Sub Index: 8  
 Sub OID: 0x78000008  
 Enclosure Index: 1  
 Enclosure OID: 0x50000001  
 Position: 8  
 SES Status: OK  
 Present: TRUE  
 Predicted Failure Ind: OFF  
 Locate Indicator: OFF  
 Part number: TCA-00300-01-A  
 Serial number: MXSCI00085LVD0A5  
 Firmware version: D02.011  
 Init string version: D02.011  
 FPGA version: 7

Sub Index: 9  
 Sub OID: 0x78000009  
 Enclosure Index: 1  
 Enclosure OID: 0x50000001  
 Position: 9  
 SES Status: OK  
 Present: TRUE  
 Predicted Failure Ind: OFF  
 Locate Indicator: OFF  
 Part number: TCA-00300-01-A  
 Serial number: MXSCI00089HVD11A  
 Firmware version: D02.011  
 Init string version: D02.011  
 FPGA version: 7

Sub Index: 10  
 Sub OID: 0x7800000a  
 Enclosure Index: 1  
 Enclosure OID: 0x50000001  
 Position: 10  
 SES Status: OK  
 Present: TRUE  
 Predicted Failure Ind: OFF  
 Locate Indicator: OFF  
 Part number: TCA-00300-01-A  
 Serial number: MXSCI00089HVD12C  
 Firmware version: D02.011  
 Init string version: D02.011  
 FPGA version: 7

Total Expanders: 10

### 3.5.4 Physical Disk Firmware Update Procedure




---

**This procedure requires that all host IO is shutdown prior to its use. Any outstanding formats or rebuilds must not be running. Check the status of any outstanding formats or rebuilds and verify that no disk IO activity is in process before updating your firmware.**

---

There are two (2) parts to update the physical disk firmware:

1. Upload the physical disk firmware to the IS16000 using either Linux Environment or Windows.
2. Update the Physical Disk using CLUI commands.

#### 3.5.4.1 Linux Environment-Firmware Upload

Obtain the firmware from SGI.

1. Use the secured copy program (scp) to transfer the file to the IS16000 with the command: **scp <firmware file name> firmware@<ip\_address\_of\_IS16000>:**

---

**NOTE :**Ensure the colon (:) is at the end of the above command.

---

2. Enter the password (case-sensitive) **Firmware**.

The file is copied to the IS16000.

#### 3.5.4.2 Windows Environment-Firmware Upload

Obtain the firmware from SGI.

1. Use the putty secured copy program (pscp) to transfer the file to the IS16000 with the command: **pscp <firmware file name> firmware@<ip\_address\_of\_IS16000>:**

---

**NOTE :**Ensure the colon (:) is at the end of the above command.

---

2. Enter the password (case-sensitive) **Firmware**.

The file is copied to the IS16000.

#### 3.5.4.3 Physical Disk Upgrade

Once the file is copied from either procedure above (Linux or Windows), follow the steps below to complete the upgrade:

1. Log onto the Controller.  
User name is **user**. Password is **user**.
2. At the CLUI prompt, enter command:  
**SET SUBSYSTEM OFFLINE**

---

**NOTE :**The subsystem must be offline before proceeding with the remaining steps.

---

- At the CLUI prompt, enter command:  
**UPDATE PD \* FILE=<file name uploaded>**

The firmware will be updated on any physical disks that match the Vendor Id, Product Id, and Drive Type (SAS/SATA) in the file. The upgrade time varies but typically takes less than a minute.

For example:

```
RAID[0]$ update pd * file="WD2002FYPS_05D07.SGI"
A request has been made to update physical disk firmware. No attempt will be made to preserve
redundancy if the physical disk resides in a pool. If the update to the physical disk
encounters catastrophic failure, then this may result in lost data if the pool loses all
of its redundancy.
It is recommended that a backup is done prior to this operation.
Are you sure you want to update physical disk firmware [Yes]?
PHYSICAL DISK 65535 OID=0xffffffff firmware update started STATUS='An asynchronous command
has been started' (0x3000068)
The controller has initiated the download operation which may take up to several minutes.
Check the progress and status of the download operation with SHOW PD n
UPDATE_FIRMWARE_PROGRESS. Additional information may be found in the event log.
```

- To monitor the upgrade progress, enter command:  
**SHOW PD \* UPDATE\_FIRMWARE\_PROGRESS**

For example (non-matching drives omitted in output for clarity):

```
RAID[0]$ show pd * update_firmware_progress
Encl|Slot| Vendor | Product ID |Type| Revision| Serial Number | Pool|Idx| WWN | % Complete| Status
-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----
1 5 HITACHI HUS153014VLS300 SAS A410 JFVWMZNC5301 UNAS 271 50014ee2032d2555 56% In Progress
1 6 HITACHI HUS153014VLS300 SAS A410 J4V1YYAA5301 UNAS 272 50014ee2032d196c 56% In Progress
1 17 HITACHI HUS153014VLS300 SAS A410 JFVWL5YC5301 UNAS 274 50014ee2032ca9a9 56% In Progress
1 18 HITACHI HUS153014VLS300 SAS A410 JFVSU5PC5301 UNAS 269 50014ee25882b499 56% In Progress
```

- When the upgrade has completed, to verify that the download succeeded, enter command:  
**SHOW PD \* UPDATE\_FIRMWARE\_PROGRESS**

For example (non-matching drives omitted in output for clarity):

```
RAID[0]$ show pd * update_firmware_progress
Encl|Slot| Vendor | Product ID |Type| Revision| Serial Number| Pool|Idx| WWN | % Complete|Status
-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----
1 5 HITACHI HUS153014VLS300 SAS A410 JFVWMZNC5301 UNAS 271 50014ee2032d2555 Done JS_GBL_SUCCESS (Success)
1 6 HITACHI HUS153014VLS300 SAS A410 J4V1YYAA5301 UNAS 272 50014ee2032d196c Done JS_GBL_SUCCESS (Success)
1 17 HITACHI HUS153014VLS300 SAS A410 JFVWL5YC5301 UNAS 274 50014ee2032ca9a9 Done JS_GBL_SUCCESS (Success)
1 18 HITACHI HUS153014VLS300 SAS A410 JFVSU5PC5301 UNAS 269 50014ee25882b499 Done JS_GBL_SUCCESS (Success)
```

- Shutdown the subsystem, enter command:  
**SHUTDOWN SUBSYSTEM**
- Power-cycle the enclosures containing the updated physical disks.
- After powering up the disk enclosures and Controller, verify the upgrade was successful, enter command:  
**SHOW PD \***

The firmware version of the updated physical disks should indicate the new version.

For example (non-matching drives omitted in output for clarity):

```
RAID[0]$ show pd *
Encl|Slot| Vendor | Product ID |Type| Cap GB | RPM|Revision| Serial Number |Pool| State|Idx | State | WWN |
-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
1 5 HITACHI HUS153014VLS300 SAS 1863 5.4K A410 JFVWMZNC5301 UNAS GOOD 279 READY 50014ee2032d2555
1 6 HITACHI HUS153014VLS300 SAS 1863 5.4K A410 J4V1YYAA5301 UNAS GOOD 280 READY 50014ee2032d196c
1 17 HITACHI HUS153014VLS300 SAS 1863 5.4K A410 JFVWL5YC5301 UNAS GOOD 282 READY 50014ee2032ca9a9
1 18 HITACHI HUS153014VLS300 SAS 1863 5.4K A410 JFVSU5PC5301 UNAS GOOD 277 READY 50014ee25882b499
```

## 3.6 The System Logs

### 3.6.1 Displaying Event Logs

To display the event log starting at the start sequence number in ascending sequence number order (Figure 115), enter command:

```
SHOW CONTROLLER <id> LOG ASCEND
```

Figure 115. Show Controller Log Example Screen (1)

```
RAID[0]$ show controller 0 log ascend

000001 2010-06-04 01:03:26:6418393 G=0 S=0 T=1 RP=0 VP=1
LOG_ES_UPS_CLIENT_ATTRIBUTE_NAME ES Controller enclosure 0x1ff0800a30000 UPS attribute 0.....

000002 2010-06-04 01:03:26:6418400 G=0 S=0 T=1 RP=0 VP=1
LOG_ES_UPS_CLIENT_ATTRIBUTE_CHANGED ES Controller UPS attribute 0 changed to 37.....

000003 2010-06-04 01:04:52:8320854 G=3 S=1 T=1 RP=0 VP=1
LOG_LOGDISK_ENABLE_RECEIVED_FROM_STATE LOG RECEIVED FROM STATE
```

To display the event log starting at the start sequence number in descending sequence number order (Figure 116), enter command:

```
SHOW CONTROLLER <id> LOG DESCEND
```

Figure 116. Show Controller Log Example Screen (2)

```
RAID[0]$ SHOW CONTROLLER 1 LOG DESCEND

000024 2010-02-11 05:08:48:7027390 G=0 S=0 T=1 RP=0 VP=1 LOG_JOI_TIME_SET JOI TIME
WAS SET BY AN ADMINISTRATOR AT 2010-2-11 5:8:48; NEARBY LOG ENTRIES MAY APPEAR OUT
OF TIME ORDER. OFFSET= 0X1C987C765CD3B2B.

000023 2010-02-06 04:49:20:5069068 G=3 S=1 T=1 RP=0 VP=1 LOG_LOGDISK_ENABLE_RECEIVED
_FROM_STATE LOGRECEIVED FROM STATE

000022 2010-02-06 04:49:20:4952631 G=0 S=0 T=1 RP=0 VP=1 LOG_JOI_TIME_SET JOI TIME
WAS SET BY AN ADMINISTRATOR AT 2010-2-6 4:49:20; NEARBY LOG ENTRIES MAY APPEAR OUT
OF TIME ORDER. OFFSET= 0X1C987C7A302483D.
```

To display the event log starting at the specified start sequence number in ascending sequence number order (Figure 117), enter command:

```
SHOW CONTROLLER <id> LOG ASCEND START_SEQUENCE <start-sequence-number>
```

Figure 117. Show Controller Log Example Screen (3)

```
RAID[0]$ SHOW CONTROLLER 1 LOG ASCEND START_SEQUENCE 20

000021 2010-02-06 04:49:20:4731906 G=4 S=2 T=1 RP=0 VP=1 LOG_ST_MIR_STATE STATE
MIR STATE STATE:000A

000022 2010-02-06 04:49:20:4952631 G=0 S=0 T=1 RP=0 VP=1 LOG_JOI_TIME_SET JOI TIME
WAS SET BY AN ADMINISTRATOR AT 2010-2-6 4:49:20; NEARBY LOG ENTRIES MAY APPEAR
OUT OF TIME ORDER.OFFSET = 0X1C987C7A302483D.

000023 2010-02-06 04:49:20:5069068 G=3 S=1 T=1 RP=0 VP=1 LOG_LOGDISK_ENABLE_
RECEIVED_FROM_STATE LOG RECEIVED FROM STATE

000024 2010-02-11 05:08:48:7027390 G=0 S=0 T=1 RP=0 VP=1 LOG_JOI_TIME_SET JOI TIME
WAS SET BY AN ADMINISTRATOR AT 2010-2-11 5:8:48; NEARBY LOG ENTRIES MAY APPEAR
OUT OF TIME ORDER. OFFSET = 0X1C987C765CD3B2B.
```

### 3.6.2 Event Log Structure

Figure 118 below illustrates the structure of an event log.


The severity levels include:

- 0: Informational
- 1: Warning
- 2: Error
- 3: Fatal

Some additional parameters are:

- ES: Enclosure WWN:Slot number (for example, 50001ff101ed0000:60)
- IOC: SAS/SATA controller number IOC0 (for example, WWN:5000cca216ed8430)
- RC: Reason Code (04 - Device Not Responding)
- PHY: Expander PHY device is attached too (for example, PHY:08)
- ASCQ: ASC/ASCQ SCSI sense data

Figure 118. Event Log Structure



### 3.6.3 Special Terminology in the Log

- **STATE** – Implements all policy, implements the metadata store, handles all dual-controller issues, and controls all other modules
- **ES** (Enclosure Services) – Monitors all disk enclosures and its local controller enclosure
- **AMPD** and **MPI** – Implements the back-end (SAS/SATA) I/O Controller drivers for access and discovery of Physical Disks and Enclosures
- **CM** (Cache Manager) – Implements read and write-back cache
- **RAID** – Implements RAID-5, RAID-6, RAID-1, and rebuilds
- **MAD** – Data transfer and parity calculations
- **RT** (Routing) – Routes VD request to the right CM
- **IOF** (I/O Forwarding) – Routes PD requests to the right AMPD
- **DUCK** – Dual-controller communication
- **JOI, JEX, JIPC, MIS, JTS** – Infrastructure, communication, and testing


## 3.7 Remote Management of IS16000

The IS16000 can be managed locally through the RS-232 interface, or remotely via SSH. The CLUI is the same regardless of the management interface (RS-232 or SSH).

### 3.7.1 Network Connection

Connect the Ethernet port on the back of the Controllers to your Ethernet network (Figure 119). Then configure the network interface as described below.

Figure 119. Ethernet Connections to Your Network



**NOTE :**Currently, the IS16000 does not support network configuration protocols such as DHCP or BOOTP.

### 3.7.2 Display Network Interface Attributes

To display the current network interface settings, enter the command (Figure 120):

```
UI SHOW NETWORK_INTERFACE [LOCAL|REMOTE|0|1] *
```

where **LOCAL** gives you information on the Controller that you are currently logged into.

Figure 120. Current Network Interface Settings Screen

```
RAID[0]$ ui show network_interface=local 0 *
Network device id 0
address 10.32.31.31
netmask 255.255.240.0
gateway 10.32.16.2
```

### 3.7.3 Change Network Interface Settings

**NOTE :**Initial network interface settings must be configured using the serial interface. Refer to Section 2.8.8, "Configure Network Interface Settings" for more information.

To change the network interface settings on the Controller you are connected to, enter the command (Figure 121):

```
UI SET NETWORK_INTERFACE=LOCAL 0 IP_ADDRESS=<ip_address> IP_MASK=<netmask>
IP_GATEWAY=<gateway>
```

Figure 121. Set Network Interface Example

```
RAID[0]$ ui set network_interface=local 0 ip_address=10.32.31.31 ip_mask=255.255.240.0 ip_gateway=10.32.16.2
NETWORK_INTERFACE 0 set with STATUS='Success' (0x0)
```

### 3.7.4 Logins

By default, the login name is **user** and its password is **user**. Both are case sensitive.

Only one SSH session is permitted at a time. Once a SSH session is initiated, the RS-232 console switches to a CLI sub-shell. The SSH client should be using port 22 with its local echoing function disabled.

Figure 122. SSH Login Screen

```
login as: user
user@10.23.23.16's password:
Linux (none) 2.6.25-sgi-016620-3 #2 SMP Wed Jan 14 10:38:28 MST 2009 x
SGI InfiniteStorage 16000
```

### Logout

To logout, enter command **QUIT**. For SSH connection, the current session will be disconnected.

## 3.7.5 Email and SNMP Notification Setup

### 3.7.5.1 Email Setup

Automatic emails will be sent as notification of a selected group of warning and error events that have occurred on the IS16000.

The recipient address is user-configurable and only one address is permitted per system.

To set the email address, enter the command (Figure 123):

```
UI SET EMAIL IP_ADDRESS=<ip_address> IP_PORT=<port>
FROM= "<email address>" TO="<email address>" SUBJECT="text"
```

To show all the email address attributes, use the **UI SHOW EMAIL ALL** command (Figure 123).

Figure 123. Email Setup Example Screen

```
RAID[0]$ ui set email ip_address=192.168.0.10
SNMP Agent set with STATUS='Success' (0x0)
RAID[0]$ ui set email ip_port=25
SNMP Agent set with STATUS='Success' (0x0)
RAID[0]$ ui set email to="jdoe@sgi.com"
SNMP Agent set with STATUS='Success' (0x0)
RAID[0]$ ui set email subject="SGI IS16000 Event Notification"
SNMP Agent set with STATUS='Success' (0x0)
RAID[0]$ ui show email
IP_ADDRESS=192.168.0.10
IP_PORT=25
FROM=jdoe@sgi.com
TO=jdoe@sgi.com
SUBJECT=SGI IS16000 Event Notification
```

### 3.7.5.2 SNMP Setup

The Simple Network Management Protocol (SNMP) monitors network attached devices for conditions that warrant administrative attention. The SNMP traps have been implemented to monitor critical and warning events. A management information base (MIB) has also been created to be used to provide inquiry objects and events to the user’s monitoring application. The IS16000 SNMP traps expose management data on the managed system in the areas of temperature sensor, fans, power supplies, pools, and physical disks as well as a variety of real-time critical and error events.

Each Controller has an SNMP\_AGENT. When changing the SNMP settings, you must set the changes on each Controller separately.

To set the IP address, enter the command (Figure 124):

```
UI SET SNMP IP_ADDRESS=<ip_address> COMMUNITY="<name>"
```

To show all the SNMP trap agent attributes, use **UI SHOW SNMP** command (Figure 124).

Figure 124. SNMP Configuration Example Screen

```
RAID[0]$ ui set snmp ip_address=192.168.0.10
SNMP Agent set with STATUS='Success' (0x0)
RAID[0]$ ui set snmp community=public
SNMP Agent set with STATUS='Success' (0x0)
RAID[0]$ ui show snmp
SNMP Trap Agent Attributes
IP_ADDRESS=192.168.0.10
COMMUNITY=public
```

### 3.7.5.3 Inquiry Items and Events

Figure 125, Figure 126, and Figure 127 below detail the additional inquiry items and events that will be trapped in the SNMP MIB and in the Email Agent.

Figure 125. SNMP Inquiry Objects

SNMP Inquiry Objects	
Item	Returned Values
Temperature Sensor	Number of temperature sensors, list of temperature sensors. For each sensor : ID, Enclosure ID, Enclosure position, Status (normal, warning, critical).
Fans	Number of fans in the system, list of fans. For each fan: ID, Enclosure ID, Enclosure position, Status (healthy, failure).
Power Supplies	Number of power supplies in the system, list of power supplies. For each power supply: ID, Enclosure ID, Enclosure position, Status (healthy, failure).
Pools	Number of pools, list of pools. For each pool: OID, type (storage, spare, unassigned), access, number of members.
Physical Disks	List of disks, for each disk: WWN, enclosure number, slot, status (normal, failed, predicted failure, unknown)

Figure 126. SNMP Only Events

SNMP ONLY Events	
Error	Description
LOG_AMPD_DEVICE_INIT_FAILED	A device failed to initialize.

Figure 126. SNMP Only Events

SNMP ONLY Events	
Error	Description
LOG_AMPD_DSK_DEVICE_INIT_FAILED	DISK device initialization failure.
LOG_AMPD_ICL_DEVICE_INIT_FAILED	ICL device initialization failure.
LOG_AMPD_MPI_DSK SCSI_SENSE_DATA	Disk data received.
LOG_AMPD_MPI_ICL SCSI_SENSE_DATA	ICL SCSI sense data was received.
LOG_AMPD_MPI SCSI_SENSE_DATA_EVENT	SCSI sense data was received.
LOG_AMPD_MPI_SES SCSI_SENSE_DATA	SES SCSI sense data was received.
LOG_AMPD_SES_DEVICE_INIT_FAILED	SES device initialization failure.
LOG_ES_BATTERY_FAILURE_PREDICTED	UPS for the Controller is predicted to fail and should be replaced.
LOG_ES_COOLING_ELEMENT_INSERTED	A fan (located in the power supply) has been inserted.
LOG_ES_COOLING_ELEMENT_NORMAL	A fan (located in the power supply) has returned to normal status.
LOG_ES_COOLING_ELEMENT_REMOVED	A fan (located in the power supply) has been removed.
LOG_ES_COOLING_ELEMENT_WARNING	Enclosure cooling element has reported a warning condition.
LOG_ES_DISK_SLOT_ELEMENT_INSERTED	A device has been inserted into a disk slot.
LOG_ES_DISK_SLOT_ELEMENT_REMOVED	A device has been removed from a disk slot.
LOG_ES_ENCL_UPS_WARN_AC	UPS for the Controller has started with no AC power.
LOG_ES_EXPANDER_ELEMENT_INSERTED	A DEM or an IO module has been inserted.
LOG_ES_EXPANDER_ELEMENT_NORMAL	The enclosure expander element has reported a warning condition.
LOG_ES_EXPANDER_ELEMENT_REMOVED	A DEM or an I/O module has been removed.
LOG_ES_EXPANDER_ELEMENT_WARNING	The DEM reports normal.
LOG_ES_POWER_SUPPLY_INSERTED	A power supply has been inserted.
LOG_ES_POWER_SUPPLY_NORMAL	The power supply has returned to a normal status.
LOG_ES_POWER_SUPPLY_REMOVED	A power supply has been removed.
LOG_ES_POWER_SUPPLY_WARNING	Power supply for the Controller issued warning.
LOG_ES_TEMPERATURE_SENSOR_INSERTED	A temperature sensor (located in the power supply) has been inserted.
LOG_ES_TEMPERATURE_SENSOR_NORMAL	A temperature sensor (located in the power supply) has returned to normal status.
LOG_ES_TEMPERATURE_SENSOR_REMOVED	A temperature sensor (located in the power supply) has been removed.
LOG_ES_TEMPERATURE_SENSOR_WARNING	A temperature sensor in the enclosure has reported a warning condition.
LOG_ES_UPS_CLIENT_IS_RESPONSIVE	Controller enclosure UPS is responsive.

Figure 126. SNMP Only Events

SNMP ONLY Events	
Error	Description
LOG_RAID_UNCORRECTED_MEDIUM_ERR	Aphysical device medium error could not be corrected due to lack of pool redundancy.
LOG_RAID_UNCORRECTED_SILENT_ERR	A SATAssure error (silent error) could not be corrected due to lack of pool redundancy.
LOG_RT_SNMP_TRAP_EVENT	Event received.
LOG_ST_MEMBER_CHANGE	A member of a storage pool has changed its status.

Figure 127. SNMP and Email Notification Events

SNMP and Email Notification Events	
Error	Description
LOG_AMPD_MPI_IOC_INIT_FAIL	SAS/SATA channel has failed to initialize.
LOG_ES_COOLING_ELEMENT_ERROR	Enclosure cooling element has reported an error condition.
LOG_ES_CTLR_PWR_SRC_CHANGED	Controller power source has changed.
LOG_ES_ENCL_UPS_WARN_BATT	UPS for the Controller indicates that its battery should be replaced.
LOG_ES_ENCL_UPS_WARN_INTF	UPS for the Controller indicates that its interface has failed. Check the cable.
LOG_ES_ENCL_UPS_WARN_UPS	UPS for the Controller indicates that it has failed.
LOG_ES_EXPANDER_ELEMENT_ERROR	A DEM or an I/O module has reported an error condition.
LOG_ES_POWER_SUPPLY_ERROR	The power supply for one of the enclosure within the subsystem reported error condition.
LOG_ES_SET_BATTERY_CHARGER_FAILED	Attempt to set Controller battery charger current and voltage failed.
LOG_ES_TEMPERATURE_SENSOR_ERROR	The enclosure temperature sensor has reported an error condition.
LOG_ES_UPS_CLIENT_IS_NOT_RESPONSIVE	Controller enclosure UPS is not responsive. Check the USB cable between the UPS and Controller.
LOG_ST_HEARTBEAT_MISMATCH	Heartbeat mismatch reboot.
LOG_ST_MIR_STATE	Manual Intervention Required state.
LOG_ST_MIRROR_JOIN_FAIL	Other Controller unable to flush mirror data status.
LOG_ST_NO_CONFIG_READ	Unable to read the configuration from backend drives status.
LOG_ST_NO_CONFIG_WRITE	Unable to write the configuration to backend drives status.
LOG_ST_POOL_CHANGE	Pool state changed.
LOG_ST_SET_AWL	Auto Write Lock condition.
LOG_ST_SET_CRITICAL	Critical condition state.
LOG_ST_SET_FAILED	Failed condition.

Figure 127. SNMP and Email Notification Events

<b>SNMP and Email Notification Events</b>	
<b>Error</b>	<b>Description</b>
LOG_ST_SPLIT_BRAIN	The Controllers have lost communications with each other and are operating in split-brain mode.
LOG_SYS_STARTUP	The system has been restarted.

# CHAPTER 4

## *Troubleshooting*

---



## 4.1 Troubleshooting

---

This section describes common problems, with possible solutions, which can occur with the IS16000 system.

### 4.1.1 “RAID[0]” Prompt is not shown correctly

The default CLUI prompt is “RAID[0]”. If “CLUI\$” is shown instead of “RAID[0]”, one of the following problems may have occurred:

- The firmware on this Controller is in a “MIR” state and the MIR state needs to be resolved.
- The CLUI has lost communication with the firmware or the firmware is not running. A restart of the system is needed.
- There are multiple CLUI connections to the firmware already and there are not enough resources to allow another connection. Only one CLUI connection is currently supported.

### 4.1.2 Event Log

Some types of issues can be seen from the event log:

- Background jobs affecting performance

```
014547 2009-08-31 12:30:08:1953906 G=62 S=0 T=1 RP=0 VP=1 LOG_ST_MEMBER_CHANGE
STATE POOL MEMBER CHANGE INDEX:00000000 ID:0x5000cca20def4516 PDIDI:0085 MEMBER_INDEX:0000
STATE:REBUILD
```

- Backend issues affecting performance

```
000425 2009-04-28 14:39:12:6963749 G=10 S=0 T=1 RP=0 VP=5
LOG_AMPD_MPI_SAS_DEVICE_DISAPPEARED AMPD IOC0 WWN:5000cca216ed8430
ES:50001ff101ed0000:60. RC:04 Hndl:0065 PrntId:50001ff101ed017f PHY:08
BT:00:14 DI:00000081 DSK:0000
```

```
000430 2009-04-28 14:39:13:8133330 G=10 S=0 T=1 RP=0 VP=5
LOG_AMPD_MPI_SAS_DEVICE_APPEARED AMPD IOC0 WWN:5000cca216ed8430
ES:50001ff101ed0000:60. RC:03 Hndl:0065 PrntId:50001ff101ed017f PHY:08
BT:00:14 DI:00000081 DSK:0000
```

- ICL problem - link bounce

```
000468 2009-08-25 22:04:20:7729086 G=60 S=0 T=1 RP=0 VP=5 LOG_AMPD_ICL_LINK_STATUS_CHANGE
AMPD Ctx:2f0006c24528 Drv:2f0006c2ed80 Old:DWN New:UP
000469 2009-08-25 22:04:20:7729497 G=60 S=0 T=1 RP=0 VP=1 LOG_DUCK_CONTROLLER_CONNECTED
DUCK Controller Connected.
```

- ICL problem - Controller failure

```
008418 2009-07-29 08:16:50:9043234 G=60 S=0 T=1 RP=0 VP=1 LOG_DUCK_CONTROLLER_DISCONNECTED
DUCK Controller Disconnected.
008419 2009-07-29 08:16:50:9043363 G=60 S=0 T=1 RP=0 VP=1 LOG_ST_OTHER_DIED
STATE OTHER CONTROLLER DIED
```

```
RAID[0]$ show controller *
OID: 0x38000000 Index: 0000 Name: A LOCAL PRIMARY
Total Controllers: 1
```

## 4.2 Manual Intervention Required (MIR) States

Manual Intervention Required (MIR) represents a condition with the Controller that requires the user to provide a solution before proceeding with normal Controller operations. This is to guard against the Controller firmware from executing operations that may not necessarily be the desired operation of the user. These conditions will most likely be seen in a new system installation environment. For example, when a system is booted and the backend physical disks have never been installed behind the Controllers, the Controller firmware has never had a chance to write out configuration metadata. The Controller recognizes that there is no valid metadata and requires the user to acknowledge proceeding or not.

Use the **SHOW CONTROLLER LOCAL ALL\_ATTRIBUTES** command to display the MIR condition of the Controller you are logged into (Figure 128).

Figure 128. Show Controller Information Screen

```
RAID[0]$ show controller 0 all
Index:                0
OID:                  0x38000000
Firmware Version:
  Release:            1.3.0.2
  Source Version:     4476
  Fully Checked In:   Yes
  Private Build:      No
  Build Type:         Production
  Build Date and Time: 2010-05-28-22:10UTC
  Builder Username:   root
  Builder Hostname:   co-bs2
  Build for CPU Type: AMD-64-bit
Hardware Version:     0000
State:                RUNNING
.
.
.
Name:                 A
Controller:           LOCAL      (SECONDARY)
Controller ID:        0x0001ff0800a30000
Enclosure OID:        0x50000006 (Index 6)
Universal LAN Address: 0x00000001ff0800a3
MIR Reason:           None
```

Listed below are the possible MIR conditions and their required actions.

### **MIR\_JIS\_DISCOVERY\_IN\_PROG**

Initialized Storage discovery is in progress. Please allow time for configuration discovery to complete. If this condition persists, please reboot the system. If this condition continues to persist after the reboot, please contact customer support.

### **MIR\_OTHER\_JIS\_DISCOVERY\_IN\_PROG**

Initialized Storage discovery is in progress (on other controller). Please allow time for configuration discovery to complete. If this condition persists, please reboot the system. If this condition continues to persist after the reboot, please contact customer support.

### **MIR\_NO\_BACKEND\_DRIVES**

This controller cannot find any disk modules on the backend. Install disk modules on the backend or fix the condition that prevents this controller from finding backend disks. Please refer to the installation guidelines for proper setup.

## **MIR\_NO\_CONFIG**

A configuration could not be created on the backend disks. Fix the condition that prevents this controller from creating a configuration on the backend disks. Please refer to the installation guidelines for proper setup.

## **MIR\_NO\_QUORUM**

No quorum disks could be found within the disk modules on the backend. Fix the condition that prevents the quorum disks from being seen. This may be caused by the disks never being in the storage array. This will normally happen on new system installations. Use the "**CLEAR SUBSYSTEM MIR\_STATE**" command to create an empty configuration. \*NOTE: This creates a new configuration and the old configuration will be deleted if existed.

## **MIR\_NOT\_LAST\_CONTROLLER**

This controller found a valid configuration, but was not present when another controller owned the configuration. Another controller may have cached data for this configuration. This may happen when controllers are swapped out or if the controllers went down and restarted individually. To use the found configuration on this controller, use the "**CLEAR SUBSYSTEM MIR\_STATE**" command.

## **MIR\_MULTIPLE\_JIS**

Multiple configurations were found on the quorum disks. This may happen if the disks from one system were installed in another system when the systems were powered down and then rebooted. If the disks were installed in the system while running, then this should not be an issue. A list of found configurations will be listed. Use the "**CLEAR SUBSYSTEM MIR\_STATE ID=<id>**" command to use the specified ID's configuration.

## **MIR\_DUAL\_NO\_AGREE**

The two connected controllers do not agree on the ID of the configuration. This may occur if one controller saw a subset of the disks and the other controller saw a different subset of disks. Please refer to the installation guidelines for proper setup.

## **MIR\_CONFIG\_MISMATCH**

The configuration version of this firmware does not match the configuration version of that on media. To proceed, either reload the previous version of firmware and do a backup then upgrade, or delete your configuration to continue. Use "**CLEAR SUBSYSTEM CONFIGURATION**" to create an empty configuration. \*NOTE: This creates a new configuration and the old configuration will be deleted if existed.

## **MIR\_NO\_LOAD\_CONFIG**

A configuration could not be loaded from the backend disks. Fix the condition that prevents this controller from loading a configuration from the backend disks, or use "**CLEAR SUBSYSTEM MIR\_STATE**" to create an empty configuration. Please refer to the installation guidelines for proper setup. \*NOTE: This creates a new configuration and the old configuration will be deleted if existed.

## 4.3 Recovery from Disk Failure

When a disk failure occurs on the IS16000, the Storage Pool containing that disk will begin operating in degraded mode. This means that the Storage Pool will continue to handle I/O commands from the host, but there will be no redundancy to protect against additional disk failures on the same Storage Pool. If another disk module fails on the same storage pool before the data on the first disk is rebuilt (to a replacement disk or hot spare), the Storage Pool will go offline.

If one disk in a Storage Pool fails, the data or parity information on the failed disk will be reconstructed from the parity disk and data disks of that Storage Pool.

### 4.3.1 Automatic Rebuild

A single disk failure in any Storage Pool does not result in data loss. The Virtual Disk(s) on that Storage Pool will continue to operate in degraded mode. If a spare disk is available and automatic rebuild is enabled, the IS16000 will automatically rebuild the data to a spare disk.

**NOTE** :System performance will be impacted while recovery is taking place.

When a disk failure occurs, the failure is written to the event log. You may monitor the rebuild progress or adjust the rebuild rate to match the user load requirements.

To display the event log (Figure 129), use the **SHOW CONTROLLER LOCAL LOG** command.

Figure 129. Display Event Log

```
RAID[0]$ show controller local log
000041 2009-02-04 15:03:17:7295774 G=4 S=0 T=1 RP=0 VP=1
LOG_ST_POOL_CHANGE STATE POOL CHANGE POOL:0003 STATE:0005
000042 2009-02-04 15:03:17:7295780 G=4 S=0 T=1 RP=0 VP=1
LOG_ST_MEMBER_CHANGE STATE MEMBER CHANGE ID:5000cca215c56e02 PDIDI:0145
POOL:0003 INDEX:0000 STATE:0003
000043 2009-02-04 15:03:17:7295810 G=4 S=0 T=1 RP=0 VP=1
LOG_ST_REBUILD_START STATE REBUILD START ID:5000cca215c56e02 PDIDI:0145
POOL:0003 INDEX:0000 FENCE:0000000000000000
```

To look at the failed disk (Figure 130), enter command **SHOW UNASSIGNED\_POOL FAILED ALL**

Figure 130. Display Failed Disk

```
RAID[0]$ show unassigned_pool failed all
OID: 0x20a7003f
Pool OID: UNASSIGNED
Capacity: 704512 MBs (0x56000000 blocks)
Raw Capacity: 715404 MBs (0x575466f0 blocks)
Block Size: 512
Enabled Disk Ch: 0x27 0x22
Disk Slot: 1:42
Vendor ID: Hitachi
Product ID: Hitachi HUA721075KLA330
Product Revision: GR80AB0A
Serial Number: GTF200P8GBVPXF
Health State: FAILED
Rotation Speed: 7200 RPM
Device Type: SATA
Member State: UNASSIGNED
Spare: FALSE
Failed: TRUE
UUID: 0x5000cca215c564560
```

To monitor the rebuild progress (Figure 131), enter command **SHOW JOB \* ALL\_ATTRIBUTES**

Figure 131. Display Rebuild Progress

```
RAID[0]$ show job * all_attributes
OID:          0x2b050003
Target:       0x19b40003
Type:         REBUILD
Status:       RUNNING
Priority:      80
Fraction Complete:12%
```

To show the Storage Pool information (Figure 132), enter command **SHOW POOL <id> ALL\_ATTRIBUTES**. Once the rebuild is complete, the status of Storage Pool will return to “NORMAL”.

Figure 132. Display Storage Pool Information

```
RAID[0]$ show pool 3 all_attributes
OID:          0x19b40003
Type:         STORAGE
Name:         raid 5 set
Chunk Size:   64KB (0x80 blocks)
Block Size:   0x200
RAID Type:    RAID5
Free Raid5 Capacity: 2752512 MBs
Total Capacity: 3522560 MBs
UUID:         0x00
Global Spare Pool: 0x1a0f000a
.
.
Initializing: FALSE
Rebuilding:   TRUE
Paused:       FALSE
AutoWriteLock: FALSE
Data Lost:    FALSE
Current Home: 0x0015b2a122b20000 0x00000000
Future Home:  0xffffffffffffffff 0x00000000
Preferred Home: 0xffffffffffffffff 0x00000000
BkgdJob OID:  0x2b050003
BkgdJob Priority: 80%
Total Phy Disks 5
State:        NOREDUNDANCY
Member Size:  704512 MB
  PID      State  UUID
  0x0191  RBLD   0x5000cca215c56e02
  0x004e  NORM   0x5000cca215c5709c
  0x0040  NORM   0x5000cca215c54c71
  0x0041  NORM   0x5000cca215c5675c
  0x0042  NORM   0x5000cca215c56e55
```

Spare Disk Rebuilding

### 4.3.2 Disk Module Replacement

Upon completion of a rebuild, the spare disk becomes a member of the Storage Pool, replacing the failed disk. After you have replaced the failed disk with a new disk, the new disk is added to the “Unassigned Pool”. It is recommended that you assign this new disk to the Spare Pool to “replace” the spare disk that has been used.

### 4.3.3 When a Spare is not available

When a disk is failed by the system and there is no spare disk available, you need to replace the failed disk immediately. After you have replaced the failed disk with a new disk, you can initiate a rebuild as described below:

1. Enter command **SHOW UNASSIGNED\_POOL \* ALL** to identify the new disk’s index name.
2. Enter command **ASSIGN PHYSICAL\_DISK <new-disk-id> TO\_POOL <pool-id> SET\_SPARE** where <new-disk-id> is the index name of the replacement disk and <pool-id> is the OID of the Storage Pool that had the failed disk.

### **4.3.4 Manual Rebuild**

You may manually replace a failed disk using the **REPLACE** command:

```
REPLACE PHYSICAL_DISK <id> NEW_DISK <new-disk-id>
```


A Replace operation is used to replace a failed disk with a healthy spare disk. The operation can take several hours to complete depending on the size of the disk and speed of the replace operation. The rate of rebuild can be adjusted (see Section [3.3.3, "Rebuild Policy Priority"](#) on page [78](#) for more information).

## 4.4 Controller Component Failure

---

The Controller Enclosure Fault LED turns amber when a fan failure, a power failure, or over temperature condition occurs (Figure 133).

Figure 133. Controller Enclosure Fault LED Indicator



A single component failure, therefore, will not shut down the system. However, in the unlikely event of component failure, you can replace the failed component while the IS16000 is running. The replaced component will automatically be returned to service once the component has been installed and booted up.



Warning

**If the IS16000 is powered up and you remove any module, replace it immediately. If the system is used with modules missing for more than a few minutes, the system can overheat, causing power failure and data loss. Such use will invalidate the warranty.**

---



Warning

**Observe all conventional ESD precautions when handling IS16000 modules and components. Avoid contact with backplane components and module connectors.**

---

### 4.4.1 Replacing a Power Supply Module

If a Controller power supply fails, the Enclosure Fault LED on the front panel will turn **amber** and the green LED on the failed power supply will be **off**.

You can also determine if a power supply has failed using the CLUI command, **SHOW POWER**. The position of the failed power supply should match the label (PSU1 or PSU2) on the back of the Controller.

If the power supply has failed, you must replace it. Once you remove it, you must replace it within 5 minutes to prevent the system from over-heating.

---


**NOTE** :Obtain a replacement module of the same type before removing any faulty module.

---

Follow these steps to replace a power supply module:

1. Identify the failed power supply.
2. Disconnect its power cord.
3. Loosen the module's thumbscrew, and then slide the module out of the bay (Figure 134).

Figure 134. Controller Power Supply Module Removal



4. Slide the replacement module into the bay, making sure that it is fully inserted.
5. Tighten the thumbscrew to secure it.
6. Connect the power cord.
7. Verify that the Status LED is **green**, indicating that the module is operating normally.
8. Verify that the Enclosure Fault LED on the front panel is no longer amber.

## 4.4.2 Replacing a Fan

If there is any problem with the fan module, the Enclosure Fault LED on the front panel will turn **amber**.

You can determine if a fan has failed using the CLUI command, **SHOW FAN**. The position of the failed fan should match the label (FAN1, FAN2, FAN3 or FAN4) on the front of the enclosure.

If a fan has failed, you must replace it. Once you remove it, you must replace it within 5 minutes to prevent the system from over-heating.

---

**NOTE** :Obtain a replacement module of the same type before removing any faulty module.

---

Follow these steps to replace a fan module:


---

**NOTE** :Attempting to replace more than one fan simultaneously will cause the Controller to fail.

---

1. Identify the failed fan.
2. Loosen the fan's thumbscrew (Figure 135).
3. Slide the module out of the bay.

Figure 135. Controller Fan Removal





4. Slide the new fan into the bay, making sure that it is fully inserted.
5. Tighten the thumbscrew to secure it.
6. Verify that the Enclosure Fault LED is no longer amber, indicating that the new module is operating normally.

### 4.4.3 Replacing Internal Disk Module

Follow these steps to replace an internal disk module at the front of the Controller:

1. Disengage the lock using the supplied key.
2. Press the handle release button to release the handle (Figure 136).
3. Pull the module out of the bay.

Figure 136. Controller Internal Disk Module Replacement



4. Slide the new module into the bay, making sure that it is fully inserted.
5. Close the handle and push the handle until it clicks, indicating that the handle is latched.

## 4.5 Disk Enclosure Faults

### 4.5.1 Front Panel Indicators

Green LEDs are always used for good or positive indication. Amber LEDs indicate there is a critical fault present within the module. The front panel indicators show the aggregated status of all the modules (Figure 137). The LEDs are defined in Figure 138. The Disk Activity LEDs indicate disk presence and flash during data I/O.

Figure 137. Disk Enclosure Front Panel LED Indicators




Figure 138. Front Panel LED Description

LED	Definition	Color	Status
	System Power	Green	ON - DC power is present OFF - DC power is not present LED does NOT flash under normal operating conditions
	System Fault	Amber	ON - one or more components within enclosure have failed. A service action is required. Exact failed component has its own amber fault LED lit. OFF - no detectable faults
	Shelf Identify	Blue	Flashing - receiving "Locate Enclosure" command OFF - NOT receiving "Locate Enclosure" command
	Cover Open	Amber	OFF - both cover pieces securely closed and latched in place ON - either of the cover pieces is NOT securely closed and latched in place
	DEM Fault	Amber	OFF - all DEMs operating correctly ON - at least one DEM has failed; service action required
	Disk Fault	Amber	ON - one or more HDDs are failed; SES must determine exact HDD OFF - no detectable disk faults
Individually numbered	Disk Activity	Green	ON - SAS HDD is present Flashing - indicates HDD activity OFF - no HDD activity

### 4.5.2 Thermal Alarm

Symptom	Cause	Action
<ol style="list-style-type: none"> <li>1. Enclosure System FAULT LED is amber.</li> <li>2. An amber LED on one or more Power Cooling Modules.</li> <li>3. Air temperature exiting PSU is above 55°C.</li> </ol>	<p>If the internal temperature measured in the airflow through the enclosure exceeds a pre-set threshold a thermal alarm will sound.</p>	<ol style="list-style-type: none"> <li>1. Check local ambient environment temperature is below the upper 40°C specification.</li> <li>2. Check the installation for any airflow restrictions at the front and rear of the enclosure. A minimum gap of 1" (25mm) at the front and 2" (50mm) at the rear is recommended.</li> <li>3. Check for restrictions due to dust build-up, clean as appropriate.</li> <li>4. Check for excessive re-circulation of heated air from rear to the front, use in a fully enclosed rack installation is not recommended.</li> <li>5. If possible shutdown the enclosure and investigate the problem before continuing.</li> </ol>



Warning

**An Enclosure will shut down when a critical temperature threshold is exceeded in order to prevent permanent damage to the disks.**

### 4.5.3 System Faults

Symptom	Cause	Action
<ol style="list-style-type: none"> <li>1. The System Fault LED turns amber on front panel.</li> </ol>	<p>The ESI (Enclosure Services Interface) processor has detected an internal fault (e.g. failure of an internal communications path)</p>	<ol style="list-style-type: none"> <li>1. Check for other AMBER LED indications on the Power Cooling modules. If there is a PSU error present there may be a communications problem with that Power Cooling module. Remove and then re-fit the module, if the problem persists then replace the module.</li> <li>2. Check for other AMBER LED indications on the disk modules. If none are evident then there may either be an ESI processor problem or a backplane problem.</li> </ol>

#### 4.5.4 Power Supply/Cooling Faults

Symptom	Cause	Action
<ol style="list-style-type: none"> <li>1. System Fault LED is amber on front panel.</li> <li>2. An amber LED on one or more Power Cooling modules.</li> </ol>	<ol style="list-style-type: none"> <li>1. Any power fault.</li> <li>2. A fan failure.</li> <li>3. A thermal condition which could cause PSU overheating.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power On/Off switch on rear of Power Cooling module is turned ON.</li> <li>2. Check AC Mains connections to Power Cooling module is live.</li> <li>3. Disconnect the Power Cooling module from mains power and remove the module from the system, re-install module. If problem persists, replace Power Cooling Module.</li> <li>4. Reduce the ambient temperature.</li> </ol>

Figure 139 describes the PCM LED status.

- Under normal conditions, the LEDs should be illuminated constant **green**.
- If a problem is detected, the color of the relevant LED will change to **amber**.

Figure 139. Power Cooling Module LEDs

Normal Operation LEDs		LED	Description	Color	Status
	Enclosure front	Enclosure front	Amber	ON - AC input, DC output, fan or other PCM fault detected	
	PCM AC	PCM AC	Green	ON - AC input to PCM within tolerances OFF - PCM failed	
	PCM DC	PCM DC	Green	ON - DC output of PCM within tolerances OFF - PCM failed	
	PCM Fault	PCM Fault	Amber	ON - AC input, DC output, fan or other PCM fault detected OFF - no fault detected	
	PCM ID	PCM ID	Blue	Flashing - this module is receiving "Locate Power Supply" or "Locate Fan" command OFF - NOT receiving "Locate Power Supply" or "Locate Fan" command	

If a power supply or fan fails, the PCM Fault LED on the module will turn **amber**.

If a power supply unit or its fan is faulty, you must replace the whole PCM. You must not take any longer than 5 minutes to replace this module to prevent the enclosure from over-heating.

---


**NOTE :** Obtain a replacement module of the same type before removing any faulty module.

---

### To replace a module:

1. Identify the failed PCM.
2. Turn off the module's power switch and disconnect the power cord (Figure 140).
3. Loosen the module's thumbscrew. Then slide the module out of the bay.

Figure 140. Power Supply Module



4. Ensure that the power switch on the new (replacement) module is OFF.
5. Slide the module into the bay, making sure that it is fully inserted.
6. Tighten the thumbscrew to secure it.
7. Connect the power cord.
8. Turn on the power switch.
9. Verify that the AC and DC LEDs are **green**, indicating that the module is operating normally.

## 4.5.5 Replacing a Disk Module

Figure 141 describes the fault LED status when an HDD has failed.

- Under normal conditions, the LEDs should be illuminated constant **green**.
- If a problem is detected, the color of the relevant LED will change to **amber**.

Figure 141. HDD Fault LED Indicators

Identifier	Location	Color	Status
Enclosure fault	Enclosure front	Amber	ON - disk fault
Disk fault	Enclosure front	Amber	ON - disk fault

---

**NOTE :**When a disk is failed by the IS16000, replace it promptly so that the operation and performance of the system are not affected.

---



Warning

**Wear an ESD wrist strap or otherwise ground yourself when handling the disk modules and components. Electrostatic discharge can damage the circuit boards.**

---

### To remove a module:

1. Slide the enclosure out from the rack by squeezing the tabs on both rack slides. Keep pulling until the enclosure locks and you hear a clicking sound.
2. Disengage both enclosure cover latches (Figure 142) and open the covers.

Figure 142. Disk Enclosure Cover Latch



3. Open the cover.

---


**NOTE :**Opening the cover affects the system cooling. Please limit service time to 5 minutes. Reminder beeps will occur occasionally. A continuous alarm will sound after 5 minutes.

---

4. Locate the disk module that has the blue LED.

5. On that module, slide the latch backward to release the handle (Figure 143).

Figure 143. Release Disk Module Handle



6. Lift the handle and pull the module up, just enough to disconnect the module from the backplane.
7. Wait for 30 seconds for the disk to completely spin down.

---

**CAUTION :** Disk spin down--Damage can occur to a disk if it is removed while still spinning.

---

8. Pull the module gently out of the disk bay.

#### To insert a module:

1. Slide the latch backward to release the handle.
2. Insert the replacement module into the disk bay. Note orientation of the module.
3. Cam the disk module home. The camming foot on the base of the module will engage into the slot in the enclosure.
4. When the module is fully inserted, close the handle. You should hear a click as the latch engages and holds the handle closed.
5. Close the enclosure covers and engage both cover locks.

---

**NOTE :**Both cover locks must be engaged before pushing the enclosure into the rack. Otherwise, open cover alarm will sound.

---

6. Squeeze the tabs on both rack slides and push the enclosure back into the rack.

### 4.5.6 Replacing a DEM (Drive Expander Module)

**NOTE :**The DEM card should only be replaced by trained personnel.

Figure 144 describes the DEM LED status.

- Under normal conditions, the LEDs should be illuminated constant **green**.
- If a problem is detected, the color of the relevant LED will change to **amber**.

Figure 144. DEM LED Indicators

Identifier	Location	Color	Status
Enclosure fault	Front enclosure	Amber	ON - DEM fault detected
DEM fault	Front enclosure	Amber	ON - DEM fault detected
DEM fault	Internal (DEM) enclosure	Amber	ON - DEM fault detected
DC OK	Internal (DEM) enclosure	Green	ON - DC voltage regulation is within limits OFF - DC output failure
Expander MIPS ready	Internal (DEM) enclosure	Green	ON - expander internal processor is booted and operating correctly OFF - expander internal processor is NOT booted or ready
DEM identify	Internal (DEM) enclosure	Blue	Flashing - receiving "Locate Expander" command OFF - NOT receiving "Locate Expander" command

A DEM failure can also be seen in the event log.

```
LOG_ES_EXPANDER_ELEMENT_ERROR      ES Enclosure 0x50001ff104521000
expander DEM1A was reported error condition. Status = 2, DISAB = 0, PF = 0.

000182 2009-10-28 15:21:58:6976333  G=62 S=1 T=1 RP=0 VP=1
LOG_ES_EXPANDER_ELEMENT_WARNING    ES Enclosure 0x50001ff104521000
expander DEM4B was reported warning condition. Status = 3, DISAB = 0, PF = 0.
```

Figure 145 shows the DEM locations in the disk enclosure.

Figure 145. DEM Locations



**To replace a DEM:**

Observe all conventional ESD precautions. Avoid contact with backplane components and module connectors.

1. Slide the enclosure out from the rack by squeezing the tabs on both rack slides. Keep pulling until the enclosure locks and you hear a clicking sound.
2. Disengage both enclosure cover latches and open the covers (Figure 146).


Figure 146. Disk Enclosure Cover Latch



**NOTE** :Opening the cover affects the system cooling. Please limit service time to 5 minutes. Reminder beeps will occur occasionally. A continuous alarm will sound after 5 minutes.

3. Locate the DEM that needs to be replaced. The handle rib will light up **blue** for service.
4. Grip the top latch, rotate it until you reach the limit of rotation, and then pull up to remove the DEM (Figure 147).

Figure 147. DEM Removal



5. Insert the replacement DEM.
6. Press on the latch to rotate it down and lock it into place.
7. Close the enclosure covers and engage both cover locks.

**NOTE** :Both cover locks must be engaged before pushing the enclosure into the rack. Otherwise, open cover alarm will sound.

8. Squeeze the tabs on both rack slides and push the enclosure back into the rack.

## 4.5.7

**Replacing an I/O Module**

**Do not remove this module unless a replacement can be immediately added. The system must not be run without all modules in place.**

Figure 148 describes the Controller LED status.

- Under normal conditions, the LEDs should be illuminated constant **green**.
- If a problem is detected, the color of the relevant LED will change to **amber**.

Figure 148. I/O Module LED Indicators

Identifier	Location	Color	Status
Enclosure fault	Front enclosure	Amber	ON - I/O fault detected
I/O OK	Rear enclosure	Green	OFF - an I/O module detectable fault is present. Independent of SAS link fault condition and stays lit during a SAS link fault.
I/O Fault	Rear enclosure	Amber	ON - an I/O module detectable fault is present. Independent of SAS link fault condition and stays lit during a SAS link fault.
SAS Link Activity	Rear enclosure	Green	ON - a valid link is present on any of the 4 links of the port. OFF - none of the 4 links of the port have a valid connection.
SAS Link Fault	Rear enclosure	Amber	ON - a valid link is present on any of the 4 links of the port. OFF - none of the 4 links of the port have a valid connection.

**To remove an I/O module:**

1. Remove the cables from the I/O module.
2. Release the two handles on the bottom of the module by simply pulling each handle out and away from the module.
3. Pull both handles forward to cam the module out of the enclosure.
4. Grip the module securely and slide it out of the bay.

**To insert a new module:**

1. With the handles in the open position, slide the I/O module into the enclosure until the handles engage automatically.
2. Cam the module home by manually closing the handles. A click should be heard as the handles engage.
3. Connect the cables to the module.



# CHAPTER 5

## *GUI Management Agent*

---



This chapter provides information on using the IS16000 GUI (Graphic User Interface) Management Agent.

---

**NOTE :**The configuration examples provided here represent only a general guideline. These examples should not be used directly to configure your particular IS16000.

---


## **5.1**      *Starting the GUI Management Agent*

---

### **5.1.1**      *Login*

Using a web browser, open a link to the IP address of the IS16000 Controller. The management system supports Mozilla FireFox (version 3.0.11 and above) as well as Microsoft Internet Explorer (version 8.0 and above).

At the login screen, enter the user name **admin** with the password **password** to log into the system. User name and passwords are case-sensitive.




The screenshot shows a web-based login interface. At the top left is the SGI logo. To its right, the text 'InfiniteStorage 16000™' is displayed. Below this header, there are two text input fields. The first is labeled 'Username:' and the second is labeled 'Password:'. Below the password field is a button labeled 'LOGIN'.

### 5.1.2 Initial Home Screen and Health Indicators

The home screen shows the Health Indicator. Figure 149 shows a newly configured system, the Health Indicator is, therefore, orange. An alert message also appears below the Health Indicator indicating that manual intervention is required for both Controllers.

Figure 149. Home Screen



Warning

**For any future encounters with MIR state issues, please refer to the Service Manual for specific instructions on how to clear them.**

1. Select the Controller name. The system displays the **Controller Show All** screen (Figure 150).  
Figure 150. Controller Show All Screen

Subsystem									
Controllers									
CONTROLLERS - SHOW ALL CONTROLLERS									
CONTROLLER NAME	FIRMWARE VERSION	HARDWARE VERSION	STATE	LOCAL/REMOTE	UP TIME (days (hh:mm))	RESTART PENDING	CRASHDUMP ENABLED	LOGDISK ENABLED	MANUAL INTERVENTION REQUIRED
<u>A</u>	1.1.0.0-2812	0	RUNNING	LOCAL	0 days (0:26)		✓	✓	NONE
<u>B</u>	1.1.0.0-2812	0	RUNNING	REMOTE	0 days (0:26)		✓	✓	NONE

2. Select the underlined Manual Intervention Required. Details of the MIR state displays, "STATUS=MIR: no quorum disks found".
3. Click **CLEAR MIR** to clear the MIR state. Your subsystem is now ready to be configured.

## 5.2 Physical Disks

### 5.2.1 Physical Disks Menu

The following commands are located under the Physical Disk pull down menu:

- Show Physical Disks
- Show Failed Disks
- Locate Disks
- Set Failed
- Assign to Pool
- Clear Failed

**NOTE :** If asterisks appear in the Physical Disk column when you attempt to view the advanced disk information or attempt to locate a disk, this shows that only one Controller sees the disk. Therefore, a Controller is down or another hardware issue exists somewhere.

### 5.2.2 Checking Status of Physical Disks

Before creating any Storage Pools, check the status of all the disks.

From the Physical Disks menu, select **Show All Physical Disks** to verify that all the disks are present and healthy (Figure 151).

Figure 151. Show Physical Disks Screen

Subsystem	Controllers	Physical Disks	Pools	Virtual Disk	Enclosures	Presentation								
PHYSICAL DISK - SHOW ALL PHYSICAL DISKS														
INDEX	PHYSICAL DISK OID	TYPE	SPEED (RPM)	POOL NAME	HEALTH	RAID STATE	SPPARE POOL	CAPACITY (GB)	DISK SLOT	ENCL-OSURE	VENDOR ID	PRODUCT ID	PRODUCT REVISION	SERIAL NUMBER
91	0x20ca005b	SATA	7200	unassigned	GOOD	N/A		465	1	1	HITACHI	HDS725050KLA360	K2A	
87	0x20c60057	SATA	7200	unassigned	GOOD	N/A		465	2	1	HITACHI	HDS725050KLA360	K2A	
86	0x20c50056	SATA	7200	unassigned	GOOD	N/A		465	3	1	HITACHI	HDS725050KLA360	K2A	
88	0x20c70058	SATA	7200	unassigned	GOOD	N/A		465	4	1	HITACHI	HDS725050KLA360	K2A	
15	0x2072000f	SATA	7200	pool-4	GOOD	NORMAL		931	5	1	SAMSUNG	HE103UU	1A	
78	0x20ba004e	SATA	7200	pool-4	GOOD	NORMAL		931	6	1	SAMSUNG	HE103UU	1A	
90	0x20c9005a	SATA	7200	unassigned	GOOD	N/A		931	7	1	SAMSUNG	HE103UU	1A	
77	0x20b9004d	SATA	7200	pool-4	GOOD	NORMAL		931	8	1	SAMSUNG	HE103UU	1A	
89	0x20c80059	SATA	7200	unassigned	GOOD	N/A		931	9	1	SAMSUNG	HE103UU	1A	
79	0x20bb004f	SATA	7200	pool-4	GOOD	NORMAL		931	10	1	SAMSUNG	HE103UU	1A	
16	0x20730010	SATA	7200	pool-4	GOOD	NORMAL		931	11	1	SAMSUNG	HE103UU	1A	
76	0x20b8004c	SATA	7200	pool-4	GOOD	NORMAL		931	12	1	SAMSUNG	HE103UU	1A	

**NOTE :** If the disks are not visible, select **Subsystem Restart** from the Subsystem Menu to reboot the system.

## 5.3 Storage Pools

---

When creating a Storage Pool on a IS16000, the following selectable attributes are available:

- **RAID Level**  
Storage Pools can be configured to use either a RAID1, RAID5 or RAID6 parity scheme. In RAID1, the capacity of one disk is used for data duplication. In RAID5, the capacity of one disk is reserved for parity, allowing data recovery in the event of a single disk loss in the Storage Pool. In RAID6, the capacity of two disks is reserved for parity, allowing data recovery if either one or two disks are down in a Storage Pool. ***For maximum data protection, SGI recommends the use of RAID6.***
- **Chunk Size**  
The chunk size (in KiB blocks) defines the amount of data written to a single disk before proceeding to the next disk in the Storage Pool.

---

**NOTE :**RAID1 is a two member RAID set where the data is mirrored on each disk. There is no parity, hence, the chunk size is fixed.

---


- **Disk Count**  
A RAID1 Storage Pool may consists of 2 physical disks. A RAID5 Storage Pool may consist of 5 or 9 physical disks. A RAID6 Storage Pool may consist of 6 or 10 physical disks. For maximum performance, select disks with the same characteristics (such as SAS/SATA, capacity, and RPM).
- **Drive Type**  
Drive types can be SAS or SATA.
- **Drive Size**  
Drive size is the capacity of the disk.
- **Spindle Speed**  
You may choose (RPM): 15000, 10000, 7200, 5400, 0 or SSD.
- **SATAAssure**  
SATAAssure technology is designed to improve the reliability of enterprise SATA disks and make sure that data integrity is always mentioned for all I/O operations.

### 5.3.1 Storage Pool Menu

The following commands are located under the Pools pull down menu ([Figure 152](#)):

- Show Storage Pools
- Create Storage Pool
- Set Storage Pool Attributes
- Delete Storage Pool
- Locate Storage Pool

Figure 152. Pools Menu



### 5.3.2 Create a Storage Pool

1. Select Create Storage Pool from the Pools Menu (Figure 153).
2. At the Create Storage Pool screen (Figure 153), select all the attributes for the pool:

**NOTE** :RAID1 does not accept a chunk size and the selection field will be disabled when RAID1 is selected.

Figure 153. Create Storage Pool

Subsystem	Controllers	Physical Disks	Pools	Virtual Disk	Enclosures	Presentation
VIRTUAL DISK: SHOW ALL VIRTUAL DISKS						
VD NAME	POOL NAME	STATE	RAID	CAP (GB)	PRESENT HOME ONLY	
vd-1_2	pool-2	NOT READY	RAID5	8		

INDEX	POOL NAME	CHUNK SIZE (KB)	RAID	STATE	FREE RAID CAP (GB)	TOTAL RAW CAP (GB)	MAX VD SIZE (GB)	DISK TIMEOUT (Min)	SATAAssure	PHYSICAL DISKS	VIRTUAL DISKS	WRITE BACK CACHE	MIRRORED	READ AHEAD CACHE
0	pool-0	128	RAID6	NORMAL	0	1200	0	10		10	1	✓	✓	✓
1	pool-1	128	RAID6	NORMAL	0	1200	0	10		10	1	✓	✓	✓

**CREATE POOL**

Select chunk size: (Not valid for RAID1)  32kb  64kb  128kb  256kb


Select SATAAssure:  Enabled  Disabled

Select Raid level:  RAID1  RAID5(4d+1p)  RAID5(8d+1p)  RAID6(4d+2p)  RAID6(8d+2p)

Select drive type: <input type="text" value="DONT CARE"/>	Select spindle Speed: <input type="text" value="DONT CARE"/>
Select drive size: <input type="text" value="DONT CARE"/>	Allow IO during initialization: <input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Set Priority (allow IO during initialization): <input type="text" value="DONT CARE"/>	

3. OPTIONAL: You may explicitly select the disks to add to the pool using the **ADVANCED OPTIONS**. At the Create Storage Pool Advanced screen (Figure 154), select the disks to add to the pool to be created. Otherwise, click **CANCEL** to cancel or click **BACK** to return to the previous screen.

Figure 154. Select Disks for Storage Pool



4. Click **CREATE STORAGE POOL** to create the pool. A message appears to indicate if the pool has been successfully created. The list of Storage Pools is displayed (Figure 155).

Figure 155. Storage Pool List

POOL NAME	CHUNK SIZE (KB)	RAID	STATE	FREE RAID CAP (GB)	TOTAL RAW CAP (GB)	MAX VDI SIZE (GB)	DISK TIMEOUT (Min)	SATAssure#	PHYSICAL DISKS	VIRTUAL DISKS	WRITE BACK CACHE	MIRRORED WRITE BACK CACHE	I/O ROUTING
pool-2	128	RAID6	NORMAL	3632	7344	3632	10		10	0	✓	✓	✓

### 5.3.3

#### Configure Storage Pool Attributes

1. Select Set Storage Pool Attributes from the Pools Menu (Figure 152).
2. At the Set Attributes for Pool screen (Figure 156), select the Storage Pool whose attributes you want to change.

Figure 156. Set Storage Pool Attributes Screen

POOL NAME	CHUNK SIZE (KB)	RAID	STATE	FREE RAID CAP (GB)	TOTAL RAW CAP (GB)	MAX VDI SIZE (GB)	DISK TIMEOUT (Min)	SATAssure	PHYSICAL DISKS	VIRTUAL DISKS	WRITE BACK CACHE	MIRRORED WRITE BACK CACHE	I/O ROUTING
pool-2	128	RAID6	NORMAL	3624	7344	3624	10		10	1	✓	✓	✓

SET ATTRIBUTES FOR POOL: (0x18540002)

Pool Name:	<input type="text" value="pool-2"/> (256 characters max)	Disk Timeout:	<input type="text" value="10"/> minutes
SATAssure:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled	Write-back cache:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Mirrored Write-back cache:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled	IO routing:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Assign Spare Pool:	<input type="text" value="NONE"/>	Select drive type:	<input type="text" value="DONT CARE"/>
Select spindle Speed:	<input type="text" value="DONT CARE"/>	Select drive size:	<input type="text" value="DONT CARE"/>

**UPDATE**

3. Make the desired changes.
4. Click **UPDATE** to save the changes. A message appears to indicate if the change was successful.

### 5.3.4 *Locate Storage Pools*

1. Select Locate Storage Pool from the Pools Menu (Figure 152).
2. At the Locate Pool screen (Figure 157), select the Storage Pool that you want to locate. The screen changes accordingly.

Figure 157. Locate Storage Pool Screen

POOL NAME	CHUNK SIZE (KB)	RAID	STATE	FREE RAID CAP (GB)	TOTAL RAW CAP (GB)	MAX VD SIZE (GB)	DISK TIMEOUT (Min)	SATAssure	PHYSICAL DISKS	VIRTUAL DISKS	WRITE BACK CACHE	MIRRORED WRITE BACK CACHE	I/O ROUTING
pool-0	64	RAID6	NORMAL	0	7344	0	10		10	1	✓	✓	✓

Enclosure:1, Pool:pool-0											
49	50	51	52	53	54	55	56	57	58	59	60
37	38	39	40	41	42	43	44	45	46	47	48
25	26	27	28	29	30	31	32	33	34	35	36
13	14	15	16	17	18	19	20	21	22	23	24
1	2	3	4	5	6	7	8	9	10	11	12

LOCATE

3. Click **LOCATE**. A message appears to indicate if the operation was successful.

### 5.3.5 *Show Storage Pools*

Select Show Storage Pools from the Pools Menu (Figure 152) to view the list of configured Storage Pools.

### 5.3.6 *Show Unassigned Pools*

Select Show Unassigned Pools from the Pools Menu (Figure 152). By default, all the disks or replacement disks are initially allocated to this pool. When a disk has failed or been released (from a Spare Pool, for example), it is also moved to this pool.

### 5.3.7 *Delete a Storage Pool*


1. Select Delete Storage Pool from the Pools Menu (Figure 152).
2. Select the Storage Pool that you want to delete.
3. Click **DELETE** to delete that Storage Pool or click **CANCEL** to cancel operation. A message appears to indicate if the deletion was successful.

### 5.3.8 Storage Pool Initialization

When a Storage Pool is created, initialization begins immediately as a background job and will continue until it is completed. Once the Storage Pool has completed its initialization, Virtual Disk(s) can be presented to host systems. However, you may immediately create the presentations.


You can monitor the progress of a job using the Show Background Jobs function under the Subsystem Menu (Figure 158).

Figure 158. Subsystem Menu




It will display the list of current jobs and the percentage of completion. Select a job to display its details (Figure 159).

Figure 159. Show Background Jobs Screen



You may also check if a Virtual Disk is ready for access using the Show Virtual Disks function from the Virtual Disk Menu (Figure 160).

Figure 160. Virtual Disk Details Screen



## 5.4 Virtual Disks

A Virtual Disk is the storage unit presented to any attached host. A Virtual Disk can be created to use all or just a part of the capacity of a single Storage Pool. VDs are created in increments of 8GiB. For example, 16GiB of storage space will be allocated when creating a VD of 10GiB.

### 5.4.1 Virtual Disk Menu

The following commands are located under the Virtual Disk pull down menu (Figure 161):

- Show Virtual Disks
- Create Virtual Disk
- Set Virtual Disk Attributes
- Delete Virtual Disk

Figure 161. Virtual Disk Menu

Pools		Virtual Disk		Enclosures		Present
		Show Virtual Disks				
		Create Virtual Disk				
		Set Virtual Disk Attributes				
		Delete Virtual Disk				
4X VD SIZE (GB)	DISK TIMEOUT (Min)	SAT		TOTAL KKS	WRITE BACK CACHE	MIR WRI CA
3632	10			0	✓	

### 5.4.2 Show Virtual Disks

Select Show Virtual Disks from the Virtual Disk Menu (Figure 161). The list of configured Virtual Disk(s) appears (Figure 162). Select the individual VD name to display its detailed information.

Figure 162. Show Virtual Disk Details Screen

VD NAME	POOL NAME	STATE	RAID	CAP (GB)	PRESENT HOME ONLY	PREFERRED HOME	CURRENT HOME	FUTURE HOME	CRITICAL	WRITE BACK CACHE	MIRRORED WRITE BACK CACHE	I/O ROUTING
vd-1_2	pool-2	NOT READY	RAID6	8	A:0	A:0				✓	✓	✓

```

VD Name : vd-1_2
VD OID : 0x885f0001
POOL OID : 0x185d0002
Useable Capacity : 8 GB
UUID : 0x601672f01f00601005f8802000000
Present Home Only : FALSE
Current home Controller id : 0x15b2a120da0000
Current home RP index : 0
Preferred home Controller id : 0x15b2a120da0000
Preferred home RP index : 0
State : NOT READY
    
```

### 5.4.3 Create a Virtual Disk

1. Select Create Virtual Disk from the Virtual Disk Menu (Figure 161).
2. At the Create Virtual Disk screen (Figure 163), select the Storage Pool to be used.

Figure 163. Create Virtual Disk Screen

VD NAME	POOL NAME	STATE	RAID	CAP (GB)	PRESENT HOME ONLY	PREFERRED HOME	CURRENT HOME	FUTURE HOME	CRITICAL	WRITE BACK CACHE	MIRRORED WRITE BACK CACHE	I/O ROUTING
VIRTUAL DISK - CREATE VIRTUAL DISK												
CREATE VIRTUAL DISK												
Select pool :		pool-2 (0x185d0002),Max VD capacity(3632GB)										
Enter Capacity:		0 GB NOTE:This Virtual Disk will be created with capacity=0Gb										
												CREATE VIRTUAL DISK

3. Enter the capacity in GiB.
4. Click **CREATE VIRTUAL DISK** to create the VD. A message appears to indicate if the VD has been successfully created. The list of Virtual Disks is displayed (Figure 164).

Figure 164. Virtual Disk List

VD NAME	POOL NAME	STATE	RAID	CAP (GB)	PRESENT HOME ONLY	PREFERRED HOME	CURRENT HOME	FUTURE HOME	CRITICAL	WRITE BACK CACHE	MIRRORED WRITE BACK CACHE	I/O ROUTING
VIRTUAL DISK - CREATE VIRTUAL DISK												
vd-1_2	pool-2	NOT READY	RAID6	8		A:0	A:0			✓	✓	✓

### 5.4.4 Configure Disk Virtual Attributes

1. Select Set Virtual Disk Attributes from the Virtual Disk Menu (Figure 161).
2. At the Set Attributes for Pool screen (Figure 165), select the VD whose attributes you want to change.

Figure 165. Set Virtual Disk Attributes Screen

VD NAME	POOL NAME	STATE	RAID	CAP (GB)	PRESENT HOME ONLY	PREFERRED HOME	CURRENT HOME	FUTURE HOME	CRITICAL	WRITE BACK CACHE	MIRRORED WRITE BACK CACHE	I/O ROUTING
VIRTUAL DISK - SET VD ATTRIBUTES - SET ATTRIBUTES												
vd-0_0	pool-0	READY	RAID6	3632		B:0	B:0			✓	✓	✓
SET VIRTUAL DISK ATTRIBUTES												
Set attributes for Virtual disk:		vd-0_0										
Virtual disk Name:		vd-0_0 (256 characters max)										
Present home only:		Enabled: <input type="radio"/> Disabled: <input checked="" type="radio"/>										
												UPDATE

3. Make the desired changes.
4. Click **UPDATE** to save the changes.

## 5.4.5 Delete a Virtual Disk



Warning

**When you delete a Virtual Disk, you lose access to all data that was stored on that Virtual Disk.**

---

1. Select Delete Virtual disk from the Virtual Disk Menu ([Figure 161](#)).
2. Select the Virtual Disk that you want to delete.
3. Click **DELETE** to delete that VD or click **CANCEL** to cancel operation. A message appears to indicate if the deletion was successful.

If a presentation is configured for a Virtual Disk, deleting the Virtual Disk will return an error. You must first delete all the presentations configured on that Virtual Disk using the Delete Presentation function under the Presentation Menu.

## 5.5 Spare Pools

The IS16000 supports the concept of Spare Pool. A Spare Pool contains physical disks that can be used as spare disks in one or more Storage Pools. In the event of a disk failure, a disk that is assigned to a Spare Pool is automatically swapped into the Storage Pool to replace the failed disk. A rebuild then occurs immediately, reducing the possibility of data loss due to additional disk failures.

Spare Pools can be shared by Storage Pools or dedicated to a particular Storage Pool in which case the spare disks will only be used by the designated Storage Pool.

---

**NOTE** :Each Storage Pool must have a Spare Pool assigned to it.

---

### 5.5.1 Spare Pool Menu

The following commands are located under the Pools pull down menu (Figure 166):

- Show Spare Pools
- Create Spare Pool
- Delete Spare Pool
- Set Spare Pool Attributes
- Locate Spare Pool

Figure 166. Pools Menu

Subsystem	Controllers	Physical Disks	Pools	Virtual Disk	Enclosures	Presentation	
VIRTUAL DISK - SHOW ALL VIRTUAL DISKS			Show Storage Pools				
VD NAME	POOL NAME	STATE	RAID	CAP (GB)	PRESENT HOME ONLY	Create Storage Pool Set Storage Pool Attributes Assign Disks Delete Storage Pools Locate Storage Pools Show Spare Pools Create Spare Pool Delete Spare Pool Set Spare Pool Attributes Locate Spare Pools Show Unassigned Pool Locate Unassigned Pool Move Pool Clear Fault	FUTURE HOME CRITICAL WRITE BACK CACHE MIRRORED WRITE BACK CACHE I/O ROUTING
vd-1_2	pool-2	NOT READY	RAID6	8		✓ ✓ ✓	
VD Name : vd-1_2							
						VD OID POOL OID Useable Capacity UUID Present Home Only Current home Controll Current home RP index Preferred home Contro Preferred home RP ind State	

### 5.5.2 Show Spare Pools

Select Show Spare Pools from the Pools Menu (Figure 166) to view the list of configured Spare Pools.

### 5.5.3 Create a Spare Pool

1. Select Create Spare Pool from the Pools Menu (Figure 166).
2. At the Create Spare Pool screen (Figure 167), select the drive size, spindle speed, and drive type for the pool.

Figure 167. Create Spare Pool

3. Click **NEXT** to bring up the Create Pool Advanced screen (Figure 168). Check to select the disks to add to the pool to be created.

**NOTE :**When assigning disk drives to a Spare Pool that is to be assigned to a given Storage Pool, be sure to select a disk that is as large or larger than any disks in the assigned Storage Pool.

Figure 168. Select Disks for Spare Pool

4. Click **CREATE SPARE POOL** to create the pool. A message appears to indicate if the pool has been successfully created. The list of Spare Pools is displayed (Figure 169).

Figure 169. Spare Pool List

SPARE POOL NAME	TOTAL MEMBERS	DISK TIMEOUT(Mins)	TOTAL RAW CAPACITY(GB)
spare_pool-4	1	10	920

5. Assign the Spare Pool to a Storage Pool as described in Section 5.5.4, "Set Spare Pool Attributes".

### 5.5.4 Set Spare Pool Attributes

1. Select Set Spare Pool Attributes from the Pools Menu (Figure 166).
2. At the Set Attributes for Pool screen (Figure 156), select the Spare Pool whose attributes you want to change.

Figure 170. Set Spare Pool Attributes Screen

SPARE POOL NAME	TOTAL MEMBERS	DISK TIMEOUT(Mins)	TOTAL RAW CAPACITY(GB)
spare_pool-4	1	10	920

**SET SPARE POOL ATTRIBUTES**

Set attributes for spare pool: spare\_pool-4

Spare pool name:

Disk timeout:  minutes

Assign spare pool:

**UPDATE**

3. Make the desired changes.

To assign the Spare Pool to a Storage Pool, select the name of the pool from the Assign Spare Pool drop down.

---

**NOTE :**When assigning a Spare Pool to a Storage Pool, be sure to select one with disks that are as large or larger than any disks in that Storage Pool.

---

4. Click **UPDATE** to save the changes. A message appears to indicate if the change was successful.

### 5.5.5 Locate Storage Pools

1. Select Locate Spare Pool from the Pools Menu (Figure 166).
2. Then select the Spare Pool you want to locate. The screen changes accordingly.
3. Click **LOCATE**. A message appears to indicate if the operation was successful.

### 5.5.6 Delete a Spare Pool

1. Select Delete Spare Pool from the Pools Menu (Figure 166).
2. Select the Spare Pool you want to delete.
3. Click **DELETE** to delete that Spare Pool or click **CANCEL** to cancel operation. A message appears to indicate if the deletion was successful.

## 5.6 Presentations

---


Virtual Disks are only presented to the hosts that have been given authorized access. A Presentation on a IS16000 has the following components:

- **Discovered Initiators**  
A Discovered Initiator is defined as a Fibre Channel or InfiniBand initiator that has logged into the IS16000. This is normally a single port on a Fibre Channel or InfiniBand HBA in an external computer.
- **Host**  
A Host is an abstract client of a Virtual Disk that has all the access to all data within the Virtual Disk. This most commonly represents an external computer with one or more Fibre Channel or InfiniBand initiators. Host attributes are OS (operating system) of which you can select GENERIC, WINDOWS, LINUX or MAC\_OS. The OS attribute dictates the way the controller responds to certain Fibre Channel commands where appropriate. For example, Mac OS X expects a different response from an inquiry of LUN0 (the Controller LUN) than a Windows host.
- **Channel**  
A Channel is one of the Fibre Channel or InfiniBand ports on the Controller. Channel attributes are MODE of which you can select either MAC\_OS or STANDARD. When MAC\_OS is selected, the port's node name will be set differently in order to be visible to a Macintosh system.
- **Stack**  
A Stack is the input side of the subsystem. In the case of the IS16000, the stack is defined as the Fibre Channel interface. In future versions of the product, different interface stacks may exist.
- **Presentation**  
A Presentation is the relationship between a Host and a Virtual Disk. A Presentation implies that the related Host has some sort of access to the Virtual Disk. Attributes of a Presentation are:
  - PORT: from which the host will see the Virtual Disk
  - READ\_ONLY: controls read only access
  - PRESENT\_HOME\_ONLY: presents the specified Virtual Disk from its designated home controller only
  - LUN: user-specified LUN number that the Virtual Disk will show to the host.

### 5.6.1 Presentation Menu

Figure 171 shows the Presentation pull down menu.

Figure 171. Presentation Menu



### 5.6.2 Show Presentations

Select Show Presentations from the Presentation Menu (Figure 171). The list of configured Presentations appears (Figure 172).

Figure 172. Show Presentations Screen

Subsystem	Controllers	Physical Disks	Pools	Virtual Disk	Enclosures	Presentation		
PRESENTATION - SHOW PRESENTATIONS								
HOST	VIRTUAL DISK	LUN	Port0 - C0:RP0	Port1 - C0:RP0	Port0 - C1:RP0	Port1 - C1:RP0	READ ONLY	PRESENT HOME ONLY
HOST01	vd-0_0	0	✓	✓	✓	✓		
HOST02	vd-0_0	1	✓	✓	✓	✓		

### 5.6.3 Set up a Presentation

Create a host:

1. Select Create Host from the Presentation Menu (Figure 171).
2. At the Create Host screen (Figure 173), enter a host name and specify the Stack and OS attributes.

Figure 173. Create Host

INDEX	HOST NAME	STACK INDEX	HOST OS
<b>CREATE HOST</b>			
Host Name:	<input type="text"/>		
Stack:	<input type="text" value="0"/>		
Select OS :	<input type="text" value="GENERIC"/>		
			<b>CREATE HOST</b>

3. Click **CREATE HOST**. A message appears to indicate if the host has been successfully created. The list of created hosts is then displayed (Figure 174).


Figure 174. Created Hosts

HOST NAME	HOST OS
Host_0000	GENERIC

**Map your newly created host to one or more Discovered Initiators:**

1. Select Import Initiators from the Presentation Menu (Figure 171).
2. At the Import Initiator screen (Figure 175), select an initiator and the corresponding host(s).

Figure 175. Import Initiator Screen




3. Click **IMPORT INITIATOR**. A message appears to indicate if the initiator has been imported successfully.

**Present the Virtual Disks to the Hosts:**

1. Select Create Presentation from the Presentation Menu (Figure 171).
2. At the Create Presentation screen (Figure 176), select a host and a Virtual Disk.

Figure 176. Create Presentation Screen



3. Then select the mask options and enter the Logical Unit Number (LUN).

OPTIONAL: To present a Virtual Disk to all host ports on both Controllers, select “ALL HOSTS” instead of individual hosts.

4. Click **CREATE PRESENTATION**. A message appears to indicate if the presentation has been successfully created.

The external computer can access the Storage Pools once it has completed its initialization. You may also check if a Virtual Disk is ready for access using the Show Virtual Disks function under the Virtual Disk Menu.

## 5.7 Email and Critical Event Notification Setup

Emails will be sent automatically as notification of a selected group of warning and error events that have occurred on the IS16000.

The recipient address is user-configurable and only one address is permitted per system.

### To set up or change the email address:

1. Select Update Email Settings from the Subsystem Menu.

The upper portion of the Update Email Settings screen (Figure 177) will display the current settings, if any.

Figure 177. Update Email Settings Screen

The screenshot shows a web interface for updating email settings. At the top, a window titled 'CONTROLLERS - UPDATE EMAIL SETTINGS' contains a scrollable area for 'E-mail Agent Attributes' with the following text: 'IP\_ADDRESS=192.168.11.137' and 'IP\_PORT=23'. Below this is a red header 'UPDATE EMAIL SETTINGS'. Underneath are five input fields with labels and current values: 'Update IP Address' (192.168.11.137), 'Update IP Port' (23), 'Update From' (IS16K@sgi.com), 'Update To' (service@sgi.com), and 'Update Subject' (SGI IS16K Event Notification). An 'UPDATE' button is located at the bottom right of the form.

2. In the Update IP Address field, enter the IP address of the SMTP server to which the IS16000 will send email notifications.
3. In the Update IP Port field, enter the IP port of the SMTP server to which the IS16000 will send email notifications.
4. In the Update From field (maximum field size 512), enter an identification string, such as the name of the Controller. This is a string which will be included on the "From" line of the email notification message sent by the agent.
5. In the Update To field (maximum field size 512), enter an Internet Mail Format (RFC2822) email address to which IS16000 will send email notifications.
6. In the Update Subject field (maximum field size 512), enter a string to be included on the subject line of the email notification sent by the email agent.
7. Click **UPDATE** to save the changes. A message appears to indicate if the change was successful.

The tables in Section 3.7.5.3, "Inquiry Items and Events" on page 103 detail the additional inquiry items and events that will be trapped in the SNMP MIB and in the Email Agent.


## 5.8 NTP Mode

NTP (Network Time Protocol) mode is available on the IS16000. It provides a means for the Controllers to synchronize their time across a network, usually within a small number of milliseconds over a long period of time. You can enter up to four NTP addresses as the time servers.

### To display the current settings:

1. Select Show Subsystem from the Subsystem Menu (Figure 178).

Figure 178. Subsystem Menu



2. The Show Subsystem screen (Figure 179) displays the current setting for NTP mode and all the configured NTP IP addresses.

Figure 179. Show Subsystem Screen



### To change the settings:

1. Select Set Subsystem Attributes from the Subsystem Menu (Figure 178).
2. At the Set Subsystem Attributes screen (Figure 180), select ON/OFF to enable/disable NTP.

Figure 180. Set Subsystem Attributes Screen

NAME	TIME	LICENSE(RAID6)	LICENSE(SATAssure)	NTP MODE	NTP IP ADDR	NTP IP ADDR	NTP IP ADDR	NTP IP ADDR
Subsystem A	Fri Sep 24 19:57:50 2010	<a href="#">Add Key</a>	<a href="#">Add Key</a>	✓	10.2.3.4			

**SET SUBSYSTEM ATTRIBUTES**

Subsystem Name:  (31 characters max)

Locate Time:  seconds(0-65535)

License Key:

Pool Verify Priority:  ▾

Date and Time:  yyyy /  mm /  dd     hour(0-23) :  minutes(0-59) :  seconds(0-59)

Network Time Protocol:  ON  OFF

IP addresses for NTP: (Max 4 IP addresses)

3. In the IP Addresses for NTP field, enter the IP address of the time servers.
4. Click **UPDATE** to save the changes. A message appears to indicate if the change was successful.

Please refer to page [74](#) for information on behavioral changes when NTP mode is enabled.

## *Appendices*

---





## Technical Specifications

---

Here are the technical specifications for the IS16000.

---

**NOTE :**Specifications subject to change without notice.

---

### Configuration, Performance, & Capacity

---

Host side technology	(16) 8Gb Fibre Channel or (8) 40Gb InfiniBand
Disk side technology	(40) 4 × 3Gb/s SAS
Supported disk technology	SAS / SATA /SLC SSD
Management interface	RS-232 and Ethernet (SSH)
Cache memory	24GB of RAM, 12GB ECC/RAID protected cache
Number of disk modules supported	Up to 600 disks, 1.2Petabytes per array
Number of Storage Pools supported	256
Number of Virtual Disks supported	512; 64 per Storage Pool
Number of Spare Pools supported	16
Hot spare capability	Yes
RAID parity protection	1+1 RAID 1, 4+1 or 8+1 RAID 5, 4+2 or 8+2 RAID 6
Throughput	12GB/s sustained with large well aligned, sequential IO
IOPS	1M to cache; 300,000 to Disk

### Reliability

---

SES (SCSI Enclosure Services) protocol support	Yes
Temperature monitoring	Yes
Battery-backed write-back cache	Yes
Redundant hot-swappable power modules	Dual-redundant
Redundant hot-swappable cooling modules	N+1
Redundant controllers	Dual-redundant
Redundant disk enclosures	N+1

## Physical, Power & Environmental

---

Active/Active Dual Controllers	Dimensions	Height: 14" (356mm) (includes 2 UPS units) Width: 17" (432mm) Depth: 25.5" (648mm)
	Weight	120 lbs (54.5kg) Controllers only; 248 lbs (112.5kg) with UPS units
	Voltage range	200-240VAC @ 47-63Hz
	Average power	1200W
	Average cooling	4095BTU/hr
	Disk Enclosure	Dimensions
	Weight	240 lbs (109kg) with disk modules; 120 lbs (54.5kg) without disk modules
	Voltage range	200-240VAC @ 47-63Hz
	Average power	1750W
	Average cooling	5973BTU/hr
Operating environment (temperature / relative humidity)		5°C to 35°C / 20% - 80%, non-condensing
Non-operating environment (temperature/ relative humidity)		-10°C to 50°C / 20% - 80%, non-condensing
Certification		UL, CE, CUL, C-Tick, FCC

---

**NOTE :**Specifications subject to change without notice.

---

# B

## Terminology

---

<b>AP</b>	Application Processor
<b>Application Stack</b>	A layer of the Controller OS that provides services external to the appliance through the use of Virtual Disks. For example, Fibre Channel block device.
<b>Client Channel</b>	A port on a Client I/O Controller that can be used by hosts to communicate with an Application Stack.
<b>Client I/O Controller</b>	A physical interface (FC or IB) that has a unique PCI bus number and is utilized for one or more Client Channels. A Client I/O Controller is managed by a single Application Stack.
<b>Couplet</b>	Dual Controller subsystem
<b>Discovered Initiator</b>	A volatile object that represents an FCP or SRP initiator port that is discovered on the fabric.
<b>Disk Channel</b>	A port on a Disk I/O Controller that can be connected to one or more Physical Disks and Disk Enclosures.
<b>Disk I/O Controller</b>	A physical interface (SAS) that has a unique PCI bus number and is utilized for one or more Disk Channels. A Disk I/O Controller is managed by the RAID Stack running on a single RAID Processor.
<b>GiB (gibibyte)</b>	A unit of digital information storage and denote 1,073,741,824 bytes ( $2^{30}$ bytes).
<b>Host</b>	A persistent logical object that represents an abstract client for one or more Virtual Disk's and that is given access to data on those Virtual Disk's.
<b>ICL</b>	Inter-Controller Link
<b>Initiator</b>	A persistent logical object associated with a Host that represents a FCP or SRP initiator port on a Host's HBA.
<b>KiB (kibibyte)</b>	A unit of digital information storage and denote 1,024 bytes ( $2^{10}$ bytes).
<b>MiB (mebibyte)</b>	A unit of digital information storage and denote 1,024 kibibytes ( $2^{20}$ bytes).

<b>Physical Disk (PD)</b>	A disk module (SAS or SATA) or solid-state device (SSD) used by the system back-end to store data and subsystem metadata.
<b>Pool</b>	A set of physical disks. There are three types: Storage Pool, Spare Pool, and Unassigned Pool.
<b>Presentation</b>	A persistent logical object that describes an association between a Host and a Virtual Disk that specifies if a Host may access the Virtual Disk and any specific constraints for access.
<b>RAIDset</b>	A container formed by a set of Physical Disk extents and controlled by one of the RAID algorithms, such as RAID6.
<b>RP</b>	RAID Processor
<b>Singlet</b>	Single Controller
<b>Spare Pool</b>	A set of physical disks that are used as spares in one or more Storage Pools.
<b>Storage Pool</b>	A set of physical disks whose extents may be parts of RAIDset's.
<b>Unassigned Pool</b>	The set of physical disks that are not assigned to any pool.
<b>Virtual Disk (VD)</b>	A set of disk blocks that may be presented to an operating system. It is also the primary logical object realized by the back-end.

# Index

## A

AC power requirement 27  
 airflow 25  
 alarm, thermal 120  
 AP 155  
 application stack 155

## B

background job 76

## C

cache  
   mirrored write back, set 79  
   write back, set 79  
 CLUI, using 57  
 Controller  
   fan 9  
   fan, replace 117  
   hardware 7  
   internal disk modules 10  
   internal disk, replace 118  
   IO ports 11  
   LED, status 8  
   power supply 9  
   power supply, replace 116  
   RAID processor 10  
 cooling requirements 26  
 create  
   spare pool 49, 70  
   storage pool 46  
   virtual disk 48  
 Customer service vi

## D

date, set system 74  
 delete  
   storage pool 66  
   virtual disk 68  
 DEM 20  
   replace 125  
 DIP switch, UPS 38  
 discovered initiators 51, 80  
 disk  
   fail a 72  
   failure recovery 112  
   fail, clear 72  
   information 60

  internal, Controller 10  
   listing all 60  
   location, physical 62  
   replace 123  
   replace, manual 72  
   states 61  
 disk enclosure 14  
   cable connections 32  
   fan 18  
   power supply 18  
   zoning 30  
 disk failure recovery 112  
 disk module 17  
   install 29  
   layout in enclosure 41  
 disk timeout 71

## E

email notification 102  
 Ethernet connection 101  
 event log 109  
   display 99  
   structure 100  
   terms 100

## F

failure  
   disk, fixing 112  
   fan, controller 117  
   fan, disk enclosure 121  
   power supply, controller 116  
 fan  
   Controller 9  
   Controller, replace 117  
   disk enclosure 18  
   disk enclosure, replace 121  
 features, system 4  
 firmware  
   current version 91  
   update 90  
   update controller 91  
   update disk enclosure 94  
   update physical disk 97  
 floor loading 26  
 fractional rebuild 71  
 full rebuild 71

**G**

GUI 131

**H**

host, connect Controller to 36

host, presentation to 51, 80

**I**

ICL 31

import discovered initiator 82

initialization 65

failed 65

installation 23

installation planning 24

inter-controller link 31

internal disk, replace controller 118

IO module, enclosure 19

replace 127

IO ports, Controller 11

IP address, set controller 101

**J**

job priority, set 76

**L**

LED

Controller 8

Controller IO port 11

cooling, disk enclosure 18

disk enclosure 16

disk enclosure internal 19

disk enclosure IO module 19

power supply, disk enclosure 18

UPS 13

loading, floor 26

login 58

logout 58, 102

log, event 99

**M**

Manual Intervention Required 110

masking 53

MIR 110

clear, state 110

    conditions 110  
    mirrored write back cache, set 79**N**

name, set subsystem 45

network interface, change 101

Network Time Protocol 73, 149

NTP, set 73, 149

**P**

packing list 28

partial rebuild 71

physical location

disk 62

storage pool 66

unassigned pool 62

pool

spare, create 49, 70

spare, display 69

storage, create 46

unassigned 60

power requirement 27

power supply

Controller 9

disk enclosure 18

replace controller 116

replace disk enclosure 121

presentation 51, 80

MacOS 89

masking 53

priority

job, set 76

rebuild, set 78

Product support vi

**R**

rack location 25

RAID processor, Controller 10

rebuild

automatic, set 71

fractional 71

full 71

manual, initialize 72

partial 71

set priority 78

replace disk, manual 72

restart

- controller 75
- subsystem 75
- right side I/O 77
- RS-232 terminal set up 57

## S

- SATAssure, set 73
- serial port, set up 57
- service clearance 25
- shutdown
  - controller 75
  - subsystem 75
- site preparation 24
- SNMP set up 103
- spare pool
  - create 49, 70
  - delete 70
  - display 69
  - global 69
  - name, change 70
  - view list of 68
- sparing policy 71
- specifications, technical 153
- SSH 101
- storage pool
  - configuration, checking 62
  - create 46, 64
  - delete 66
  - initialization 65
  - list of, view 63
  - location, physical 66
  - name, change 66
  - SATAssure, set 73
  - sparing policy 71
  - status 63
  - verify 66

## T

- technical specifications 153
- Technical support vi
- Telnet 101
- terminology 155
- time, set system 74

## U

- unassigned
  - location, physical 62

- unassigned pool 60
- unpack the system 28
- UPS 13
  - battery, connect 37
  - connect to Controller 37
  - DIP switch 38

## V

- verify pool 66
- version information 91
- virtual disk
  - assign to host 82
  - associated with storage pool,
    - view 64
  - counters 77
  - create 48, 68
  - delete 68
  - name, change 68
  - status, checking 67
- visual indication
  - disk 62
  - storage pool 66
  - unassigned pool 62

## W

- write back cache, set 79

## Z

- zoning configuration, disk enclosure 30

