B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
0A3	50	37	*70	2	11	3	5	1
*Normally Shows Short on Position No. 11.								
*Normally Shows Grid Emission.								
0B3	50	37	*69	2	11	3	5	1
*Normally Shows Short on Position No. 11.								
*Normally Shows Grid Emission.								
0C3	50	37	*85	2	11	3	5	1
*Normally Shows Short on Position No. 11.								
*Normally Shows Grid Emission.								
0D3	50	37	*99	2	11	3	5	1
*Normally Shows Short on Position No. 11.								
*Normally Shows Grid Emission.								
*Tube Good if it Reads 60 or More.								
0Z4	6	31	8					1
			8					2
1A3	2	40	*70	7	1	2	6	1
*Normally Shows Short on Position 5 and 11.								
1A5	1	37	55	7	2	12	5	1
1A7	1	37	57	7	2	12	5	1
1AB6	1	40	54	7	1	12	4	1
1AC6	1	40	48	7	1	12	4	1
1AF4	1	40	50	7	1	5	6	1
1AH5	1	40	58	7	1	12	6	1
			70	7	1	12	3	1
1AJ4	1	40	58	7	1	5	6	1
1AN5	1	40	40	7	1	5	6	1
1AU3	1	32	95					1
1AX2	1	24	93					1
1B3	1	32	55					1
1B7	1	37	55	7	2	12	5	1
1C1	1	40	57	7	1	5	4	1
1C5	1	37	54	7	2	12	5	1
1C7	2	37	54	7	2	12	5	1
1D5GT	2	37	54	7	2	12	10	1
1D8	1	37	58	7	2	12	5	1
			86	7	2	12	10	1
			*99	7	2	12	8	1
*Tube Good if it Reads 30 or More.								
1DN5	1	40	60	7	1	12	6	1
1F1	1	40	58	7	1	5	6	1
1F2	1	40	55	7	1	5	6	1
1F3	1	40	55	7	1	5	6	1
1F5	2	37	48	7	2	12	5	1
1F7	2	37	54	7	2	12	10	1
			64	7	2	12	4	1
			67	7	2	12	5	1
1FD1	1	40	58	7	1	12	6	1
			70	7	1	12	3	1
1FD9	1	40	56	7	1	12	6	1
			95	7	1	12	3	1
1G3	1	32	55					1
1G6	1	37	55	7	2	12	4	1
			55	7	2	12	5	1
1H2	1	24	58					1
1H5	1	37	55	7	2	12	10	1
1H6	2	37	54	7	2	12	6	1
			65	7	2	12	4	1
			65	7	2	12	5	1
1J3	1	32	88					1
1J6	2	37	53	7	2	12	4	1
		37	53	7	2	12	5	1
1K3	1	32	90					1
1L4	1	40	55	7	1	5	6	1
1L6	1	40	58	7	1	12	4	1
1LA4	1	36	54	8	1	12	6	1
1LA6	1	36	62	8	1	12	4	1
1LB4	1	36	55	8	1	12	6	1
1LC5	1	36	54	8	1	5	6	1
1LC6	1	36	68	8	1	12	4	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
1LD5	2	36	53	8	1	12	6	1
			63	8	1	12	4	1
1LE3	1	36	55	8	1	12	6	1
1LG5	2	36	50	8	1	5	6	1
1LH4	2	36	52	8	1	12	6	1
			60	8	1	12	4	1
1LN5	1	36	53	8	1	5	6	1
1N2-A	1	32	53					1
1N5	2	37	53	7	2	12	10	1
1P5	2	37	53	7	2	12	10	1
1P10	3	40	*48	7	1	5	3	1
*Normally Shows Short Position 2-6.								
1P11	3	40	45	7	1	5	6	1
1Q5	1	37	48	7	2	12	5	1
1R4	2	36	60	8	1	12	4	1
1R5	1	40	57	7	1	5	4	1
1S2-A	1	24	35					1
1S4	1	40	*55	7	1	5	3	1
*Normally Shows Short Position 2-6.								
1S5	1	40	56	7	1	12	6	1
		40	95	7	1	12	3	1
1T4	1	40	55	7	1	5	6	1
1T5	1	37	54	7	2	12	5	1
1U4	1	40	52	7	1	5	6	1
1U5	1	40	55	7	1	12	6	1
	2	40	70	7	1	12	4	1
1V2	1	38	99	5	4	1	9	1
1X2	1	24	56					1
2AF4	2	40	*33	4	3	2	6	1
*Normally Shows Short Position 1-7.								
2B3	2	32	30					1
2BN4	2	40	*33	4	3	2	7	1
*Normally Shows Short Position 1-6.								
2C51	6	38	29	9	1	12	3	1
			29	9	1	12	7	1
2CW4	2	41	*87	10	12	12	2	1
*For Grid Emission Turn D Switch to Position 4.								
2CY5	2	1	54					1
2D21	6	40	32	4	3	5	1	1
2E26	6	37	*40	7	2	1	5	1
*Normally Shows Short Position 4-6.								
2EA5	2	1	80					1
2EN5	2	5	62					1
			62					2
2ER5	2	40	33	4	3	1	2	1
2ES5	2	40	33	4	3	1	2	1
2EV5	2	1	52					1
2FH5	2	40	33	4	3	1	2	1
2FS5	2	1	99					1
2FQ5	2	40	33	4	3	1	2	1
2FQ5A	2	40	31	4	3	1	2	1
2FV6	2	1	54					1
2FY5	2	40	33	4	3	1	2	1
2GK5	2	40	25	4	3	1	2	1
2T4	2	40	*33	4	3	2	6	1
*Normally Shows Short Position 1-7.								
3A2	3	24	35					1
3A3	3	32	60					1
3A4	3	40	*36	7	1	5	4	1
*Normally Shows Short Position 2-6.								
3A5	3	40	45	7	1	4	3	1
		40	45	7	1	4	5	1
3A8	3	37	54	7	2	1	[illegible]	1
			55	7	2	1		1
			92	7	2	1		1
3AF4	3	40	*33	4	3	2	6	1
*Normally Shows Short Position 1-7.								
3AJ8	3	38	85	5	4	12	1	1
			38	5	4	12	9	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
3AL5	3	5	62					1
			62					2
3AU6	3	1	82					1
3AV6	3	6	88					1
			78					2
3AW3	3	32	59					1
3B2	3	32	72					1
3B7	3	36	45	8	1	4	3	1
			45	8	1	4	6	1
3BA6	3	1	78					1
3BC5	3	1	74					1
3BE6	3	1	91					1
3BN4	3	40	*33	4	3	2	7	1
*Normally Shows Short Position 1-6.								
3BN6	3	7	75					1
3BU8	3	21	92					1
			92					2
3BX6	3	38	33	5	4	1	2	1
3BY6	3	1	91					1
3BY7	3	38	33	5	4	1	2	1
3BZ6	3	1	61					1
3C2	3	32	22					1
3C4	2	40	48	7	1	5	6	1
3CB6	3	1	64					1
3CE5	3	1	62					1
3CF6	3	1	60					1
3CS6	3	1	94					1
3CY5	3	1	54					1
3D6	2	36	43	8	1	[illegible]	6	1
3DG4	3	37	26	1	3	12	5	1
			26	1	3	12	7	1
3DK6	3	1	61					1
3DT6	3	1	91					1
3EA5	3	1	80					1
3EH7	3	38	30	5	4	3	2	1
3EJ7	3	38	29	5	4	3	2	1
3ER5	3	40	33	4	3	1	2	1
3ES5	3	40	33	4	3	1	2	1
3EV5	3	1	52					1
3FH5	3	40	33	4	3	1	2	1
3FQ5	3	40	33	4	3	1	2	1
3FQ5A	3	40	31	4	3	1	2	1
3FS5	3	1	99					1
3FY5	3	40	33	4	3	1	2	1
3GK5	3	40	25	4	3	1	2	1
3GS8	3	21	95					1
			95					2
3HS8	3	21	99					1
			99					2
3L35	3	40	*36	7	1	5	4	1
*Normally Shows Short Position 2-6.								
3LF4	3	36	43	8	1	7	6	1
3Q4	3	40	*42	7	1	5	3	1
*Normally Shows Short Position 2-6.								
3Q5	3	37	45	7	2	8	5	1
3S4	3	40	*48	7	1	5	3	1
*Normally Shows Short Position 2-6.								
3V4	3	40	45	7	1	5	6	1
4AU6	4	1	82					1
4AU8	4	12	59					1
			71					2
4AV6	4	6	91					1
			78					2
4BA6	4	1	78					1
4BC5	4	1	74					1
4BC8	4	8	53					1
			53					2
4BE6	4	1	91					1
4BL8	4	11	66					1
			55					2

*Normal Shorts [illegible] "Switch

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
4BN4	4	40	*33	4	3	2	7	1
*Normally Shows Short Position 1-6.								
4BN6	4	7	75					1
4BQ7	4	8	54					1
			54					2
4BS8	4	8	54					1
			54					2
4BU8	4	21	92					1
			92					2
4BX8	4	38	33	5	4	12	2	1
			33	5	4	12	7	1
4BZ6	4	1	61					1
4BZ7	4	8	53					1
			53					2
4BZ8	4	8	55					1
			55					2
4CB6	4	1	64					1
4CE5	4	1	62					1
4CS6	4	1	94					1
4CY5	4	1	54					1
4DE6	4	1	61					1
4DK6	4	1	61					1
4DT6	4	1	91					1
4EH7	4	38	30	5	4	3	2	1
4EJ7	4	38	29	5	4	3	2	1
4ES8	4	38	30	5	4	12	2	1
			30	5	4	12	7	1
4EW6	4	1	77					1
4GK5	4	40	25	4	3	1	2	1
4GM6	4	1	64					1
4GS8	4	21	95					1
			95					2
4HS8	4	21	99					1
			99					2
5AM8	5	38	30	5	4	12	2	1
			30	5	4	12	8	1
5AN8	5	13	62					1
			61					2
5AQ5	5	3	77					1
5AR4	5	33	10					1
			10					2
5AS4	5	33	17					1
			17					2
5AS8	5	38	31	5	4	12	2	1
			32	5	4	12	6	1
5AT8	5	14	77					1
			55					2
5AU4	5	33	16					1
			16					2
5AV8	5	22	62					1
			86					2
5AW4	5	33	17					1
			17					2
5AZ4	5	36	53	8	2	12	4	1
			53	8	2	12	6	1
5B8	5	22	62					1
			86					2
5BC3	5	42	*33	1	3	6	5	1
			**33	1	3	8	9	1
*Normally Shows Short Position 8-9.								
**Normally Shows Short Position 5-6.								
5BE8	5	14	72					1
			55					2
5BK7	5	8	55					1
			55					2
5BQ5	5	23	68					1
5BQ7	5	8	54					1
			54					2
5BR8	5	14	72					1
			55					2

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
5BS8	5	8	54					1
			54					2
5BT8	5	38	33	5	4	12	8	1
			54	5	4	12	1	1
			54	5	4	12	2	1
5BW8	5	38	33	5	4	2	6	1
			34	5	4	7	1	1
			34	5	4	7	3	1
5BZ7	5	8	53					1
			53					2
5CG8	5	14	73					1
			59					2
5CL8	5	14	69					1
			51					2
5CM6	5	16	64					1
5CM8	5	38	33	5	4	12	2	1
			38	5	4	12	9	1
5CQ8	5	11	72					1
			55					2
5CR8	5	38	*32	5	4	12	2	1
			*34	5	4	12	9	1
*Normally Shows Short Position 8.								
5CU4	5	37	28	8	2	12	4	1
			28	8	2	12	6	1
5CZ5	5	16	60					1
5DB4	5	33	16					1
			16					2
5DH8	5	14	61					1
			73					2
5DJ4	5	33	16					1
			16					2
5EA8	5	11	71					1
			56					2
5EH8	5	12	71					1
			54					2
5ES8	5	38	30	5	4	12	2	1
			30	5	4	12	7	1
5EU8	5	38	32	5	4	12	7	1
			32	5	4	12	2	1
5EW6	5	1	77					1
5FG7	5	14	68					1
			56					2
5FV8	5	14	65					1
			54					2
5GH8	5	11	68					1
			56					2
5GM6	5	1	64					1
5GX6	5	1	85					1
5J6	5	2	60					1
			60					2
5N1039A	6	1	63					1
5R4	5	33	22					1
			22					2
5T4	5	33	16					1
			16					2
5T8	5	17	90					1
			63					2
5U4	5	33	16					1
			16					2
5U8	5	11	79					1
			55					2
5V3	5	33	15					1
			15					2
5V4	5	33	12					1
			12					2
5V6	5	29	79					1
5W4	5	33	32					1
			32					2
5X4	5	37	47	8	7	12	3	1
			47	8	7	12	5	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
5X8	5	12	73					1
			61					2
5Y3	5	33	32					1
			32					2
5Y4	5	37	52	8	7	12	3	1
			52	8	7	12	5	1
5Z4	5	33	12					1
			12					2
5Z10	5	33	16					1
			16					2
6A8	6	37	45	7	2	1	5	1
6AB4	6	40	30	4	3	12	6	1
6AB7	6	30	74					1
6AB8	6	38	37	5	4	12	9	1
			44	5	4	12	2	1
6AC5	6	37	40	7	2	12	5	1
6AC7	6	30	60					1
6AD7	6	37	54	7	2	12	5	1
			62	7	2	12	1	1
6AF3	6	15	12					1
6AF4	6	40	*33	4	3	2	6	1
*Normally Shows Short Position 1-7.								
6AG5	6	1	80					1
6AG7	6	30	38					1
6AH4	6	37	33	7	2	12	1	1
6AH6	6	1	58					1
6AH7	6	37	48	8	7	12	1	1
			48	8	7	12	5	1
6AJ4	6	38	*84	8	7	1	5	1
*Normally Shows Short Position 3-4-6-9.								
6AJ5	6	40	36	4	3	2	1	1
6AJ7	6	30	60					1
6AJ8	6	38	85	5	4	12	1	1
			38	5	4	12	9	1
6AK5	6	1	63					1
6AK6	6	1	82					1
6AK7	6	30	38					1
6AK8	6	17	90					1
			63					2
6AL3	6	39	25	5	4	6	3	1
6AL5	6	5	62					1
			62					2
6AM4	6	38	*96	8	7	1	5	1
*Normally Shows Short Position 3-4-6-9.								
6AM5	6	40	34	4	3	12	1	1
6AM6	6	40	30	4	3	12	1	1
6AM8	6	38	30	5	4	12	2	1
			30	5	4	12	8	1
6AN4	6	40	*30	4	3	2	6	1
*May Show Short Position 1-7.								
6AN5	6	1	26					1
6AN6	6	40	52	7	1	12	2	1
			52	7	1	12	3	1
			52	7	1	12	4	1
			52	7	1	12	5	1
6AN8	6	13	62					1
			61					2
6AQ4	6	40	*29	4	3	6	1	1
*Normally Shows Short Position 2-5.								
6AQ5	6	3	77					1
6AQ6	6	6	89					1
			80					2
6AQ7	6	37	45	8	7	12	4	1
			58	8	7	12	1	1
			58	8	7	12	3	1
6AQ8	6	8	70					1
			70					2
6AR5	6	3	91					1
6AR6	6	37	33	8	6	12	7	1
6AR8	6	38	30	5	4	12	6	1

*Normal Shorts refer to position of "3" Switch

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
6AS5	6	4	55					1
6AS6	6	1	77					1
6AS7	6	37	35	8	7	12	1	1
			35	8	7	12	4	1
6AS8	6	38	31	5	4	12	2	1
			32	5	4	12	6	1
6AT6	6	6	85					1
			78					2
6AT8	6	14	77					1
			55					2
6AU4	6	34	10					1
6AU5	6	28	71					1
6AU6	6	1	82					1
6AU7	6	8	75					1
			75					2
6AU8	6	12	56					1
			72					2
6AV5	6	28	62					1
6AV6	6	6	91					1
			78					2
6AV11	6	35	30	1	12	12	7	1
			30	1	12	12	9	1
			30	1	12	12	11	1
6AW8	6	12	44					1
			78					2
6AX2	6	24	88					1
6AX3	6	35	30	1	12	10	4	1
6AX4	6	34	13					1
6AX5	6	33	22					1
			22					2
6AX7	6	8	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
6AX8	6	11	73					1
			54					2
6AY3	6	42	27	5	4	7	2	1
6AZ8	6	38	32	5	4	12	6	1
			36	5	4	12	9	1
6B4	6	37	35	7	2	12	5	1
6B6	6	37	37	7	2	12	10	1
			58	7	2	12	4	1
			58	7	2	12	5	1
6B8	6	37	55	7	2	12	10	1
			65	7	2	12	4	1
			65	7	2	12	5	1
6B10	6	35	34	1	12	12	3	1
			34	1	12	12	5	1
			34	1	12	12	8	1
			34	1	12	12	10	1
6B31	6	5	62					1
			62					2
6B32	6	5	62					1
			62					2
6BA6	6	1	78					1
6BA7	6	38	33	5	4	12	2	1
6BA8	6	12	53					1
			59					2
6BC4	6	39	30	5	4	3	7	1
6BC5	6	1	74					1
6BC7	6	38	32	5	4	12	2	1
			32	5	4	12	6	1
			32	5	4	12	8	1
6BC8	6	8	53					1
			53					2
6BC32	6	6	91					1
			78					2
6BD5	6	37	29	7	2	12	1	1
6BD6	6	1	85					1
6BE6	6	1	91					1
6BE7	6	38	33	5	4	3	7	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
6BE8	6	14	72					1
			55					2
6BF5	6	3	40					1
6BF6	6	6	85					1
			80					2
6BF8	6	38	25	4	5	12	1	1
			25	4	5	12	2	1
			25	4	5	12	3	1
			25	4	5	12	7	1
			25	4	5	12	8	1
			25	4	5	12	9	1
6BG6	6	26	66					1
6BH3	6	42	27	5	4	7	2	1
6BH6	6	1	89					1
6BH8	6	12	59					1
			54					2
6BJ6	6	1	81					1
6BJ7	6	38	33	5	4	12	2	1
			33	5	4	12	6	1
			33	5	4	12	8	1
6BJ8	6	38	38	5	4	12	8	1
			34	5	4	12	1	1
			34	5	4	12	6	1
6BK4	6	37	*55	7	2	3	5	1
*Normally Shows Short Position 1-4-6-8.								
6BK5	6	10	53					1
6BK6	6	6	86					1
			70					2
6BK7	6	8	55					1
			55					2
6BL4	6	34	10					1
6BL7	6	25	57					1
			57					2
6BL8	6	11	66					1
			55					2
6BM8	6	38	33	5	4	12	3	1
			39	5	4	12	1	1
6BN4	6	40	*33	4	3	2	7	1
*Normally Shows Short Position 1-6.								
6BN5	6	38	*39	5	4	1	2	1
*Normally Shows Short Position 6-8.								
6BN6	6	7	75					1
6BN8	6	38	35	5	4	12	8	1
			35	5	4	12	1	1
			35	5	4	12	6	1
6BQ5	6	23	68					1
6BQ6	6	27	69					1
6BQ7	6	8	54					1
			54					2
6BR8	6	14	72					1
			55					2
6BS8	6	8	54					1
			54					2
6BT6	6	6	85					1
			78					2
6BT8	6	38	33	5	4	12	8	1
			54	5	4	12	1	1
			54	5	4	12	2	1
6BU6	6	6	85					1
			80					2
6BU8	6	21	92					1
			92					2
6BV8	6	38	31	5	4	12	2	1
			33	5	4	12	6	1
			33	5	4	12	9	1
6BW4	6	38	50	5	4	12	1	1
			50	5	4	12	7	1
6BW8	6	38	33	5	4	2	6	1
			34	5	4	7	1	1
			34	5	4	7	3	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
6BX6	6	38	33	5	4	1	2	1
6BX7	6	25	55					1
			55					2
6BX8	6	38	33	5	4	12	2	1
			33	5	4	12	7	1
6BY5	5	37	38	7	2	12	4	1
			38	7	2	12	5	1
6BY6	6	1	88					1
6BY7	6	38	33	5	4	1	2	1
6BY8	6	38	34	5	4	12	1	1
			34	5	4	12	6	1
6BZ6	6	1	61					1
6BZ7	6	8	53					1
			53					2
6BZ8	6	8	55					1
			55					2
6C4	6	40	41	4	3	1	6	1
6C5	6	29	99					1
6C8	6	37	48	7	2	12	5	1
				7	2	12	10	1
6C9	6	38	28	5	4	6	1	1
			28	5	4	10	7	1
6C31	6	40	*80	4	3	1	7	1
*Normally Shows Short Position 5-6.								
6CA4	6	38	34	5	4	12	1	1
			34	5	4	12	7	1
6CA5	6	4	55					1
6CA7	6	29	53					1
6CB5	6	26	43					1
6CB6	6	1	64					1
6C10	6	35	42	1	12	12	7	1
			42	1	12	12	9	1
			42	1	12	12	11	1
6CCYZ	6	38	29	9	1	12	3	1
			29	9	1	12	7	1
6CD6	6	26	53					1
6CE5	6	1	62					1
6CF6	6	1	60					1
6CG7	6	8	76					1
			76					2
6CG8	6	14	73					1
			57					2
6CH6	6	38	28	5	4	12	2	1
6CH8	6	38	33	5	4	12	7	1
			36	5	4	12	8	1
6CJ6	6	38	*32	5	4	7	2	1
*Normally Shows Short Position 1-6-9.								
6CK4	6	37	34	7	2	1	3	1
6CK6	6	38	30	5	4	12	2	1
6CL5	6	26	54					1
6CL6	6	38	*32	5	4	2	9	1
*Normally Shows Short Position 3-8.								
6CL8	6	14	69					1
			51					2
6CM5	6	27	58					1
6CM6	6	16	64					1
6CM7	6	19	80					1
			94					2
6CM8	6	38	33	5	4	12	2	1
			38	5	4	12	9	1
6CN6	6	29	*62					1
*For Plate Cap Use Jack Next to Socket 26.								
6CN7	6	18	94					1
			60					2
6CQ4	6	34	11					1
6CQ5	6	40	35	4	3	12	1	1
6CQ8	6	11	72					1
			55					2
6CR6	6	40	39	4	3	12	7	1
			61	4	3	12	2	1

*Normal Shorts refer to position of "D" Switch.

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
6CR8	6	38	*32	5	4	12	2	1
			*34	5	4	12	9	1
*Normally Shows Short Position 8.								
6CS6	6	1	94					1
6CS7	6	20	96					1
			95					2
6CU5	6	4	47					1
6CU6	6	27	69					1
6CU8	6	38	32	5	4	1	7	1
			33	5	4	6	8	1
6CW4	6	41	*87	10	12	12	2	1
*For Grid Emission Turn D Switch to Position 4.								
6CW5	6	23	58					1
6CW7	6	38	33	5	4	7	2	1
			33	5	4	7	6	1
6CX8	6	12	45					1
			67					2
6CY5	6	1	54					1
6CY7	6	38	31	5	4	2	3	1
			45	5	4	2	7	1
6CZ5	6	16	60					1
6D2	6	5	62					1
			62					2
6D4	6	40	43	4	3	12	1	1
6D8	6	37	43	7	2	12	5	1
6D10	6	35	32	1	12	12	7	1
			32	1	12	12	9	1
			32	1	12	12	11	1
6DA4	6	34	11					1
6DA6	6	38	34	5	4	1	2	1
6DB5	6	16	30					1
6DB6	6	1	87					1
6DC6	6	1	67					1
6DC8	6	38	33	5	4	12	2	1
			60	5	4	12	7	1
			60	5	4	12	8	1
6DE4	6	34	13					1
6DE6	6	1	61					1
6DE7	6	20	81					1
			90					2
6DG6	6	29	38					1
6DJ8	6	38	31	5	4	12	2	1
			31	5	4	12	7	1
6DK6	6	1	61					1
6DL5	6	3	88					1
6DM4	6	34	11					1
6DN6	6	26	47					1
6DN7	6	25	56					1
			77					2
6DQ4	6	34	11					1
6DQ5	6	26	55					1
6DQ6	6	27	65					1
6DQ6B	6	27	62					1
6DR7	6	38	32	4	5	2	3	1
			40	4	5	2	7	1
*Normally Shows Short Position 4-10.								
6DR8	6	38	31	5	4	12	2	1
			62	5	4	12	7	1
			62	5	4	12	8	1
6DS4	6	41	*87	10	12	12	2	1
*For Grid Emission Turn D Switch Position 4.								
6DS5	6	3	76					1
6DS8	6	38	30	5	4	12	2	1
			34	5	4	12	9	1
6DT5	6	16	45					1
6DT6	6	1	91					1
6DT8	6	8	71					1
			71					2
6DW5	6	16	30					1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
6DX8	6	38	26	4	5	12	8	1
			26	4	5	12	1	1
6DZ7	6	37	40	7	2	12	1	1
			40	7	2	12	5	1
6DZ8	6	38	27	4	5	8	3	1
			30	4	5	2	1	1
6EA5	6	1	80					1
6EA7	6	37	35	8	7	12	1	1
			39	8	7	12	4	1
6EA8	6	11	71					1
			56					2
6EB5	6	5	71					1
			71					2
6EB8	6	12	35					1
			99					2
6EH5	6	4	57					1
6EH7	6	38	30	5	4	3	2	1
6EH8	6	12	71					1
			54					2
6EJ7	6	38	29	5	4	3	2	1
6EM5	6	16	53					1
6EM7	6	37	32	8	7	12	1	1
			45	8	7	12	4	1
6EQ7	6	38	34	5	4	12	2	1
			71	5	4	12	8	1
6ER5	6	40	33	4	3	1	2	1
6ES5	6	40	33	4	3	1	2	1
6ES8	6	38	30	5	4	12	2	1
			30	5	4	12	7	1
6ET6	6	40	30	4	3	12	1	1
6ET7	6	38	30	5	4	12	7	1
			70	5	4	12	2	1
			70	5	4	12	3	1
6EU7	6	38	35	2	1	12	5	1
			35	2	1	12	8	1
6EU8	6	38	32	5	4	12	7	1
			32	5	4	12	2	1
6EV5	6	1	52					1
6EV7	6	8	78					1
			78					2
6EW6	6	1	77					1
6EW7	6	20	83					1
			92					2
6EX6	6	26	42					1
6EY6	6	29	65					1
6EZ5	6	29	65					1
6EZ8	6	38	33	5	4	12	2	1
			33	5	4	12	7	1
6F5	6	37	40	7	2	1	10	1
6F6	6	29	91					1
6F8	6	37	45	7	2	12	5	1
			45	7	2	12	10	1
6F10	6	30	60					1
6F31	6	1	78					1
6F33	6	1	77					1
6F36	6	1	58					1
6F40	6	38	39	5	4	2	9	1
6FA7	6	38	33	5	4	12	7	1
			65	5	4	12	3	1
6FD6	6	40	26	3	4	2	1	1
6FD7	6	38	25	4	5	2	3	1
			32	4	5	2	7	1
6FE5	6	29	37					1
6FG5	6	40	31	4	3	2	1	1
6FG7	6	14	68					1
			56					2
6FH5	6	40	33	4	3	1	2	1
6FH8	6	38	32	5	4	12	6	1
			32	5	4	12	2	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
6FJ7	6	35	36	1	12	12	3	1
			44	1	12	12	10	1
6FM8	6	38	47	5	4	12	8	1
			34	5	4	12	2	1
			34	5	4	12	6	1
6FQ5	6	40	33	4	3	1	2	1
6FQ5A	6	40	31	4	3	1	2	1
6FQ7	6	8	68					1
			68					2
6FR7	6	38	24	4	5	2	3	1
			32	4	5	2	7	1
6FS5	6	1	99					1
6FV6	6	1	54					1
6FV8	6	14	65					1
			54					2
6FW5	6	28	57					1
6FW8	6	8	30					1
			30					2
6FY5	6	40	33	4	3	1	2	1
6GB5	6	42	*25	4	5	2	1	1
*Normally Shows Short Position 3-6-7-8.								
6G6	6	29	94					1
6GC5	6	16	26					1
6GC6	6	26	52					1
6GE5	6	35	*24	1	12	11	3	1
*Normally Shows Short Position 4-10.								
6GE8	6	38	33	5	4	12	8	1
			33	5	4	12	3	1
6GF5	6	35	*24	1	12	11	3	1
*Normally Shows Short Position 4-10.								
6GH8	6	11	68					1
			56					2
6GJ5	6	42	*30	4	5	6	2	1
*Normally Shows Short Position 1-7.								
6GJ8	6	11	70					1
			53					2
6GK5	6	40	25	4	3	1	2	1
6GK6	6	38	33	5	4	3	2	1
6GM5	6	38	*26	4	5	2	6	1
*May Show Short Position 3-8.								
6GM6	6	1	64					1
6GM8	6	38	33	5	4	12	2	1
			33	5	4	12	7	1
6GN8	6	12	36					1
			98					2
6GS8	6	21	95					1
			95					2
6GT5	6	42	*30	4	5	6	2	1
*Normally Shows Short Position 1-7.								
6GV8	6	38	25	4	5	12	9	1
			25	4	5	12	2	1
6GW6	6	27	62					1
6GW8	6	38	25	4	5	2	8	1
			35	4	5	7	1	1
6GX6	6	1	85					1
6GY6	6	1	82					1
6GY8	6	38	*32	5	4	12	1	1
			*32	5	4	12	3	1
			*94	5	4	12	6	1
*Normally Shows Short Position 4.								
6H6	6	37	48	7	2	1	3	1
			48	7	2	1	5	1
6H31	6	1	91					1
6HB6	6	38	*24	4	5	6	2	1
*Normally Shows Short Position 3-9.								
6HC8	6	38	36	5	4	12	3	1
			38	5	4	12	1	1
6HF8	6	12	27					1
			80					2
6HG8	6	38	25	4	5	3	2	1
			25	4	5	1	6	1

*Normal Shorts refer to position of "D" Switch.

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
6HJ8	6	38	29	5	4	12	2	1
			31	5	4	12	8	1
6HL8	6	11	60					1
			60					2
6HS6	6	1	66					1
6HS8	6	21	99					1
			99					2
6HZ8	6	12	28					1
			75					2
6J4	6	40	*85	4	3	1	7	1
*Normally Shows Short Position 5-6.								
6J5	6	29	93					1
6J6	6	2	60					1
			60					2
6J7	6	37	50	7	2	1	10	1
6J11	6	35	22	1	12	12	5	1
			22	1	12	12	11	1
6JC8	6	38	24	4	5	1	2	1
			24	4	5	1	8	1
6JE8	6	12	56					1
			78					2
6JH8	6	38	26	4	5	12	6	1
6JK8	6	8	54					1
			55					2
6JU8	6	38	*32	4	5	2	1	1
			**32	4	5	8	7	1
*Normally Shows Short Position 8.								
**Normally Shows Short Position 2.								
6K6	6	29	92					1
6K7	6	37	52	7	2	1	10	1
6K8	6	37	35	7	2	1	5	1
6K11	6	35	38	1	12	12	7	1
			38	1	12	12	9	1
			38	1	12	12	11	1
6L5	6	37	53	7	2	6	5	1
6L6	6	29	63					1
6L7	6	37	44	7	2	1	10	1
6L10	6	30	38					1
6L12	6	8	70					1
			70					2
6L41	6	38	33	5	4	8	9	1
6L43	6	38	*32	5	4	2	9	1
*Normally Shows Short Position 3-8.								
6LD12	6	16	90					1
			63					2
6N7	6	37	47	7	2	1	4	1
			47	7	2	1	5	1
6N8	6	38	37	5	4	12	2	1
			64	5	4	12	7	1
			64	5	4	12	8	1
6NK7GT	6	30	84					1
6P5	6	29	93					1
6P15	6	23	68					1
6Q7	6	37	40	7	2	1	10	1
			63	7	2	1	4	1
			63	7	2	1	5	1
6Q11	6	35	38	1	12	12	7	1
			38	1	12	12	9	1
			38	1	12	12	11	1
6R3	6	38	33	5	4	2	9	1
6R4	6	38	30	4	5	12	1	1
6R7	6	37	52	7	2	1	10	1
			63	7	2	1	4	1
			63	7	2	1	5	1
6R8	6	17	86					1
			62					2
6S2	6	24	35					1
6S4	6	16	58					1
6S7	6	37	47	7	2	1	10	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
6S8	6	37	45	8	7	5	10	1
			62	8	7	5	1	1
			62	8	7	5	4	1
			63	8	7	2	3	1
6SA7	6	37	37	7	2	1	5	1
6SB7Y	6	37	34	7	2	1	5	1
6SC7	6	37	48	8	7	1	3	1
			48	8	7	1	4	1
6SD7	6	30	69					1
6SF5	6	37	41	8	7	1	3	1
6SF7	6	37	46	8	7	1	2	1
			69	8	7	1	5	1
6SG7	6	30	77					1
6SH7	6	30	77					1
6SJ7	6	30	83					1
6SK7	6	30	84					1
6SL7	6	25	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
6SN7	6	25	78					1
			78					2
6SQ7	6	37	42	8	7	1	2	1
			71	8	7	1	4	1
			71	8	7	1	5	1
6SR7	6	37	46	8	7	1	2	1
			68	8	7	1	4	1
			68	8	7	1	5	1
6SS7	6	37	46	7	2	1	4	1
6ST7	6	37	52	8	7	1	2	1
			72	8	7	1	4	1
			72	8	7	1	5	1
6SU7	6	37	43	8	7	12	1	1
			43	8	7	12	4	1
6SZ7	6	37	44	8	7	1	2	1
			72	8	7	1	4	1
			72	8	7	1	5	1
6T4	6	40	*33	4	3	2	6	1
*Normally Shows Short Position 1-7.								
6T8	6	17	90					1
			63					2
6U4	6	34	11					1
6U6	6	29	54					1
6U7	6	37	35	7	2	12	10	1
6U8	6	11	79					1
			55					2
6V3	6	15	10					1
6V4	6	38	40	5	4	12	1	1
			40	5	4	12	7	1
6V6	6	29	79					1
6V8	6	38	40	5	4	12	6	1
			32	5	4	12	2	1
			32	5	4	12	7	1
			61	5	4	12	9	1
6W4	6	34	11					1
6W6	6	29	51					1
6W7	6	37	50	7	2	12	10	1
6X4	6	40	44	4	3	12	1	1
			44	4	3	12	6	1
6X5	6	33	15					1
			15					2
6X6	6	37	48	7	2	12	3	1
			48	7	2	12	5	1
6X8	6	12	73					1
			61					2
6Y6	6	29	40					1
6Z31	6	40	44	4	3	12	1	1
			44	4	3	12	6	1
6ZY5	6	33	17					1
7A4	6	36	41	8	1	12	6	1
7A5	6	36	34	8	1	12	6	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
7A6	6	36	48	8	1	12	3	1
			48	8	1	12	6	1
7A7	6	36	45	8	1	12	6	1
7A8	6	36	40	8	1	12	4	1
7AD7	6	36	35	8	1	12	6	1
7AF7	6	36	41	8	1	12	4	1
			41	8	1	12	5	1
7AG7	6	36	32	8	1	12	6	1
7AH7	6	36	32	8	1	12	6	1
7AK7	6	36	33	8	1	12	6	1
7AN7	7	38	33	5	4	7	2	1
			33	5	4	7	6	1
7AU7	7	8	75					1
			75					2
7B4	6	36	40	8	1	12	6	1
7B5	6	36	52	8	1	12	6	1
7B6	6	36	40	8	1	4	3	1
			68	8	1	4	5	1
			68	8	1	4	6	1
7B7	6	36	45	8	1	12	6	1
7B8	6	36	42	8	1	12	4	1
7C4	6	36	53	8	1	12	4	1
7C5	6	36	38	8	1	12	6	1
7C6	6	36	50	8	1	4	3	1
			68	8	1	4	5	1
			68	8	1	4	6	1
7C7	6	36	37	8	1	12	6	1
7DJ8	7	38	31	5	4	12	2	1
			31	5	4	12	7	1
7E5	6	36	*33	8	2	1	5	1
*Normally Shows Short Position 3-4-6-7.								
7E6	6	36	40	8	1	4	3	1
			69	8	1	4	5	1
			69	8	1	4	6	1
7E7	6	36	47	8	1	12	6	1
			68	8	1	12	3	1
			68	8	1	12	4	1
7ES8	7	38	30	5	4	12	2	1
			30	5	4	12	7	1
7EY6	7	29	65					1
7F7	6	36	45	8	1	12	4	1
			45	8	1	12	5	1
7F8	6	36	30	7	2	12	1	1
			30	7	2	12	8	1
7G7	6	36	36	8	1	12	6	1
7H7	6	36	35	8	1	12	6	1
7HG8	7	38	25	4	5	3	2	1
			25	4	5	1	6	1
7J7	6	36	35	8	1	12	6	1
			50	8	1	12	4	1
7K7	6	36	45	8	1	12	4	1
			65	8	1	12	5	1
			65	8	1	12	6	1
7L7	6	36	36	8	1	12	6	1
7N7	6	36	42	8	1	12	4	1
			42	8	1	12	5	1
7Q7	6	36	35	8	1	12	4	1
7R7	6	36	35	8	1	12	6	1
			72	8	1	12	3	1
			72	8	1	12	4	1
7S7	6	36	38	8	1	12	6	1
			52	8	1	12	4	1
7V7	6	36	32	8	1	12	6	1
7W7	6	36	31	8	1	4	6	1
7X6	6	36	35	8	1	12	3	1
			35	8	1	12	6	1
7X7	6	36	43	8	1	12	3	1
			36	8	1	12	5	1
			35	8	1	12	6	1

PM 245B 7-62 RR PRESS—5

*Normal Shorts refer to position of "D" Switch.

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
7Y4	6	36	45	8	1	12	3	1
			45	8	1	12	6	1
7Z4	6	36	50	8	1	12	3	1
			50	8	1	12	6	1
8A8	9	11	66					1
8AU8	8	12	56					1
			72					2
8AW8	8	12	44					1
			78					2
8B8	8	38	33	4	5	12	3	1
			39	4	5	12	1	1
8BA8	8	12	53					1
			59					2
8BH8	8	12	59					1
			54					2
8BN8	8	38	35	5	4	12	8	1
			35	5	4	12	1	1
8BQ5	8	23	68					1
8BQ7	8	8	54					1
			54					2
8CG7	8	8	76					1
			76					2
8CH8	8	38	33	5	4	12	7	1
			36	5	4	12	8	1
8CM7	8	19	80					1
			94					2
8CN7	8	18	94					1
			60					2
8CS7	8	20	96					1
			95					2
8CU8	8	38	32	5	4	1	7	1
			33	5	4	6	8	1
8CW5	8	23	58					1
8CX8	8	12	45					1
			67					2
8CY7	8	38	31	5	4	2	3	1
			45	5	4	2	7	1
8DE7	8	20	81					1
			90					2
8DX8	8	38	26	4	5	12	8	1
			26	4	5	12	1	1
8EB8	8	12	35					1
			99					2
8EM5	8	16	53					1
8ET7	8	38	30	5	4	12	7	1
			70	5	4	12	2	1
			70	5	4	12	3	1
8FQ7	8	8	68					1
			68					2
8GN8	8	12	36					1
			98					2
8HG8	8	38	25	4	5	3	2	1
			25	4	5	1	6	2
8JE8	8	12	56					1
			78					2
8JK8	8	8	54					1
			55					2
8SN7	8	25	78					1
			78					2
9A8	9	11	66					1
			55					2
9AK8	9	16	90					1
			63					2
9AQ8	9	8	70					1
			70					2
9AU7	9	8	75					1
			75					2
9BR7	9	38	32	5	4	9	2	1
			37	5	4	9	6	1
			37	5	4	9	7	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
9BR8	9	14	72					1
			55					2
9CL8	9	14	69					1
			51					2
9J6	9	2	60					1
			60					2
9U8	9	11	79					1
			55					2
9X8	9	12	73					1
			61					2
10BQ5	10	23	68					1
10C8	10	13	59					1
			73					2
10D2	19	5	62					1
			62					2
10DE7	10	20	81					1
			90					2
10DR7	10	38	32	5	4	2	3	1
			41	5	4	2	7	1
10/E/312	25	29	47					1
10/E/349	6	29	79					1
10/E/558	6	37	52	7	2	12	10	1
10/E/11448	6	29	93					1
10/E/11533	6	29	63					1
10/E/11581	6	37	40	7	2	12	10	1
10EB8	10	12	35					1
			99					2
10EG7	10	37	32	8	7	12	1	1
			45	8	7	12	4	1
10EM7	10	37	32	8	7	12	1	1
			45	8	7	12	4	1
10EW7	10	20	83					1
			92					2
10FD7	10	38	25	4	5	2	3	1
			32	4	5	2	7	1
10FR7	10	38	24	4	5	2	3	1
			32	4	5	2	7	1
10GN8	10	12	36					1
			98					2
10HF8	10	12	27					1
			80					2
11C5	12	4	54					1
11CY7	12	38	31	5	4	2	3	1
			45	5	4	2	7	1
11JE8	10	12	56					1
			78					2
12A4	12	39	32	5	4	3	7	1
12A6	12	29	92					1
12A8	12	37	45	7	2	12	5	1
12AB5	12	16	67					1
12AC6	12	40	42	4	3	12	1	1
12AD6	12	40	35	4	3	12	1	1
12AD7	12	8	85					1
			85					2
12AE6	12	40	52	4	3	12	1	1
			66	4	3	12	5	1
			66	4	3	12	6	1
12AE7	12	38	32	5	4	9	2	1
			32	5	4	9	7	1
12AF3	12	15	12					1
12AF6	12	40	37	4	3	12	1	1
12AG6	12	40	35	4	3	12	1	1
12AH7	12	37	48	8	7	12	1	1
			48	8	7	12	5	1
12AJ6	12	40	40	4	3	12	1	1
			66	4	3	12	5	1
			66	4	3	12	6	1
12AJ7	12	38	32	5	4	12	2	1
			35	5	4	12	9	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
12AL5	12	5	62					1
			62					2
12AL8	12	38	34	5	4	12	3	1
			52	5	4	12	8	1
12AQ5	12	3	77					1
12AS5	12	4	55					1
12AT6	12	6	85					1
			78					2
12AT7	12	8	74					1
			74					2
12AU5	12	28	71					1
12AU6	12	1	82					1
12AU7	12	8	75					1
			75					2
12AU8	12	12	56					1
			72					2
12AV5	12	28	62					1
12AV6	12	6	91					1
			78					2
12AV7	12	8	55*					1
			55					2
12AW6	12	1	78					1
12AW8	12	12	44					1
			78					2
12AX3	12	35	30	1	12	10	4	1
12AX4	12	34	13					1
12AX7	12	8	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
12AY3	12	42	27	5	4	7	2	1
12AY7	12	8	93					1
			93					2
12AZ7	12	8	73					1
			73					2
12B4	12	39	35	5	4	3	7	1
12B7	12	36	45	8	1	12	6	1
12BA6	12	1	78					1
12BA7	12	38	33	5	4	12	2	1
12BC32	12	6	91					1
			78					2
12BD6	12	1	85					1
12BE6	12	1	91					1
12BF6	12	6	85					1
			80					2
12BH7	12	8	56					1
			56					2
12BK5	12	10	53					1
12BK6	12	6	86					1
			70					2
12BL6	12	40	35	4	3	12	1	1
12BN6	12	7	75					1
12BQ6	12	27	69					1
12BR7	12	38	32	5	4	9	2	1
			36	5	4	9	6	1
			36	5	4	9	7	1
12BT6	12	6	85					1
			78					2
12BU6	12	6	85					1
			80					2
12BV7	12	9	39					1
12BW4	12	38	50	5	4	12	1	1
			50	5	4	12	7	1
12BX6	12	38	33	5	4	1	2	1
12BX7	12	25	55					1
			55					2
12BY7	12	9	42					1
12BZ6	12	1	61					1
12BZ7	12	8	95					1
			95					2
12C5	12	4	44					1

*Normal Shorts refer to position of "D" Switch.

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
12C8	12	37	55	7	2	12	10	1
			65	7	2	12	4	1
			65	7	2	12	5	1
12C8Y	12	37	55	7	2	12	10	1
			65	7	2	12	4	1
			65	7	2	12	5	1
12CA5	12	4	55					1
12CM6	12	16	64					1
12CN5	12	40	33	4	3	2	5	1
12CR6	12	40	39	4	3	12	7	1
			61	4	3	12	2	1
12CS6	12	1	94					1
12CT8	12	13	57					1
			63					2
12CU5	12	4	47					1
12CU6	12	27	69					1
12CX6	12	40	30	4	3	12	1	1
12D4	12	34	11					1
12DB5	12	16	30					1
12DE8	12	38	36	5	4	12	1	1
			34	5	4	12	3	1
12DF5	12	38	52	5	4	9	1	1
			52	5	4	9	6	1
12DF7	12	8	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
12DJ8	12	38	31	5	4	12	2	1
			31	5	4	12	7	1
12DK7	12	38	33	5	4	8	1	1
			80	5	4	8	6	1
			80	5	4	8	9	1
12DL8	12	38	35	5	4	12	3	1
			65	5	4	12	9	1
			65	5	4	12	1	1
12DM4	12	34	11					1
12DN6	12	26	47					1
12DQ4	12	34	11					1
12DQ6	12	27	65					1
12DQ6B	12	27	62					1
12DQ7	12	9	36					1
12DS7	12	38	34	5	4	12	3	1
			85	5	4	12	1	1
			85	5	4	12	9	1
12DT5	12	16	45					1
12DT7	12	8	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
12DT8	12	8	71					1
			71					2
12DU7	12	38	31	5	4	12	1	1
			77	5	4	12	7	1
			77	5	4	12	9	1
12DV7	12	38	49	5	4	9	7	1
			78	5	4	9	2	1
			78	5	4	9	3	1
12DV8	12	38	35	5	4	12	3	1
			58	5	4	12	9	1
			58	5	4	12	1	1
12DW5	12	16	30					1
12DW7	12	8	75					1
			*78					2
*Tube Good if it Reads 22 or More.								
12DW8	12	38	32	5	4	12	2	1
			32	5	4	12	7	1
			44	5	4	12	9	1
12DY8	12	38	30	5	4	12	1	1
			35	5	4	12	9	1
12DZ6	12	40	33	4	3	12	1	1
12DZ8	12	38	27	4	5	8	3	1
			30	4	5	2	1	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
12E5	12	25	93					1
12EA6	12	40	32	4	3	12	1	1
12EC8	12	38	30	5	4	12	9	1
			32	5	4	12	1	1
12ED5	12	4	57					1
12EG6	12	40	36	4	3	12	1	1
12EH5	12	4	57					1
12EK6	12	40	31	4	3	12	1	1
12EL6	12	40	38	4	3	12	1	1
			68	4	3	12	5	1
			68	4	3	12	6	1
12EM6	12	38	34	5	4	12	1	1
			90	5	4	12	9	1
12EN6	12	29	36					1
12EQ7	12	38	34	5	4	12	2	1
			71	5	4	12	8	1
12EZ6	12	40	32	4	3	12	1	1
12F5	12	37	40	7	2	12	10	1
12F8	12	38	40	5	4	12	8	1
			62	5	4	12	1	1
			62	5	4	12	6	1
12F31	12	1	78					1
12FK6	12	40	40	4	3	12	1	1
			65	4	3	12	5	1
			65	4	3	12	6	1
12FM6	12	40	35	4	3	12	1	1
			68	4	3	12	5	1
			68	4	3	12	6	1
12FQ8	12	38	39	5	4	12	2	1
			39	5	4	12	7	1
12FR8	12	38	*25	4	5	12	3	1
			*37	4	5	12	1	1
			*62	4	5	12	8	1
*Normally Shows Short on Position No. 5.								
12FT6	12	40	52	4	3	12	1	1
			66	4	3	12	5	1
			66	4	3	12	6	1
12FV7	12	8	42					1
			42					2
12FX8	12	38	32	5	4	12	2	1
			28	5	4	12	6	1
12G4	12	40	41	4	3	1	6	1
12GA6	12	40	36	4	3	12	1	1
12GC6	12	26	52					1
12GE5	12	35	*24	1	12	11	3	1
*Normally Shows Short Positions 4-10.								
12GJ5	12	42	*30	4	5	6	2	1
*Normally Shows Short Position 1-7.								
12GT5	12	42	*30	4	5	6	2	1
*Normally Shows Short Position 1-7.								
12GW6	12	27	62					1
12H4	12	40	44	4	3	2	6	1
12H6	12	37	48	7	2	12	3	1
			48	7	2	12	5	1
12H31	12	1	91					1
12J5	12	29	93					1
12J7	12	37	50	7	2	12	10	1
12J8	12	38	30	5	4	12	1	1
			35	5	4	12	8	1
			35	5	4	12	9	1
12K5	12	40	35	4	3	5	6	1
12K7	12	37	52	7	2	12	10	1
12K8	12	37	35	7	2	12	5	1
12L6	12	29	47					1
12Q7	12	37	40	7	2	12	10	1
			63	7	2	12	4	1
			63	7	2	12	5	1
12R5	12	40	39	4	3	2	5	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
12S8	12	37	45	8	7	5	10	1
			62	8	7	5	1	1
			62	8	7	5	4	1
			63	8	7	2	3	1
12SA7	12	37	37	7	2	12	5	1
12SG7	12	37	48	8	7	12	3	1
			48	8	7	12	4	1
12SF5	12	37	41	8	7	12	3	1
12SF7	12	37	46	8	7	12	2	1
			69	8	7	12	5	1
12SG7	12	30	77					1
12SH7	12	30	77					1
12SJ7	12	30	83					1
12SK7	12	30	84					1
12SL7	12	25	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
12SN7	12	25	78					1
			78					2
12SQ7	12	37	42	8	7	12	2	1
			71	8	7	12	4	1
			71	8	7	12	5	1
12SR7	12	37	46	8	7	12	2	1
			68	8	7	12	4	1
			68	8	7	12	5	1
12SS7	12	30	97					1
12SW7	12	37	52	8	7	12	2	1
			70	8	7	12	4	1
			70	8	7	12	5	1
12SX7	12	25	78					1
			78					2
12SY7	12	37	39	7	2	12	5	1
12U7	12	38	40	5	4	9	2	1
			40	5	4	9	7	1
12V6	12	29	79					1
12W6	12	29	51					1
12X4	12	40	44	4	3	12	1	1
			44	4	3	12	6	1
13CM5	12	27	57					1
13D1	25	25	78					1
			78					2
13DE7	12	20	81					1
			90					2
13DR7	12	38	32	5	4	2	3	1
			41	5	4	2	7	1
13EM7	12	37	32	8	7	12	1	1
			45	8	7	12	4	1
13FD7	12	38	25	4	5	2	3	1
			32	4	5	2	7	1
13FR7	12	38	24	4	5	2	3	1
			32	4	5	2	7	1
13SJ7	12	30	83					1
14A4	12	36	41	8	1	12	6	1
14A5	12	36	34	8	1	12	6	1
14A7	12	36	45	8	1	12	6	1
14AF7	12	36	41	8	1	12	4	1
			41	8	1	12	5	1
14B6	12	36	40	8	1	4	3	1
			68	8	1	4	5	1
			68	8	1	4	6	1
14B8	12	36	42	8	1	12	4	1
14C5	12	36	38	8	1	12	6	1
14C7	12	36	37	8	1	12	6	1
14E6	12	36	40	8	1	4	3	1
			69	8	1	4	5	1
			69	8	1	4	6	1
14E7	12	36	47	8	1	12	6	1
			68	8	1	12	3	1
			68	8	1	12	4	1

*Normal Shorts refer to position of "D" Switch.

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
14F7	12	36	45	8	1	12	4	1
			45	8	1	12	5	1
14F8	12	36	30	7	2	12	1	1
			30	7	2	12	8	1
14GT8	14	38	52	5	4	12	8	1
			35	5	4	12	2	1
			35	5	4	12	6	1
14GW8	14	38	25	4	5	2	8	1
			35	4	5	7	1	1
14H7	12	36	35	8	1	12	6	1
14J7	12	36	35	8	1	12	6	1
			50	8	1	12	4	1
14JG8	14	38	32	4	5	12	8	1
			27	4	5	12	2	1
			27	4	5	12	6	1
14N7	12	36	42	8	1	12	4	1
			42	8	1	12	5	1
14Q7	12	36	35	8	1	12	4	1
14R7	12	36	35	8	1	12	6	1
			72	8	1	12	3	1
			72	8	1	12	4	1
14S7	12	36	38	8	1	12	6	1
			52	8	1	12	4	1
14V7	12	36	32	8	1	12	6	1
14W7	12	36	31	8	1	4	6	1
14X7	12	36	43	8	1	12	3	1
			36	8	1	12	5	1
			35	8	1	12	6	1
14Y4	12	36	45	8	1	12	3	1
			45	8	1	12	6	1
15A6	12	38	30	5	4	12	2	1
15A8	15	37	36	7	2	12	4	1
			40	7	2	12	3	1
15CW5	15	23	58					1
15EA7	15	37	35	8	7	12	1	1
			39	8	7	12	4	1
15EW6	15	1	77					1
16A8	16	38	33	5	4	12	3	1
			39	5	4	12	1	1
16AQ3	16	39	30	5	4	7	3	1
16CL8	16	14	69					1
			51					2
16GK6	16	38	33	5	4	3	2	1
17AV5	17	28	62					1
17AX4	17	34	13					1
17AY3	17	42	27	5	4	7	2	1
17BH3	17	42	27	5	4	7	2	1
17BQ6	17	27	69					1
17C5	17	4	44					1
17C8	17	38	33	5	4	12	2	1
			65	5	4	12	7	1
			65	5	4	12	8	1
17C9	17	38	28	5	4	6	1	1
			28	5	4	10	7	1
17CA5	17	4	55					1
17CQ4	17	34	11					1
17CU5	17	4	47					1
17D4	17	34	11					1
17DE4	17	34	13					1
17DM4	17	34	11					1
17DQ4	17	34	11					1
17DQ6	17	27	65					1
17DQ6B	17	27	62					1
17EW8	17	8	65					1
			65					2
17GJ5	17	42	*30	4	5	6	2	1
*Normally Shows Short Position 1-7.								
17GT5	17	42	*30	4	5	6	2	1
*Normally Shows Short Position 1-7.								

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
17GW6	17	27	62					1
17H3	17	15	13					1
17HC8	17	38	36	5	4	12	3	1
			38	5	4	12	1	1
17JK8	17	8	54					1
			55					2
17L6	17	29	47					1
17R5	17	4	50					1
17W6	17	29	52					1
17Z3	17	38	33	4	5	2	9	1
18A5	18	28	69					1
18AK5	18	1	63					1
18AQ5	18	3	77					1
18C51	18	38	29	9	1	12	3	1
			29	9	1	12	7	1
18DZ8	18	38	27	4	5	8	3	1
			30	4	5	2	1	1
18FW6	18	1	79					1
18FX6	18	1	92					1
18FY6	18	6	84					1
			81					2
18GD6	19	1	80					1
18GE6	19	6	78					1
			85					2
18GV8	18	38	25	4	5	12	9	1
			25	4	5	12	2	1
18HB8	18	38	36	5	4	12	9	1
			33	5	4	12	1	1
18J6	12	2	60					1
			60					2
19AQ5	19	3	77					1
19AU4	19	34	10					1
19BG6	19	26	66					1
19C8	19	17	94					1
			62					2
19CL8-A	19	14	74					1
			53					2
19D8	19	38	32	5	4	12	2	1
			35	5	4	12	9	1
19DE7	19	20	81					1
			90					2
19EA8	19	11	71					1
			56					2
19DN6	19	26	47					1
19EZ8	19	38	33	5	4	12	2	1
			33	5	4	12	7	1
			33	5	4	12	9	1
19HS6	19	1	66					1
19HV8	19	14	64					1
			*99					2
*Tube Good if it Reads 40 or More.								
19J6	19	2	60					1
			60					2
19JN8	19	14	67					1
			53					2
19T8	19	17	90					1
			63					2
19V8	19	38	40	5	4	12	6	1
			32	5	4	12	2	1
			32	5	4	12	7	1
			61	5	4	12	9	1
19X3	19	38	29	5	4	12	9	1
19X8	19	12	73					1
			61					2
20D1	9	5	62					1
			62					2
20EQ7	19	38	34	5	4	12	2	1
			71	5	4	12	8	1
20EZ7	19	38	35	2	1	3	5	1
			35	2	1	3	8	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
21A6	22	38	*32	5	4	7	2	1
*Normally Shows Short Position 1-6-9.								
21EX6	22	26	42					1
22BH3	22	42	27	5	4	7	2	1
22DE4	22	34	13					1
25A6	25	29	74					1
25AU4	25	34	10					1
25AV5	25	28	62					1
25AX4	25	34	13					1
25B6	25	29	48					1
25BK5	25	10	53					1
25BQ6	25	27	69					1
25C5	25	4	44					1
25C6	25	29	45					1
25CA5	25	4	55					1
25CD6	25	26	53					1
25CU6	25	27	69					1
25D4	25	34	11					1
25DK4	25	40	26	3	4	6	5	1
25DN6	25	26	47					1
25DQ6	25	27	65					1
25DT5	25	16	45					1
25E5	25	27	58					1
25EC6	25	26	53					1
25EH5	25	4	57					1
25F5	25	4	54					1
25L6	25	29	47					1
25SN7	25	25	78					1
			78					2
25U4	25	34	11					1
25W4	25	34	11					1
25W6	25	29	51					1
25Z6	25	37	34	7	2	12	3	1
			34	7	2	12	5	1
26A6	25	1	77					1
26A7	25	37	29	7	6	12	1	1
			29	7	6	12	3	1
26BK6	25	6	86					1
			70					2
26C6	25	6	85					1
			82					2
26D6	25	1	93					1
26E6	25	29	40					1
27GB5	25	42	*25	4	5	2	1	1
*Normally Shows Short Position 3-6-7-8.								
28D7	30	36	40	8	1	12	2	1
			40	8	1	12	7	1
28GB5	30	42	*25	4	5	2	1	1
*Normally Shows Short Position 3-6-7-8.								
30C1	9	11	66					1
30L1	7	38	33	5	4	7	2	1
			33	5	4	7	6	1
32ET5	30	4	60					1
34GD5	35	4	57					1
35A5	35	36	34	8	1	12	6	1
35B5	35	3	55					1
35C5	35	4	54					1
35CD6	35	26	53					1
35DZ8	35	38	27	4	5	8	3	1
			30	4	5	2	1	1
35EH5	35	4	57					1
35GL6	35	40	39	4	3	6	2	1
35HB8	35	38	36	5	4	12	9	1
			33	5	4	12	1	1
35L6	35	29	54					1
35W4	35	40	*33	4	3	6	5	1
*Normally Shows Short Position 7.								
35Y4	35	36	31	8	1	4	2	1
35Z3	35	36	31	8	1	12	2	1
35Z4	35	37	33	7	2	12	5	1

*Normal Shorts refer to position of "D" Switch.

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
35Z5	35	37	33	7	2	3	5	1
36AM3	35	40	35	4	3	6	5	1
38A3	35	39	30	4	5	1	6	1
40FR5	40	4	54					1
40Z5	50	37	31	7	2	3	5	1
45B5	50	23	68					1
45Z3	50	40	32	7	1	6	2	1
45Z5	50	37	31	7	2	3	5	1
50A5	50	36	35	8	1	12	6	1
50B5	50	3	38					1
50BK5	50	10	53					1
50BM8	50	38	33	5	4	12	3	1
			39	5	4	12	1	1
50C5	50	4	44					1
50C6	50	29	45					1
50CA5	50	4	55					1
50CD6	50	26	53					1
50DC4	50	40	33	4	3	6	5	1
50EH5	50	4	57					1
50FA5	50	4	54					1
50FE5	50	29	37					1
50FK5	50	4	88					1
50HC6	50	40	26	3	4	6	2	1
50HK6	50	40	27	3	4	6	2	1
50L6	50	29	47					1
50X6	50	36	35	8	1	12	3	1
			35	8	1	12	6	1
50Y6	50	37	35	7	2	12	3	1
			35	7	2	12	5	1
50Y7	50	37	35	7	2	6	3	1
			35	7	2	6	5	1
53KU	5	33	10					1
			10					2
60EH5	50	4	57					1
60FX5	50	4	68					1
64SPT	6	38	33	5	4	1	2	1
150C3	50	37	*99	2	11	3	5	1
*Tube Good if it Reads 60 or More.								
*Normally Shows Short Position 11.								
*Normally Shows Grid Emission.								
213PEN	19	38	*32	5	4	7	2	1
*Normally Shows Short Position 1-6-9.								
403B	6	1	63					1
407A	40	38	29	1	9	5	3	1
			29	1	9	5	7	1
408A	19	1	65					1
884	6	37	35	2	7	12	5	1
1003	6	31	8					1
			8					2
1201	6	36	*33	8	2	1	5	1
*Normally Shows Short Position 3-4-6-7.								
1203	6	36	53	8	1	12	4	1
1222A	6	37	25	1	6	12	4	1
1223	6	37	50	7	2	12	10	1
1232	6	36	36	8	1	12	6	1
1273	6	36	37	8	1	12	6	1
1274	6	36	45	8	1	12	3	1
			45	8	1	12	6	1
1280	12	36	37	8	1	12	6	1
1294	2	36	60	8	1	12	4	1
1611	6	29	91					1
1614	6	29	67					1
1619	3	37	39	7	2	12	5	1
1620	6	37	50	7	2	12	10	1
1621	6	29	91					1
1622	6	29	63					1
1631	6	29	63					1
1632	12	29	47					1
1634	12	37	48	8	7	12	3	1
			48	8	7	12	4	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
1665	6	40	32	4	3	5	1	1
1667	6	40	32	4	3	5	1	1
1852	6	30	60					1
1853	6	30	74					1
2050	6	37	34	7	2	12	5	1
5591	6	1	63					1
5649	12	29	92					1
5654	6	1	63					1
5659	12	29	92					1
5661	12	30	84					1
5663	6	40	25	3	4	12	1	1
5670	6	38	29	9	1	12	3	1
			29	9	1	12	7	1
5679	6	36	48	8	1	12	3	1
			48	8	1	12	6	1
5686	6	23	87					1
5687	12	38	37	5	4	8	2	1
			37	5	4	8	7	1
5691	6	25	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
5692	6	25	78					1
			78					2
5693	6	30	83					1
5696	6	40	34	4	3	5	6	1
5725	6	1	77					1
5726	6	5	62					1
			62					2
5727	6	40	32	4	3	5	1	1
5749	6	1	78					1
5750	6	1	91					1
5751	12	8	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
5763	6	38	33	5	4	8	9	1
5814-A	12	8	75					1
			75					2
5824	25	29	48					1
5871	6	29	79					1
5879	6	38	52	5	4	12	1	1
5881	6	29	63					1
5915	6	1	92					1
5920	6	2	49					1
			49					2
5931	5	33	16					1
			16					2
5932	6	29	63					1
5961	6	37	37	7	2	12	5	1
5963	12	8	76					1
			76					2
5964	6	2	67					1
			67					2
5965	12	8	54					1
			54					2
5992	6	29	79					1
6005	6	3	77					1
6006	6	30	77					1
6028	19	1	63					1
6042	6	25	78					1
			78					2
6046	25	29	47					1
6057	12	8	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
6058	6	5	62					1
			62					2
6060	12	8	74					1
			74					2
6062	6	38	33	5	4	8	9	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
6066	6	6	85					1
			78					2
6067	12	8	75					1
			75					2
6069	6	1	63					1
6072	12	8	93					1
			93					2
6080	6	37	35	8	7	12	1	1
			35	8	7	12	4	1
6082	25	37	35	8	7	12	1	1
			35	8	7	12	4	1
6085	12	8	74					1
			74					2
6087	5	33	23					1
			23					2
6096	6	1	63					1
6097	6	5	62					1
			62					2
6100	6	40	41	4	3	1	6	1
6101	6	2	60					1
			60					2
6113	6	25	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
6134	6	30	60					1
6135	6	40	41	4	3	1	6	1
6136	6	1	82					1
6137	6	30	84					1
6146	6	37	*38	7	2	1	5	1
*Normally Shows Short Position 4-6.								
6147	6	29	63					1
6159	25	37	*38	7	2	1	5	1
*Normally Shows Short Position 4-6.								
6180	6	25	78					1
			78					2
6186	6	1	80					1
6187	6	1	87					1
6188	6	25	*81					1
			*81					2
*Tube Good if it Reads 22 or More.								
6189	12	8	75					1
			75					2
6197	6	38	32	5	4	2	9	1
6198	12	8	75					1
			75					2
6201	12	8	74					1
			74					2
6202	6	40	44	4	3	12	1	1
			44	4	3	12	6	1
6211	12	8	54					1
			54					2
6227	6	38	25	4	5	1	2	1
6265	6	1	89					1
6267	6	38	40	5	4	2	9	1
6336	6	37	29	8	7	12	1	1
			29	8	7	12	4	1
6350	12	38	31	4	5	9	3	1
			31	4	5	9	8	1
6360	12	38	30	4	5	9	1	1
			30	4	5	9	3	1
6384	6	37	33	8	6	12	7	1
6417	12	38	33	5	4	8	9	1
6463	12	38	28	4	5	9	3	1
			28	4	5	9	8	1
6485	6	1	58					1
6516	6	40	34	4	3	12	1	1
6520	6	37	35	8	7	12	1	1
			35	8	7	12	4	1
6550	6	29	52					1
6660	6	1	78					1

*Normal Shorts refer to position of "D" Switch.

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
6661	6	1	89					1
6662	6	1	81					1
6663	6	5	62					1
			62					2
6664	6	40	30	4	3	12	6	1
6669	6	3	77					1
6676	6	1	64					1
6677	6	38	*32	5	4	2	9	1
*Normally Shows Short Position 3-8.								
6678	6	11	79					1
			55					2
6679	12	8	79					1
			79					2
6680	12	8	75					1
			75					2
6681	12	8	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
6686	6	38	24	4	5	1	2	1
6688	6	38	25	4	5	1	2	1
6829	12	8	54					1
			54					2
6883	12	37	*38	7	2	1	5	1
*Normally Shows Short Position 4-6.								
6887	6	40	33	4	3	12	2	1
			33	4	3	12	7	1
6919	6	5	62					1
			62					2
6922	6	8	24					1
			24					2
6968	6	1	63					1
6973	6	16	62					1
7000	6	37	50	7	2	12	10	1
7025	12	8	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
7027	6	37	*36	7	2	5	6	1
*Normally Shows Short Position 1-4.								
7036	6	1	92					1
7044	12	38	30	4	5	8	2	1
			30	4	5	8	7	1
7054	12	9	42					1
7055	12	5	62					1
			62					2
7056	12	1	64					1
7057	12	8	53					1
			53					2
7058	12	8	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
7059	12	11	79					1
			55					2
7060	12	13	55					1
			75					2
7061	12	16	67					1
7105	12	37	35	8	7	12	1	1
			35	8	7	12	4	1
7167	12	1	54					1
7189	6	38	*33	5	4	1	2	1
*Normally Shows Short Position 1-3-6-9.								
7199	6	38	30	5	4	12	7	1
			32	5	4	12	9	1
7233	6	38	*33	5	4	2	7	1
*Normally Shows Short Position 1-3-6-9.								
7247	12	8	75					1
			*90					2
*Tube Good if it Reads 22 or More.								
7258	12	13	62					1
			61					2

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
7308	6	8	23					1
			24					2
7355	6	37	37	7	2	12	6	1
7370	40	38	24	4	5	8	2	1
			24	4	5	8	7	1
7408	6	29	80					1
7543	6	1	85					1
7558	6	38	*26	4	5	3	2	1
*Normally Shows Short Position 1-9.								
7581	6	29	64					1
7586	6	41	*65	10	12	12	2	1
*For Grid Emission Turn D Switch to Position 4.								
7587	6	41	*67	10	12	12	2	1
*For Grid Emission Turn D Switch to Position 4.								
7591	6	37	34	7	2	4	6	1
7607	6	37	*32	7	2	1	5	1
*Normally Shows Short Position 4-6.								
7643	6	11	72					1
			55					2
7687	6	11	77					1
			67					2
7695	50	38	34	5	4	12	6	1
7701	12	38	*38	5	4	1	2	1
*Normally Shows Short Position 3-7-8-9.								
7716	12	12	53					1
			*97					2
*Tube Good if it Reads 20 or More.								
7724	14	38	52	5	4	12	8	1
			35	5	4	12	2	1
			35	5	4	12	6	1
7728	12	8	74					1
			74					2
7729	12	8	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
7730	12	8	75					1
			75					2
7731	6	11	79					1
			55					2
7732	6	1	64					1
7733	12	9	42					1
7738	6	40	*33	4	3	2	6	1
*Normally Shows Short Position 1-7.								
7754	6	38	34	5	4	12	6	1
7868	6	42	*27	4	5	2	6	1
*Normally Shows Short Position 1-7.								
7895	6	41	*85	10	12	12	2	1
*For Grid Emission Turn D Switch to Position 4.								
8016	1	32	55					1
8056	6	41	23	10	12	12	4	1
9001	6	1	93					1
9002	6	40	*46	4	3	1	6	1
*Normally Shows Short.								
9003	6	1	*73					1
*Tube Good if it Reads 23 or More.								
9006	6	40	*55	4	3	1	5	1
*Normally Shows Short Position 2-7.								
A863	6	37	50	7	2	12	10	1
A1834	6	37	35	8	7	12	1	1
			35	8	7	12	4	1
AR18	6	37	40	7	2	12	10	1
			63	7	2	12	4	1
			63	7	2	12	5	1
ARDD3	6	37	48	7	2	12	3	1
			48	7	2	12	5	1
ARH1	6	37	44	7	2	12	10	1
ARP15	6	37	52	7	2	12	10	1
ARP16	6	37	50	7	2	12	10	1
ARP17	6	29	91					1
ARP32	6	29	79					1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
ARP33	6	29	79					1
ARTH-1	6	37	35	7	2	12	5	1
AU13	5	33	32					1
			32					2
AZ32	4	33	32					1
			32					2
B36	12	25	78					1
			78					2
B65	6	25	78					1
			78					2
B152	12	8	74					1
			74					2
B309	12	8	74					1
			74					2
B319	7	38	33	5	4	7	2	1
			33	5	4	7	6	1
B329	12	8	75					1
			75					2
B339	12	8	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
B719	6	8	70					1
			70					2
BPM04	6	3	77					1
CV131	6	40	35	4	3	12	1	1
CV133	6	40	41	4	3	1	6	1
CV136	6	40	34	4	3	12	1	1
CV138	6	40	30	4	3	12	1	1
CV140	6	5	62					1
			62					2
CV216	50	37	*99	2	11	3	5	1
*Normally Shows Short Position No. 11.								
*Normally Shows Grid Emmission.								
*Tube Good if it Reads 60 or More.								
CV283	6	5	62					1
			62					2
CV450	6	29	*62					1
*For Plate Cap Use Jack Next to Socket 26.								
CV452	6	6	85					1
			78					2
CV453	6	1	91					1
CV454	6	1	78					1
CV455	12	8	74					1
			74					2
CV491	12	8	75					1
			75					2
CV492	12	8	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
CV493	6	40	44	4	3	12	1	1
			44	4	3	12	6	1
CV511	6	29	79					1
CV538	12	37	37	7	2	12	5	1
CV544	12	30	84					1
CV547	12	37	42	8	7	12	2	1
			71	8	7	12	4	1
			71	8	7	12	5	1
CV551	25	29	45					1
CV552	25	29	47					1
CV553	25	29	47					1
CV554	6	37	48	7	2	12	3	1
			48	7	2	12	5	1
CV559	25	37	34	7	2	12	3	1
			34	7	2	12	5	1
CV561	35	29	54					1
CV562	35	29	54					1
CV565	35	36	31	8	1	12	2	1
CV567	35	37	33	7	2	3	5	1
CV568	35	37	33	7	2	3	5	1
CV571	50	29	47					1

PM 2458 7-62 RR PRESS—10

*Normal Shorts refer to position of "D" Switch.

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
CV572	6	33	15					1
			15					2
CV573	6	33	15					1
			15					2
CV574	6	33	15					1
			15					2
CV575	5	33	16					1
			16					2
CV578	6	37	45	7	2	12	5	1
CV579	6	37	45	7	2	12	5	1
CV580	6	37	45	7	2	12	5	1
CV581	6	29	99					1
CV582	6	29	99					1
CV583	6	29	99					1
CV586	6	29	63					1
CV587	6	37	40	7	2	12	10	1
			63	7	2	12	4	1
			63	7	2	12	5	1
CV588	6	37	40	7	2	12	10	1
			63	7	2	12	4	1
			63	7	2	12	5	1
CV589	6	37	40	7	2	12	10	1
			63	7	2	12	4	1
			63	7	2	12	5	1
CV590	6	30	83					1
CV591	6	30	83					1
CV592	6	30	83					1
CV593	5	33	12					1
			12					2
CV594	6	30	77					1
CV595	6	30	77					1
CV657	6	37	50	7	2	12	10	1
CV660	6	30	60					1
CV661	6	30	74					1
CV664	6	40	*46	4	3	1	6	1
*Normally Shows Short Position 2-7.								
CV665	6	1	*73					1
*Tube Good if it Reads 23 or More.								
CV686	50	37	*85	2	11	3	5	1
*Normally Shows Short Position 11.								
*Normally Shows Grid Emission.								
CV692	6	31	8					1
			8					2
CV694	12	30	77					1
CV697	12	30	83					1
CV698	12	30	83					1
CV700	12	37	46	8	7	12	2	1
			68	8	7	12	4	1
			68	8	7	12	5	1
CV703	6	37	35	7	2	12	5	1
CV706	6	37	48	7	2	12	10	1
CV717	5	33	22					1
			22					2
CV723	3	37	39	7	2	12	5	1
CV726	35	36	31	8	1	12	2	1
CV728	2	37	53	7	2	12	10	1
CV729	5	33	12					1
			12					2
CV731	6	29	91					1
CV732	6	34	11					1
CV747	6	30	60					1
CV753	2	40	*70	7	1	2	6	1
*Normally Shows Short Position 5-11.								
CV755	1	37	55	7	2	12	5	1
CV756	1	37	55	7	2	12	5	1
CV760	1	37	55	7	2	12	5	1
CV764	2	37	54	7	2	12	10	1
CV768	2	37	48	7	2	12	5	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
CV770	2	37	54	7	2	12	10	1
			64	7	2	12	4	1
			67	7	2	12	5	1
CV772	1	37	55	7	2	12	4	1
			55	7	2	12	5	1
CV773	1	37	55	7	2	12	4	1
			55	7	2	12	5	1
CV775	1	36	62	8	1	12	4	1
CV776	1	36	55	8	1	12	6	1
CV777	1	36	54	8	1	5	6	1
CV778	1	36	68	8	1	12	4	1
CV779	2	36	53	8	1	12	6	1
			63	8	1	12	4	1
CV780	2	36	52	8	1	12	6	1
			60	8	1	12	4	1
CV781	1	36	53	8	1	5	6	1
CV782	1	40	57	7	1	5	4	1
CV783	1	40	*55	7	1	5	3	1
*Normally Shows Short Position 2-6.								
CV784	1	40	56	7	1	12	6	1
			95	7	1	12	3	1
CV785	1	40	55	7	1	5	6	1
CV786	1	37	54	7	2	12	5	1
CV797	6	40	32	4	3	5	1	1
CV805	50	37	35	7	2	12	3	1
			35	7	2	12	5	1
CV807	3	40	*36	7	1	5	4	1
*Normally Shows Short Position 2-6.								
CV808	3	40	45	7	1	4	3	1
			45	7	1	4	5	1
CV815	2	36	43	8	1	7	6	1
CV818	3	40	*42	7	1	5	3	1
*Normally Shows Short Position 2-6.								
CV819	3	37	45	7	2	8	5	1
CV820	3	40	*48	7	1	5	3	1
*Normally Shows Short Position 2-6.								
CV841	5	33	16					1
			16					2
CV842	5	33	32					1
			32					2
CV844	6	37	40	7	2	12	5	1
CV845	6	37	40	7	2	12	5	1
CV846	6	30	60					1
CV848	6	1	80					1
CV849	6	30	60					1
CV850	6	1	63					1
CV851	6	37	35	7	2	12	5	1
CV852	6	40	41	4	3	1	6	1
CV858	6	2	60					1
			60					2
CV862	6	37	53	7	2	12	5	1
CV865	6	30	69					1
CV866	6	30	83					1
CV867	6	37	46	8	7	12	2	1
			68	8	7	12	4	1
			68	8	7	12	5	1
CV873	6	33	17					1
			17					2
CV876	6	36	48	8	1	12	3	1
			48	8	1	12	6	1
CV877	6	36	45	8	1	12	6	1
CV878	6	36	40	8	1	12	4	1
CV879	6	36	40	8	1	12	6	1
CV880	6	36	52	8	1	12	6	1
CV881	6	36	52	8	1	12	6	1
CV882	6	36	40	8	1	4	3	1
			68	8	1	4	5	1
			68	8	1	4	6	1
CV883	6	36	42	8	1	12	4	1
CV885	6	36	38	8	1	12	6	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
CV886	6	36	38	8	1	12	6	1
CV887	6	36	50	8	1	4	3	1
			68	8	1	4	5	1
			68	8	1	4	6	1
CV890	6	36	*33	8	2	1	5	1
*Normally Shows Short Position 3-4-6-7.								
CV891	6	36	40	8	1	4	3	1
			69	8	1	4	5	1
			69	8	1	4	6	1
CV892	6	36	47	8	1	12	6	1
			68	8	1	12	3	1
			68	8	1	12	4	1
CV893	6	36	45	8	1	12	4	1
			45	8	1	12	5	1
CV894	6	36	36	8	1	12	6	1
CV895	6	36	35	8	1	12	6	1
CV896	6	36	45	8	1	12	4	1
			65	8	1	12	5	1
			65	8	1	12	6	1
CV897	6	36	35	8	1	12	6	1
			50	8	1	12	4	1
CV898	6	36	42	8	1	12	4	1
			42	8	1	12	5	1
CV899	6	36	35	8	1	12	4	1
CV900	6	36	35	8	1	12	6	1
			72	8	1	12	3	1
			72	8	1	12	4	1
CV901	6	36	45	8	1	12	3	1
			45	8	1	12	6	1
CV910	12	37	45	7	2	12	5	1
CV916	12	37	48	7	2	12	3	1
			48	7	2	12	5	1
CV917	12	37	50	7	2	12	10	1
CV918	12	37	52	7	2	12	10	1
CV919	12	37	41	8	7	12	3	1
CV920	12	37	41	8	7	12	3	1
CV921	12	37	46	8	7	12	2	1
			69	8	7	12	5	1
CV922	12	30	77					1
CV924	12	25	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
CV925	12	25	78					1
			78					2
CV930	12	36	45	8	1	12	4	1
			45	8	1	12	5	1
CV939	25	37	40	7	2	12	5	1
CV945	30	36	40	8	1	12	2	1
			40	8	1	12	7	1
CV946	30	36	40	8	1	12	2	1
			40	8	1	12	7	1
CV995	6	40	36	4	3	2	1	1
CV1067	6	29	93					1
CV1071	5	33	16					1
			16					2
CV1074	6	37	50	7	2	12	10	1
CV1268	5	33	32					1
			32					2
CV1280	6	37	44	7	2	12	10	1
CV1285	6	37	47	7	2	12	4	1
			47	7	2	12	5	1
CV1301	6	37	48	7	2	12	3	1
			48	7	2	12	5	1
CV1375	6	38	33	5	4	1	2	1
CV1377	5	33	10					1
			10					2
CV1633	12	8	74					1
			74					2
CV1649	6	29	99					1
CV1741	6	29	53					1

*Normal Shorts refer to position of "D" Switch.

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
CV1753	35	36	34	8	1	12	6	1
CV1757	6	1	93					1
CV1758	1	40	55	7	1	5	6	1
CV1762	6	1	82					1
CV1763	6	40	*85	4	3	1	7	1
*Normally Shows Short Position 5-6.								
CV1777	6	36	37	8	1	12	6	1
CV1784	6	30	38					1
CV1790	6	36	50	8	1	12	3	1
			50	8	1	12	6	1
CV1800	1	37	57	7	2	12	5	1
CV1802	1	37	57	7	2	12	5	1
CV1803	1	37	54	7	2	12	5	1
CV1805	1	37	54	7	2	12	5	1
CV1811	1	37	58	7	2	12	5	1
			86	7	2	12	10	1
			*99	7	2	12	8	1
*Tube Good if it Reads 30 or More.								
CV1818	1	37	55	7	2	12	10	1
			96	7	2	12	5	1
CV1819	6	29	93					1
CV1820	1	37	55	7	2	12	10	1
			96	7	2	12	5	1
CV1821	2	37	53	7	2	12	10	1
CV1823	2	37	53	7	2	12	10	1
CV1824	1	37	48	7	2	12	5	1
CV1826	1	37	48	7	2	12	5	1
CV1829	1	37	54	7	2	12	5	1
CV1846	5	33	22					1
			22					2
CV1849	5	33	32					1
			32					2
CV1851	5	37	47	8	7	12	3	1
			47	8	7	12	5	1
CV1852	5	37	47	8	7	12	3	1
			47	8	7	12	5	1
CV1854	5	33	32					1
			32					2
CV1856	5	33	32					1
			32					2
CV1857	5	37	52	8	7	12	3	1
			52	8	7	12	5	1
CV1862	6	3	77					1
CV1863	5	33	12					1
			12					2
CV1864	5	33	12					1
			12					2
CV1873	6	30	74					1
CV1876	6	30	60					1
CV1878	6	37	54	7	2	12	5	1
			62	7	2	12	1	1
CV1882	6	30	38					1
CV1893	6	37	55	7	2	12	10	1
			65	7	2	12	4	1
			65	7	2	12	5	1
CV1894	6	37	55	7	2	12	10	1
			65	7	2	12	4	1
			65	7	2	12	5	1
CV1895	50	37	*70	2	11	3	5	1
*Normally Shows Short Position 11.								
*Normally Shows Grid Emission.								
CV1902	6	37	45	7	2	12	5	1
CV1908	6	37	40	7	2	12	10	1
CV1909	6	37	40	7	2	12	10	1
CV1910	6	37	40	7	2	12	10	1
CV1911	6	29	91					1
CV1912	6	29	91					1
CV1926	6	26	52					1
CV1928	12	1	78					1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
CV1929	6	37	48	7	2	12	3	1
			48	7	2	12	5	1
CV1930	6	37	48	7	2	12	3	1
			48	7	2	12	5	1
CV1931	6	37	48	7	2	12	3	1
			48	7	2	12	5	1
CV1932	6	29	93					1
CV1933	6	29	93					1
CV1934	6	29	93					1
CV1935	6	37	50	7	2	12	10	1
CV1936	6	37	50	7	2	12	10	1
CV1937	6	37	50	7	2	12	10	1
CV1938	6	29	92					1
CV1940	6	29	92					1
CV1941	6	37	52	7	2	12	10	1
CV1942	6	37	52	7	2	12	10	1
CV1943	6	37	52	7	2	12	10	1
CV1944	6	37	35	7	2	12	5	1
CV1945	6	37	35	7	2	12	5	1
CV1946	6	37	35	7	2	12	5	1
CV1947	6	29	63					1
CV1948	6	29	63					1
CV1949	6	40	43	4	3	12	1	1
CV1950	6	37	44	7	2	12	10	1
CV1951	6	37	44	7	2	12	10	1
CV1956	6	37	47	7	2	12	4	1
			47	7	2	12	5	1
CV1957	6	37	47	7	2	12	4	1
			47	7	2	12	5	1
CV1958	6	37	47	7	2	12	4	1
			47	7	2	12	5	1
CV1959	50	4	44					1
CV1961	12	1	82					1
CV1962	6	37	52	7	2	12	10	1
			63	7	2	12	4	1
			63	7	2	12	5	1
CV1963	6	37	52	7	2	12	10	1
			63	7	2	12	4	1
			63	7	2	12	5	1
CV1964	6	37	52	7	2	12	10	1
			63	7	2	12	4	1
			63	7	2	12	5	1
CV1966	6	37	37	7	2	12	5	1
CV1967	6	37	37	7	2	12	5	1
CV1969	6	37	48	8	7	12	3	1
			48	8	7	12	4	1
CV1970	6	37	48	8	7	12	3	1
			48	8	7	12	4	1
CV1972	6	37	41	8	7	12	3	1
CV1973	6	37	41	8	7	12	3	1
CV1974	6	37	47	7	2	12	10	1
CV1975	6	37	47	7	2	12	10	1
CV1976	6	37	37	7	2	12	5	1
CV1978	6	30	77					1
CV1981	6	30	84					1
CV1982	6	30	84					1
CV1985	6	25	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
CV1988	6	25	78					1
			78					2
CV1990	6	37	42	8	7	12	2	1
			71	8	7	12	4	1
			71	8	7	12	5	1
CV1991	6	37	42	8	7	12	2	1
			71	8	7	12	4	1
			71	8	7	12	5	1
CV1993	6	30	92					1
CV1995	6	37	52	8	7	12	2	1
			72	8	7	12	4	1
			72	8	7	12	5	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
CV1996	6	37	52	8	7	12	2	1
			72	8	7	12	4	1
			72	8	7	12	5	1
CV2128	6	38	85	5	4	12	1	1
			38	5	4	12	9	1
CV2129	6	38	33	5	4	8	9	1
CV2370	3	40	*48	7	1	5	3	1
*Normally Shows Short Position 2-6.								
CV2390	3	40	*36	7	1	5	4	1
*Normally Shows Short Position 2-6.								
CV2500	35	37	33	7	2	12	5	1
CV2507	1	40	52	7	1	5	6	1
CV2522	6	1	77					1
CV2524	6	1	82					1
CV2526	6	6	91					1
			78					2
CV2534	50	29	47					1
CV2704	6	36	*33	8	2	1	5	1
*Normally Shows Short Position 3-4-6-7.								
CV2706	6	36	53	8	1	12	4	1
CV2714	6	29	67					1
CV2716	6	37	48	8	7	12	3	1
			48	8	7	12	4	1
CV2721	6	38	*32	5	4	7	2	1
*Normally Shows Short Position 1-6-9.								
CV2748	5	33	12					1
			12					2
CV2769	6	40	*55	4	3	1	5	1
*Normally Shows Short Position 2-7.								
CV2901	6	38	40	4	3	2	9	1
CV2938	6	29	53					1
CV2975	6	38	33	5	4	1	2	1
CV2983	3	40	45	7	1	5	6	1
CV2984	6	37	35	8	7	12	1	1
			35	8	7	12	4	1
CV3512	6	40	34	4	3	5	6	1
CV3523	6	37	*38	7	2	1	5	1
*Normally Shows Short Position 4-6.								
*Normally Shows Grid Emission.								
CV3798	50	37	*70	2	11	3	5	1
*Normally Shows Short Position 11.								
*Normally Shows Grid Emission.								
CV3799	50	37	*69	2	11	3	5	1
*Normally Shows Short Position 11.								
*Normally Shows Grid Emission.								
CV4007	6	5	62					1
			62					2
CV4010	6	1	63					1
CV4018	6	40	32	4	3	5	1	1
CV4024	12	8	74					1
			74					2
D2M9	6	5	62					1
			62					2
D63	6	37	48	7	2	12	3	1
			48	7	2	12	5	1
D77	6	5	62					1
			62					2
D152	6	5	62					1
			62					2
D193	3	40	*36	7	1	5	4	1
*Normally Shows Short Position 2-6.								
DA90	2	40	*70	7	1	2	6	1
*Normally Shows Short Position 5-11.								
DAC32	1	37	55	7	2	12	10	1
			96	7	2	12	5	1
DAF91	1	40	56	7	1	12	6	1
			95	7	1	12	3	1
DAF92	1	40	55	7	1	12	6	1
	2		70	7	1	12	4	1
DAF96	1	40	58	7	1	12	6	1
			70	7	1	12	3	1

*Normal Shorts refer to position of "D" Switch.

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
DC90	1	40	*70	7	1	5	6	1
*Normally Shows Short Position 2-3.								
DCC90	3	40	45	7	1	4	3	1
			45	7	1	4	5	1
DD6	6	5	62					1
			62					2
DF33	2	37	53	7	2	12	10	1
DF91	1	40	55	7	1	5	6	1
DF92	1	40	55	7	1	5	6	1
DF96	1	40	58	7	1	5	6	1
DF97	1	40	40	7	1	5	6	1
DF904	1	40	52	7	1	5	6	1
DH63	6	37	40	7	2	12	10	1
			63	7	2	12	4	1
			63	7	2	12	5	1
DH74	12	37	40	7	2	12	10	1
			63	7	2	12	4	1
			63	7	2	12	5	1
DH76	12	37	40	7	2	12	10	1
			63	7	2	12	4	1
			63	7	2	12	5	1
DH77	6	6	85					1
			78					2
DH107	19	6	85					1
			78					2
DH149	6	36	50	8	1	4	3	1
			68	8	1	4	5	1
			68	8	1	4	6	1
DH710	6	17	90					1
			63					2
DH719	6	17	90					1
			63					2
DK91	1	40	57	7	1	5	4	1
DK92	1	40	48	7	1	12	4	1
DK96	1	40	54	7	1	12	4	1
DL33	3	37	45	7	2	8	5	1
DL35	1	37	54	7	2	12	5	1
DL36	1	37	48	7	2	12	5	1
DL91	1	40	*55	7	1	5	3	1
*Normally Shows Short Position 2-6.								
DL92	3	40	*48	7	1	5	3	1
*Normally Shows Short Position 2-6.								
DL93	3	40	*36	7	1	5	4	1
*Normally Shows Short Position 2-6.								
DL94	3	40	45	7	1	5	6	1
DL95	3	40	*42	7	1	5	3	1
*Normally Shows Short Position 2-6.								
DL96	3	40	45	7	1	5	6	1
DP61	6	1	63					1
DY30	1	32	55					1
DY80	1	24	85					1
DY86	1	24	35					1
DY87	1	24	35					1
E80CC	12	8	74					1
			74					2
E80CF	6	11	72					1
			55					2
E80L	6	38	25	4	5	1	2	1
E81L	6	38	24	4	5	1	2	1
E88CC	6	8	24					1
			24					2
E90CC	6	2	49					1
			49					2
E91AA	6	5	62					1
			62					2
E91N	6	40	32	4	3	5	1	1
E180F	6	38	25	4	5	1	2	1
E188CC	6	8	23					1
			24					2

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
EAA91	6	5	62					1
			62					2
EABC80	6	17	90					1
			63					2
EB34	6	37	48	7	2	1	3	1
			48	7	2	1	5	1
EB91	6	5	62					1
			62					2
EBC90	6	6	85					1
			78					2
EBC91	6	6	91					1
			78					2
EBF80	6	38	37	5	4	12	2	1
			64	5	4	12	7	1
			64	5	4	12	8	1
EBF83	6	38	31	5	4	12	2	1
			62	5	4	12	7	1
			62	5	4	12	8	1
EBF89	6	38	33	5	4	12	2	1
			60	5	4	12	7	1
			60	5	4	12	8	1
EC81	6	38	30	4	5	12	1	1
EC90	6	40	41	4	3	1	6	1
EC91	6	40	*29	4	3	6	1	1
*Normally Shows Short Position 2-5.								
EC92	6	40	30	4	3	12	6	1
EC95	6	40	32	4	3	1	2	1
EC97	6	40	33	4	3	1	2	1
ECC35	6	25	*85					1
			*85					2
*Tube Good If It Reads 22 Or More.								
ECC81	12	8	74					1
			74					2
ECC82	12	8	75					1
			75					2
ECC83	12	8	*85					1
			*85					2
*Tube Good if it Reads 22 or More.								
ECC84	6	38	33	5	4	7	2	1
			33	5	4	7	6	1
ECC85	6	8	70					1
			70					2
ECC86	6	38	33	5	4	12	2	1
			33	5	4	12	7	1
ECC88	6	38	31	5	4	12	2	1
			31	5	4	12	7	1
ECC91	6	2	60					1
			60					2
ECC189	6	38	30	5	4	12	2	1
			30	5	4	12	7	1
ECC801S	12	8	74					1
			74					2
ECC802S	12	8	75					1
			75					2
ECC960	6	2	49					1
			49					2
ECF80	6	11	66					1
			55					2
ECF82	6	11	79					1
			56					2
ECF86	6	38	25	4	5	3	2	1
			25	4	5	1	6	1
ECH81	6	38	85	5	4	12	1	1
			38	5	4	12	9	1
ECH83	6	38	30	5	4	12	2	1
			34	5	4	12	9	1
ECL80	6	38	37	5	4	12	9	1
			44	5	4	12	2	1
ECL82	6	38	33	5	4	12	3	1
			39	5	4	12	1	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
ECL84	6	38	26	4	5	12	8	1
			26	4	5	12	1	1
ECL85	6	38	25	4	5	12	9	1
			25	4	5	12	2	1
ECL86	6	38	25	4	5	2	8	1
			35	4	5	7	1	1
ED2	6	5	62					1
			62					2
EF22	6	36	36	8	1	12	6	1
EF80	6	38	33	5	4	1	2	1
EF85	6	38	33	5	4	1	2	1
EF86	6	38	40	5	4	2	9	1
EF89	6	38	34	5	4	1	2	1
EF91	6	40	30	4	3	12	1	1
EF92	6	40	35	4	3	12	1	1
EF93	6	1	78					1
EF94	6	1	82					1
EF95	6	1	63					1
EF96	6	1	80					1
EF98	6	40	30	4	3	12	1	1
EF183	6	38	30	5	4	3	2	1
EF184	6	38	29	5	4	3	2	1
EF804	6	38	39	5	4	2	9	1
EH90	6	1	94					1
EK90	6	1	91					1
EL34	6	29	53					1
EL36	6	27	58					1
EL37	6	29	63					1
EL38	6	29	*62					1
*For Plate Cap Use Jack Next to Socket 26.								
EL81	6	38	*32	5	4	7	2	1
*Normally Shows Short Position 1-6-9.								
EL83	6	38	30	5	4	12	2	1
EL84	6	23	68					1
EL85	6	38	*39	5	4	1	2	1
*Normally Shows Short Position 6-8.								
EL86	6	23	58					1
EL90	6	3	77					1
EL91	6	40	34	4	3	12	1	1
EL95	6	3	88					1
EL500	6	42	*25	4	5	2	1	1
*Normally Shows Short Position 3-6-7-8.								
EL803	6	38	30	5	4	12	2	1
EL820	6	38	*32	5	4	7	2	1
*Normally Shows Short Position 1-6-9.								
EL821	6	38	28	5	4	12	2	1
EN93	6	40	43	4	3	12	1	1
EQ80	6	38	33	5	4	3	7	1
EY81	6	38	33	5	4	2	9	1
EY86	6	39	*95	5	4	1	10	1
*Normally Shows Short Position 6-11.								
EY87	6	39	*95	5	4	1	10	1
*Normally Shows Short Position 6-11.								
EY88	6	39	25	5	4	6	3	1
EZ35	6	33	15					1
			15					2
EZ80	6	38	40	5	4	12	1	1
			40	5	4	12	7	1
EZ81	6	38	34	5	4	1	2	1
			34	5	4	12	7	1
EZ90	6	40	44	4	3	12	1	1
			44	4	3	12	6	1
G180/ZM	50	37	*99	2	11	3	5	1
*Tube Good if it Reads 60 or More.								
*Normally Shows Short Position 11.								
*Normally Shows Grid Emission.								
GZ-30	5	33	12					1
			12					2

PM 245B 7-62 RR PRESS—13

*Normal Shorts refer to position of "D" Switch.

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
GZ-32	5	33	12					1
			12					2
GZ34	5	33	10					1
			10					2
H63	6	37	40	7	2	12	10	1
HABC80	19	17	90					1
			63					2
HBC90	12	6	85					1
			78					2
HBC91	12	6	91					1
			78					2
HCC85	17	8	65					1
			65					2
HCH81	12	38	32	5	4	12	2	1
			35	5	4	12	9	1
HD14	1	37	55	7	2	12	10	1
			96	7	2	12	5	1
HF93	12	1	78					1
HF94	12	1	82					1
HK90	12	1	91					1
HL90	19	3	77					1
HL92	50	4	44					1
HM04	6	1	91					1
HY90	35	40	*33	4	3	6	5	1
*Normally Shows Short Position 7.								
KT32	25	29	47					1
KT63	6	29	91					1
KT66	6	29	63					1
KT88	6	29	43					1
KTZ63	6	37	50	7	2	12	10	1
L63	6	29	93					1
L77	6	40	41	4	3	1	6	1
LN152	6	38	37	5	4	12	9	1
			44	5	4	12	2	1
LZ319	9	11	66					1
			55					2
M8081	6	2	60					1
			60					2
M8100	6	1	63					1
N14	1	37	54	7	2	12	5	1
N17	3	40	*48	7	1	5	3	1
*Normally Sows Short Position 2-6.								
N18	3	40	*42	7	1	5	3	1
*Normally Shows Short Position 2-6.								
N19	3	40	45	7	1	5	6	1
N152	19	38	*32	5	4	7	2	1
*Normally Shows Short Position 1-6-9.								
N709	6	23	68					1
NR67	6	37	44	7	2	12	10	1
NR78	6	29	99					1
NR78A	6	29	93					1
NR81	6	37	52	7	2	12	10	1
NR83	6	37	50	7	2	12	10	1
NR85	6	29	91					1
NR95	25	29	47					1
NU20	5	33	32					1
			32					2
OBC3	12	37	42	8	7	12	2	1
			71	8	7	12	4	1
OF1	6	37	47	7	2	12	10	1
OH4	12	37	45	7	2	12	5	1
OSW2190	6	30	60					1
OSW2192	6	30	38					1
OSW2600	6	30	60					1
OSW2601	6	30	38					1
OSW3105	6	37	42	8	1	12	2	1
			71	8	1	12	4	1
			71	8	1	12	5	1
OSW3106	6	29	79					1
OSW3108	6	29	63					1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
OSW3109	6	37	48	7	2	12	3	1
			48	7	2	12	5	1
OSW3111	6	30	84					1
OSW3112	6	29	93					1
PABC80	9	17	90					1
			63					2
PCC84	7	38	33	5	4	7	2	1
			33	5	4	7	6	1
PCC85	9	8	70					1
			70					2
PCC88	7	38	31	5	4	12	2	1
			31	5	4	12	7	1
PCC189	7	38	30	5	4	12	2	1
			30	5	4	12	7	1
PCF80	9	11	66					1
			55					2
PCF82	9	11	79					1
			55					2
PCF86	7	38	25	4	5	3	2	1
			25	4	5	1	6	1
PCL82	16	38	33	5	4	12	3	1
			39	5	4	12	1	1
PCL84	15	38	26	4	5	12	8	1
			26	4	5	12	1	1
PCL85	18	38	25	4	5	12	9	1
			25	4	5	12	2	1
PCL86	14	38	25	4	5	2	8	1
			35	4	5	7	1	1
PF9	6	37	52	7	2	12	10	1
PH4	6	37	45	7	2	12	5	1
PL36	25	27	58					1
PL81	19	38	*32	5	4	7	2	1
*Normally Shows Short Position 1-6-9.								
PL83	12	38	30	5	4	12	2	1
PL84	15	23	58					1
PL-500	30	42	*25	4	5	2	1	1
*Normally Shows Short On Position 3-6-7-8.								
PL820	19	38	*32	5	4	7	2	1
*Normally Shows Short Position 1-6-9.								
PM04	6	1	78					1
PM05	6	1	63					1
PY32	30	37	24	2	7	6	3	1
			24	2	7	6	5	1
PY80	19	38	29	5	4	12	9	1
PY81	17	38	33	5	4	2	9	1
PY88	30	39	25	5	4	6	3	1
QA240	6	40	41	4	3	1	6	1
QA2404	6	5	62					1
			62					2
QA2406	12	8	74					1
			74					2
QA2407	6	40	44	4	3	12	1	1
			44	4	3	12	6	1
QA2408	6	25	78					1
			78					2
QE03/10	6	38	33	5	4	8	9	1
QE05/40	6	37	*38	7	2	1	5	1
*Normally Shows Short Position 4-6.								
QS150/40	50	37	*99	2	11	3	5	1
*Tube Good if it Reads 60 or More.								
*Normally Shows Short Position 11.								
*Normally Shows Grid Emission.								
QV03/12	6	38	33	5	4	8	9	1
QV06/20	6	37	*38	7	2	1	5	1
*Normally Shows Short Position 4 6.								
R52	5	33	12					1
			12					2
SN7	1	32	55					1
SP6	6	40	30	4	3	12	1	1

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
T2M05	6	40	34	4	3	12	5	1
			34	4	3	12	6	1
TM12	6	40	*85	4	3	1	7	1
*Normally Shows Short Position 5-6.								
TS51	6	1	63					1
TS52	6	2	60					1
			60					2
U50	5	33	32					1
			32					2
U52	5	33	16					1
			16					2
U54	5	33	10					1
			10					2
U78	6	40	44	4	3	12	1	1
			44	4	3	12	6	1
U147	6	33	15					1
			15					2
U149	6	36	45	8	1	12	3	1
			45	8	1	12	6	1
U153	17	38	33	4	5	2	9	1
U709	6	38	34	5	4	12	1	1
			34	5	4	12	7	1
UAA91	6	5	62					1
			62					2
UABC80	6	17	90					1
			63					2
UBF80	17	38	33	5	4	12	2	1
			65	5	4	12	7	1
			65	5	4	12	8	1
UCC84	22	38	33	5	4	7	2	1
			33	5	4	7	6	1
UCC85	6	8	70					1
			70					2
UCF80	25	11	66					1
			55					2
UCH81	19	38	32	5	4	12	2	1
			35	5	4	12	9	1
UCL82	50	38	33	5	4	12	3	1
			39	5	4	12	1	1
UL84	50	23	58					1
UU12	6	38	34	5	4	12	1	1
			34	5	4	12	7	1
UY85	35	39	30	4	5	1	6	1
V2M70	6	40	44	4	3	12	1	1
			44	4	3	12	6	1
V884	6	40	35	4	3	12	1	1
VP6	6	40	35	4	3	12	1	1
VP1321	12	40	*55	4	3	1	5	1
*Normally Shows Short Position 2-7.								
VR75	50	37	*70	2	11	3	5	1
*Normally Shows Short Position 11.								
*Normally Shows Grid Emission.								
VR90	50	37	*69	2	11	3	5	1
*Normally Shows Short Position 11.								
*Normally Shows Grid Emission.								
VR105	50	37	*85	2	11	3	5	1
*Normally Shows Short on Position 11.								
*Normally Shows Grid Emission.								
VR150/30	50	37	*99	2	11	3	5	1
*Tube Good if it Reads 60 or More.								
*Normally Shows Short on Position 11.								
*Normally Shows Grid Emission.								
VT52	6	29	92					1
VT65	7	29	99					1
VT66	6	29	91					1
VT74	5	33	12					1
			12					2
VT86	6	37	52	7	2	12	10	1
VT87	6	37	44	7	2	12	10	1

*Normal Shorts refer to position of "D" Switch.

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
VT88	6	37	52	7	2	12	10	1
			63	7	2	12	4	1
			63	7	2	12	5	1
VT90	6	37	48	7	2	12	3	1
			48	7	2	12	5	1
VT91	6	37	50	7	2	12	10	1
VT93	6	37	55	7	2	12	10	1
			65	7	2	12	4	1
VT94	6	29	93					1
VT96	6	37	47	7	2	12	4	1
			47	7	2	12	5	1
VT97	5	33	32					1
			32					2
VT99	6	37	45	7	2	12	5	1
			45	7	2	12	10	1
VT102	6	29	92					1
VT103	6	37	42	8	7	12	2	1
			71	8	7	12	4	1
			71	8	7	12	5	1
VT104	12	37	42	8	7	12	2	1
			71	8	7	12	4	1
			71	8	7	12	5	1
VT105	6	37	48	8	7	12	3	1
			48	8	7	12	4	1
VT107	6	29	79					1
VT112	6	30	60					1
VT114	5	33	16					1
			16					2
VT115	6	29	63					1
VT116	6	30	83					1
VT117	6	30	84					1
VT124	1	37	55	7	2	12	5	1
VT125	1	37	54	7	2	12	5	1
VT126	6	33	15					1
			15					2
W17	1	40	55	7	1	5	6	1
W77	6	40	35	4	3	12	1	1
W149	6	36	45	8	1	12	6	1
W719	6	38	33	5	4	1	2	1
W727	6	1	78					1
X63 (M)	6	37	45	7	2	12	5	1
X73 (M)	6	37	45	7	2	12	5	1
X107	19	1	91					1
X155	6	8	55					1
			55					2
X727	6	1	91					1
XB767A	6	37	34	7	2	12	5	1
XC95	2	40	33	4	3	1	2	1
XCC189	4	38	30	5	4	12	2	1
			30	5	4	12	7	1
XCF80	4	11	66					1
			65					2
XCH81	3	38	85	5	4	12	1	1
			38	5	4	12	9	1
XCL82	8	38	33	5	4	12	3	1
			39	5	4	12	1	1
XCL84	8	38	26	4	5	12	8	1
			26	4	5	12	1	1
XF80	3	38	33	5	4	1	2	1
XF85	3	38	33	5	4	1	2	1
XF183	3	38	30	5	4	3	2	1
XF184	3	38	29	5	4	3	2	1
XL36	12	27	57					1
XL84	8	23	68					1
XL86	8	23	58					1
XY88	16	39	30	5	4	7	3	1
XXD	12	36	41	8	1	12	4	1
			41	8	1	12	5	1
XXFM	6	36	43	8	1	12	3	1
			36	8	1	12	5	1
			35	8	1	12	6	1
XXL	6	36	41	8	1	12	6	1
YF183	4	38	30	5	4	3	2	1
YF184	4	38	29	5	4	3	2	1
Z14	2	37	53	7	2	12	10	1
Z63	6	37	50	7	2	12	10	1
Z719	6	38	33	5	4	1	2	1
Z729	6	38	40	5	4	2	9	1
ZD17	1	40	*55	7	1	5	3	1
*Normally Shows Short Position 2-6.								
ZD151	6	38	37	5	4	12	2	1
			64	5	4	12	7	1
			64	5	4	12	8	1
ZD152	6	38	37	5	4	12	2	1
			64	5	4	12	7	1
			64	5	4	12	8	1

PM 2450 7-62 RR PRESS—18

*Normal Shorts refer to position of "D" Switch.