

SERVICE BULLETIN #3

Power Transformer Design Change

Due to improvement of transformer design on all our tube type amplifiers, Fender Replacement Power Transformers currently being shipped no longer have a filament center tap lead. In place of this lead, install 2 - 100 ohm 1/2 watt resistors, one from each side of the filament line to ground. A convenient point for such installation is at the pilot bulb socket terminals.

The orange lead is a shield lead and has no electrical wiring connection. This lead should also be connected to a convenient ground.