


1. CONTROLS AND CONNECTIONS



OPTIONAL ACCESSORIES

- | | |
|--|--|
| CTN520: CTCSS (tone squelch) unit | CMC150: Mobile charger
(for CNB150, CNB151 and CNB153) |
| CNB150: Compact rechargeable battery pack
(7.2 V, 400 mAh) | CMB111: Mobile bracket |
| CNB150: Rechargeable battery pack
(7.2 V, 700 mAh) | CLC520: Soft case
(used with CNB151 or CBT151) |
| CNB152: High-power rechargeable battery pack
(12 V, 600 mAh) | CLC521: Long-sized soft case
(used with CNB152 or CNB153) |
| CNB153: Long-life rechargeable battery pack
(7.2 V, 1200 mAh) | CBT151: Battery tray (for 6 "AA"-size batteries) |
| CWC150: AC charger (for CNB150, CNB151 and
CNB153) | CMP111: Microphone/speaker |
| CWC151: AC charger (for CNB152) | CMP112: Compact microphone/speaker |
| CSA150: Desk-top charger (Rapid charger) | CHP111: Headset with PTT button |
| CAW150: Mobile power cable | CMP113: Tiepin microphone |
| | CAW151: Base station power cable |
| | CAX02: Bottom cap |