

Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system 320i & Touring & CAT (E30) 1988 to 1993

Type		M20/B20 20 6EE 95kW
Capacity (cm ³) / number of cylinders		1990 / 6
Compression ratio / pressure	bar	9.4 / ≥10.0 ¹
Oil pressure	bar	0.5 [4.0]
Oil temperature	°C	80
Valve clearance - inlet	mm	0.25
Valve clearance - exhaust	mm	0.25
Firing order		1-5-3-6-2-4
No 1 cylinder position		TBE
Thermostat opening temperature	°C	80
Radiator cap pressure	bar	1.0±0.1

Fuel system 320i & Touring & CAT (E30) 1988 to 1993

Idle speed - manual [auto]	rpm	760±40
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	≤0.3
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO ₂ @ idle speed [3000 rpm] - see page VI	%	—
O ₂ @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		Bosch
Type / ref		M1.1 or M1.3-Motronic
Main jet / needle		—
Injection pressure	bar	2.5±0.05
Pump pressure	bar	3.0
Octane rating	RON	98[E 95 RON] ¹

Ignition system 320i & Touring & CAT (E30) 1988 to 1993

Type		DME Motronic
Ignition coil		Bosch 0 221 122 319
Primary resistance	ohms	0.82
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	≥10.8
Distributor		Bosch
Points gap (air gap)	mm	[0.30 to 0.70]
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		—
Ignition timing - basic [static V = Vacuum NV = No Vacuum]	° Crankshaft @ rpm	Computer control
Total ignition advance	° Crankshaft @ rpm	Computer control
Centrifugal check.	° Crankshaft @ rpm	Computer control
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs		Bosch/Champion
Type		W8LCR / N9YCX
Electrode gap	mm	0.70+0.10

Electrical system 320i & Touring & CAT (E30) 1988 to 1993

Battery	V / CC / RC	12 / 50Ah
Alternator voltage / full load current / engine rpm		13.5 to 14.2 / 80 or 90 / 1500
Starter motor current / voltage - cranking	A / V	170 / 9.0
- locked	A / V	—

Running gear 320i & Touring & CAT (E30) 1988 to 1993

Brakes -		
Front (min. friction material thickness)	mm	2.0
Rear (min. friction material thickness)	mm	1.5
Tyres		
Saloon	Size	195/65x14
Estate / Van	Size	195/65x14
Pressure - front / rear - Saloon	bar	1.9 / 2.0 ²
- Estate / Van	bar	1.9 / 2.0
Front suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	[+18'±5']
Camber		-40'±30'
Castor		+8°46'±30'
King pin inclination		+14°15'±30' (20° lock)
Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	[+22'±7']. Conv: [+23'±7']
Camber		-2°±30'. Conv: -1°50'±30'

Torque wrench settings 320i & Touring & CAT (E30) 1988 to 1993

Cylinder head - stage 1	Nm	TORX: 30 to 32 WSM
- stage 2	Nm	+ 90±3°
Cylinder head - stage 3	Nm	+ 90±3°
- stage 4	Nm	—
Big-end bearings	Nm	23 + 70° N
Main bearings	Nm	58 to 63
Clutch cover	Nm	24. 10.9 hex: 35
Flywheel [driveplate]	Nm	113 to 130 N
Front hubs	Nm	290
Rear hubs	Nm	195 to 210
Wheel nuts / bolts	Nm	110
Spark plugs	Nm	30 to 33


Capacities 320i & Touring & CAT (E30) 1988 to 1993

Engine oil & filter	litres	4.25
Gearbox - 4-speed [5-speed]	litres	1.1
Automatic transmission - refill	litres	3.0
Final drive	litres	0.9
Cooling system	litres	10.5
Fuel tank	litres	63 or 70


Notes and Illustrations

- ¹CAT: 8.8 / _10.0
- ²CAT: 95 [U]
- ³Convertible: 2.1 / 2.3

1: Idle speed 2: CO / Mixture



1990 cm³, 12V



M1.1 / M1.3-Motronic