



## **ILLUSTRATION BOOKLET**


## PARTS PICTORIAL















PICTORIAL 2-3







PICTORIAL 2-6







PICTORIAL 3-2







PICTORIAL 4-1






PICTORIAL 6-2







PICTORIAL 6-3

Page 11







**PICTORIAL 6-4** 




PICTORIAL 8-1



PICTORIAL 8-2





## SCHEMATIC OF THE HEATHKIT® DELUXE ANTENNA TUNER MODEL SA-2060A

## NOTES:

- 1. ALL RESISTOR VALUES ARE IN OHMS  $(\Omega)$ ; (K=1000).
- ALL RESISTORS ARE 1/4-WATT, 5% TOLERANCE UNLESS OTHERWISE NOTED.
- CAPACITOR VALUES LESS THAN 1 ARE IN μF (MICRO-FARADS). VALUES OF 1 OR GREATER ARE IN μF (PICOFARADS) UNLESS OTHERWISE MARKED.
- 4. THIS SYMBOL INDICATES A CHASSIS GROUND.
- 5.  $\bigvee_{\text{CROUND.}}$  THIS SYMBOL INDICATES A CIRCUIT BOARD
- 6. THIS SYMBOL INDICATES A CIRCUIT BOARD WIRE CONNECTION.
- 7. SWITCH SW101 SHOWN IN BYPASS POSITION.

