



JUMPER USAGE TABLE	
JU1	ADD FOR BASE STATION WITH INTERCOM
JU2	REMOVE TO REQUIRE MONITOR DURING PTT
JU3	REMOVE FOR ISOLATED AUDIO & PTT GROUNDS

