

## TABELA DE FREQUÊNCIAS TRANSVERTER ZAMIN

CH	80		40		20	
	-CLAR	+CLAR	-CLAR	+CLAR	-CLAR	+CLAR
4			6990	7005		
5			7000	7015		
6			7010	7025		
7			7020	7035		
8			7040	7055		
9			7050	7065		
10	3480	3495	7060	7075		
11	3490	3505	7070	7085	13995	14905
12	3510	3525	7090	7105	14015	14025
13	3520	3535	7100	7115	14025	14035
14	3530	3545	7110	7125	14035	14045
15	3540	3555	7120	7135	14045	14055
16	3560	3575	7140	7155	14065	14075
17	3570	3585	7150	7165	14075	14085
18	3585	3600	7160	7175	14085	14095
19	3590	3605	7170	7185	14095	14105
20	3610	3625	7190	7205	14115	14125
21	3620	3635	7200	7215	14125	14135
22	3630	3645	7210	7225	14135	14145
23	3660	3675	7240	7255	14165	14175
24	3640	3665	7220	7235	14145	14155
25	3650	3665	7230	7245	14155	14165
26	3670	3685	7250	7265	14175	14185
27	3680	3695	7260	7275	14185	14195
28	3690	3705	7270	7285	14195	14205
29	3700	3715	7280	7295	14205	14215
30	3710	3725	7290	7305	14215	14225
31	3720	3735			14225	14235
32	3730	3745			14235	14245
33	3740	3755			14245	14255
34	3750	3765			14255	14265
35	3760	3775			14265	14275
36	3770	3785			14275	14285
37	3780	3795			14285	14295
38	3790	3805			14295	14305
39	3800	3815				
40	3810	3825				