

Catalog No. 4890328-02  
Issued: April 1975

**AG-440C**  
**RECORDER/REPRODUCER**

**OPERATION AND MAINTENANCE**

**AMPEX CORPORATION**  
**AUDIO-VIDEO SYSTEMS DIVISION**

# LIST OF EFFECTIVE PAGES

CATALOG NO. 4890328-02

Issued: April 1975

Pages	Dash No.	Pages	Dash No.
Title . . . . .	-02	6-41 through 6-47/48 . . . . .	-02
A . . . . .	-02	6-49 through 6-55/56 . . . . .	-02
i through v/vi . . . . .	-02	6-57/58 . . . . .	-02
1-0 through 1-11/12 . . . . .	-02	6-59 through 6-61/62 . . . . .	-02
2-1 through 2-15/16 . . . . .	-02	6-63/64 . . . . .	-02
3-1 through 3-10 . . . . .	-02	6-65 through 6-67/68 . . . . .	-02
4-1 through 4-7/8 . . . . .	-02	6-69 through 6-79/80 . . . . .	-02
4-9/10 . . . . .	-02	6-81/82 . . . . .	-02
4-11/12 . . . . .	-02	6-83/84 . . . . .	-02
4-13/14 . . . . .	-02	6-85 through 6-87/88 . . . . .	-02
4-15 through 4-17/18 . . . . .	-02	6-89 through 6-93/94 . . . . .	-02
4-19 through 4-21/22 . . . . .	-02	6-95/96 . . . . .	-02
4-23 through 4-32 . . . . .	-02	6-97 through 6-105/106 . . . . .	-02
5-1 through 5-50 . . . . .	-02	6-107 through 6-113/114 . . . . .	-02
6-1 through 6-5/6 . . . . .	-02	6-115 through 6-119/120 . . . . .	-02
6-7 through 6-11/12 . . . . .	-02	6-121/122 . . . . .	-02
6-13 through 6-18 . . . . .	-02	6-123/124 . . . . .	-02
6-19/20 . . . . .	-02	6-125/126 . . . . .	-02
6-21 through 6-23/24 . . . . .	-02	6-127/128 . . . . .	-02
6-25/26 . . . . .	-02	6-129 through 6-133/134 . . . . .	-02
6-27 through 6-39/40 . . . . .	-02		

Prepared By

AVSD TECHNICAL PUBLICATIONS

AMPEX CORPORATION 401 Broadway Redwood City, California 94063

Catalog No. 4890355-01  
Issued: November 1974

**AG 445C  
REPRODUCER**

**OPERATION AND MAINTENANCE**

**AMPEX CORPORATION  
AUDIO-VIDEO SYSTEMS DIVISION**

# LIST OF EFFECTIVE PAGES

# CATALOG NO. 4890355-01

Issued: November 1974

Page	Dash No.	Page	Dash No.
Title . . . . .	Original	6-37/38 . . . . .	Original
A . . . . .	Original	6-39 through 6-41/42 . . . . .	Original
i/ii . . . . .	Original	6-43 through 6-45/46 . . . . .	Original
iii through v/vi . . . . .	Original	6-47/48 . . . . .	Original
1-0 through 1-9/10 . . . . .	Original	6-49/50 . . . . .	Original
2-1 through 2-10 . . . . .	Original	6-51/52 . . . . .	Original
3-1 through 3-7/8 . . . . .	Original	6-53/54 . . . . .	Original
4-1 through 4-9/10 . . . . .	Original	6-55/56 . . . . .	Original
4-11/12 . . . . .	Original	6-57 through 6-59/60 . . . . .	Original
4-13/14 . . . . .	Original	6-61 through 6-65/66 . . . . .	Original
4-15/16 . . . . .	Original	6-67 through 6-71/72 . . . . .	Original
4-17/18 . . . . .	Original	6-73 through 6-75/76 . . . . .	Original
4-19 through 4-25/26 . . . . .	Original	6-77/78 . . . . .	Original
5-1 through 5-47/48 . . . . .	Original	6-79 through 6-81/82 . . . . .	Original
6-1 through 6-3/4 . . . . .	Original	6-83/84 . . . . .	Original
6-5 through 6-7/8 . . . . .	Original	6-85/86 . . . . .	Original
6-9 through 6-11/12 . . . . .	Original	6-87 through 6-93/94 . . . . .	Original
6-13 through 6-21/22 . . . . .	Original	6-95/96 . . . . .	Original
6-23/24 . . . . .	Original	6-97 through 6-99/100 . . . . .	Original
6-25/26 . . . . .	Original	6-101/102 . . . . .	Original
6-27/28 . . . . .	Original	6-103/104 . . . . .	Original
6-29/30 . . . . .	Original	6-105 through 6-107/108 . . . . .	Original
6-31/32 . . . . .	Original	6-109/110 . . . . .	Original
6-33/34 . . . . .	Original	6-111 through 6-113/114 . . . . .	Original
6-35/36 . . . . .	Original	6-115 and 6-116 . . . . .	Original

Prepared By

AVSD TECHNICAL PUBLICATIONS

AMPEX CORPORATION 401 Broadway Redwood City, California 94063

Printed in USA

## **INTRODUCTION**

This manual, Catalog No. 4890328-02, provides descriptive information, installation, operation, theory of operation, and maintenance instructions for the Ampex Model AG-440C Tape Recorder/Reproducer, Ampex Part numbers 4010202-01 through -42, 4010203-01 through -39, and 4010204-01 through -18.

# TABLE OF CONTENTS

SECTION	TITLE	PAGE NO.
I	DESCRIPTION . . . . .	1-1
	TAPE TRANSPORT . . . . .	1-1
	RECORD/REPRODUCE ELECTRONIC UNIT . . . . .	1-2
	HEAD ASSEMBLY . . . . .	1-3
	EQUIPMENT CONFIGURATIONS . . . . .	1-4
	OPTIONAL EQUIPMENT . . . . .	1-6
	SPECIFICATIONS . . . . .	1-6
II	INSTALLATION . . . . .	2-1
	UNPACKING AND INSPECTION . . . . .	2-1
	Console-Mounted Equipment . . . . .	2-1
	Unmounted and Portable Equipment . . . . .	2-1
	MOUNTING UNITS . . . . .	2-1
	CONSOLE FRONT-PANEL REMOVAL AND INSTALLATION . . . . .	2-4
	INTERCONNECTING CABLES . . . . .	2-4
	CHECKING CABLES AND COMPONENTS . . . . .	2-4
	INITIAL LUBRICATION . . . . .	2-6
	AC Capstan Motor . . . . .	2-6
	Capstan Idler . . . . .	2-7
	CONNECTING AC POWER . . . . .	2-8
	AUDIO SIGNAL CONNECTIONS . . . . .	2-8
	Input/Output Connectors . . . . .	2-8
	Input Signal Setup . . . . .	2-8
	Output Signal Setup . . . . .	2-9
	ACCESSORIES . . . . .	2-9
	Input Transformer or Microphone Preamplifier . . . . .	2-9
	Remote Control Unit . . . . .	2-9
	Console Rear Covers . . . . .	2-9
	Scrape-Flutter Idler . . . . .	2-9
	INITIAL ADJUSTMENTS . . . . .	2-10
	Test Equipment . . . . .	2-10
	Biasing For Different Tape . . . . .	2-10
	Equalizing For A Different Tape . . . . .	2-10
	Short Cut Procedures . . . . .	2-10
	VERIFICATION OF OPERATING LEVEL USING TAPE SATURATION . . . . .	2-12
	CONVERSION . . . . .	2-12
	Turntable Repositioning For Different Reel Size . . . . .	2-12
	Tape-Width Conversion . . . . .	2-13
	Scrape-Flutter Idler Addition . . . . .	2-14
	Channel Addition . . . . .	2-14

# TABLE OF CONTENTS (Continued)

SECTION	TITLE	PAGE NO.
III	OPERATION . . . . .	3-1
	GENERAL . . . . .	3-1
	CONTROLS AND INDICATORS . . . . .	3-1
	OPERATING INFORMATION . . . . .	3-4
	Pre-Operating Procedures . . . . .	3-4
	Recording . . . . .	3-6
	Reproducing . . . . .	3-6
	Sel-Sync Function . . . . .	3-6
	Fast-Winding . . . . .	3-7
	Editing . . . . .	3-7
	Servo Equipped Transport . . . . .	3-7
	Remote Control Operation . . . . .	3-10
IV	THEORY OF OPERATION . . . . .	4-1
	GENERAL SYSTEM DESCRIPTION . . . . .	4-1
	Tape Transport . . . . .	4-1
	Block Diagram Functional Description . . . . .	4-2
	DETAILED CIRCUIT DESCRIPTION . . . . .	4-2
	Control Circuitry . . . . .	4-2
	Signal Circuitry . . . . .	4-20
	Bias/Erase Amplifier . . . . .	4-23
	Record Amplifier . . . . .	4-24
	Reproduce Amplifier . . . . .	4-25
	AC Capstan Drive Motor . . . . .	4-25
	Servo Capstan Drive Motor . . . . .	4-25
	Servo System Block Diagram . . . . .	4-26
	Servo System Circuit Description . . . . .	4-27
	Bias/Erase Oscillator . . . . .	4-29
	Power Supplies . . . . .	4-30
	Power Distribution . . . . .	4-31
V	MAINTENANCE . . . . .	5-1
	GENERAL . . . . .	5-1
	OVERALL TEST EQUIPMENT . . . . .	5-1
	PREVENTIVE MAINTENANCE . . . . .	5-2
	Cleaning . . . . .	5-2
	Demagnetizing . . . . .	5-3
	Lubrication . . . . .	5-3
	PERFORMANCE TESTS . . . . .	5-5

# TABLE OF CONTENTS (Continued)

SECTION	TITLE	PAGE NO.
V	<b>MAINTENANCE (Continued)</b>	
	Test Equipment . . . . .	5-5
	Operating-Level Check . . . . .	5-6
	Test Conditions . . . . .	5-7
	Overall Frequency Response . . . . .	5-7
	Overall Signal-To-Noise . . . . .	5-8
	Overall Distortion Check . . . . .	5-9
	Flutter Check . . . . .	5-9
	Measuring Tape Speed . . . . .	5-10
	<b>TAPE TRANSPORT ADJUSTMENTS</b>	5-10
	Test Equipment . . . . .	5-11
	Tape Tension . . . . .	5-11
	Brakes . . . . .	5-12
	Capstan Idler . . . . .	5-14
	<b>ELECTRONIC ALIGNMENT</b>	5-15
	Test Equipment . . . . .	5-15
	Preliminary Procedures . . . . .	5-16
	Reproduce Alignment . . . . .	5-17
	Record Alignment . . . . .	5-21
	Servo Gain Adjustment . . . . .	5-24
	<b>HEAD MAINTENANCE</b>	5-24
	Adjusting Head Height . . . . .	5-24
	Adjusting Tape Wrap and Zenith . . . . .	5-26
	Changing Head Stacks . . . . .	5-27
	Replacing Head Tape Guides . . . . .	5-28
	<b>TRANSPORT MAINTENANCE</b>	5-28
	Servicing Hints . . . . .	5-28
	Replacement of Head-Cable Box . . . . .	5-30
	Replacement of Power Supply Box . . . . .	5-30
	Takeup and Rewind Assemblies . . . . .	5-31
	AC and Servo Capstan Motor . . . . .	5-34
	Reel Idler . . . . .	5-35
	Takeup Tension Arm . . . . .	5-36
	Capstan Idler . . . . .	5-38
	Tape Lifter . . . . .	5-39
	Safety Switch Removal . . . . .	5-41
	<b>REMOVAL OF ELECTRONIC ASSEMBLIES AND COMPONENTS</b>	5-41
	Control Box Cover . . . . .	5-41
	Control Box . . . . .	5-42



# TABLE OF CONTENTS (Continued)

SECTION	TITLE	PAGE NO.
V	<b>MAINTENANCE (Continued)</b>	
	Power Lamp . . . . .	5-42
	Control Box Switches . . . . .	5-42
	Indicator Lamp Removal . . . . .	5-42
	Circuit Board Components . . . . .	5-42
	Other Components . . . . .	5-43
	<b>TROUBLESHOOTING</b> . . . . .	5-43
	Possible Corrective Actions . . . . .	5-43
	Causes of Tape Speed Error . . . . .	5-43
	Causes of Noise . . . . .	5-44
	Causes of Distortion . . . . .	5-44
	Causes of Flutter . . . . .	5-45
	Flutter Troubleshooting Hints . . . . .	5-45
	Extender Boards . . . . .	5-45
	Troubleshooting the Reproduce Amplifier . . . . .	5-46
	Troubleshooting the Record Amplifier . . . . .	5-46
	Troubleshooting Hints . . . . .	5-50
VI	<b>PARTS LISTS AND SCHEMATICS</b> . . . . .	6-1
	<b>CATALOG/PART NUMBER IDENTIFICATION</b> . . . . .	6-1
	<b>INDENTURED LIST OF ASSEMBLIES</b> . . . . .	6-7
	<b>NUMERICAL LIST OF ASSEMBLIES.</b> . . . . .	6-9
	<b>NUMERICAL LIST OF SCHEMATIC DIAGRAMS.</b> . . . . .	6-11