

DBX 166 PARTS LIST

PART NO#	DESCRIPTION	COST
90-0351	POWER TRANSFORMER 166 110V	10.12
90-0361	INSERT FOR KNOB, 166 #3	.44
90-0360	BUSHING FOR KNOB, 166 #2 <i>BRASS BUSHING FOR KNOB</i>	.36
90-0146	NUT/SLOTTED FOR KNOB, 166 #1	.28
34-0135	KNOB & ASSY FOR, 166	2.56
44-0159	STEREO/SWITCH 6 POLE	3.32 <u>NO longer</u>
90-0314	SWITCH/4 POLE	2.24 <u>no longer</u>
90-0339	POT 5KA (PEAK STOP ONLY) ✓	3.08 <u>NO longer Available</u> ✗
90-0337	POT 20KB (FOR ALL ELSE)	3.08 <u>NO longer Available</u>
34-0139	BUTTON CAP/RED FOR, 166	.84
34-0138	BUTTON CAP/ORANGE FOR, 166	.84
34-0140	BUTTON CAP/BLUE FOR, 166	.84
34-0136	BUTTON CAP/GREEN FOR, 166	.84
<u>90-0302</u>	<u>JACK 1/2" PHONE TYPE</u>	<u>1.84</u> <u>NO longer Available</u>
<u>90-0168</u>	RACKEAR, 166	2.80
18-2028	USER'S MANUAL, 166	3.04
18-2051	SERVICE MANUAL, 166	12.44
18-2012	USERS MANUAL, 166A	2.32
90-0137	SWITCH, CAP, 166	.36
90-0135	SWITCH, CAP GUIDE	.40
28-3337	SCREW, RACKEAR	.04

MAYBE

90-0352

POWER XFORMER 240V

→ Refer to a Vintage Parts house or call Musicians Service Center.