


'62 AMERICAN VINTAGE JAZZMASTER 0100800

SWITCH & CONTROL FUNCTION



DETAIL
3 WAY SWITCH

3 WAY SWITCH POSITION			
			← 3 WAY SWITCH POSITION
			← NECK PICKUP
			← BRIDGE PICKUP
	PICKUP IS ON		
			PICKUP IS OFF

NECK PICKUP ON

BRIDGE PICKUP ON

NECK PICKUP VOL

NECK PICKUP TONE

NECK PICKUP

BRIDGE PICKUP

SEE 3 WAY SWITCH &
DETAIL DIAGRAM

○ 3
○ 2
○ 1

MASTER VOLUME
WHEN NECK / BRIDGE
SWITCH IS IN BRIDGE
POSITION. NON FUNC-
TIONAL IN NECK
POSITION.

MASTER TONE
WHEN NECK / BRIDGE
SWITCH IS IN BRIDGE
POSITION. NON FUNC-
TIONAL IN NECK
POSITION.