

PRS Wiring Diagram For 5-Way Rotary

Wiring Standard as of January 1989

Rotary Positions

- 1) Position 10: Treble Pickup
- 2) Position 9: Power Out of Phase
- 3) Position 8: Series Single Coil
- 4) Position 7: Single Coil
- 5) Position 6: Bass Pickup

