



LESLIE AMPLIFIER MODEL 31H TYPE 2

5



TYPE 2 ADAPTER
USE ON EXTRA CABINETS IF NOT LESLIE-VIBRATONES ABOVE SERIAL 5200.



RED DOT