

OCTANE™ Upgrade Instructions for MXE Graphics, SSE Graphics, SE Graphics, SE Texture, SSE Texture, and Dual Head with SE Graphics

Enclosed is the IRIX 6.4 Recommended/Required April 1998 CD. This CD contains patches for IRIX 6.4 operating system for Origin, Onyx2, and OCTANE systems.

If you want to upgrade your OCTANE system to the new MXE graphics, SSE graphics, SE graphics, SE texture, SSE texture, or Dual Head with SE graphics, install this CD before installing the upgrade board.

Note: You must load the IRIX 6.4 Recommended/Required April 1998 CD before installing the MXE graphics, SSE graphics, SE graphics, SE texture, SSE texture, or Dual Head with SE graphics board or your system will not operate correctly.

To upgrade your OCTANE system to MXE graphics, SSE graphics, SE graphics, SE texture, SSE texture, or Dual Head with SE graphics, follow these steps:

1. Load the IRIX 6.4 Recommended/Required April 1998 CD.
2. Rebuild the kernel:

```
cd /  
mv /unix /unix.save  
autoconfig -vf
```
3. Shut down and power off the system.
4. Remove your current graphics board and install the new MXE graphics, SSE graphics, SE graphics, SE texture, SSE texture, or Dual Head with SE graphics board.
5. Power on the system and enter the *hinv* command to make sure your system recognized the new board. It should display the following lines:

Upgrade	Display
MXE Graphics	Graphics board: EMXI
SSE Graphics	Graphics board: ESSI
SE Graphics	Graphics board: ESI
SE Texture	Graphics board: ESI with texture option
SSE Texture	Graphics board: ESSI with texture option

6. Remove the file */unix.save* once the system is running.

For questions concerning installation or use of software, contact your authorized service provider

©1998, Silicon Graphics, Inc. All rights reserved.

Silicon Graphics, the Silicon Graphics logo, and IRIX are registered trademarks and OCTANE is a trademark of Silicon Graphics, Inc.

