**IMPORTANT NOTE:**

This document contains proprietary information,




Notes:

IC1,2 & 3: TL072CP.
C4X,C11,C14B,C17 deleted.
Power On/Off jack switch works in battery mode only.

DRG NO: 06011/JD10 iss A

| SIONS | DATE | TITLE | DRAWN | CHECKED | | | DRG DATE |
|---|---|---|---|---|---|---|---|
| | | Schematic for model: | SW | | | | 16.09.95 |
| | | SESSIONMASTER JD10 | DRG NO: | 06011/JD10 iss A | | | |
| | | PROFESSIONAL GUITAR PRE-AMP/DI | AWARD-SESSION, BASINGSTOKE, ENGLAND | | | | |
| | | Use with PCB Drg No: 07011 iss C & D | | | | | |