

**SGI® Foundation 1 Service Pack 1 Software  
Start Here**

007-5488-002

---

#### COPYRIGHT

© 2008, Silicon Graphics, Inc. All rights reserved; provided portions may be copyright in third parties, as indicated elsewhere herein. No permission is granted to copy, distribute, or create derivative works from the contents of this electronic documentation in any manner, in whole or in part, without the prior written permission of Silicon Graphics, Inc.

---

#### LIMITED RIGHTS LEGEND

The software described in this document is "commercial computer software" provided with restricted rights (except as to included open/free source) as specified in the FAR 52.227-19 and/or the DFAR 227.7202, or successive sections. Use beyond license provisions is a violation of worldwide intellectual property laws, treaties and conventions. This document is provided with limited rights as defined in 52.227-14.

---

#### TRADEMARKS AND ATTRIBUTIONS

SGI, Altix, the SGI cube, the SGI logo, Silicon Graphics, and SGI are registered trademarks of SGI in the United States and/or other countries worldwide.

Intel, Xeon, and Itanium are trademarks or registered trademarks of Intel Corporation. InfiniBand is a trademark of the InfiniBand Trade Association. Linux is a registered trademark of Linus Torvalds. Intel, Xeon, and Itanium are trademarks or registered trademarks of Intel Corporation. Novell is a registered trademark, and SUSE is a trademark of Novell, Inc., in the United States and other countries. Red Hat and all Red Hat-based trademarks are trademarks or registered trademarks of Red Hat, Inc. in the United States and other countries. Platform Manager is a trademark of Platform Computing Inc.

All other trademarks mentioned herein are the property of their respective owners.

## Record of Revision

Version	Description
001	July 2008 Original publication. Supports the SGI Foundation 1 software release.
002	October 2008 Supports the SGI Foundation 1 Service Pack 1 software release.



## Contents

<b>SGI Foundation Software</b>	<b>1</b>
About This Guide	1
Obtaining Publications	2
Reader Comments	2
Audience	4
Helpful Online Resources	4
Software Introduction	7
SGI Foundation Software CD Contents	7
Getting Updates	8
System Controller Software 1.23 CD	9
Getting the Latest Firmware/Software for Your SGI Altix XE or SGI Altix ICE 8200 System	10
License Manager Updates	10
Embedded Support Partner	11
Installing SGI Foundation Software	12
Installing on SUSE Linux Enterprise Server 10 SP2	12
<b>007-5488-002</b>	<b>v</b>

Installing on Red Hat Enterprise Linux 5.2	15
Upgrade from Earlier Releases	16
Obtaining and Installing the Latest SGI Altix System Firmware	17
Reinstalling Your Software	19

## **SGI Foundation Software**

This manual describes the contents of the SGI Foundation 1 Service Pack 1 (SP1) software release and how to install and configure it.

### **About This Guide**

This guide documents the installation, configuration, and administration of SGI Foundation1 SP1 software.

This guide contains the following sections:

- "Audience," page 4
- "Helpful Online Resources," page 4
- "Software Introduction," page 7
- "SGI Foundation Software CD Contents," page 7
- "Getting Updates," page 8
- "System Controller Software 1.23 CD," page 9

- "Getting the Latest Firmware/Software for Your SGI Altix XE or SGI Altix ICE 8200 System," page 10
- "License Manager Updates," page 10
- "Embedded Support Partner," page 11
- "Installing SGI Foundation Software," page 12
- "Upgrade from Earlier Releases," page 16
- "Obtaining and Installing the Latest SGI Altix System Firmware ," page 17
- "Reinstalling Your Software," page 19

### ***Obtaining Publications***

To obtain SGI documentation, go to the SGI Technical Publications Library at <http://docs.sgi.com>.

### ***Reader Comments***

If you have comments about the technical accuracy, content, or organization of this document, please tell us. Be sure to include the title and document number of the manual with your comments. (Online, the



document number is located in the front matter of the manual. In printed manuals, the document number can be found on the back cover.)

You can contact us in any of the following ways:

- Send e-mail to the following address:

`techpubs@sgi.com`

- Use the Feedback option on the Technical Publications Library World Wide Web page:

*<http://docs.sgi.com>*

- Contact your customer service representative and ask that an incident be filed in the SGI incident tracking system.
- Send mail to the following address:

Technical Publications  
SGI  
1140 East Arques Avenue  
Sunnyvale, CA 94085-4602

SGI values your comments and will respond to them promptly.

## **Audience**

This guide is written for system administrators who are responsible for installing, configuring, and administering SGI Foundation Software running on SGI Altix systems.

## **Helpful Online Resources**

This section describes the electronic support services available for your SGI system running SGI Foundation software, as follows:

- Supportfolio

Supportfolio, the SGI support web site, including the SGI Knowledgebase, SGI YaST Update Online (YOU) server, SUSE YaST Online Server, links for software supports and updates, as described in this listing.

*<https://support.sgi.com/login>*

- Supportfolio SGI Knowledgebase

The SGI Knowledgebase available from Supportfolio has answers to common questions, problem resolutions, how-to documents, and many other useful articles for system administrators.

*<https://support.sgi.com/kb/publisher.asp>*

- SGI YaST Online Update Server

The SGI YaST Update Online (YOU) server is available for your convenience. Get updates to SGI Foundation1 Service Pack 1 Software for Linux, SGI ProPack 6 Service Pack 1 for Linux, and SUSE Linux Enterprise Server 10 (SLES10) using the YaST install tool right from your system. The **YaST Online Update - Patch Media Instructions** describes how to update your system using patch media. Use your Supportfolio account name and password, and point YaST to this location:

*<https://update.sgi.com/>*

- Supportfolio Software Updates

Check for new updates to your purchased SGI software, and download or order CDs all in one convenient place. Supportfolio Software Updates provides one-stop shopping to check for and get new updates for your SGI software.

*<https://support.sgi.com/software?cmd=order>*

- SGI Customer Support Center

You can open calls to the SGI Customer Support Center on-line, keep track of all your cases, and receive automatic update information when your case is updated via the Supportfolio Problem Resolution Tools at:

*<https://support.sgi.com/caselist>*

- SGI Software Licensing

If you need to get your license for SGI software, you can order your software licenses conveniently via e-mail or on-line.

You can send a blank email to [license@sgi.com](mailto:license@sgi.com), and you will receive a simple template to fill out. You will quickly receive your new license back with complete instructions for installing it back via E-Mail.

Or, you can go on-line to the SGI Key-O-Matic at:

*<http://www.sgi.com/support/licensing/>*

## Software Introduction

The SGI Foundation software product includes software to support the SGI differentiated hardware solutions. This product adds to or enhances features in the base SUSE Linux Enterprise Server 10 (SLES10) Service Pack 2 (SP2) Linux distribution or Red Hat Enterprise Linux 5.2 (RHEL5.2) distribution. SGI Foundation software is designed to run on any SGI Altix, SGI Altix XE, or SGI Altix ICE 8200 system.

SGI hardware platforms and operating system configuration settings supported by SGI in this release are documented at the following URL:  
<http://www.sgi.com/servers/altix/>

## SGI Foundation Software CD Contents

This section describes the contents of the SGI Foundation Software 1 Service Pack 1 CD, as follows:

- Direct Access Programming Library (DAPL) for high performance communication between processes
- SGI Itanium 2 PROM (System controller software)
- SGI x86\_64 Baseboard Management Controller (BMC), chassis management control (CMC), and Basic Input/Output System (BIOS) software

- OFED OpenSM software package and InfiniBand libraries, management tools and diagnostic tools
- Device driver libraries
- LSI Logic LSIUtil (`lsiutil`) configuration utility
- Memory logging utility
- `kdump` utility
- Open source Performance Co-Pilot (`pcp-open` package)
- Embedded Support Partner (ESP)
- SGI support tools
- SGI LK software licensing mechanism

## Getting Updates

This section describes how to get software updates for SGI Foundation 1 SP1 software release.

Detailed instructions for downloading and installing SGI Foundation 1 SP1 software updates are available from the SGI Foundation Software product pages on Supportfolio:  
[https://support.sgi.com/content\\_request/961100/index.html](https://support.sgi.com/content_request/961100/index.html).

**Note:** You must have a Supportfolio account to access this page and the SGI update server.

Customers that received SGI Foundation 1 pre-installed on their new SGI Altix system may run the following command to add the proper update source for SGI Foundation 1:

```
$ /usr/sbin/sgi-foundation-update-source
```

This script will prompt you for your Supportfolio login and then add the proper SGI update source for the given architecture.

## **System Controller Software 1.23 CD**

The System Controller software provides a system control platform for field service and system maintenance applications.

**Note:** The System Controller Software 1.23 CD is not shipped by default. You can download the System Controller Software 1.23 package from <http://support.sgi.com/> or order it on CD-ROM (P/N 812-1138-023). Contact your SGI account representative if you need assistance obtaining the software package.

For installation instructions, see *System Controller Software 1.2x Update Guide* available on <http://docs.sgi.com>.

## **Getting the Latest Firmware/Software for Your SGI Altix XE or SGI Altix ICE 8200 System**

For information on the basic input/output system (BIOS), Baseboard Management Controller (BMC) firmware, Intelligent Platform Management Interface (IPMI) control utility, Field Replaceable Unit/Sensor Data Record (FRUSDR) software, Hierarchical Storage Controller (HSC) software, LSI RAID firmware, Platform Manager cluster management software, Infiniband drivers, INTEL MPI Runtime Environment Kit for Linux, and Java Runtime Environment (JRE), see the SGI Altix XE Firmware/Software page on SGI Supportfolio at:

[https://support.sgi.com/content\\_request/691346/index.html](https://support.sgi.com/content_request/691346/index.html)

For information on SGI Altix ICE system firmware, see the “System Firmware” section in Chapter 5, “System Maintenance, Monitoring, and Debugging” in the *SGI Tempo System Administrator’s Guide* available on <http://docs.sgi.com>.

## **License Manager Updates**

Please backup your license key files prior to installing SLES10 SP1 and/or SGI ProPack 6 SP1. A license key file is not included in these RPMs. Your original license key files will need to be restored after you complete your installation.



In terms of software licensing support, the Redhat and SUSE distributors do not ship any code. ISVs are responsible for obtaining and including software licensing components into their products.

SGI Foundation Software contains a licensing mechanism called LK. LK was developed by SGI for SGI products only. For more information, see the specific product release notes or the FAQ, as follows:

*<http://www.sgi.com/support/licensing/faq.html>*

If you encounter any license related problems, please contact your local support center at this location:

*<http://www.sgi.com/support/supportcenters.html>*

## **Embedded Support Partner**

Embedded Support Partner (ESP) is a support infrastructure which is integrated into the operating system. ESP components capture and store system level events, system configuration information, system availability information, provide an electronic logbook of activities performed on the system, log calls to the ESP database at SGI and other support related activities. For more information, see *Embedded Support Partner User Guide* available on *<http://docs.sgi.com>*.

## Installing SGI Foundation Software

The following set of instructions is based on an install using the physical product media. For other installation methods, see the product release notes. This section covers these topics:

- "Installing on SUSE Linux Enterprise Server 10 SP2", page 12
- "Installing on Red Hat Enterprise Linux 5.2", page 15

### ***Installing on SUSE Linux Enterprise Server 10 SP2***

To install SGI Foundation 1 SP1 software on SLES10 SP2, perform the following steps:

1. Remove any previous SGI ProPack 5 install sources if present. Skip this step if you are not installing on a system that is already running SGI ProPack 5.
  - a. Start the graphical (`yast2`) or text version of YaST (`yast`).
  - b. Select **Software - Installation Source**
  - c. Find and remove any SGI ProPack 5 related install sources.
  - d. Select **Finish** to exit the tool.
2. Add SGI Foundation Software as an add-on product, as follows:

- a. Start the graphical (`yast2`) or text version of YaST (`yast`).
- b. Select **Software** -> **Add-on Product**
- c. Select **CD...** and click **Next**.

You will be prompted to insert the media.

- d. YaST will add the product as a new installation source.

**Note:** YaST will display an error message that states: "**An error occurred while connecting to the server. Details: Unknown source type for https://update.sgi.com/SGI-Foundation/1/ia64. Try again?**" YaST attempts to add both the media and the online update repositories as install sources, but fails to add the online update repositories.

- e. Click **Yes** in order to enter your authentication information required to access the online update repositories. Click **No** if you would rather not add the online update repositories at this time.
- f. Unselect the **Anonymous** box and then enter your Supportfolio login name and password in the **User** name and **Password** fields.

YaST will add the online update repositories as an install source.

3. YaST transitions to the software manager after adding the install sources. Perform the following steps:

- a. Select **Patterns** from the available **Filter** options.
- b. In graphical mode, perform the following:
  - i. Verify that the **SGI Foundation Libraries, Software and Drivers** pattern is selected. Installation of the product requires this pattern.
  - ii. Select any other patterns that you may require, such as, the **SGI Foundation InfiniBand Libraries, Utilities, and Drivers** if you have Infiniband devices.
  - iii. Verify that packages in the patterns are marked for installation and/or upgrade.
- c. In text mode, perform the following:
  - i. Highlight the **SGI Foundation Libraries, Software, and Drivers** pattern and select OK. Installation of the product requires this pattern.
  - ii. Select any other patterns that you may require, such as, the **SGI Foundation InfiniBand Libraries, Utilities, and Drivers** if you have InfiniBand devices
  - iii. Verify that packages in the patterns are marked for installation (+) and/or upgrade (>).

4. Select **Accept** to install.

### ***Installing on Red Hat Enterprise Linux 5.2***

These instructions assume that you have a VGA display or that you are able to remotely display X11 graphics. If you do not have a VGA display, you should connect from your workstation to the target server with the following command:

```
% ssh -X root@target-server
```

To install SGI Foundation 1 SP1 software on RHEL 5.2, perform the following steps:

1. Make sure you have registered with the Red Hat Network (RHN). If you have not yet registered, run the following command:

```
% /usr/bin/rhn_register
```

2. Insert the product media and enter the following command to mount it:

```
% mount /dev/cdrom/mnt
```

3. Run the install script, as follows:

```
% /mnt/INSTALL
```

4. Click the **Forward** button. Check the box next to **SGI Foundation Software**. Click the **Optional packages** button to de-select any packages you do not want to install. Click the **Forward** button.
5. Review the **Installation Overview** screen and click the **Forward** button. You may see a screen that indicates that dependencies are being added. If so, click the **Continue** button.
6. You should see a screen indicating that the installation was successful. Click the **Close** button to close this screen.

## Upgrade from Earlier Releases

For information on upgrading from SLES SP1 to SLES SP2, see the appropriate Novell, Inc. documentation. In the "Installing on SUSE Linux Enterprise Server 10 SP2", page 12 section, refer to step 3, "Verify that packages in the patterns are marked for installation and/or upgrade".

For information on upgrading from RHEL 5.1 to RHEL 5.2, see the appropriate Red Hat, Inc. documentation.

For information on upgrading SGI ProPack 6 software, see the *SGI ProPack 6 for Linux Service Pack 1 Start Here*.

## Obtaining and Installing the Latest SGI Altix System Firmware

There are three levels of firmware to consider on your SGI Altix system, as follows:

- L2 controller software (only configurations of SGI systems with routers have L2 controllers)
- L1 controllers on routers, IX-bricks, PX-bricks, C-bricks, Individual Rack Units (IRU) and so on.
- The system PROM (each node has a system PROM and each C-brick has two nodes).

**Note:** This section only applies to SGI Altix 4000 series systems with Intel Itanium processors.

On an SGI Altix 450 or SGI Altix 4700 system, the L1 firmware consists of three parts: the boot image, A image, and B image. For more information, see the "Upgrading L1 Firmware" section in either the *SGI Altix 450 User's Guide* or *SGI Altix 4700 User's Guide*.

L1 and L2 system controller firmware provides support for managing and monitoring the power, cooling, and testing functions for a brick and system compute rack.

On an SGI Altix 450 or SGI Altix 4700 system, the L2 system controller is an application that provides control over multiple L1s and communication to other L2s. For more information, see Chapter 3, "System Control" in the *SGI Altix 450 User's Guide* or Chapter 2, "System Control" in the *SGI Altix 4700 User's Guide*, respectively.

You can always download the latest L1/L2 system controller software and PROM firmware via Supportfolio at <http://support.sgi.com/linux/>.

You can also find system controller software by using the search term "system controller" at: [http://support.sgi.com/search\\_request/downloads/index](http://support.sgi.com/search_request/downloads/index).

PROM is released as patches and the latest firmware can also be found at: [http://support.sgi.com/browse\\_request/linux\\_patches\\_by\\_os](http://support.sgi.com/browse_request/linux_patches_by_os)

**Note:** SGI Altix 450 or SGI Altix 4700 systems running SGI ProPack 6 for Linux should use PROM located in `shub2snprom.bin`. All other SGI systems should use the PROM located in `shub1snprom.bin`. This note does not apply to SGI Altix XE systems (instead see "Getting the Latest Firmware/Software for Your SGI Altix XE System"). Software support contract customers can download the most recent PROM versions from SGI Supportfolio: <https://support.sgi.com/>

To update or "flash" the system PROM, you first need to download the prom RPM from Supportfolio as described above.



**Note:** The PROM image on your hard drive is automatically updated when you upgrade your system to the latest SGI ProPack for Linux release. The installation of the `snprom` RPM happens automatically as part of the SGI ProPack installation. Flashing it must be performed.

Once you have the latest PROM RPM, instructions on how to flash the PROM are available in the PROM Readme file at `/boot/efi/efi/sgi/snprom/README.snprom`.

For partitioned systems, it is important to upgrade all nodes (including all nodes in all partitions) before resetting any partitions. In other words, do not reset any partitions until all nodes in all partitions have been upgraded.

## Reinstalling Your Software

To reinstall all of the software on your system, follow the entire set of installation instructions listed previously, using the latest SGI Foundation 1 Service Pack 1 CD.