



<b>INTRODUCTION.....</b>	<b>1</b>
--------------------------	----------

## **PART ONE: ABOUT REMOTE CONTROL ..... 3**

<b>CHAPTER ONE: OVERVIEW.....</b>	<b>5</b>
-----------------------------------	----------

<b>Operate Waverunner by Remote Control.....</b>	<b>5</b>
STANDARDS.....	6
PROGRAM MESSAGES.....	6
COMMANDS AND QUERIES.....	7
HEADERS.....	8
HEADER PATHS.....	8
DATA.....	9
CHARACTER DATA.....	9
NUMERIC DATA.....	9
STRING DATA.....	10
BLOCK DATA.....	10
RESPONSE MESSAGES.....	10
USE SCOPEEXPLORER.....	11

<b>CHAPTER TWO: CONTROL BY GPIB.....</b>	<b>13</b>
--	-----------

<b>Talk, Listen or Control.....</b>	<b>13</b>
TALK, LISTEN OR CONTROL.....	13
INTERFACE.....	13
ADDRESS.....	14
GPIB SIGNALS.....	14
I/O BUFFERS.....	14
USE IEEE 488.1 STANDARD MESSAGES.....	15
DEVICE CLEAR.....	15
GROUP EXECUTE TRIGGER.....	15
REMOTE ENABLE.....	15
INTERFACE CLEAR.....	16
CONFIGURE THE GPIB-DRIVER SOFTWARE.....	16
MAKE SIMPLE TRANSFERS.....	17
USE ADDITIONAL DRIVER CALLS.....	19
MAKE SERVICE REQUESTS.....	19
<b>Take Instrument Polls.....</b>	<b>21</b>
DO CONTINUOUS POLLING.....	21
TAKE A SERIAL POLL.....	21
DO A PARALLEL POLL.....	22

## TABLE OF CONTENTS

---

PERFORM AN *IST POLL .....	24
<b>Drive Hard-copy Devices on the GPIB .....</b>	<b>25</b>
READ DATA BY CONTROLLER .....	25
SEND DATA TO BOTH .....	25
TALK DIRECTLY TO PRINTER .....	26
<b>CHAPTER THREE: CONTROL BY RS232.....</b>	<b>29</b>
<b>Communicate through the RS-232-C Port .....</b>	<b>29</b>
HANDSHAKE CONTROL .....	29
EDITING FEATURES.....	30
MESSAGE TERMINATORS.....	30
SRQ MESSAGE .....	31
LONG LINE SPLITTING .....	31
REMARKS .....	32
<b>Simulate GPIB Messages.....</b>	<b>33</b>
<b>CHAPTER FOUR: UNDERSTAND AND MANAGE WAVEFORMS.....</b>	<b>35</b>
<b>Know Your Waveform.....</b>	<b>35</b>
LOGICAL DATA BLOCKS .....	35
INSPECT WAVEFORM CONTENTS .....	36
USE THE WAVEFORM QUERY .....	37
INTERPRET VERTICAL DATA .....	39
CALCULATE A DATA POINT'S HORIZONTAL POSITION .....	40
USE THE WAVEFORM COMMAND .....	42
<b>Transfer Waveforms at High Speed.....</b>	<b>43</b>
<b>CHAPTER FIVE: CHECK WAVEFORM STATUS .....</b>	<b>45</b>
<b>Use Status Registers.....</b>	<b>45</b>
OVERVIEW .....	45
STATUS BYTE REGISTER (STB) .....	47
STANDARD EVENT STATUS REGISTER (ESR) .....	47
STANDARD EVENT STATUS ENABLE REGISTER (ESE).....	48
SERVICE REQUEST ENABLE REGISTER (SRE) .....	48
PARALLEL POLL ENABLE REGISTER (PRE).....	48
INTERNAL STATE CHANGE STATUS REGISTER (INR).....	48
INTERNAL STATE CHANGE ENABLE REGISTER (INE) .....	49
COMMAND ERROR STATUS REGISTER (CMR) .....	49
DEVICE DEPENDENT ERROR STATUS REGISTER (DDR).....	49
EXECUTION ERROR STATUS REGISTER (EXR) .....	49
USER REQUEST STATUS REGISTER (URR) .....	49

<b>PART TWO: COMMANDS .....</b>	<b>53</b>
<b>Use Waverunner Commands and Queries.....</b>	<b>53</b>
COMMAND NOTATION .....	53
<b>Table of Commands and Queries – By Short Form..</b>	<b>55</b>
<b>Table of Commands and Queries – By Subsystem..</b>	<b>59</b>
<b>APPENDIX I, GPIB PROGRAM EXAMPLES.....</b>	<b>255</b>
<b>Example 1.....</b>	<b>255</b>
USE THE INTERACTIVE GPIB PROGRAM “IBIC” .....	255
<b>Example 2.....</b>	<b>256</b>
USE THE GPIB PROGRAM FOR IBM PC (HIGH-LEVEL FUNCTION CALLS).....	256
<b>Example 3.....</b>	<b>260</b>
USE GPIB PROGRAM FOR IBM PC (LOW-LEVELFUNCTION CALLS).....	260
<b>APPENDIX II, WAVEFORM TEMPLATE .....</b>	<b>263</b>
<b>Waveform Template.....</b>	<b>263</b>
<b>INDEX.....</b>	<b>275</b>

BLANK PAGE