

Service documentation

# Receiver type series EKD 500

EKD 511/type 1340.42 A1

EKD 512/type 1340.42 A2

Volume 1

To go with this:

Service documentation 1340.042-91700 Su 02, Vol. 2

We reserve the right to make modifications to the construction and design which serve the improvement and development of our equipment without prior notice.

Order-No. of the Service documentation 1340.042-91700 Su 02  
Edition 2/1989  
Volume 1

<u>Contents</u>	<u>Page</u>
1. General remarks	5
2. Test equipment and auxiliary testing means	7
3. Hints for dismounting and mounting	9
4. Hints for troubleshooting	11
5. Localization of the faulty subassembly and reestablishment of the functionality of the receiver by subassembly exchange	15
5.1. Check "power supply section"	17
5.2. Check "control unit"	18
5.3. Check "frequency processing"	21
5.4. Check "signal path"	23
6. Repair of the faulty subassembly	26
6.1. Power supply section 1340.039-01500	27
6.1.1. Input and output values	27
6.1.2. Measuring values within the power supply section	28
6.1.3. Troubleshooting table	30
6.2. Control unit 1340.041-01401	34
6.2.1. Function principle	34
6.2.2. Test and check arrangements	37
6.2.3. Repair sequence "local operation"	38
6.2.4. Repair sequence operation "external"	39
6.2.5. Control computer	40
6.2.6. Input-output logic	42
6.2.7. Keyboard	44
6.2.8. Digital display	47
6.2.9. Register and interface	48
6.3. Frequency processing	55
6.3.1. Troubleshooting sequence	55
6.3.2. Frequency processing - outline	56
6.3.3. Phase-lock loop 1 (PLL1)	58
6.3.4. Oscillator 1	60
6.3.5. Frequency divider 1	64
6.3.6. Oscillator 3 (PLL3)	66

ContentsPage

6.3.7.	Phase-lock loop 2 (PLL2)		70
6.3.8.	Oscillator 2		72
6.3.9.	Frequency divider 2		76
6.4.	Signal path		78
6.4.1.	Check or correction of levelling		78
6.4.1.1.	Basic amplification "signal path 1"		78
6.4.1.2.	Control volume "signal path 1"		78
6.4.1.3.	Mixer - symmetry		78
6.4.1.4.	Basic amplification "signal path 1 and 2"		79
6.4.1.5.	Levelling "A3E"		79
6.4.1.5.	Changing AF line levels (max +6 dBm)		79
6.4.1.7.	Balancing "control synchronism/channel A and B, manual control		79
6.4.1.8.	Balancing "automatic control/channel A and B"		80
6.4.1.9.	Check "control synchronism/channel A and B, automatic control		80
6.4.1.10.	Adjustment "control start/control element 1" (mixer 1)		80
6.4.1.11.	Adjustment "trigger - control amplifier"		80
6.4.1.12.	Adjustment "short-time detector"		81
6.4.1.13.	Balancing "display E "		81
6.4.2.	Signal path 1,	1340.041-01311 or -01312	82
6.4.2.1.	Preselector 1,	1340.041-01351	83
	Preselector 2,	1340.041-01352	
6.4.2.2.	Mixer 1,	1340.041-01353	87
	Mixer 2,	1340.041-01354	
6.4.3.	Signal path 2,	1340.041-01321 or -01322	88
6.4.3.1.	Carrier oscillator	1340.037-01355	90
6.4.3.2.	IF2/A,	1340.041-01357 or -01367	95
	IF2/B,	1340.041-01356 or -01366	
6.4.3.3.	Demodulator and AF section,	1340.039-01358	96
6.5.	F1B-demodulator,	1340.041-01258	98
6.5.1.	Check "input signal"		98
6.5.2.	Check "input band-pass"		98
6.5.3.	Check "limiter amplifier"		98

<u>Contents</u>	<u>Page</u>
6.4.5. Check "PLL"	98
6.5.5. Check "changeover switch for low passes 100/600 Bd"	99
6.5.6. Check "amplifier"	99
6.5.7. Check "evaluator circuit"	99
6.5.8. Check "line current for teleprinter"	99
6.5.9. Check "holding and capture range of PLL"	99
7. Measuring the main parameters	101
7.1. Frequency accuracy	101
7.1.1. Measuring and correcting; with standard test conditions	101
7.1.2. Check and correction on service conditions	101
7.2. Sensitivity	103
7.3. Amplification control	106
8. Components selected by the manufacturer	109
List of terms translated	110

1. General remarks

For carrying out repair work on receivers of series EKD 500, the following unit-specific documentation is required:

- Equipment documentation series EKD 500 1340.042-91700 Eu 02 (specification, operation, maintenance) forming part of every unit supply.
- Service documentation series EKD 500 1340.042-91700 Su 02
  - Volume 1: Repair instructions
  - Volume 2: Outline of subassemblies
    - Functional diagram
    - Circuit diagrams
    - Complementation drawings

**Attention!**

When performing service work adhere to the safety instructions especially to those concerning

- \* earthing of the unit to be repaired
- \* work on open units

Repair work is only to be carried out by authorized and particularly instructed specialists being well acquainted with the analogue and digital integrated circuit engineering as well as with the work of electronic units.

Any person meeting these demands will be able to repair every subassembly.

Reestablishment of troublefree functioning of the receiver can be performed through

- \* detecting and replacing the faulty subassembly (Section 5)
- \* repairing the faulty subassembly (Section 6)

In case of fault indication (F1 to F4) during ROM test (A5), the complete printed circuit "Control computer" (contained in spare part list E9) is to be replaced.

The spare part assortment offered by the manufacturer is to be taken from the spare part lists which are supplied on special request.

Spare part list E1: mechanical and electrical wear parts.

Spare part list E7: complete spare subassemblies (cassettes, control unit, power supply section)

Spare part list E9: stock spares for unit-specific spare parts

Capacitors, resistors, diodes, transistors, and integrated circuits required for repair work can also be procured from other manufacturers. It is to be observed that the electrical and mechanical values are equivalent. Component replacement on the double-clad pc boards requires utmost care when soldering on the plated-through holes.

If the requirements for subassembly repair are not met, it is recommended to exchange the entire subassemblies and have them repaired in a service workshop.

Performing repair work on the basis of this service documentation requires the test equipment and auxiliary testing means listed below. In the following, the abridged designation of the instruments is used; e.g. RF generator: P4.

- P1 Counting frequency meter  
 $f_e \approx 120 \text{ MHz}$   
 $\Delta f/f \approx 1 \cdot 10^{-7}$   
 $U_e \approx 50 \text{ mV}$
- P2 RF-mV meter with RF  
measuring head and  
50 ohm load  
 $f = 10 \text{ kHz to } 200 \text{ MHz}$   
 $U_e = 3 \text{ mV to } 10 \text{ V}$
- P3 AF-mV meter  
(2x)  $f = 5 \text{ Hz to } 200 \text{ kHz}$   
 $U_e = 15 \text{ mV to } 5 \text{ V}$   
 $R_e \approx 100 \text{ kohm/V}$
- P4 RF generator  
 $f = 10 \text{ kHz to } 30 \text{ MHz}$   
 $R_i = 75 \text{ ohm}$   
emf = 1  $\mu\text{V}$  to 3 V  
unmodulated/modulated  
1000 Hz m = 0.3
- P5 Double-beam oscilloscope  
 $f_e \approx 50 \text{ MHz}$
- P6 Single-beam oscilloscope  
 $f_B \approx 10 \text{ MHz}$
- P7 Wobble oscillator with  
display unit and probe  
 $f = 100 \text{ kHz to } 200 \text{ MHz}$
- P8 Multimeter  
 $R_i \approx 100 \text{ kohm/V}$
- P9 Digital voltmeter  
 $U_e \approx 30 \text{ V dc}$

- P 10      Tone oscillator
    - f        = 300 Hz to 6000 Hz
    - R<sub>i</sub>      = 20 ohm
    - U<sub>a</sub>      = 2 mV to 1 V
  - P 11      Mains control transformer      0 to 250 V/6 A
  - P 12      Line tester
  - P 13      Test plug 'substitution - control unit'  
1340.042-01602
  - P 14      Adapter cable 'input-output logic'  
1340.042-01603
  - P 15      Connection adapter 'control unit'  
1340.042-01604
- 
- RF cable (BNC-50 ohm) 2 pcs. 1340.037-01124
  - RF adapter                            33 TGL 200-380
- 
- 'Test cable set  
1340.042-01601  
(cf. equipment  
documentation  
1340.042-01700 Eu 02  
Section I 6)
  - } contained in the  
accessories  
1340.037-10001  
Z1 02 (4)



### 3. Dismounting and mounting

Pull the mains plug before starting dismounting. Loosen the red-ring marked screws provided below the handle of the plug-in. Withdraw the plug-in out of the rack by pressing the laterally arranged latches inwards.

Attention! Place the plug-in directly next to the casing and separate the BNC plug of the aerial cable from the plug-in.

After pulling the mains plug, the electric connection between the plug-in and the casing can be reestablished by means of the 30-core or 8-core adapter cable contained in the accessories.

Upon loosening the 8 screws marked with a red ring located on the right plug-in wall, the power supply section can be withdrawn upwards and connected again with the plug-in via the 16-core adapter cable contained in the accessories. An extractor, forming part of the accessories, (drwg.-No. 1340.037-02823) can be used for this purpose.

For cassette exchange, slacken per cassette 2 wing nuts provided on the rear wall of the plug-in and 2 hexagon screws (SW 8) on the front.

The front plate can be swung down by 90° thus providing access to the connections of all control elements as well as to the cassette terminals by only loosening the two screws located next to the plug-in handles.

For exchanging the "control unit" (with the front plate swung down by 90°), slacken both controls " " (13) and "changeover switch for LED row" (2) as well as the 4 fastening screws. After removing the two plug-and-socket connections X1022 and X1023 the subassembly can be lifted out.

The defective control elements

- \* regulator "volume" (4)
- \* regulator "RF/AF amplification" (6)
- \* regulator "A1/pitch" (5)
- \* changeover switch/monitoring channel (3)
- \* unit switch ON/OFF (1)

can only be replaced with the "control unit" taken out of the receiver.

Access to all components of the cassettes is provided after loosening the 4 wing screws, swivelling out the two outer cassettes and unscrewing the 4 inner lids (with the pressed-in fastening points).

When a pc board is to be exchanged, take the respective cassette out of the casing and unscrew both lids. On the soldering side, slacken the 4 hexagon nuts by means of a socket wrench (7 mm). On the complementation side, remove the probably existing connections to the adjacent circuit.

The pc board can be withdrawn to the rear.

For carrying out repair work on the inner side of the rear wall of the casing, loosen the 4 hexagon nuts of the rear wall and the earth connections provided on the right inner side of the casing. Then, the rear wall of the casing can be removed.

Mounting is carried out in the reverse order.

#### 4. Hints on troubleshooting

In case of faulty operation, fault localization is necessary for aimed repair work.

The sequence is the following:

- External fault sources in the incoming and outgoing cables are to be excluded by checking.
  - Exclude wrong operation of the receiver.
  - If a total breakdown is present, check the fuse link in the receiver plug-in (equipment documentation EKD 500, section III.6.1.)
  - Check the functionability of the receiver (equipment documentation EKD 500, Section III.5.).
  - Reestablish the functionability of the receiver by:
    - . detecting and replacing the faulty subassembly (Section 5 of this service documentation)
- Recondition: Spare subassembly according to the  
spare part list 1340.042-00001 E7
- . replacing the faulty component  
(fault detection acc. to Section 6 of this service documentation)

#### - Marking of subassemblies:

All subassemblies are marked - in addition to the drwg.-No. - (referred to the electric components) with two-digit numbers. (viz. subassembly survey 1340.042-00001 U 02 (3))

#### - Marking of components:

All components are marked with four- (five)- digit numbers. The two first digits correspond with the code number of the sub-assembly.


Example: V04 in the circuit diagram 'mixer 1'      ≅ V3304  
L01 in the circuit diagram 'oscillator 2'      ≅ L2501

When ordering spare parts, these four-(five)- digit numbers are to be indicated.

- Marking of subassemblies in printed circuits:

Code No.	Subassembly/printed circuit	Drwg.-No.	
00	Casing	1340.042-01001	
	DC filter	1340.042-01022	
10	<u>Plug-in</u>	1340.041-00001	
20	<u>Frequency processing</u> )	1340.041-01211	
21	Oscillator 1	1340.037-01251	
22	Frequency divider 1	1340.037-01252	
23	Oscillator 3	1340.039-01253	
205	<u>Frequency processing</u> )	1340.041-01221	
24	Reference frequency	1340.037-01254	
25	Oscillator 2	1340.037-01255	
26	Frequency divider 2	1340.037-01256	
28	F1 demodulator	1340.041-01258	
30	<u>Signal path 1</u> )	1340.041-01311	(EKD 511)
		1340.041-01312	(EKD 512)
31	Preselector 1	1340.037-01351	
32	Preselector 2	1340.041-01352	
33	Mixer 1	1340.041-01353	
34	Mixer 2	1340.041-01354	
305	<u>Signal path 2</u> )	1340.041-01321	(EKD 511)
		1340.041-01322	(EKD 512)
35	Carrier oscillator	1340.037-01355	
36	IF2/B	1340.041-01356	(EKD 511)
		1340.041-01366	(EKD 512)
37	IF2/A	1340.041-01357	(EKD 511)
		1340.041-01367	(EKD 512)
38	Demodulator and AF section	1340.039-01358	
40	<u>Control unit</u> )	1340.041-01401	
41	Diode board	1340.041-01451	
42	Transistor board	1340.041-01452	
43	Input-output logic	1340.041-01453	
44	Control computer	1340.041-01454	
45	Register and interface	1340.041-01455	
46	Display	1340.041-01456	
47	Keyboard, complete	1340.041-01402	
50	<u>Power supply section</u> )	1340.039-01500	
51	Transverter	1340.039-01551	

\*) Spare subassemblies according to spare part list E7



86-029a

Figure 1  
Plug-in with the front plate swung down




Figure 2  
 Plug-in - Rear view

the functionability of the receiver by subassembly exchange

To make service work easier and to reduce the outage times of the receiver, we recommend to replace entire subassemblies. For this purpose, the manufacturer of the equipment offers spare subassemblies according to the spare part list E7.

Variant	EKD 511	EKD 512
Spare subassembly	1340.042-01871 E7	1340.042-01872 E7
Frequency processing 1	1340.041-01211	1340.041-01211
Frequency processing 2	1340.041-01221	1340.041-01221
Signal path 1	1340.041-01311	1340.041-01312
Signal path 2	1340.041-01321	1340.041-01322
Control unit	1340.041-01401	1340.041-01401
Power supply section	1340.039-01500	1340.039-01500

**Attention!**

The cassettes of receiver EKD 500 and of EKD 300 are not interchangeable.

The Power supply sections of receiver EKD 500 and EKD 300 can be exchanged with each other.

Subassembly exchange requires no readjustment for the functionability of the receiver.

Sections 6.1. to 6.5. contain hints on readjustment in order to minimize tolerances.

In case that the fault symptoms detected during functional check (carried out in accordance with Section III/5) did not result in localization of the faulty subassembly, checks on the receiver plug-in outside the casing are necessary.

- . Attention! Pull mains plug before taking the plug-in out of the casing.
- . Establish electric connections between casing and plug-in via the 30-core adapter cable (contained in the accessories). For checks via interfaces EXT and EXP, connect additionally the 8-core adapter cable.
- . Dismounting and mounting according to Section 3.
- . For all checks mentioned in Section 5 opening the cassette lids is not necessary.




Figure 3

Troubleshooting and reestablishment  
of unit function



The undermentioned remarks serve to detect the faulty subassembly with only a few test means.

1. Check 'power supply section'

5.1.1. Measuring of the output voltages with digital voltmeter (P9)

	Test point	Correction with
+18 V $\pm$ 0.2 V	X1001/A7, B7	R 5213
+ 5 V $\pm$ 0.1 V	X1003/A1, B1	R 5217
+22 V $\pm$ 2 V	X1003/A7, B7	-
-12 V $\pm$ 0.1 V	X1003/A5, B5	R 5114

5.1.2. In case of voltage breakdowns

+18 V, +5 V, +22V, -12 V: F 1001 and F 1002

+18 V, +5 V, +22V: F 5101

For battery operation: battery cable  
fuse

} to be  
checked

For localizing short-circuits in the subassemblies, the cassettes are to be withdrawn one after the other.

5.1.3. In case of faulty power supply section

→ replacement by spare part subassembly  
(Pay attention to the correct voltage adjustment  
(X 5002) or

→ repair according to Section 6.1.

5.2. Check 'control unit'

5.2.1. When the functional check of the receiver (equipment documentation Section III/5) proved the control unit being faulty

- . fault recognition by control test A1 to A5
- . no correspondence between operation and display

the following has to be carried out:

- replacement by spare subassembly  
(required readjustment: tolerance minimization for receiving level display;  
balance R 45145, R 45146, R 45148, R 45147 according to Section 6.2.) or
- repair in accordance with Section 6.2.


5.2.2. Functional breakdown of the receiver although operation and display correspond with each other

- Possible fault reasons:

- . Register and interface - output faulty
- . Frequency processing faulty
- . Signal path faulty

- Fault delimitation by substitution of the control unit by test plug pair P 13

— (Drwg.-No. 1340.042-01602)




- The test result supplies other hints on possible fault sources: 'control unit'

- 'frequency processing1' and '2'
- 'signal path 1' and '2'

unscrew front plate fastening and swing front plate down by 90°.

Separate terminal sockets X 1022 and X 1023 from the control unit and connect them with test plug pair P 13.

Changeover switch at P 13 to position  according to EKD adjustment 


13 E	0.00
------	------

 GC 1, SEL 0  
i.e.: PLL2:  $f_2/100 = 400 \text{ kHz}$   
PLL3:  $f_3 = 69.6 \text{ MHz}$   
 $\pm f_70$

If: A1 tone audible in the loudspeaker, at the IF output (X 0003): 200.000 kHz (measure with P1),

Then: frequency processing 1: }  
frequency processing 2: } troublefree  
signal path 1 (from mixer 1): }  
signal path 2: }  
register and interface output: } faulty  
(incl. connection cables)

- Replace control unit by spare subassembly (required readjustment: tolerance minimization for receive level display according to Section 6.2.)
- or repair in accordance with Section 6.2.

Changeover switch at P 13 to position  according to EKD adjustment 

13 E	9999.99
------	---------

 GC 1, SEL 0  
i.e.: PLL2:  $f_2/100 = 300.01 \text{ kHz}$   
PLL3:  $f_3 = 69.69999 \text{ MHz}$   
 $\pm \Delta f_70$

Connect X 2051 ( $f_N = 10 \text{ MHz}$ ) with receiver input (X 0001) by means of RF cable 1340.037-01124 (in the accessories).

If: A1 tone audible in the loudspeaker, at the IF output (X 0003): 199.99 kHz (measure with P1),

Then: frequency processing 1: }  
frequency processing 2: } troublefree  
signal path 1: }  
signal path 2: }

register and interface output:      faulty  
(incl. connection cables)

- Replace control unit by spare subassembly  
(required readjustment: receive level display  
according to Section 6.2.)
- or repair in accordance with Section 6.2.


5.3. Check 'frequency processing'

5.3.1. Cassette 'frequency processing 2'

- f2/100 to X 1004/A 8 (frequency divider 2)

. Check of frequency (with P1) and voltage


(with P6)

$f_E$ input (kHz)	f2/100 (kHz)	$u_{f2/100}$ ( $V_{SS}$ )
0.00	400.00	
99.99	300.01	

. Potential conversion of all logic conditions for 'frequency divider 2' drive.

$f_D$ input (kHz)	f2/100 (kHz)
77.77	322.23
88.88	311.12

- 200 kHz at X 1002/B 11 (reference frequency)  
 check of frequency: 200.000 kHz (with P1)  
 and voltage: 150 mV to 300 mV (with P2)

- 50 kHz at X 1002/B 1 (reference frequency)  
 check of frequency: 50.000 kHz (with P1)  
 and voltage:   $\geq 2.4 V_{SS}$  (with P6)

- In case of faulty 'frequency processing 2':  
 → replacement by spare subassembly  
 → or repair in accordance with Section 6.3.

5.3.2. Cassette 'frequency processing 1'

- f1 to X 2002 (rear of the plug-in)

. Check of frequency (with P1) and voltage (with P2) for the subranges of oscillator 1

Range of csc. 1	$f_D$ input (kHz)	f1 (kHz)	admissible fault $\Delta f$ (Hz)	$u_{f1}$ across 50 ohm (mV)
1a	0.00 1999.00	70200.00 72199.00	$\cong \pm 150 *$	80 ... 100
1b	2000.00 9999.00	72200.00 80199.00		
2	10000.00 29999.00	80200.00 100199.00		

Check of f1 with potential conversion of all logic conditions for the drive of 'frequency divider 1'

f <sub>E</sub> input (kHz)	f1 (kHz)	admissible fault Δ f1 (Hz)
17700.00	87900.00	} ≅ ± 150 *
28800.00	99000.00	

\* Δ f1 = Δ f70 ≅ 150 Hz

Δ f70 is eliminated with the 2nd frequency conversion (mixer 2)

- f 70 to X 2001 (rear of the plug-in)

Check of frequency (with P1) and voltage (with P2)

f70	70 MHz ± ≅ 150 Hz
u <sub>f70</sub>	80 mV to 100 mV


- In case of faulty 'frequency processing 1':

→ replacement by spare subassembly

→ or repair in accordance with Section 6.3.

Precondition: 'power supply section' } troublefree  
 'control unit' }  
 'frequency processing' }

5.4.1. Check 'signal path 2' with 200 kHz from 'frequency processing 2'




- 'signal path 2' in order: E<sub>γ</sub> display .. LED row: 80 to 100 dB (μV)  
 digital: 42 ... 52  
 A1 tone available

- 'signal path 2' faulty:

- replace it by spare subassembly  
 (readjustment: tolerance minimization for E<sub>γ</sub> display according to Section 6.2.)
- or repair in accordance with Section 6.4.

5.4.2. Check 'signal path 1' and '2' with 200 kHz from 'frequency processing 2'




- 'signal path 1' and '2' in order:  
 E<sub>γ</sub> display: .. LED row: approx. 60 dB (μV)  
 digital: 28 ... 35

A1 tone available

- 'signal path 1' faulty:
- replacement by spare subassembly  
(readjustment: tolerance minimization for E<sub>y</sub> display according to Section 6.2.)
- or repair in accordance with Section 6.4.


5.4.3. Check 'signal path 1 - subsections'  
 5.4.3.1. Mixer 2 → X 3002 → signal path 2



- Signal path 1 - subsections in order:
- E<sub>y</sub> display . LBD row: 80 ... 90 dB (μV)
- . digital: 38 ... 45
- A1 tone available

- Signal path 1 - subsections F70 ampl. → mixer 2 → X 3002: faulty
- replace signal path 1 by spare subassembly  
(readjustment: tolerance minimization for E<sub>y</sub> display according to 6.2.)
- or repair in accordance with Section 6.4.

5.4.3.2. Mixer → IF-1 ampl. → Mixer 2 → X 3002 → signal path 2






- Signal path 1 - subsection in order:  
 $E_{\gamma}$  display . LED row: approx. 90 dB ( $\mu$ V)  
                               digital: 42 ... 48  
 A1 tone available


- Signal path 1 - subsection: f1 ampl. → mixer 1 →  
 OF1 ampl → 70.2 MHz crystal filter: faulty  
     → replace signal path 1 by spare subassembly  
       (readjustment: tolerance minimization for  
        $E_{\gamma}$  display according to Section 6.2.)  
     → or repair in accordance with Section 6.4.

5.4.3.3. Preselector 1 and 2 → control element 1 → mixer 1 →  
 IF1 ampl. → mixer 2 → X 3002 → signal path 2



- Signal path 1 in order:  
 $E_{\gamma}$  display . LED row: approx. 100 dB ( $\mu$ V)  
                               digital: 47 ... 53  
 A1 tone available
- Signal path 1 - subsection:  
 X 3004 → preselector 1 and 2 → control element →  
 → TP = 30 MHz: faulty  
     → Replace signal path 1 by spare subassembly  
       (readjustment: tolerance minimization  
       for  $E_{\gamma}$  display according to 6.2.)  
     → or repair in accordance with Section 6.4.


6. Repair of the faulty subassembly



86-038

Figure 4

Service work on the cassettes of the signal path (SW1 and SW2) or on the cassettes of the frequency processing (FA1 and FA2)



86-039

Figure 5

Unit arrangement for service work on the power supply section

Master Library  
Digitized by  
US Army  
Library

Library  
US Army  
Library

6.1. Power supply section 1340.039-01500

6.1.1. Input and output values

EKD:  $f_E = 2.00$  kHz

B<sub>R</sub>BB, channel A

medium volume,  $I_{\square} = 40$  mA

Power consumption of the entire unit

Current measurements with PB at  $U_{\text{rated}}$  in the mains- or battery lead.

All indicated current values are approximate ones.

Mains operation:       $\sim 127$  V ac      :      approx. 400 mA  
                          $\sim 220$  V ac      :      approx. 230 mA

Battery operation:     $= 24$  V dc      :      approx. 1.5 A  
                          $= 12$  V dc      :      approx. 3.0 A

Output voltages

For measuring or correction:

Operate the plug-in outside the casing via the 30-core adapter cable (accessories).

Measurement with P6 at the measuring points according to Figure 1

+18 V      :      at X1001/A7, B7

+22 V      :      at X1003/A7, B7

-12 V      :      at X1003/A5, B5

+5 V      :      at X1004/A1, A2

Line corrections only after an operating time of the receiver of = 30 min.

+18 V       $\pm$       100 mV      correction with R 5213      (I = approx. 650 mA)  
+5 V       $\pm$       20 mV      correction with R 5217      (I = approx. 1.2 A)  
-12 V       $\pm$       50 mV      correction with R 5114      (I = approx. 250 mA)  
+22 V      -      2 V      -      -      (I = approx. 70 mA)

Check current load before every correction.

### Hum voltages of the output voltages

The ripple is to be measured with load and 220 V ac input voltage by means of P6 (peak-to-peak value).

+18 V path	:	≅ 30 mV	(20 kHz)
+5 V path	:	≅ 50 mV	(20 kHz)
-12 V path	:	≅ 20 mV	(100 Hz or noise)
-22 V path	:	≅ 50 mV	(20 kHz + 100 Hz)

### Centro. behaviour

With change of the input voltage by  $\pm 10\%$ , the variations of the individual output voltages - measured with P9, amount to:

+18 V path	:	$\Delta U = 60$ mV
+5 V path	:	$\Delta U = 20$ mV
-12 V path	:	$\Delta U = 10$ mV

The input voltage variation is to be simulated with the adjustable transformer (P 12).

### 6.1.2. Measuring values within the power supply divider

measured with mains operation 220 V and load

### Rectifier voltages

+18/+5 V path

(measured at C 5903) : approx. 30 V

-12 V path

(measured at C 5105) : approx. 20 V

Additional voltage for 22 V path

(measured at C 5108) : approx. 4 V

### Overcurrent limitation

The +18 V-, +5 V-, and -12 V path are provided each with a permanently adjusted current limitation.

This current limitation is to be checked by an additional load (slide resistor (R1) 100  $\rightarrow$  0 ohm).

Path	Sweep current	s-c current
+18 V path	approx. 2 A	≅ 2.5 A
+5 V path	approx. 3 A	≅ 4 A
-12 V path	approx. 0.4 A	≅ 0.25 A

Shorting the +18 V- and +5 V paths causes switching controller noises in the audible range.

Curve shape

At the test points P01 to P06 indicated in the circuit diagram the prescribed curve shapes shall be detected with P6.

Working frequency


The transverter operates at rated voltage with a frequency of roughly 80 Hz.

It greatly depends on the input voltage.

The switching controller is to be adjusted to 20 kHz  $\pm$  3 kHz by means of R 5227.

Closing behaviour

The unit-specific time sequence of the partial voltages in case of ON and OFF switching is the precondition for the functionality of the control unit.



$t_{y1}, t_{y2}$  = delay time of ON and OFF switching

When  $t_{y1}, t_{y2}$  is not kept, the power supply needs repair.

26

### 6.1.3. Troubleshooting table

Fault	Possible fault reason	Fault elimination
<p>a) Transverter does not start to oscillate</p>	<ul style="list-style-type: none"> <li>- False voltage protection responds</li> <li>- V5101, V5102 faulty</li> <li>- Contact troubles at K5001/5002</li> <li>- Contact troubles at circuit closer on front plate</li> <li>- Overload at secondary end</li> </ul>	<ul style="list-style-type: none"> <li>- viz. b)</li> <li>- Replace V5101, V5102</li> <li>- Replace K5001, K5002</li> <li>- viz. c)</li> <li>- causes increased power consumption with mains operation.</li> </ul>
<p>b) False voltage protection responds</p>	<ul style="list-style-type: none"> <li>- Battery voltage does not comply with the voltage adjusted on the terminal board X 5002.</li> <li>- Component in the protective circuit faulty</li> </ul>	<ul style="list-style-type: none"> <li>e.g. V 5107, V 5106, V 5103, K 5101</li> </ul>
<p>c) Starting aid for oscillation not excited (C 5101 not charged or not discharged with connection or disconnection)</p>	<ul style="list-style-type: none"> <li>- Interruption in the oscillation-start circuit</li> <li>X 5001/b3(+)-</li> <li>k 02/7/5/11/13-</li> <li>R 5111-V 5110-</li> <li>circuit closer (on front plate)</li> </ul>	

Fault	Possible fault reason	Fault elimination
d) F 5101 responds	<ul style="list-style-type: none"> <li>- Overvoltage in the +5 V- or +18 V path</li> </ul>	<ul style="list-style-type: none"> <li>- Disconnect load in the unit (e.g. TTL circuits) - dissolder connections 6 and 7 on pc board 51 - check if an exceeding voltage presents at the output of one of the two paths. In this case e.g. transistor V 5101 or V 5102 or the control (MAA 723) is faulty.</li> </ul>
	<ul style="list-style-type: none"> <li>- Short in the circuit</li> </ul>	<ul style="list-style-type: none"> <li>- Separate load and check if the fuses keep responding. In this case e.g. V 5212, V 5214 or transistor insulation faulty.</li> </ul>
	<ul style="list-style-type: none"> <li>- Overvoltage protection circuit faulty</li> </ul>	<ul style="list-style-type: none"> <li>- e.g. V 5107, V 5108 or V 5109 (thyristor)</li> </ul>
e) Noise caused by switching controller	<ul style="list-style-type: none"> <li>- Sawtooth generator (V 5210, V 5207) faulty</li> </ul>	<ul style="list-style-type: none"> <li>- Check curve shapes at P 01, P 02. Trace signal up to circuit connection 3</li> </ul>

Fault	Possible fault reason	Fault elimination
c) Output voltage of the -12-V-path too high	- V 5001 faulty - N 5101 faulty	
d) Frequency of rectifier hum voltage amounts, with mains oper., to 50 Hz instead of 100 Hz	- One rectifier branch of the respective rectifier faulty	- Measurement at C 5105: -12-V path C 5108: Additional voltage for 22-V path C 5003: +5-V path +18-V path




Figure 6  
Power supply section 1340.039-01500



Stromversorgungsteil (Seitenansicht)  
1340.039-01500

(50)




Figure 7  
Power supply section 1340.039-01500

## 6.2. Control unit

### 6.2.1. Function principle

After switching on the unit as well as after mains failure the microcomputer is brought in the initial position and the receiver is adjusted to its condition before the disconnection or mains failure.


Subsequently, a program for multiplexer control of the display is initiated.

All operating measurements carried out via keyboard or 24-V interface cause via port A an interruption of the PIO circuit.

Mains failure and test routines are controlled via the non-maskable interrupt input of CPU. The RAM circuits of the control computer are backed by an internal battery.

In case of a total breakdown, it is recommended to start troubleshooting in the computer core because fault detecting is supported by the software. The following sequence is to be adhered to:

Control computer - input-output logic - keyboard - display - register and interface.






Figure 8 Control unit Front view

35




Figure 9  
Control unit - view from above

86 - 036 a

Wenn Eigentum  
Militär ist  
es wird zerstört

## 6.2.2. Test and check arrangements

### - Control unit inserted

The following components of the plug-in are accessible from above:

- R45145 ... R45147 to balance the control voltage linearization (cf. Section 6.2.9.)
- X4701, X4702 to check and repair the keyboard (cf. Section 6.2.7.)
- Strip 01-02 (RESET) on input-output logic.

Open the receiver front plate, remove screening. The control unit is accessible from the soldering side of the register and interface.

On the soldering side of the control computer  $U_{RAM}$  can be checked at CA408.

### - Control unit removed

By means of connection adapter P15 the control unit can be operated from an external mains unit; +5 V, +18 V, -12 V,  $\perp$

### - Check of display and keyboard

Open the front plate of the plug-in, slacken the plug-and-socket connections X4501-X1023 and X4505-X1022, take off the control unit and place it upright such that the plug-and-socket connections can be reestablished again. The complementation side of the display is accessible. If necessary, unscrew the cover.

### - Check of control computer and input-output logic

Take off the control computer; establish connection plug-in X1023 - input-output logic X4303/04/05 by means of adapter cable P14. The complementation side of the control computer and the input-output logic is accessible.

Connect P14 with P15 when power supply is to be performed from an external mains unit.

6.2.3. Repair sequence 'local operation'




Figure 10

35

6.2.4. Repair sequence Operation 'external'





Figure 11

1) The unit is to be programmed in advance as 'slave'.

39

### 6.2.5. Control computer

- Operating voltages

+5 V at D04/11,  $U_{RAM}$  at C08 (cf. Section 6.2.6.  $U_{RAM}$  changeover)

- Input signals of CPU

$\overline{BUSRQ}$ ,  $\overline{WAIT}$ ,  $\overline{RESET}$ ,  $\overline{NMI}$ ,  $\overline{INT} = 1$  ( $\approx 3.5$  V)

Clock at D04/6  $\square\square$  1.2 MHz  $U_{high} \approx 4.8$  V,  $U_{low} \approx 0.5$  V

- CPU bus and store selection signals

Open wire strap 03-04, establish connection 04-13.

Cyclic program call is performed. The data bus, the address bus and the control bus of the CPU can be oscillographically checked concerning correct low-high signal change. With this, also the connections of the bus lines to the circuits as well as shorts can be checked.

Signal	$U_{low}$	$U_{high}$
D0 ... D7	} $< 0.7$ V	3.5 V
A0 ... A3		> 3.5 V
A4 ... A15		> 2.5 V
M1, RD, WR, MREQ, RFSH		> 2.5 V
CS0 test point 03		> 2.5 V
CS1 R07		> 3.5 V
CS2 test point 05		> 2.5 V
CS3 test point 07		> 2.5 V
CS4 test point 09		> 2.5 V
CS5 test point 11		> 2.5 V



- Software-aided checks

(cf. equipment documentation Section III/5.2.)

a. Test (key  EXT and  EXT PCT )

This test, an NMI access to the CPU, checks the function of the input gate PIO port A, i.e. it is tested if the data are read. Furthermore, the function of the EPROMs are checked, i.e. if data are put out.

Troublefree function:

All keys are open (PA 6...PA 0 = 78 H), serial input in STOP condition (PA 7 = 1). All EPROMs supply data.

Display: AA-A0 last receive condition. In condition AA a program loop is running cyclically. It is possible to check oscillographically the CPU signals  $\overline{IOMQ}$ ,  $\overline{NERQ}$ ,  $\overline{M1}$ ,  $\overline{RD}$ ,  $\overline{WR}$ , and the decoder signals CS 0 ... CS 5.

Malfunctioning:

The key code of a faulty key is indicated or PA 7 is not in STOP condition or port A of the PIO does not work.

Display 01 indicates: EPROMs by switching further with key  (01, 02 ...); the faulty EPROM does not appear on the display but any display as e.g. FF. Consider the departure from the correct sequence.

b. Test A4 RAM test

Results: FF, F1, F2

FF = troublefree, F1 = RAM 1 (D 4405) faulty,  
F2 = RAM 2 (D 4406) faulty.

c. Test A5 ROM test

Results: FF, F1, F2, F3, F4

FF = troublefree, F1 ... F4 = faulty EPROM D 4408 ... D 4411.

Attention

Individual EPROMs must not be exchanged.

When a component - circuits D 4408, D 4409, D 4410, D 4411, (D 4412) - has proved itself to be faulty, the entire pc board control computer 1340.041-01454 is to be replaced.


6.2.6. Input-output logic

Test sequence:

- RESET and NMI generation
- RAM changeover
- Input-output gate addresses and assigned output signals
- RESET and NMI generation


unit switch ON/OFF, check voltage curve with double-beam oscillograph P5

+5 V and +18 V




When these conditions are not met — repair power supply in accordance with Section 6.1.


NMI and RESET



RESET pulse











NMI pulse



- U<sub>RAM</sub> changeover

Unit switch	U <sub>RAM</sub> to C 4408
ON	+5 V from power supply
OFF	+ (3.6 ... 4.1)V from support battery

- Input-output gate addresses and assigned output signals

Input	Output	Pulses to be checked	Output signals
Test	AA	$\overline{30H}$ at D 4302/12 	
Test A1	8 ... 8	$\overline{10H}$ at D 4302/14 $\overline{20H}$ at D 4302/13 	a1 ... g1 a2 ... g2 p1, p2 St0 ... St4 X 4301 2.)
Test A2 Key EXT	00	$\overline{30H}$ at D 4303/12 Oscillogram without synchronization U 2.5 V	
Test-A3	A3 00	$\overline{10H}$ at D 4302/14 $\overline{20H}$ at D 4302/13  $\overline{50H}$ at D 4302/10 	a1 ... g1 a2 ... g2 St0 X 4301 (3.4 ... 4.3)V 
Test A6	A6	$\overline{40H}$ at D 4302/11 	D0 ... D7 to X 4303/1...8 A0 ... A2 at X 4304/6,7,8 

1) of. Section 6.2.9. V24 interface/example 2

2) of. Sections 6.2.8. and 6.2.9.

6.2.7. Keyboard  
Output signals.

Figure 12.

Taste	Hexa- code	847017								847027		µs
		1	2	3	4	5	6	7	8	9	10	
		PA6	PA5	PA4	PA3	PA2	PA1	PA0	IB	III		
EXT	00	U	U	U	U	0	0	0	1	1	} 3 ms	
MOD	6d	1	1	U	1	1	0	1	1	1		
9	62	1	1	U	U	0	1	0	1	1		
4C	67	1	1	U	U	1	1	1	1	1		
DEL	76	1	1	1	U	1	1	0	1	1		
EXT FCT	20	0	1	0	0	0	0	0	0	1		
SCAN FCT	61	1	1	U	U	0	1	1	1	1		
SCAN	6C	1	1	U	1	1	0	0	1	1		
	64	1	1	U	U	1	0	0	1	1		
	66	1	1	U	U	1	1	0	1	1		
CALL 99	21	U	1	U	U	0	0	1	0	1		
CALL 90	22	U	1	U	U	0	1	0	1	1		
CALL	63	1	1	U	U	0	1	1	1	1		
510	73	1	1	1	U	0	1	1	1	1		
	65	1	1	U	U	1	0	1	1	1		
	30	U	1	1	U	0	0	0	1	1		
	31	U	1	1	U	0	0	1	1	1		
	32	U	1	1	U	0	1	0	1	1		
	33	U	1	1	U	0	1	1	1	1		
	34	U	1	1	U	1	0	0	1	1		
	35	U	1	1	U	1	0	1	1	1		
	36	U	1	1	U	1	1	0	1	1		
	37	U	1	1	U	1	1	1	1	1		
	38	U	1	1	U	0	0	0	1	1		
	39	U	1	1	U	0	0	1	1	1		
	2E	U	1	U	1	1	1	0	1	1		
	3b	U	1	1	1	0	1	1	1	1		
EXT EXT FCT	00	0	0	0	0	0	0	0	0	0		
	20	U	1	U	1	0	11	11	1	1		
	24	U	1	U	1	11	0	11	1	1		
keine Taste	70	1	1	1	1	0	0	0	1	1		

3 ms

0,5 ms

Für jede Taste kann der Code stattdessen erzeugt werden, wenn gleichzeitig die Taste EXT FCT gedrückt wird.  
Code can be generated for each key if EXT FCT is pressed simultaneously


\* wird verbleibt.

- Low/high levels


Static L/H levels are to be provided at the outputs by depressing the respective key. Checks should be performed according to the scheme below.

Outputs		Low		High	
		Key	Level	Key	Level
X 4701/8	$\overline{TR}$	"CALL 99"			
7	PA 0	"EXT" and "EXT FCT"	-0.5 V	"7"	>4.0 V
6	1				
5	2				
4	3				
3	4				
2	5				
1	6				
X 4702/6	$\overline{TN}$				

- Pulse generation




Key pulse



L/H level

Test point	L (V)	H (V)
X 4701/1 PA 6	< 0.5	> 4.5
7 PA 0	< 0.5	> 4.5
8 TR	< 0.5	> 3
X 4701/6 TN	< 2.6	> 3

- Pulse diagram for rotary pulse generator



6.2.8.

- Digital display

Voltage curve in test A1

Segment	Test point at X 4601	$\hat{U}$	
a1 ... g1	A4, B3, B13; B12 A13, A3, B4	~3.4 V	
a2 ... g2	A1, A2, A11, A12 B11, B2, B1		
p1, p2 St0...St4	A5, B10 A8, B9, B7, A10 B8	~4.3 V	
LED EXT	A9	~4.3 V ~4.7 V	

- LED row

Voltage values

Position S 4001	U at input	Point	U at point 15	Lighting LED
$\Delta F \times 1$	0 V	04	2.7 V <sub>=</sub>	V 17
$\Delta F \times 2$				V 17
E $\gamma$	4.8 V <sub>=</sub>	19		V 17
U <sub>AF</sub>	1.4 V <sub>~</sub> (1 kHz)	03	4.7 V <sub>=</sub> (1)	V 22

1) correction with R 4631

Check entire row with test A3 according to the Equipment documentation Section III/5,

S 4001 to E $\gamma$

0.2.3. Register and interface

- Register and interface matrix

The receiver setting is stored in the 12 register circuits D 4504 to D 4515 that form the register and interface being arranged as matrix (7 rows/8 columns). The rows are the addresses, the columns the data.

Assignment of the circuit function

A \ D	7	6	5	4	3	2	1	0
1	D 4505 100Hz				D 4504 10Hz			
2	D 4707 10 kHz				D 4506 1 kHz			
3	D 4509 1 MHz				D 4508 100 kHz			
4					D 4510 10 MHz			
5	D 4512 MOD				D 4511 B			
6	D 4514 SEL				D 4513 SEL			
7					D 4515 GC			

Example

Short-time reaction at  $\Delta F \approx 1 \text{ kHz}$

Setting

73 B 12345.67

SEL 1

GC 4

A \ D	7	6	5	4	3	2	1	0
1	0	1	1	0	0	1	1	1
2	0	1	0	0	0	1	0	1
3	0	1	0	0	0	1	0	1
4	0	0	1	0	0	0	1	1
5	0	1	1	1	1	1	0	0
6	0	1	1	0			0	1
7						1	0	0

Note:

Data for B stored in inverted form. The letterings on the lines at the outputs of the register circuits correspond with this matrix.

48



Example: 3/5 means address 3/data bit 5, i.e. bit 2<sup>1</sup> of the 1-Hz digit of the frequency.

- The frequency data correspond with the decimal places in the 8-4-2-1 code. Output is performed via drivers D 4516 to D 4520. The output lines are marked in accordance with the decimal points. The levels are CMOS levels.

Example: Setting to 1.23 kHz

Frequency	x 1 kHz				x 100 Hz				x 10 Hz			
	d3	c3	b3	a3	d2	c2	b2	a2	d1	c1	b1	a1
Logic condition	0	0	0	1	0	0	1	0	0	0	1	1
X 4501	B20	B19	B18	B17	B24	B23	B22	B21	B28	B27	B26	B25

- The selector data are derived automatically from the frequency i.e. the interconnection is contained in the ROM test. The output lines go directly out from the store circuits; the voltages are CMOS levels. For MOD, B and GC the store data are decoded and logically connected. The output signals are generated via driver stages.

- Check of the register and interface outputs

Precondition: Input and display in order. Input signals A0...A2 at X 4503 and D0...D6 at X 4504 available, if not, check 40 H at input-output logic (cf. Section 6.2.6.).

Correct display does not indicate proper output of the register and interface.

Checking the outputs is performed with test A6

Setting

A6


(test 6)

With key  switch digits 00 to 99 further ones after the other; Check with this the logic conditions at the soldering side according to the table for register and interface test. (cf. Fig. 13) Observe the following:

X 4501/a 16 This point lies next to +18 V  
Be cautious with test prod.

X 4505/B7 }  
/B9 } Check of the logic conditions with pull-up  
resistance 3.3 kohm to 10 kohm

X4505  
B7, B9



X 4501/A 16 }  
X 4505/B5 }  
/B9 }

At these points, carry out an additional check of the short-time reaction at  $\Delta F \approx 1$  kHz.

Table Display in testing procedure

	Measur. point	Register and interface test										Level 0/1	
		00	11	22	33	44	55	66	77	88	99		
F	X4501/B3	0	0	1	1	0	0	1	1	0	0	$\approx 0,8V / \approx 2,4V$	
	B4	0	1	0	1	0	1	0	1	0	1		
	Code 8421 corresponds to d o b a												
	x 10 Hz	B25	0	1	0	1	0	1	0	1	0		1
	B26	0	0	1	1	0	0	1	1	0	0		
	B27	0	0	0	0	1	1	1	1	0	0		
	B28	0	0	0	0	0	0	0	0	1	1		
SEL	X4501/A26	0	1	0	1	0	1	0	1	0	1	$\approx 0,5V / \approx 4,5V$	
	A27	0	0	1	1	0	0	1	1	0	0		
	A28	0	1	0	1	0	1	0	1	0	1		
	A29	0	0	1	1	0	0	1	1	0	0		
	B29	0	0	0	0	1	1	1	1	0	0		
MOD	X4501/A25	0	1	0	0	0	0	0	0	0	0	$\approx 0,2V / \approx 17,5V$	
	A24	0	0	1	0	0	0	0	0	0	0		
	A23	0	0	0	1	0	1	0	0	0	0		
	A22	0	0	0	1	0	1	0	0	0	0		
	A21	0	0	0	0	1	0	1	0	0	0		
	A20	0	0	0	0	0	1	1	0	0	0		
	A19	0	0	0	0	0	0	0	1	1	0		
	A18	0	0	0	0	0	0	0	0	0	1		
	A17	0	0	0	0	0	0	0	1	1	1		
A16	0	0	0	0	0	0	0	0	1	1			
B	X4505/B1	0	1	0	1	0	1	0	1	0	1	$\approx 1V / \approx 6V$	
	B2	0	0	1	1	0	0	1	1	0	0		
	B3	0	0	0	0	1	1	1	1	0	0		
	B4	0	0	0	0	0	0	0	0	0	1		
	B5	0	0	0	0	0	0	0	0	0	1		
GC	X4505/B7	0	1	0	1	0	1	1	1	1	1	$\approx 0,2V / \approx 3V$	
	B8	1	0	0	1	1	1	1	1	1	0		
	B9	1	1	1	1	1	0	1	1	1	0		

Figure 13

- Short-time reactions

In case of frequency changes of  $\approx 1$  kHz the control computer supplies the output GC = 8 that initiates through the monostable flipflop (D 4523) a dynamic behaviour of lines FS 1/0,  $\downarrow$  and  $U_{block}$ . A short lighting up of V 4623 (right LED) presents in the LED row.

Setting 73 E 0.00  $dF \approx 1$  kHz

Test point	Line	Pulse	Condition
X 4501/A 16	FS 1/0		MOD 8 or 9
X 4505/B9	$\downarrow$		GC $\neq$ 5
X 4505/B5	$U_{block}$		

$T = 125 \dots 155$  ms

- Receive blocking (cf. Equipment documentation, Section II/2.7.)

The blocking signal of  $+ (3 \dots 15)$  V at X 0013/X 0014 and bandwidth B = 9 have the same effects:

Test point	Line	Logic condition	Level
X 4505/B4	5/3	1	$\approx 1$ V / $\approx 6$ V
X 4505/B5	$U_{block}$	1	$\approx 1$ V / $\approx 6$ V
X 4501/A16	FS 1/0	0	$\approx 0.2$ V / $\approx 12$ V

- SCAN STOP

The control signal at X 0015/X 0016 acts via N 4501/8 and D 4501/4 on PB  $\emptyset$ .

Function	$U_{-}$ at X 0015/X 0016	PB $\emptyset$ at X 4502/6	Level 0/1
SCAN	-15 V ... +0.8 V 1)	1	$\approx 4.5$ V
SCAN STOP	+3 V .. +15 V	0	$\approx 0.5$ V

1) Control signal -15 V ... +8 V is equivalent to 'sockets open'.

5/1

Precondition: Function of the signal path in order.

Setting 1 16 E 0.00 GC 1

Set  $f_{AF}$  to 1 kHz with A1  $\approx$

Set  $U_{AF}$  to 0 dB<sub>m</sub> (0.77 V) at X 1020/A - B with  $\approx$

Frequency F = 1.50 kHz

Check if  $U_{AF} \approx -12$  dBm

Setting 2 48 E 1.00 GC 1

$U_{AF}$  to 0 dBm as above

Frequency F = 2.50 kHz

Check if  $U_{AF} \approx -3$  dBm

If  $U_{AF}$  is not adjustable or in case of distortions, check level with setting 1:

Incoming AF voltage at X 4505/A 13 ~ 0 dBm (0.77 V)

outgoing AF voltage at X 4505/B 13 ~ -12 dBm (0.2 V)

Checking and balancing the control voltage linearization

Precondition: Function of the signal path in order.

Do not unscrew front panel of the plug-in; balancing elements are accessible from above (cf. Figure 9). Balancing requires feeding of a defined aerial signal with calibration level. Use aerial socket X 0001 at the casing rear;  $Z = 75$  ohm. The voltages to be supplied are emf ratings.

Setting 47 E 4500.00 GC 1, SEL 0

Frequency setting on test oscillator 4501.00 kHz

Make use of A3, perform balancing according to the table below:

Aerial emf	Number	Balancing element	Remarks
30 dB ( $\mu$ V) $\approx$ 32 $\mu$ V	15	R 45 145	} alternating until residual error = 0
90 dB ( $\mu$ V) $\approx$ 32 mV	45	R 45 146	
10 dB ( $\mu$ V) $\approx$ 3.2 $\mu$ V	05	R 45 148	
120 dB ( $\mu$ V) $\approx$ 1 V	60	R 45 147	

Check by repetition


In balanced condition, the display fault amounts in digits to  $\pm 2$ , i.e. to  $\pm 4$  dB ( $\mu$ V).

- V-24 interface

Lines

- 101 Protective earth
- 102 System earth
- 103 Transmitting data to data transmission equipment (DUE)
- 104 Receiving data from DUE
- 105 Request to transmit to DUE
- 106 Ready for transmission from DUE

. Schematic circuit diagram




Setting test A2

Double-beam oscillograph

B channel at line 1/103, X 0005/E - A, B (⊥) } A channel  
 A channel at line 1/105, X 0005/C - A, B (⊥) } synchronizes  
 B channel


Oscillograph pulse curve

Example 1 Key 1 , 31 H



If no double-beam oscillograph available, select key EXT , 00 H. Oscillograph lines 1/103 and 1/105 separately.

Example 2 Key EXT , 00 H




If no pulses can be detected, trace the signal back up to X 4501

Line 1/103 X 4501/A2, line 1/105 X 4501/A 4

6.3. Frequency processing


6.3.1. Troubleshooting sequence

The test programs for troubleshooting are given in the following in accordance with the principle of frequency processing. Each program starts with indication of the fault, e.g.




that means that frequency f2/100 is wrong, the 1-kHz signal correct.

After that, different test measurements are carried out which are indicated as abridged questions, e.g.




that means that the voltage or the voltage curve Uf2/ are available as represented in the General diagram.

The measurements indicate which component is to be checked. The required test program or test instructions are given, e.g. PLL2



For each test program the measuring points are given in the opposite diagrams.


The test program is terminated with the information that the component to be tested is troublefree, e.g.



Vierzigste  
Fälligung  
i. wird verfertigt.

# 6.3.2. Frequency processing - outline.


1 Programm für die Fehlersuche




2  
 1. Schritt = Frequenz für sich  
 an diesem Punkt werden die  
 unterschiedlichen Teilfrequenzen

2 Vereinfachter Übersichtsschaltplan - Frequenzen und Pegel

35 Frequenzabstimmung 1



PLL1 PLL2 PLL3 PLL4



Bedienwert 334000: 0:0:0

- 14 \* 334000 = 11380000
- 15 \* 334000 = 5000000
- 16 \* 334000 = 10000000
- 17 \* 334000 = 5000000
- 18 \* 334000 = 10000000
- 19 \* 334000 = 5000000
- 20 \* 334000 = 10000000
- 21 \* 334000 = 5000000
- 22 \* 334000 = 10000000
- 23 \* 334000 = 5000000
- 24 \* 334000 = 10000000
- 25 \* 334000 = 5000000
- 26 \* 334000 = 10000000
- 27 \* 334000 = 5000000
- 28 \* 334000 = 10000000
- 29 \* 334000 = 5000000
- 30 \* 334000 = 10000000

35  
 Frequenzabstimmung - Übersicht







Figure 14  
 Frequency processing 1 1340.041-01211

57

# 6.3.3. Phase-lock loop 1 (PLL1)


7 Prüfprogramm PLL1




f1	700	700	700
f2	100	100	100
f3	100	100	100
Δf1	100	100	100
Δf2	100	100	100
Δf3	100	100	100

Bereich	f1 in kHz	f2 in kHz	f3 in kHz
1	100	100	100
2	100	100	100
3	100	100	100
4	100	100	100
5	100	100	100
6	100	100	100
7	100	100	100
8	100	100	100
9	100	100	100
10	100	100	100
11	100	100	100

12 Blockschaltbild PLL1



21 Synchronisierter Zustand



22 Phasenspektren (PLL1)

130

(1) synchronisierter Zustand






Figure 15


Positions of test points PLL1

# 6.3.4. Oscillator 1

## 2) Arbeitsweise des Frequenzdiskriminators




## 3) Impulschema des Frequenzdiskriminators



Oszillator 1

## 7) Kontrolle des Frequenzdiskriminators (Frequenzhilfe)

3 C1, 302, 303, V10, V11, u. V12  
 Brücke 09...10 öffnen  
 Brücke 11...12 öffnen  
 an 12 ca. +3 V anlegen (C15 hat Zenerdioden-Spannung)



Brücke 09...10 öffnen  
 Brücke 11...12 öffnen  
 mit 2225 einarbeiten

Abgleich der Oszillatordfrequenz  
 Form 2225, V2125, V2125 oder V2125 verwendet werden. Ist die  
 Abgleich der Oszillatordfrequenz notwendig, der Abgleich erfolgt im Bereich 1  
 mit C24 und im Bereich 2 mit C34 durch Wechseln der Kondensatoren.  
 Abgleichbedingungen (mit Abgleich-Kappe gemessen):

Frequenz-Einstellung	Ug an Zkt. 11/P. 8, Z. 3
1. 10 000 00	2,7...2,9 V - U (1.)
2. 30 000 00	< 14 V
3. 31 000 00	Synchronisiert?
4. 00 000 00	U (1.) - 0,2 V
5. 09 999 99	9...11 V

Abgleich des Frequenzdiskriminators  
 Einstellen mit R2125  
 U<sub>p</sub> 7...10 V an Zkt. 15...18 bei f<sub>e</sub> 20 000 00  
 Oszillogramm an C2108 und R2117 beschalten!

Test sequence

No output voltage f1

1. UC45 or UC47
2. U 1 (15...18)
3. J81 (12)
4. Does oscillator work?

Control circuit does not synchronize (06)


1. Operating voltages
2. 50 kHz (ref) (05)
3.  $\Delta F1/2N1$  (07)
4. U f 4 (15...18)
5. U81 (12)
6. Open bridge 11...12, apply approx. +8 V dc to 12, synchronize with frequency switch '10 MHz' and '1 MHz'
7. Check capture aid and N 02
8. Balance phase discriminator

# 6.3.4. Oszillator 1

5  
 Prüfplan

Keine Ausgangsspannung 71

1. UC45 bzw. UC47
  2. U1 (45..18)
  3. U51 (12)
  4. schwingt Oszillator 7
- 
1. Espektroskopische Messung (06)
  2. Schwingungsmessungen
  3. 50 kHz (Rec) (07)
  4. AP1/200 (07) (45..18)
  5. 100
  6. Spannung 11..12 werden, um 12 ca. 16V anzulegen, die Frequenzmessung mit dem Oszilloskop durchführen und die Frequenz auf 100 kHz einstellen
  7. Abgleich Plattenabstände



Check of the frequency discriminator (capture aid)

D01, D02, D03, V10, V11 and V12

Open bridge 09 ... 10

Open bridge 11 ... 12

Apply approx. +8 V dc to 12 (suitable voltage applied to C1E)

f <sub>e</sub>	f <sub>1</sub> /N <sub>1</sub>	D03		09
		Pin 9	Pin 5	
10 000 00	> 50 kHz			< 1 V
30 000 00	< 50 kHz			> 14 V

Check of the amplifier N 02

Open bridge 09 ... 10

Open bridge 11 ... 12

Adjust with R 2125

$U_{\text{pin 4}} \gg U_{\text{pin 5}} \longrightarrow U(11) < 2 \text{ V}$

$U_{\text{pin 4}} \gg U_{\text{pin 5}} \longrightarrow U(11) > 13 \text{ V}$

Balancing the oscillator frequency

After replacing V 2125, V 2126, V 2128 or V 2129 the oscillators have to be balanced. Balancing is performed in range 1 with C24 and in range 2 with C34 by exchanging the capacitors.

Balancing conditions (had measurement been performed with screening cap?)

Frequency setting	$U_S$ at point 11 P 8, R <sub>1</sub> 3 Mohm
1. 10 000 00	2.7 ... 2.9 V = U (1.)
2. 30 000 00	< 14 V
3. 31 000 00	synchronized ?
4. 00 000 00	U (1.) - 0.2 V.
5. 09 999 99	9 ... 11 V

Balancing the phase discriminator


Setting with R 2125

$U_{\varphi} = 7 \dots 10 \text{ V}$  at point 15 ... 18 at  $f_E = 20 000 00$

Observe oscillogram at C 2108 and R 2111


# 6.3.5. Frequency divider 1

1 Prüfprogramm Frequenzteiler 1




- 2 Prüfe und repariere 2N1: 1-Teiler
- Verstärker
- Rücksetzzeit
- Zähler
- Frequenzeinstellung
- instabile
- Frequenz

10 Lage der Meßpunkte



3 Kods für Oszillator 1-Bereiche





7 Prüfung des Einstellbaren Frequenzteilers 1

-Rücksetzeinheit (3:1-Teilung)

- Züchen 2-3 offen
- 4-5 verbunden
- 6-7 offen
- 8-9 verbunden

Teil an 0/15  
R1A an 0/5  
R1B an 2

U<sub>eff</sub> = 50 mV

-Zähler

- U<sub>eff</sub> = 200
- Züchen 2-3 offen
- 4-5 offen
- 6-7 offen
- 8-9 verbunden

U<sub>eff</sub> = 50 mV

-Frequenzinstellung

- Züchen 2-3 offen
- 4-5 offen
- 6-7 verbunden
- 8-9 verbunden

U<sub>eff</sub> = 50 mV

-Einstellbare Frequenzteilung

- Züchen 2-3 verbunden
- 4-5 verbunden
- 6-7 verbunden


U<sub>eff</sub> = 50 mV

3 für die Festlegung kann man am Eingang (Punkt 11) ein Signal mit einem Pegel von 50 mV aus einem externen Generator (P4) einspeisen


Einstellbarer Frequenzteiler 1

- Eingangsfrequenz  $\Delta f1 = 0,5 \cdot 2^N \dots 255 \text{ kHz}$
- Ausgangsfrequenz  $\Delta f2/\Delta f1 = 50 \text{ kHz}$  im niedrigsten Zustand von 201
- Teilerfaktor  $2^N = 2 \cdot (6 + N)$
- Zählentlang  $N1 = 00 \dots 255$  Zifferwahl von 8-4-2-1-Code
- Zählende  $n1 = 98$
- Zählung nächstes, am 8-4-2-1-Code

11 Blockschaltbild



Impulsdiagramme für 200 kHz



12 Frequenzteiler 1

Level balancing! Accomplish the following adjustments:

With L 04 70-MHz voltage at 17 to minimum

With L 02 70-MHz voltage at 17 to maximum

With R 37 70-MHz voltage at 26

With R 28 70-MHz voltage at 17

Frequency balancing


Balance  $f = 70$  MHz with L 03,  $\Delta f < \pm 150$  Hz.

6.3.6.2.  $f_3$  oscillator

Level balancing  $f_3$ :

Set 03 to  $\sim 50$  mV/50 ohm with R 02 (tapping on the coil decoupling loop of L 01).

Frequency balancing  $f_3$ :



Open bridge 38/39.

Apply positive voltage via opposite voltage divider to 38.

In position A (10 V dc)  $f_3 > 69.7$  MHz; in position B (4 V dc)

$f_3 = 69.6$  MHz. If this cannot be reached, change C 04. Increasing C 04 causes decrease of frequency.

6.3.6.3. Phase discriminator

Image wave test:

$f_3 = 70$  MHz -- point 9/D02 =  $U_{39} < 2$  V dc

Capture test:

$f_2/100 = 350$  kHz at 33

$f_3 = 69.650$  MHz -- wide negative pulses at point 5/D-02

--  $U_{39} = 13$  V dc

$f_3 > 69.650$  MHz -- wide negative pulses at point 9/D-02

--  $U_{39} = 4$  V dc

(The narrow negative pulses presenting at point 9/D-02 or 5/D-02 - approx. 50 ns - are only visible with appropriate setting of the oscillograph.)


Phase discriminator:

Close bridge 38/39.



PLL synchronized ( $U_{39} = 4 \dots 11$  V).

In case of triggering with  $f_2/100$  the oscillograph supplies a stationary pattern of P30 and P54.


Prüfprogramm (oszillator 3) 1




70 kHz - Oszillator 1






Oszillator 2




(1) H-Oszillator und Verstärker



(2) Phasenschieber



Oszillator 3






Figure 16 Frequency processing 2 and F1 - Demodulator 1340.041-01221

6.3.7. Phase-lock loop 2 (PLL 2)





Figure 17


Position of test points PLL 2  
19910-190.0A01

1) Prüfprogramm PLL2



1) falsch: - kein Ausgangssignal f2/100  
 - PLL2 synchronisiert nicht  
 - PLL2 synchronisiert aber Frequenz ist falsch

10) Blockschaltbild PLL2



11)

Frequenzteiler 2 (PLL2)

# 6.3.8. Oszillator 2


2 2 2 0 5 1 2 2 2

Koils Ausgangsspannung, Hz

1.	-12 V	C09
2.	-9 V	C29
3.	U72	(10)
4.	U52	(12)

## Reglerrolle synchronisierfortschritt (1)

1. Betriebsspannung
2. 1 kHz (R02) (01)
3. f2/f12 (03)
4. U72 (10)
5. U52 (12)
6. Betrieb 11...12 Betrieb, an 12 oder 10 Verschiebung, mit Frequenzänderung v 10 kHz u. = 1 kHz synchronisierfortschritt
7. Frequenz und Netz Überprüfen
8. Abgleich Frequenzänderungen



Water Control  
February 1958



No output voltage f2

1. -12 V 030
2. -9 V 029
3. U 2 (10)
4. US2 (12)

1

1. Operating voltages

2. 1 kHz (ref) (01)
3. f2/N2 (03)
4. U 2 (10)
5. U<sub>g</sub>2 (12)

6. Open bridge 11...12, apply approx. +8 V dc to 12, synchronize with frequency switch '10 kHz' and '1 kHz'

7. Check capture aid and N 02

8. Balance phase discriminator

03

unter Eigentum  
Hilfungs oder  
wird verfiel

6.4.1.9. Kontrolle "Regelgleichlauf / Kanal A und B"  
Automatikregelung"

- EKD:  F 4 500.00 kHz,  MOD 6,  B 6,  SEL 0,  GC 1,  
 df 2.00 kHz
- auf jeweils 1000 Hz-Ton im Kanal A bzw. B abstimmen.
- P4-EMK = 2  $\mu$ V ... 200 mV in 20 dB-Schritten schalten,  
Meßwert P3 (A) bzw. (B) = -3,5 dBm ... 3,5 dBm,  
maximale Pegeldifferenz zwischen (A) und (B) =  $\pm$  2 dB

6.4.1.10. Einstellen "Regelersatz Regelglied 1" (Mischer 1)

- HF-Generator P4 an Empfängereingang X 3004 (Y),  
f = 4501 kHz, EMK = 100  $\mu$ V.
- ZF2 - Übergabepegel an X 3001 mit Millivoltmeter P3 messen  
(über BNC-T-Stück -- Zubehör),
- EKD:  F 4 500.00 kHz,  MOD 4,  B 7,  SEL 0,  GC 5,  
  $\approx$   $\nabla$  mit P4 auf ca. 1000 Hz-Ton im Kanal A abstimmen.
- ZF2 - Übergabepegel - Sollwert: 5.5  $\pm$  0,5 mV.
- Auf  GC 1 umschalten.  
Mit R 3836 auf - 12 dB unter den bei  GC 5   $\approx$   $\nabla$  von P3  
angezeigten Pegelwert einstellen.

6.4.1.11. Einstellen "Trigger - Regelverstärker"

- HF-Generator P4 an Empfängereingang X 3004 (Y)  
f<sub>E</sub> 4 500.00 kHz, EMK = 1  $\mu$ V
- EKD:  F 4 500.00 kHz,  MOD 4,  B 7,  SEL 0,  GC 2,  
Mit P4 auf ca. 1000 Hz-Ton im Kanal A abstimmen
- mit Digital-Voltmeter P9 Kollektorspannung an V 3826 messen  
und R 3813 so einstellen, daß U<sub>C</sub> = V 3826 auf ca. +18 V  
springt und diesen Wert beibehält.
- Zur Kontrolle: P4-EMK von 30  $\mu$ V in 10 dB-Schritten schalten.  
U<sub>C</sub> = V 3826 muß kurzzeitig < 1,5 V werden und wieder auf  
ca. +18 V ansteigen.

Check of the frequency discriminator (capture aid)

D01, D02, D03, V10, V11 and V12

Open bridge 05...06

Open bridge 11...12

Apply approx. +8 V dc to 12 (suitable voltage applied to C14)

fe	f2/N2	D03		05
		Pin 9	Pin 5	
xxx 9999	> 1 kHz			< 1 V
xxx 0000	< 1 kHz			> 14 V

Check of amplifier N 02

Open bridge 05...06

Open bridge 11...12

Adjust with R 2525

$U_{pin4} \gg U_{pin5} \rightarrow U(11) < 2 V$

$U_{pin4} \ll U_{pin5} \rightarrow U(11) > 13 V$

Balancing the oscillator frequency

After replacing V 2516 or V 2517/19 (KB105B) the frequency range of the oscillator is to be checked. Balancing is performed with additional winding at L 2501-wire 0.6 mm  $\varnothing$  Cul.

- Possibilities: 2 turns in equal direction of winding  
 1 turn " " "  
 0 " " "  
 1 turn in opposite direction of winding

fe	f2	U point 12
xxx 0000	40 0000 kHz	$\leq 14 V$ type 13 V P 8, $R_1 > 3 M\Omega$
xxx 9999	30 0001 kHz	$> 3.5 V$ type 4.5 V

x = optional setting put on shielding cap for meas

Balancing the phase discriminator

Adjustment with R 2525


$U\varphi = 8...11 V$  at point 09 with  $f_E = xxx 5000$

Observe oscillogram at C 2506 and R 2511



22222222  
 11111111  
 22222222

# 6.3.9. Frequency divider 2


## 1 Prüfprogramm Frequenzteiler 2





## 7 Prinzip des 5:1 - Teilers



## 8 Verstärker A: Saisitzlinie und HF-Regel




1 Prüfung des Einstellbaren Frequenzteilers 2



Frequenzeinstellung

- Brücken 16 - 17 verbunden  
18 - 19 offen  
21 - 22 verbunden  
18 - 17 verbunden
- Uf2 = 50 mV<sup>-</sup>

Einstellbare Frequenzteilung A/B - N2 = 40.000 - (0000...9999)



10 Einstellbarer Frequenzteiler 2

- Eingangsfrequenz f2 = 40.000 - (0.000...9999) Hz
- Ausgangsfrequenz f2/N2 = 1kHz, im Synchronisationszustand von PLL
- Teilerfaktor N2 = 40.000 - f2
- Zählerwert f2 = 9999, Ziffernwert im 8+2+1+1-Code
- Zählercode N2 = 40.000
- Zählung • 40 kHz, 1MHz und 100 Hz - Dekade im 8+2+1+1-Code
- 40 Hz - Dekade und 2 Bit - Erzeuger siehe Blockplan

11 40 Hz - Dekade



0	1	2	3	4	5	6	7	8	9
0	1	2	3	4	5	6	7	8	9
0	1	2	3	4	5	6	7	8	9
0	1	2	3	4	5	6	7	8	9
0	1	2	3	4	5	6	7	8	9

12 d1 wird umschaltet


13 2 Bit - Erzeuger

0	1	2	3	4	5	6	7	8	9
0	1	2	3	4	5	6	7	8	9
0	1	2	3	4	5	6	7	8	9
0	1	2	3	4	5	6	7	8	9
0	1	2	3	4	5	6	7	8	9

Blockschaltbild



Impulsdiagramm



3 Für die Frequenz kann man an Punkt T1 ein Signal mit einem Pegel von ca. 50 mV<sup>-</sup> und einer Frequenz < 40 kHz empfangen (P4).

6.4. Signal path (reference: Ladder 'C' and A Frequency)

6.4.1. Check or correction of levelling

Open cassette lid (complementation side) of cassettes

'signal path 1' and 'signal path 2' and fasten outer cassettes in hinged position with cassette support (contained in the accessories).

6.4.1.1. Basic amplification 'signal path 1'

- RF generator (P4) to receiver input X 3004 ( $\gamma$ )

$f_p = 4\ 500\ \text{kHz}$ , emf = 1 mV

- RF millivoltmeter P2 (150-mV range) via BNC-T-piece (accessories) at X 3002 (IF2 = 200 kHz)

- EKD:  4 500.00 kHz,  4,  5,  0,  5  $\approx \gamma$

- Tune with P4 to zero beat (required forward centre)

Test value P2: 50 to 60 mV

Correction: 'coarse' with R 3434 } when holding the control volume  
'fine' with R 3409 } for 'signal path 1': 60  $\begin{matrix} +2 \\ -1 \end{matrix}$  dB

6.4.1.2. Control volume 'signal path 1'

- Actual value from point 6.4.1.1. (test value P2) is the reference value

-  $\approx \gamma$

- P4 - emf = 1 V

- Test value P2: Actual value from point 6.4.1.1.  $\begin{matrix} +1 \\ -2 \end{matrix}$  dB

- Correction: with R 3409

6.4.1.3. Mixer - symmetry

- receiver input X 3004 ( $\gamma$ ) not connected

- P2 (500-mV range) to X 3002 (IF2 = 200 kHz) via BNC-T-piece (accessories)

- EKD:  0.00 kHz,  4,  5,  0,  5  $\approx \gamma$

- Test value P2  $\approx$  200 mV

Correction (minimization): with C 3336 (balancing capacity)

Channel A and B, manual control)

- RF generator P4 to X 0001 (casing) and via connection cable to X 3004 (plug-in).

$$f_E = 4\ 500\ \text{kHz}, \text{ emf} = 1\ \mu\text{V}$$

- AF millivoltmeter P3 and load resistance 600 ohm in parallel to line output A (25) and B (26)

- EKD:  F 4 500.00 kHz,  MOD 6,  B 7,  SEL 0,  GC 5  $\approx \gamma$   
 dp 2.00 kHz

- Tune with P4 to approx. 1000-Hz tone in channel B, test value P3 (B): +1 dBm, correction with R 3617 \*

- Set 1000-Hz tone with rotary button (2.00-kHz step) in channel A, test value P3 (A): +1 dBm, correction with R 3855 \*)  
maximum level fault: 0.5 dB.

#### 6.4.1.5. Levelling 'A3E'

- RF generator P4 to receiver input X 3004 (Y)

$$f_E = 4\ 500\ \text{kHz}, \text{ emf} = 5\ \mu\text{V}, \quad m = 0.5 \quad f_{\text{mod}} = 1\ \text{kHz}$$

- AF millivoltmeter P3 in parallel to 600-ohm load resistance at AF line output A (25)

- EKD:  F 4 500.00 kHz,  MOD 2,  B 6,  SEL 0,  GC 1

- Tune with P4 1000-Hz tone in channel A to minimum noise

- Balance test value P3 (A) = -1 dBm by means of R 3847 \*)

#### 6.4.1.6. Changing AF line levels (max +6 dBm)

A change of the AF line levels (up to max +6 dBm) is to be carried out with

Channel A: for A3E with R 3847

for A1A, J3E, B8E (+SB) with R 3855 (Demod. and AF)

Channel B: for B8E (-SB) with R 3617 (IF 2/B)

Cf. also Sections 6.4.1.4. and 6.4.1.5.

#### 6.4.1.7. Balancing 'control synchronism/channel A and B, man. con

- RF generator P4, emf = 20  $\mu\text{V}$

- EKD:  F 4 500.00 kHz,  MOD 6,  B 6,  SEL 0,  GC 5

- Tune to 1000-Hz tone in channel A or B

- Adjust test value P3 (B) = 0 dBm with  $\approx$

- Adjust test value P3 (A) = 0 dBm  $\pm$  0.5 dB with R 3734

- Switch P4-- emf = 2  $\mu\text{V}$  in 20-dB steps and set test value P3 (B) = 0 dBm with  $\approx$

- Maximum level difference between (A) and (B):  $\leq$  1.5 dB

\*) For increased AF output level (e.g. + 6 dBm) balance to a value being 6 dB higher

4.1.8. Balancing 'automatic control/channel A and B'

RF generator P4, emf = 200 mV  
 EKD:  F 4 500.00 kHz,  MOD 6,  B 7,  SEL 0,  GC 1,  df 2.00 kHz. Tune with P4 to approx. 1000-Hz tone in channel B, set measuring value P3 (B) = +2 dBm with R 3616  
 Set 1000-Hz tone with rotary button  $\approx$  (2.00-kHz step) in channel A  
 Set test value P3 (A) = +2 dBm with R 3801, max. level fault: 0.5 dB  
 P4-emf = 2  $\mu$ V, test values P3 (A) or (B) = -2 dBm ... 0 dBm

4.1.9. Check 'control synchronism/channel A and B, automatic control'

EKD:  F 4 500.00 kHz,  MOD 6,  B 6,  SEL 0,  GC 1,  df 2.00 kHz  
 Tune to 1000-Hz tone in channel A or B  
 Switch P4 - emf = 2  $\mu$ V ... 200 mV in 20-dB steps  
 test values P3 (A) or (B) = -3.5 dBm ... 3.5 dBm,  
 maximum level difference between (A) and (B):  $\leq$  2 dB

4.1.10. Adjustment 'control start/control element 1' (mixer 1)

RF generator P4 to receiver input X 3004 (Y), f = 4501 kHz,  
 emf = 100  $\mu$ V  
 IF 2 - interposition level on X 3001 to be measured with millivoltmeter P3 (via BNC-T-element - accessories).  
 EKD:  F 4 500.00 kHz,  MOD 4,  B 7,  SEL 0,  GC 5,  
 Tune  $\approx$  with P4 to approx. 1000 Hz-tone in channel A  
 IF 2 - interposition level - rated value : 5.5  $\pm$  0.5 mV  
 Switch over to  GC 1  
 Adjust to a value -12 dB below the one read by P3 for  GC 5  $\approx$  with R 3836.

4.1.11. Adjustment 'trigger - control amplifier'

RF generator P4 at receiver input X 3004 (Y)  
 f = 4 500.00 kHz, emf = 1  $\mu$ V  
 EKD:  F 4 500.00 kHz,  MOD 4,  B 7,  SEL 0,  GC 2  
 Tune with P4 to approx. 1000-Hz tone in channel A  
 Measure with digital voltmeter P9 collector voltage at V 3826 and adjust R 3813 such that  $U_C = V 3826$  jumps to approx. +18 V and maintains this value.  
 For checking: Switch P4 - emf from 30  $\mu$ V to 1  $\mu$ V in 10-dB steps.  $U_C$  shall decrease for a short time to < 1.5 V and increase then again to approx. +18 V.



- RF generator P4 to receiver input X 3004 ( Y )

$f_E = 4\ 500\ \text{kHz}, \text{ emf} = 30\ \mu\text{V}$

- EKD:  F 4 500.00 kHz,  MOD 4,  B 7,  SEL 0,  GC 1

- Tune with P4 to approx. 1000-Hz tone in channel A

- Measure with digital voltmeter P9 capacitor voltage C 3808

- Measure with P9 the voltage at slider of R 3829 and adjust with

R 3829 to a value that is 0.5 V below  $U_C\ 3808$

(guide value:  $4.3\ \text{V} - 0.5\ \text{V} = 3.8\ \text{V}$ )

6.4.1.13. Balancing 'display E $\gamma$ ' (LED row and decimal digital dis

- RF generator P4 to receiver input X 3004 ( Y )

$f_E = 4\ 500\ \text{kHz}, \text{ emf} = 1\ \text{mV}$

- EKD:  F 4 500.00 kHz,  MOD 4,  B 2,  SEL 0,  GC 1, TEST 3

Changeover switch 'LED row' (2)  $\rightarrow$  E $\gamma$

- Tune P4 to zero beat (IF forward centre)

- Balance the emf pairs in the sequence 30  $\mu\text{V}$ , 30 mV and 3  $\mu\text{V}$  a 1 V with the assigned preset controllers R 45145 ... R 45148 to the values 'decimal digital display' given in the table below.

	P4 - emf			
	30 $\mu\text{V}$	30 mV	3 $\mu\text{V}$	1 V
LED row	30 dB ( $\mu\text{V}$ )	90 dB ( $\mu\text{V}$ )	10 dB ( $\mu\text{V}$ )	120 dB ( $\mu\text{V}$ )
Decimal digital display	$15 \pm 1$	$45 \pm 1$	$5 \pm 1$	$60 \pm 1$
Preset controller	R 45145	R 45146	R 45148	R 45147

(Position of preset controller cf. Figure 1)

Note: dB ( $\mu\text{V}$ ) = dB exceeding 1  $\mu\text{V}$  i.e., 0 dB ( $\mu\text{V}$ )


If rated balancing cannot be achieved: change shift register R 45122 (150 kohm ... 220 kohm)

dB ( $\mu\text{V}$ ) = dB over 1  $\mu\text{V}$ , i.e. 0 dB ( $\mu\text{V}$ ) = 1  $\mu\text{V}$

100% Kopierrecht  
 für den  
 privaten Gebrauch  
 ohne  
 weitere  
 Vergütung

100% Kopierrecht  
 für den  
 privaten Gebrauch  
 ohne  
 weitere  
 Vergütung


The following section provides hints on troubleshooting in the cassette 'signal path 1'.  
 For this purpose, the plug-in is to be connected outside the casing via adapter cable (30- and 8-core cable, contained in the accessories).  
 For fault localization: : dismount cassette lid (complementation side)  
 . perform level check according to the figure



86-033 a

Figure 18  
 Signal path 1 1340.041-01311

6.4.2.1.1. - Selectivity characteristics 'preselector 1'  
 (Switchable suboctave filter 1.5 MHz to 24 MHz in 12 subranges)



	Pass range ( $\leq 2$ dB) $f_A \dots f_E$ (MHz)	Blocking range (mean value $\leq 20$ dB)		Balancing frequency	Balancing elements
		$\leq 0.5 \cdot f_E$ (MHz)	$\leq 2 \cdot f_A$ (MHz)		
III 1	1.5 ... 2	$\leq 1$	$\leq 3$	-	-
III 2	2 ... 2.5	$\leq 1.25$	$\leq 4$	2.25 MHz	L3101, L3102
III 3	2.5 ... 3	$\leq 1.5$	$\leq 5$	-	-
IV 1	3 ... 4	$\leq 2$	$\leq 6$	-	-
IV 2	4 ... 5	$\leq 2.5$	$\leq 8$	4.5 MHz	L3103, L3104
IV 3	5 ... 6	$\leq 3$	$\leq 10$	-	-
V 1	6 ... 8	$\leq 4$	$\leq 12$	-	-
V 2	8 ... 10	$\leq 5$	$\leq 16$	9 MHz	L3105, L3106
V 3	10 ... 12	$\leq 6$	$\leq 20$	-	-
VI 1	12 ... 16	$\leq 8$	$\leq 24$	-	-
VI 2	16 ... 20	$\leq 10$	$\leq 32$	18 MHz	L3107, L3108
VI 3	20 ... 24	$\leq 12$	$\leq 40$	-	-

Each subrange ends at  $f_E - 10$  Hz

- For all measurements  $Z_E = Z_A = 75$  ohm
- Balancing with broad-band wobble measuring set-up (P7)\* between cassette input X 3004 and preselector 2 output P 3205.

\* ) When balancing with RF generator (P4), attenuate the coil that is not to be balanced with a 300-ohm resistance.

- For balancing: Remove connection to mixer 1 (P 3205  $\rightarrow$  P 3301) at P 3205: 75-ohm resistance  $\rightarrow$   $\perp$

unter Erhalten  
 Wahrung der  
 wird verfolgt.

For switching on the subrange to be balanced:

- EKD: for range III 2:  F 2250.00,  SEL 1
- range IV 2: " 4500.00, " 1
- range V 2: " 9000.00, " 1
- range VI 2: " 18000.00, " 1

- Coil balancing according to set-point value-selectivity characteristics

Adjust with strap to insertion loss of  $\approx 2.5$  dB at the pass-range limits  $f_A$  and  $f_E$  with adherence to the selection ratings at  $0.5 \cdot f_E$  and  $2 \cdot f_A$ .

- In the other subranges (III 1 ... VI 1 and III 3 ... VI 3):  
Check insertion loss  $\leq 3$  dB and selection ratings according to 6.4.2.1.1.

84


Range I LP  $\approx$  1.5 MHz

Balancing elements

L 3214

L 3215

L 3216



Range II HP  $\approx$  1.5 MHz LP  $\approx$  30 MHz

LP  $\approx$  30 MHz

Balancing elements

L 3217

L 3218


L 3219

Balancing elements

L 3211

L 3212

L 3213



Range VII HP  $\approx$  24 MHz LP  $\approx$  30 MHz

LP  $\approx$  30 MHz

Balancing elements

L 3220


L 3221

Balancing elements

L 3211

L 3212

L 3213



www.egon.de  
Hilflosig sein  
is wind-verloren

is wind-verloren

- For all measurements  $Z_E = Z_A = 75 \text{ ohm}$
- Balancing with broad-band wobble measuring set-up (P7) between: cassette input X 3004 and preselector 2 - output P 3205
- When balancing: Remove connection to mixer 1 (P 3205  $\rightarrow$  P 3301) at P 3205: 75-ohm resistance  $\rightarrow \perp$
- For balancing the respective preselection range the following operation of the receiver is required:

For range: I : BKD: F 250.00 kHz, SEL 1  
 " II : BKD: " 4500.00 kHz, " 0  
 " VII : BKD: " 26000.00 kHz, " 1


### 6.4.3. Signal path 2 1340.041-01321

The following section supplies hints on troubleshooting in the cassette 'signal path 2'.

For this purpose, the plug-in is to be connected outside the casing via adapter cable (30-and 8-core cable, contained in the accessories).

For fault localization:

- . Dismount cassette lid (complementation side)
- . Apply input signal from NF generator (P4) to X 3051 (input socket for signal path 2)
- . Load line output A (25) and line output B (26) at one end — 1 and with R = 600 ohm to avoid interferences
- . Perform level check acc. to figure 19 or 20.



86-0340

Figure 19  
Signal path 2 1340.041-01321


Pegelkontrollen bzw. Pegelkorrektur

	HP-Generator (74)		Sendeleist.	Bandbreite	Verst. Regelung	Prüfung	Prüfpunkt	Messwerte	
	f	U <sub>e</sub>						U <sub>best.</sub>	U <sub>max.</sub>
OC 5 U <sub>ZP2</sub> -Verst. U <sub>f<sub>2</sub></sub> -Verst. U <sub>f<sub>2</sub></sub> -Kont.	-	-	MOD 1	B 5	OC 5	Kontrolle U <sub>best.</sub> U <sub>max.</sub>	X 3801 /B11	U <sub>best.</sub> U <sub>max.</sub>	U <sub>best.</sub> U <sub>max.</sub>
	199 kHz	55 µV	-	-	OC 5	I 3701 Max.	ZP2 - Ausgang (27)	199 kHz	> 100 mV
	200 kHz	10 µV	MOD 3	-	-	T 3701 Max.	ZP2/B P 3605	200 kHz	> 30 mV Leuchtbild
Drehoszillator (U <sub>f<sub>2</sub></sub> , f <sub>2</sub> )	-	-	MOD 1	beliebig ander	-	Kontrolle	X 3801 /B2	199,8 kHz 199,5 kHz	110...160 mV
	200 kHz	-	MOD 3		Kontrolle f und U <sub>e</sub>	-	-	200,00 kHz	120...170 mV
	-	-	MOD 4		-	-	-	200,00 kHz	-
Regelung/323 UR/1A1	-	-	MOD 5	-	-	-	-	-	-
	201 kHz	55 µV	MOD 4	B 16	OC 5	R 3895 einstellen	NP-Lage-Ausg.	1 kHz	0 dB
	201 kHz	110 µV	-	-	OC 1	R 3801 einstellen Kontrolle f, U <sub>e</sub>	-	1 kHz	-1 dB
	201 kHz	25 mV	-	-	-	R 3836 einstellen	-	1 kHz	-1,2 dB
	201 kHz	1,5 mV	-	-	-	R 3847 einstellen	X 3801 /B10 NP-Lage-Ausg. A	1 kHz	12,5 V
	201 kHz	1,5 mV	MOD 2	-	-	Kontrolle □ est.	-	1 kHz	-1 dB
Regelung/433 UHF (A)	201 kHz	55 µV	MOD 4	-	OC 5	I 3601 Max. R 3617 einstellen	NP-Lage-Ausg. B	1 kHz	≥ 2 V <sub>eff</sub> B Ohm
	201 kHz	55 µV	MOD 6	B 7	OC 5	-	-	1 kHz	0 dB


Figure 20

© 1974





Main characteristics are values and frequency response of the output voltage  $U_A$  as well as the function of the LED V 4602 

Test and troubleshooting are accomplished in the sequence "Value of the output voltage" - "Frequency of the output voltage".

The tables (figure 21, 22) show, in dependence on the class of emission (MOD) selected, the voltage  $U$  of the functional groups or the voltages and frequencies at the inputs  $U_E, f_E$  and at the output  $U_A, f_A (\hat{=} f_{U3})$  as well as the function of the LED V 4602 

6.4.3.1.1. Output voltage and control voltage generator

The maximum balancing L 3503 is performed at A1A (very flat maximum) or at F  alternating with F  to the equal value of  $U_A$ . The crystal oscillator is amplitude-controlled via T 3514.

6.4.3.1.2. Crystal oscillator

The crystal-stabilized oscillator is tuned at its frequency by means of the parallel circuit L 3501-C 3521, C 3530 and the capacity diode V 3529.

The frequency range is balanced at A1A with C 3530 (coarse) and L 3501 (fine) to  $f_A = 198.8$  kHz with 0 V at X 3501/B7 and  $f_A = 199.5$  kHz with 9.5 V at X 3501/B7.

Access to the balancing core of L 3501 is provided after dissoldering of the metal tip in the cap centre. After accomplishing balancing work the coil is to be covered again with the metal tip.

6.4.3.1.3. Store and switch

The switch is actuated by the trigger.

Class of emission R3E,  $U_E = 200$  mV,  $f_E = 200$  kHz  $\pm \Delta f_E$ .

The switch is closed as V 3523 and V 3526 are blocking and V 3508 or V 3509 cause opening - depending on the potential difference - between emitter and collector thus closing the phase control loop

$$\Delta f_A = \Delta f_E.$$

20

Class of emission R3E,  $U_E = 50 \text{ mV}$ ,  $f_E = 200 \text{ kHz} \pm \Delta f_E$ .

The switch is open because V 3508 and V 3509 are blocking via V 3521.  
The phase control loop is open,  $\Delta f_A$  is independent of  $\Delta f_E$ ,  $f_A$  is nearly constant and changes with  $-3 \text{ Hz/min}$  (discharge of store capacitor C 3518).

In case  $f_A$  is dependant on  $f_E$ : check V 3523, V 3526, V 3508, and V 3509.

When change of  $f_A$  too large: replace T 3508, T 3509, T 3510, T 3525, C 3518 in this sequence.

Attention! V 3510 is a MOS transistor. When changing V 3510 or any components which are fed to its transistor terminals these are to be shortened.

In the class of emission J3E,  $U_E = 200 \text{ mV}$ ,  $f_E = 200.000 \text{ kHz}$  the operating condition R3E is equal to  $U_E = 200 \text{ mV}$ ,  $f_E = 200.000 \text{ kHz}$ . The inverse voltages for V 3523 and V 3526 are firmly switched on via V 3540.

#### 6.4.3.1.4. Phase detector

Direct voltage to N 3501/8 at  $U_E = 0$ : approx. 6 V.

With the control loop closed the voltage at N 3501/8 varies irregularly by approx.  $\pm 10 \%$  (phase jumps of  $f_A$ ).

#### 6.4.3.1.5. Voltage path 200.000 kHz

Characteristic of the voltage path: V3501/B3-R3506-V3516-R3503-N3501/14

#### 6.4.3.1.6. Voltage path 200 kHz + $\Delta f_E$

Characteristic of the voltage path: V3501-R3508-V3518-C3505-R3503-N3501/14

#### 6.4.3.1.7. Amplifier and trigger

Gate D 3504/9, 10, 11, 8 is included in the amplifier. E 3520 causes slow recharging of C 3517 after having applied the input voltage and with this the delayed response of the trigger (0.5 s).  $U_E \cong 200 \text{ V}$   
V 3504C 15.5 V  $\rightarrow$  5 V; V 3503E 3.5 V  $\rightarrow$  13.5 V.

V 3521 provokes quick recharging of C 3517 after disconnection of the input voltage and thus immediate response of the trigger.

6.4.3.1.8. Divider 200 kHz/1.905 kHz

Divider ratio 1:105.

In the classes of emission F the divider is put into operation via K input D 3503/10 by applying 2.7 V. The divider consists of the counter components D 3501 and D 3502 as well as of the decoding circuit D 3504 (2 gates) and D 3503 for releasing a reset pulse. Every 103rd pulse at D 3501/14 causes that H potential is applied to the J inputs of D 3503. Thus, the 104th pulse can release a reset pulse at the Q output. This pulse is terminated with the trailing edge of the 105th pulse.

6.4.3.1.9. Mixer 200 kHz  $\pm$  1.905 kHz

The summation and difference frequencies are available opposite in phase at the outputs N 3502/12 and N 3502/13.

Input voltages: N 3502/6.14 approx. 2 V; N 3502/7.9 approx. 3.6 V.

A summation voltage of approx. 400 mV is applied to N 3502/12, 13 (both input- and mixed frequencies).

6.4.3.1.10. Crystal filter 201.905 kHz and 198.095 kHz

Both crystal filters are bridge filters whose branches are activated opposite in phase by N 3502/12 or N 3502/13. After crystal exchange a maximum balance von  $U_A$  by minimum tuning of the crystal frequency with C 3535 or C 3536 may be required.

C 3537 and C 3538 provide minimum balancing of the distortion products of  $U_A$  (suppression of the undesired frequencies).

Table

DC voltages of the function groups in dependence of the class of emission selected (MOD)

Test value	Function group	Test point	A1A	A3E	R3E, B, SE	J3E, BSE	F0, F 11	F 11
Output amplifier and control voltage generator	Crystal oscillator	X3501/B7	18	18	18	18	18	18
			0...9.5	0	0	0	0	0
Store and switch	Crystal oscillator	X3542/K	0	0	16.5	16.5	0	0
			0	0	16.0	16.0	0	0
Phase detector	Voltage path	V3519/K	0	0	16.5	16.0	0	0
			0	0	0.7	0.7	0	0.7
DC voltages of the function groups	Amplifier and trigger	V3546/K	0	0	16.0	(5)	16	16
			0	0	0	0	0	0
D (V)	Divider 200/11.905 MHz	X3501/A1 D3503/10	5	5	5	5	5	5
			0	0	0	0	0	0
Mixer 200 MHz + 1.905 MHz	Crystal filter	V3534/K	0	0	0	0	16.5	16.5
			0	0	0	0	17.5	0
Crystal filter	Crystal filter	X3501/A9 X3501/411	0	0	0	0	0	17.5
			0	0	0	0	0	17.5

Table

Voltages and frequencies at the inputs and at the output as well as the function of the carrier display in dependence on the class of emission selected (MOD)

Test value	Function group	Connection points	A1A	A3E	R3E, R <sub>E</sub> EE	J3E, JEE	F0, FΠ	FU
Input voltages and frequencies (test)	Voltage path 200.000 kHz	X3501/B3 — X3501/A3 ⊥	—	—	—	200 mV	200 mV	200 mV
						200.00 kHz	200.00 kHz	200.00 kHz
Output voltages and frequencies	Voltage path 200 kHz + Δf <sub>E</sub>	P3501 — P3502 ⊥	—	—	50mV/200mV 200kHz+Δf <sub>E</sub> Δf <sub>E</sub> ≈ 50Hz	—	—	—
					Output amplifier	110 mV to 160 mV	0	120 to 170 mV
R <sub>A</sub> = 680 ohm	f <sub>A</sub> f <sub>U3</sub>	X3501/B13 X3501/A13	< 198.8 to > 199.5 kHz (A1-pitch control)	—	200kHz+Δf <sub>A</sub> U <sub>E</sub> =200mV Δf <sub>A</sub> =Δf <sub>E</sub> U <sub>E</sub> =50mV Δf <sub>A</sub> const. (~3Hz/min)	200.000 kHz f <sub>A</sub> =f <sub>E</sub>	201.905 kHz	198.095 kHz
			Trigger	dark	dark	U <sub>E</sub> =200mV lit U <sub>E</sub> =50mV dark	dark	dark
Function Carrier display		X3501/B11	dark	dark				

Figure 22

6.4.3.2.1. Amplification in signal path 2 (X3051 — P3705)

$U_e = 55 \mu V$  at X3051 (RF generator P4), **GC** 5 and  $\approx \rightarrow$

$U_a = 100 \text{ mV to } 200 \text{ mV}$  at P3705 —  $\perp$  (millivoltmeter P3)

$U_{R2} = 0.75 \text{ V}$

Amplification difference with bandwidths **B** 2... **B** 4 :  $\approx 4 \text{ dB}$   
with **B** 1 :  $\approx 6 \text{ dB}$

Attention Exchange IF2 amplifier circuits N3603 (IF2/B) and N3702 (IF2/A) only in pairs (spare part in B1)

6.4.3.2.2. Carrier amplifier (for R3E and  $B_{R8E}$ )

200 kHz/ $U_e = 10 \mu V$  at X3051 (RF generator P4)

$U_a = 30 \text{ mV to } 100 \text{ mV}$  at P3605 —  $\perp$  (millivoltmeter P3)

3 dB bandwidth :  $\approx \pm 50 \text{ Hz}$

6.4.3.2.3. Bandwidth and selection of mechanic filters

<b>B</b>	Rated bandwidth	3 dB bandwidth	60 dB bandwidth
1	0.15 kHz	$\approx \pm 50 \text{ Hz}$	$\approx \pm 250 \text{ Hz}$
2	0.4 kHz	$\approx \pm 150 \text{ Hz}$	$\approx \pm 500 \text{ Hz}$
3	0.75 kHz	$\approx \pm 300 \text{ Hz}$	$\approx \pm 850 \text{ Hz}$
4	1.75 kHz	$\approx \pm 750 \text{ Hz}$	$\approx \pm 1250 \text{ Hz}$
5	3.1 kHz	$\approx \pm 1.5 \text{ kHz}$	$\approx \pm 2.15 \text{ kHz}$
6	6.0 kHz	$\approx \pm 3.0 \text{ kHz}$	$\approx \pm 4.0 \text{ kHz}$
7*)	+3.0 kHz	$\approx +(0.25...3.0) \text{ kHz}$	$\approx -0.25 \text{ kHz}; \approx +3.5 \text{ kHz}$
**)	+6.0 kHz	$\approx +(0.3...5.9) \text{ kHz}$	$\approx -0.3 \text{ kHz}; \approx +6.8 \text{ kHz}$
8*)	-3.0 kHz	$\approx -(0.25...3.0) \text{ kHz}$	$\approx +0.25 \text{ kHz}; \approx -3.5 \text{ kHz}$
**)	-6.0 kHz	$\approx -(0.3...5.9) \text{ kHz}$	$\approx +0.3 \text{ kHz}; \approx -6.8 \text{ kHz}$
9		signal path blocked	

\*) EKD 511

\*\*\*) EKD 512

Attention The signs of the built-in sideband channel filters are opposite to that of the input signal (sideband commutation in mixer 1).

Lucrer Eigentum  
 Hältigung sehr  
 e wird verweigert

9  
 wird verweigert

6.4.3.3. Demodulator and AF section 1340.039-01358

6.4.3.3.1. Demodulator/A1A; J3E; F1B; F3C

Level outline with input signal applied

At P 3801 → ⊥ : IF2 signal = 201 kHz or 200 kHz/100 mV, GC 5

At N 3801/14 :  $U_{\text{carrier (lim.)}}$  = 200 mV to 350 mV<sub>ss</sub>

At N 3801/9 :  $U_{\text{IF2}}$  = 7 ... 15 mV<sub>≈</sub>

At N 3801/8 :  $U_{\text{AF}}$  = 50 ... 55 mV<sub>≈</sub>

adjust with R 3855

6.4.3.3.2. Demodulator/A3E

Level outline with input signal applied

At P01 → ⊥ : IF2 signal = 200 kHz/m = 0.5; 1 kHz, 100 mV, GC 5

At X01/14 : IF2 signal = 3 ... 5 mV<sub>≈</sub>

At X01/8 :  $U_{\text{AF}}$  = 50 ... 55 mV<sub>≈</sub> ; adjust with R 3847

Attention At input P 3801 → ⊥ : approx. 1.1 V dc voltage

6.4.3.3.3. AF line amplifier 'channel A'

Level outline with input signal applied

At N 3802/3 :  $U_{\text{AF}}$  = 50 ... 55 mV<sub>≈</sub>


At N 3802/6 :  $U_{\text{AF}}$  = 0.775 V<sub>≈</sub> (with 52 mV at N 3801/8)

At X 3801/B4 :  $U_{\text{AF}}$  = 0.775 V<sub>≈</sub>

Line output 'A' : at X 3802/5 : 8.8 ... 9.2 V<sub>==</sub>

at X3802/10 : 8.8 ... 9.2 V<sub>==</sub>

6.4.3.3.4. Monitoring amplifier

$U_{\text{B}}$  at X X 3801: 100 mV (for 0.5 W across 8 ohm X 1021  external)

(Correcting of amplification possible with R 71.)

Attention Do not generate AF power with the heat radiator disconnected (thermal overload) !

6.4.3.3.5. Control amplifier

- Manual control: GC 5

Generation of U manual control by voltage divider

R 3845, R 1002 (  $\approx$  ) and R 1007

R 1002	→ Mixer 1	→ IF amplification A/B
$\gamma$	$U_{R1} \approx 14.5 \text{ V} \approx$	$U_{R2} \approx 0.75 \text{ V} \approx$
$\gamma$	$U_{R1} \approx 9.5 \text{ V} \approx$	$U_{R2} \approx 0.3 \text{ V} \approx$

- Automatic control: GC 1, GC 2

At P 3801 →  $\perp$  :  $U \approx = 100 \text{ mV}/200 \text{ kHz}$

At IF output (27):  $\approx 100 \text{ mV}$  (without load)

U at V 3821<sub>B</sub> = approx. 45 mV  $\approx$  (adjustable with R 3801)

Control detector/A : U at V 3824<sub>B</sub> > +4 V

	Trigger (not driven)	Trigger (driven)
Trigger V 3826 <sub>C</sub>	$\approx 0.55 \text{ V} \approx$	$>17 \text{ V} \approx$
Holding circuit V 3827 <sub>C</sub>	approx. 1,25 V $\approx$	approx. 0.25 V $\approx$
Long-time detector V 3828 <sub>B</sub>	approx. 0.66 V $\approx$	0

$U_C 3808 = ,3 \dots 4 \text{ V}$

Short-time detector  $U_{R3829/R3830} = 3 \dots 4 \text{ V} \approx$

Amplifier V 3829<sub>B</sub> ,  $= 13 \dots 14 \text{ V} \approx$

Amplifier V 3830<sub>C</sub>  $= 12 \dots 13 \text{ V} \approx$

Voltage of slider R 29 =  $U_C 3808 - 0.6 \text{ V}$

Dieser Eigenton  
 freiliegend oder  
 nicht verfügbar.

Freiliegend oder  
 nicht verfügbar.



6.5. PLL demodulator 1340.041-01258

6.5.1. Check 'input signal' (X 2801/A, B1 or X 0002)

Receiver setting:  F 0,00 kHz

B 6

MOD 7, 8 or 9

GC 5

Adjust input voltage with control "  $\approx$  " to 0.8 V.

Measure input frequency at MOD 7, 8 and 9

Setpoint value: 1905 Hz  $\pm$  1 Hz

6.5.2. Check 'input band-pass' (N 2801)

(P 12 serves as earth reference for all measurements on this pc board.)

Measure 3-dB decrease at P 01 with  $\Delta F = 0.10$  kHz

Pass range approx. 1.1 kHz to 2.7 kHz

Slope steepness approx. 12 dB/oct.

Operating residual attenuation 1.5 dB to 2 dB

6.5.3. Check 'limiter amplifier' (W 2802, V 2804, V 2805)

$U_{P02}$  : approx.  $V_{rms}$  at  $U_e = 500$  mV to 2.5 V

(adjust with control  $\approx$ )

$U_{P03}$  : approx. 0.8 V<sub>pp</sub>

6.5.4. Check 'PLL' (N 2803, N 2804, D 2801, V 2806 ... V 2816)

Measure PLL zero position and VCO frequency with the signal path blocked ( B 9).

Rebalancing: PLL zero position with R 2826 (0 V  $\pm$  5 mV at P04)

VCO frequency with R 2842 (1905 Hz  $\pm$  2 Hz at P05)

(Forced changeover with IF bandwidth  B )

100-Bd low pass: at  B 1, 2, 3 ( $f_g$  approx. 150 Hz)

600-Bd low pass: at  B 4, 5, 6 ( $f_g$  approx. 900 Hz)

Offset correction : for 100-Bd low pass with R2867 at P 09  
for 600-Bd low pass with R2876 and R2883  
at P 08 and P 09

6.5.6. Check 'amplifier' (N 2810)

Measure  $V =$  approx. 40 with low  $\Delta f$  (e.g. 80 Hz)

Offset correction with R 2891.

6.5.7. Check 'evaluator circuit' (N 2811)

At centre frequency (1905 Hz)

:  $U_{P11} = 0 \text{ V} \pm 15 \text{ mV}$

At centre frequency  $+\Delta f = 500 \text{ Hz}$

:  $U_{P11} = + 1 \text{ V} \pm 50 \text{ mV}$

At centre frequency  $-\Delta f = 500 \text{ Hz}$

:  $U_{P11} = - 1 \text{ V} \pm 50 \text{ mV}$

In case of exceeding  $U_{P11}$  values

: balance with R 2892

In case of too low  $U_{P11}$  values

: balance with R 2897

6.5.8. Check 'Line current for teleprinter'

Connect ammeter with 200 ohm (load resistance) in series to teleprinter terminal (X 0008, 3 and 4).

At  MOD 1 ... 7 : 40 mA  $\pm$  5 mA (correction with R 28106)

6.5.9. Check 'holding and capture range of PLL'

Receiver setting:  F 0.00 kHz

dF 0.01 kHz

MOD 8 and 9

B 6

GC 1

Changeover switch 'LED row' (2)  $\rightarrow$  ' $\Delta f \times 2$ '

Dieser Dokument  
effektiv sein  
zu wird verbleibt.

Holding range: Setpoint value:  $\Delta f \approx \pm 900$  Hz referred to centre frequency

Increase frequency with rotary button "  $\approx$  " until luminous point of the LED row jumps from row end to row centre.

Capture range: Setpoint value:  $\Delta f \approx \pm 800$  Hz referred to centre frequency

Detune frequency of  $\Delta f$  values 2.00 kHz towards 0.00 kHz by means of rotary button "  $\approx$  ".

accomplish this function check at  MOD 8 and  MOD 9.


check simultaneously the synchronization process through monitoring tone.

100

7.1. Frequency accuracy

7.1.1. Measuring and correcting with standard test conditions

Temperature +15 °C to +35 °C  
 Relative air humidity 45 to 75 %  
 Before testing the receiver is to be operated on the a.m. conditions for  $\approx$  4 hours  
 Voltage variations of power supply  $\approx$   $\pm$  2 %



Receiver setting:

F	10 000.00 kHz
B	1
MOD	4
GC	1

IF  $f_{ref} = 200 \text{ kHz} \approx \pm 5 \text{ Hz}$

In case of greater frequency fault:

Correction of the receiver frequency standard (TCXO) with R2410 (reference frequency) on the plug-in rear.

For this, operate the receiver plug-in via a 30-core adapter cable (accessories) outside the casing.

7.1.2. Check and correction on service conditions

- Before testing, the receiver is to be operated at least 2 hours under the a.m. conditions.
- Connect the aerial for receiving a standard frequency transmission 10 MHz or 20 MHz to receiver input socket (29).

unser Eigentum  
Verleiheung oder  
Verkauf wird verweigert.

101

- Receiver settings:

<input type="checkbox"/> F	according to standard frequency $f_N$
<input type="checkbox"/> MOD	4
<input type="checkbox"/> B	1
<input type="checkbox"/> GC	5

Control  $\approx$  (4)  $\gamma$

Control  $\approx$  (6)  $\gamma$

- A noise signal changing its volume in the rhythm of the frequency fault is audible in the loudspeaker.

- Admissible frequency fault:  $\frac{\Delta f}{f_N} \approx 1 \cdot 10^{-6}/\text{year}$

i.e. with  $f_N = 10 \text{ MHz}$        $\Delta f \approx 10 \text{ Hz}$   
       $= 20 \text{ MHz}$                  $\approx 20 \text{ Hz}$

- Correction of the frequency fault:

Minimize the beat frequency by balancing with R 2419 (reference frequency) on the plug-in rear.

For this, operate the receiver plug-in outside the casing via a 30-core adapter cable (accessories).

102

## 7.2. Sensitivity

### 7.2.1. Classes of emission A1A and F1B

- RF generator (P4) to receiver input socket (29)  
emf (75 ohm) = 0.5  $\mu$ V ( $f_G \cong 150$  kHz)  
                  = 3  $\mu$ V ( $f_G \cong 150$  kHz)
- AF millivoltmeter (P3) to AF output socket (28)  
(measuring range 0.5 V)

- Receiver setting:

F            according to test frequency

MOD        1

B            1

GC          5

SEL        0 and 1

$\approx$   $\approx$

- Tune to maximum with RF generator (P4) at millivoltmeter (P3)
- Adjust level to 250 mV with control  $\approx$  (6) at millivoltmeter (P3).
- Measure display decrease (interference voltage spacing in dB) at millivoltmeter after disconnecting the RF generator (P4).

$$\left[ \frac{S + R}{R} = 10 \text{ dB} \right]$$

- Repeat measurements for class of emission F1B with  MOD 7.

### 7.2.2. Class of emission A3E

- RF generator (P4) to receiver input socket (29),  
emf (75 ohm) = 5  $\mu$ V ( $m = 0.5$   $f_{MOD} = 1000$  Hz).
- AF millivoltmeter to AF output socket (28), (1.5-V range)

- Receiver setting

A according to test frequency

MOD 2

B 6

GC 5

SEL 0 and 1

~~⚡~~ ≈ ⚡

~~⚡~~ ≈ ⚡

- Tune with RF generator (P4) to 1000 Hz (noise minimum)
- Adjust level to 0,775 V (0 dB) with ~~⚡~~ ≈ at AF millivoltmeter (P 3)
- Disconnect modulation on RF generator (P4) and measure display decrease (noise voltage spacing in dB)

$$\left[ \frac{S + R}{R} \approx 10 \text{ dB} \right]$$

7.2.3. Classes of emission J3E, R3E, B8E, B<sub>R</sub>3E

- RF generator (P4) to receiver input socket (29),  
 emf (75 ohm) = 1.5 μV (EKD 511)  
 = 2.2 μV (EKD 512)

- AF millivoltmeter (P3) to AF output (28), 1.5-V range

Observe position A (+ SB) or B (-SB) of the monitoring changeover switch (3).

- Receiver setting:

F according to test frequency

MOD 3,4,5,6

B 7,8

GC 5

SEL 1 and 2

~~⚡~~ ≈ ⚡

~~⚡~~ ≈ ⚡

104

- Tune with RF generator (P4) to 1000-Hz tone
- Adjust level to 0.775 V (0 dB) with  $\Delta \approx$  at AF millivoltmeter (P3)
- Disconnect RF generator and measure display decrease (noise voltage spacing in dB) at millivoltmeter

$$\left[ \frac{S + R}{R} = 10 \text{ dB} \right]$$

7.2.4. Check of the residual carrier synchronization (R3E and E<sub>R</sub>8E)


- RF generator (P4) to receiver input socket (29)  
emf (75 ohm) = 1  $\mu$ V
- Receiver setting:

F according to test frequency

MOD 5, 6

GC 5

$\Delta \approx \gamma$   
 $\Delta \approx \gamma$

- Tune to zero beat with RF generator (P4)
- Check display  (11) for residual carrier synchronization shall light in the detuning range  $\Delta f = \pm 50 \text{ Hz}$ .

Dieser Empfänger  
 ist ein Eigentum  
 der Bundeswehr  
 und darf nicht  
 weitergegeben  
 werden.

Dieser Empfänger  
 ist ein Eigentum  
 der Bundeswehr  
 und darf nicht  
 weitergegeben  
 werden.



7.3. Amplification control (17A) ~~EMF generator~~ (29) (25) (26)

7.3.1. Manual control 'basic amplification'

- RF generator (P4) to receiver input socket (29),  
emf (75 ohm) = 1  $\mu$ V
- AF millivoltmeter (P3) to line outputs A (25) or B (26) terminated with 500 ohm, 1,5-V range.
- Receiver setting:

F	4 500.00 kHz
MOD	6
B	6
GC	5
SEL	0

~~X~~  $\approx$   $\gamma$

- Tune with RF generator (P4) to 1000-Hz tone in AF channel B or A and read test values on AF millivoltmeter.

Setpoint values: 0.775 V  $\pm$  1 dB

- Correction of the AF output level
 

Channel A : with R 3847	}	cassette 'signal path 2'
Channel B : with R 3617		

- Check of the display 'U  $\approx$  ' on LED row (12).  
Monitoring changeover switch (3)  $\rightarrow$  'U  $\approx$  '

7.3.2. Manual control 'synchronism, control volume'

(Test arrangement as with Section 7.3.1.)

- Increase emf of the RF generator from 1  $\mu$ V to 1V in 20-dB steps, level at AF line output B (26) to 0 dBm each by means of and compare level with AF line output A (25)  $\rightarrow$  2-kHz step.

196

3 wird verlegt

Setpoint values: synchronism  $\frac{U_{AF} 'A'}{U_{AF} 'B'} = \pm 2 \text{ dB}$

control volume = 120 dB (setting to 0 dBm)

- Correction of synchronism ( $U_{AF} 'A'$ ) with R. 3734 (signal path 2).

7.3.3. Automatic control 'synchronism, control volume'

(Test arrangement as with Section 7.3.1.  GC  1)

- Increase emf of the RF generator from 2  $\mu\text{V}$  to 200 mV in 20-dB steps and measure AF level at every time at line output A (25) and B (26).

Setpoint values: synchronism  $\frac{U_{AF} 'A'}{U_{AF} 'B'} = \pm 2 \text{ dB}$

control volume = 0.775 V  $\pm 3 \text{ dB}$

- Correction:  $U_{AF} 'A'$  with R 3801 }  
 $U_{AF} 'B'$  with R 3616 } signal path 2

7.3.4. Automatic control 'digital display of the receiving signal'

- Receiver setting:

F 4 500.00 kHz

MOD 1

B 2

GC 1

SEL 0

Changeover switch 'LED row'  $\rightarrow$  E  $\rightarrow$

A-D converter test A 3

(  EXT  EXT  $\leftarrow$  1.5 s  $\rightarrow$

ohne Egektor  
 fällung nach  
 wird befolgt

11/1987

- Turn LED row to maximum with RF generator (emf = 100  $\mu$ V)
- Increase emf values from 1  $\mu$ V ( $\approx$  0 dB  $\mu$ V) to 1 V ( $\approx$  120 dB  $\mu$ V) in 10-dB steps.
- Doubly indicated digit value  $\approx$  dB  $\mu$ V (tolerance:  $\pm$  2)  
(e.g.: 30  $\approx$  60 dB  $\mu$ V  $\approx$  1 mV)
- Simultaneously with that: Check display value on LED row  
(tolerance:  $\pm$  1 LED)

8. Components selected by the manufacturer

Repair work on some circuits of the receiver requires particularly pretested or prepared (programmed) components which can be ordered from the manufacturer of the equipment.

V3304 Si-Schottky diode quartette 4 KAS 34  
( $\Delta U_F \cong 20$  mV at  $I_F = 1 \dots 7$  mA,  $\Delta C_o \cong 0,2$  pF)

V3305, V3306 } Transistor pairs SF235  
V3309, V3310 } acc. to 1340.041-<sup>01353</sup>/<sub>01354</sub> Pv 2  
V3311, V3312 } ( $\Delta I_C \cong 10$  % at  $I_B =$  constant,  
V3402, V3403 }  $U_{CE} = 4.5$  V,  $I_C =$  approx. 5 mA)

V3405, V3406 FET KP307 A  
acc. to 1340.041-01354 Pv 3  
( $U_{\text{pinch-off}} = -0.8 \dots -1.3$  V at  $I_D = 100$   $\mu$ A,  
 $U_{DS} = 10$  V)

N3602, N3704 Circuit pair A281 D  
acc. to 1340.037-<sup>01356</sup>/<sub>01357</sub> Pv 2  
( $\Delta V \cong 2$  dB within the control range)

V3601, V3701, V3704 FET KP307 A  
acc. to 1340.041-01345 Pv 3  
( $I_D > 100$   $\mu$ A at  $U_{DS} = 10$  V,  
 $U_{\text{pinch-off}} = -1.3$  V)

V2209...V2212 Si diode quartette SAY17  
acc. to 1340.037-01253 Pv 2  
( $C_o \cong 1.5$  pF at 10 MHz)

V2104, V2106, } FET KP307 A  
V2108, V2113, } acc. to 1340.037-01251 Pv 2  
V2115, V2301, }  
V2312, V2504 } Group 3...7, ( $I_D = 3$  mA,  $U_{GS} = 0.33 \dots 1.1$  V  
V2506, V2508, }  $/Y_{21S}/ = 3.5$  mS at 20 kHz  
V2513 }

V2105, V2505 FET KP307 A  
acc. to 1340.037-01251 Pv 2  
Group 9...11 ( $I_D = 3$  mA,  $U_{GS} = 2 \dots 4$  V  
 $/Y_{21S}/ = 3.5$  mS at 20 kHz)

D4408...D4411 Circuit U2716C 65 (EPROM)  
programmed acc. to 1340.041-01454 Bv  
Indicate program-No., e.g. progr. 2/1...4.

SERVICE-UNTERLAGE

EMPFÄNGER - TYPREIHE

EKD 500

EKD 511	TYP 1340.42 A1
EKD 512	TYP 1340.42 A2
EKD 514	TYP 1340.42 A4
EKD 515	TYP 1340.42 A5

BAND 2

Hierzu gehört:  
SERVICE-UNTERLAGE 1340.042-91700 SU Band 1

Änderungen in Konstruktion und Ausführung, die der technischen Verbesserung und Weiterentwicklung unserer Erzeugnisse dienen, behalten wir uns vor.

Bestellnummer : 1340.042-91700 SU Band 2  
Ausgabe 2/1987

665 BkG 011/00762/88




**VEB FUNKWERK KÖPENICK**  
BETRIEB DES VEB KOMBINAT NACHRICHTENELEKTRONIK

DDR · 1170 Berlin, Wendenschloßstr. 142-174

# INHALTSVERZEICHNIS

		Seite
EMPFÄNGER EKD 500	1340.042-00001 Fp	5
EINSCHUB	1340.041-10004 Sp Bl.1	6
	1340.041-10004 Sp Bl.2	7
BAUGRUPPENÜBERSICHT	1340.042-00001 ü	8
GEHÄUSE , VOLLSTÄNDIG	1340.042-01001 Sp	9
GLEICHSTROMWEICHE	1340.042-01022	
STROMVERSORGUNGSTEIL	1340.039.01500 Sp	10
SCHALTREGLER , VOLLSTÄNDIG	1340.039-01552	12
TRANSVERTER	1340.039-01551	
BEDIENEINHEIT	1340.041-01401 Sp	13
STEUERRECHNER	1340.041-01454 Sp	14
	1340.041-01454	15
EIN - AUSGABELOGIK	1340.041-01453 Sp	16
	1340.041-01453	17
TASTATUR , VOLLSTÄNDIG	1340.041-01402 Sp	18
DREHIMPULSGEBER	1340.041-01431 Sp	
TASTATUR , VOLLSTÄNDIG	1340.041-01402	19
ANZEIGE	1340.041-01456 Sp	20
	1340.041-01456	21
STELLSPEICHER	1340.041-01455 Sp Bl.1	22
	1340.041-01455 Sp Bl.2	23
	1340.041-01455	24
	1340.041-01455	25
FREQUENZAUFBEREITUNG 1	1340.041-01211 Sp	27
OSZILLATOR 1	1340.037-01251 Sp	28
	1340.037-01251	29
FREQUENZTEILER 1	1340.037-01252 Sp	30
	1340.037-01252	31
OSZILLATOR 3	1340.039-01253 Sp	32
	1340.039-01253	33

FREQUENZAUFBEREITUNG 2 und F1-DEMULATOR	1340.041-01221 Sp	35
OSZILLATOR 2	1340.037-01255 Sp 1340.037-01255	36 37
FREQUENZTEILER 2	1340.037-01256 Sp 1340.037-01256	38 39
REFERENZFREQUENZ	1340.037-01254 Sp 1340.037-01254	40 41
SIGNALWEG 1	1340.041-01311 Sp	43
VORSELEKTOR 1	1340.037-01351 Sp 1340.037-01351	44 45
VORSELEKTOR 2	1340.041-01352 Sp 1340.041-01352	46 47
MISCHER 1	1340.041-01353 Sp 1340.041-01353	48 49
MISCHER 2	1340.041-01354 Sp 1340.041-01354	50 51
SIGNALWEG 2	1340.041-01321 Sp 1340.041-01322 Sp	52 53
TRAGEROSZILLATOR	1340.037-01355 Sp 1340.037-01355	54 55
ZF 2 / B	1340.041-01356 Sp 1340.041-01356 / 01366	56 57
ZF 2 / A	1340.041-01357 Sp 1340.041-01357 / 01367	58 59
ZF 2 / B	1340.041-01366 Sp	60
ZF 2 / A	1340.041-01367 Sp	61
DEMULATOR und NF-TEIL	1340.039-01358 Sp 1340.039-01358	62 63
F1-DEMULATOR	1340.041-01258 Sp 1340.041-01258	64 65
200 kHz / 1.7 kHz - UMSETZER	1340.041-01257 Sp 1340.041-01257	66 67



EMPFÄNGER EKD 500  
 1340.042-00001 Fp




Gehäuse, vollst.  
1340.042-01001

Frequenzteiler 2

Oszillator 2

Referenzfrequenz

F1 - Demodulator



200 kHz / 17 kHz - Umsatzer

1) Bauelemente nur im  
EWS 516 / 220 315  
enthalten

2) 817 MHz  
(0 dBm)

3) per numerische Schalt-  
510 für EWS 516  
4) EWS 516 / 220 315  
5) EWS 516 / 220 315  
6) EWS 516 / 220 315  
7) EWS 516 / 220 315

EINSCHUB


1340.041-10004 Sp B1.1

- E - Teile enthalten in
- Aufbau - 010001 STL
  - Quasiteil, mont. - 010001 STL
  - Mikrogeplante, vorm. - 010014 STL
  - Kassetteneaufnahme - 01011 STL
  - Frontplatte, vollst. - 01031 STL

Zzeichnung besteht aus Blatt 1 und 2  
Blatt 1, A.C. Foc/mat

X21


nur im EKD 514 / 515 enthalten



EINSCHUB  
1340.041-10004 Sp Bl. 2

Gleichstrommelche  
1340.042-01022




Gebhuse, vollst. 1340.042-01001 (00)




- Frequenzaufbereitung 2  
1340.041-01221 (20) [schwarz]
- Frequenzaufbereitung 1  
1340.041-01211 1)2) [rot]  
-01214 4)5) (20)
- Signalweg 1  
1340.041-01311 1)4)  
-01312 2)5) [selb] (30)
- Signalweg 2  
1340.041-01321 1)4)  
-01322 2)5) [grün] (30)

- 1) EXD 511 : 1340.042-10001
- 2) EXD 512 : 1340.042-10002
- 4) EXD 514 : 1340.042-10004
- 5) EXD 515 : 1340.042-10005


BAUGRUPPENÜBERSICHT  
1340.042-00001 G




**GLEICHSTROMWEICHE  
1340.042-01022**






**E-Teile enthalten in**  
 Rückwand mont. 1340 042-01010 STL  
 Steckerplatte vollst. -01011 STL  
 Netzanschluss -01013 STL  
 Gleichstromweiche -01022 STL




**GEHÄUSE , VOLLSTÄNDIG  
1340.042-01001 Sp**




STROMVERSORUNGSTEIL  
1340.039.01500 Sp





**STROMVERSORGUNGSTEIL**  
1340.039.01500 Sp




**SCHALTREGLER , VOLLSTÄNDIG**  
1340.039-01552



**TRANSVERTER**  
1340.039-01551




**BEDIENEINHEIT**  
1340.041-01401 Sp




S01	Anzeige
1/7	$\Delta F \times 1$
2/8	$\Delta F \times 2$
3/9	EY
4/10	UHF







**STUERERCHNER**  
**1340.041-01454 Sp**




Ein - Ausgabelogik




STEUERRECHNER  
 1340.041-01454




EIN - AUSGABELOGIK  
1340.041-01453 Sp



1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100



**EIN - AUSGABELOGIK**  
**1340.041-01453**




Tastatur (GS) 1340.041 - 01457  
S01 bis S27 enthalten in - 01402

on X+306, X+307  
Ein-Ausgabebelg

Kenn-Nr. der Bauelemente  
C4701 = C01


0,5ms bei Drehimpuls  
3ms bei Tastendruck



S07	S08	S09
37H	38H	39H
S04	S05	S06
34H	35H	36H
S01	S02	S03
31H	32H	33H
S10	S11	S12
30H	2EH	36H


S13	S14	S15	S16	S17
DOH	16H	62H	67H	76H
S18	S19	S20	S21	S22
20H	161H	16CH	64H	66H

S23	S24	S25	S26	S27
21H	22H	63H	73H	65H




Beispiel: Tastencode 76 H


PAU	2*	0
PA1	2*	1
PA2	2*	1
PA3	2*	0
PA4	2*	1
PA5	2*	1
PA6	2*	1




TASTATUR , VOLLSTÄNDIG  
1340.041-01402 Sp




TASTATUR , VOLLSTÄNDIG  
1340.041-01402



**ANZEIGE**  
**1340.041-01456 Sp**



**ANZEIGE**  
**1340.041-01456**



Raum für Einföhrung der Lichtleiter-Gruppe der LED-VDA 24 in der LED-Zelle  
Schrift: LIG schwarz  
FWB-N 102.905

Anordnung der Bauelemente nach PWS W 170.023 Seite 51

S1 wo gefaltet nach APA


Maßzahl in ( ) gilt nicht für die Bearbeitung

\*) Wertweise Bestückung

① Bei Einsoitz von D492


② Bei Einsoitz der Ausweich BE






**STELLSPEICHER**  
**1340.041-01455 Sp Bl.1**

Stellspeicher / Treiber "MOD, B, GC, SEL"



STELLSPEICHER  
1340.041-01455 Sp B1.2



V2+ - Antiforce

an Ext-Ausgangsbogen X01, X04, X05

an X 702


an X 4001

Abgleich Anzeige EY

Regelspannung - Linearisierung

STELLSPEICHER  
1340.041-01455


Ein-Ausgabeblock



V24-Interface

NF-Tiefpaß

X 10 MHz	15V	1	SCAN	STOP
X 1 MHz	5V	3	103	EXT
X 100 kHz	0.5V	5	103	EXT
X 10 kHz	0.5V	11	118V	
X 1 kHz	0.5V	118V		
X 100 Hz	0.5V	118V		
X 10 Hz	0.5V	118V		





45

Ausgangstreiber  
D16...D20


Stellspeichermatrix  
D04...D15

V35-----V27


Ziffer 15 45 05 60  
Anzeige E Y  
Abturch



STELLSPEICHER  
1340.041-01455



FREQUENZAUFBEREITUNG 1  
1340.041-01211 Sp



OSZILLATOR 1  
1340.037-01251 Sp

1340.037-01251-05<sup>1</sup>

f1 - 70,2 ... 100,2 MHz  
 Uf1 - 80 ... 100 mV an 50 Ω  
 Uf1 = 50 ... 100 mV




V20 u V22 E1V-

Bereich		
1	2	
+0,5	-12	V20/C
-11,5	0	V21/C
-12	+0,5	V22/C
0	-11,5	V23/C
-8...9	0	C45
0	-8...9	C47


US1

Bereich	Richtwert
1	2,7 ... 10 V-
2	2,9 ... 14 V-

Bereich		
a	b	
+0,5	+16,5	V13/C
-16	-12	V19/C




**OSZILLATOR 1**  
**1340.037-01251**




- SF 235
- A K
- E B C
- Q25W
- E B C
- SF 235
- Q1W
- KSY 71

- EL 000 D; o. E100 C, D, MH8K00
- EL 051 D; o. E150 C, D
- EL 151 D; C
- E 172 C, D; o. MH 8K72
- EL 192 D; o. E192 C, D
- SN 54 S112; o. MH 84 S12
- MH 54 S112


**FREQUENZTEILER 1**  
**1340.037-01252 Sp**









**FREQUENZTEILER 1**  
**1340.037-01252**




Kennnummer der Bauelemente  
C2301 = C01



OSZILLATOR 3  
1340.039-01253 Sp




OSZILLATOR 3  
1340.039-01253




FREQUENZAUFBEREITUNG 2 und F1-DEMODULATOR  
1340.041-01221 Sp





OSZILLATOR 2  
1340.037-01255




- SF 245
- EBC
- 0,25W
- 0,3W
- MSY 71

EL 074 D, 0 E 174 D, MH 8474,  
 MH 54 S 20, MH 84 S 20, SF 54 S 20 H  
 EL 010 D1, 0 E 110 D,  
 E 100 D, MH 84 00,  
 174


X01  
 auf die Kontakte gesehen  
 MH 54 S 112, MH 84 S 112, SN 54 S 112  
 EL 192 D, E 192 J

1340.037-01256 50



FREQUENZTEILER 2  
1340.037-01256





Kennummer der Bauelemente  
C 2401 & C 01



auf die Kontakte gesehen



MH 8490 o. UCA 8480n  
E 110D o. E 110C  
EL 080D




55218C



TCXO Typ +  
10,0 MHz


Ansicht von unten

REFERENZFREQUENZ  
1340.037-01254 Sp




REFERENZFREQUENZ  
 1340.037-01254

Gilt auch für Signalweg 1  
1340.041 - 01312




1) Einbauichtung - Quarzfitter (Z 3001):  
 Farbpunkt = Mischer 1 - Seite

**SIGNALWEG 1**  
**1340.041-01311 Sp**




III	1,5 ... 3	1,5 ... 2 ... 2,5 ... 3	MHz
IV	3 ... 6	3 ... 4 ... 5 ... 6	MHz
V	6 ... 12	6 ... 8 ... 10 ... 12	MHz
VI	12 ... 24	12 ... 16 ... 20 ... 24	MHz
		1 2 *) 3	

\*) Abgleichstellung





VORSELEKTOR 1  
1340.037-01351 Sp




VORSELEKTOR 1  
1340.037-01351



$f_z = 16 \text{ kHz} \dots 30 \text{ MHz}$   
 $Z_A = 75 \Omega$



**VORSELEKTOR 2**  
 1340.041-01352 Sp



Bereich	I	2	3	Vors 2	
	1,5	2	3	3	3
	1,5 ... 30	2,5	3	3	3
	1,5 ... 3	4	5	6	6
	3 ... 6	6	8	10	12
	6 ... 12	12	16	20	24
	12 ... 24	24	30		
	24 ... 30				



② Kennnummer der Bauelemente C3201 = C01

⑤ Bereich  
 "Ein" = 1/  
 "Aus" = 0/1

Y-Signal (Antenne)


Abgleich-TP  
\* 30 MHz

Abgleich-TP  
= 15 MHz (II)

Abgleich-HP  
= 15 MHz (III)

zum Mischtr 1  
(14 MHz bis 30 MHz)  
(Bereich I bis VIII)

Bereich „Ein“: ca. 1V  
Bereich „Aus“: ca. 10V



(P02)


zum Vorselektor 1  
(15 bis 24 MHz)  
(III bis VI)

Abgleich-HP  
= 24 MHz (VIII) Ansicht 2

vom Vorselektor 2  
(III bis VI)


**VORSELEKTOR 2**  
**1340.041-01352**

$f_c = 14.4 \text{ kHz} \dots 30 \text{ MHz}$  vom Trägersektor 2)  
75  $\Omega$




statische Meßwerte	
UR1	15V
P1	14.6V ± 0.2
P2	0V
P3	-8V ± 0.5
P4	17.9V ± 0.1
P5	1.9V ± 0.2
P6	1.2V ± 0.2
P7	1.2V ± 0.2
P8	7.9V ± 0.5
P9	7.2V ± 0.5
P10	7.2V ± 0.5
P11	5.1V ± 0.4
P12	5.3V ± 0.4
P13	5.3V ± 0.4

- 1) 2) 3) 2 x SF 235 paargl.  
 $\Delta U_{CE}$  bei  $I_{05}$  konst.  $\approx 10\%$   
 $U_{CE} 4.5V, I_{CE} \sim 5mA$
- 4) Abgleichwert






MISCHER 1  
1340.041-01353 Sp






**MISCHER 1**  
1340.041-01353






INTERFACE „VORSELEKTORSTEUERUNG“

	Eingangs-Signal TTL-Pegel					Ausgangs-Signal ( $< 1/18V$ )												Bereich (Hz)		
	X01	A2	A3	A4	A5	A6	A7	A8	A9	A10	A11	A12	A13	A14	A15	A16	A17		A18	
I	0	0	1	-	-	<1	18	18	18	18	18	18	18	18	18	18	18	18	<13	
	0	1	0	-	-	18	<1	18	18	18	18	18	18	18	18	18	18	18	15...30	
	0	1	1	-	-	18	18	<1	18	18	18	18	18	18	18	18	18	18	15...<1	
	1	0	0	-	-	18	18	18	<1	18	18	18	18	18	18	18	18	18	3...<6	
	1	0	1	-	-	18	18	18	18	<1	18	18	18	18	18	18	18	18	6...<2*	
	1	1	0	-	-	18	18	18	18	18	<1	18	18	18	18	18	18	18	12...<2*	
	1	1	1	-	-	18	18	18	18	18	18	<1	18	18	18	18	18	18	≥2*	
II	1	-	-	1	0	-	-	-	-	-	-	-	-	-	-	-	-	<1	18	II 1 15 <*
	2	-	-	0	1	-	-	-	-	-	-	-	-	-	-	-	-	18	<1	II 2 3... <*
	3	-	-	1	1	-	-	-	-	-	-	-	-	-	-	-	-	18	18	II 3 6 <*
	4	-	-	0	1	-	-	-	-	-	-	-	-	-	-	-	-	18	18	II 4 12 <*
	5	-	-	1	1	-	-	-	-	-	-	-	-	-	-	-	-	18	18	II 5 2... <*
	6	-	-	1	1	-	-	-	-	-	-	-	-	-	-	-	-	18	18	II 6 8... <*




DREHPULSGEBER  
1340.041-01431 Sp

MISCHER 2  
1340.041-01354



**SIGNALWEG 2**  
**1340.041-01321 Sp**

Kern-Nr. der Bauelemente  
 C 3001 = C01



SIGNALWEG 2  
 1340.041-01322 Sp



3.5V =, R3E  $U_E = 50 \text{ mV} \approx$   
 13.5V =, R3E  $U_E = 200 \text{ mV} \approx$

3  
 200.000 kHz,  $\approx 7.5 \text{ V}$ -schwankend

15.5V =, R3E  $U_E = 50 \text{ mV} \approx$

R3E 5V =, R3E  $U_E = 200 \text{ mV} \approx$

200.000 kHz,  $\approx 4 \text{ V}$ -schwankend  
 $f = 1.905 \text{ kHz}$

3.5V<sub>ss</sub>

3.5V<sub>ss</sub>

4.2V =, R3E  $U_E = 50 \text{ mV} \approx$

2.2V =, R3E  $U_E = 200 \text{ mV} \approx$

Minimumabgleich der  
 Welligkeit für 198.095 kHz

3V<sub>ss</sub>

1.3V =

12 mV  $\approx$

12.2V =

R3E, 200.000 kHz  
 (6 bis 7) V =  
 schwankend

200 mV  $\approx$


11.6V =

$\approx 3 \text{ mV} \approx$

4.5V =, F

$U_E = (50 \text{ bis } 250) \text{ mV} \approx$   
 $f_E = 200 \text{ kHz} \pm \Delta f_E$

$U_E = 200 \text{ mV} \approx$   
 $f_E = 200.000 \text{ kHz}$



$\approx 7.5 \text{ V}$  =, R3E 200.000 kHz  
 MOS-FET!

$\approx 13.8$ , R3E 200.000 kHz

2.7V =, F

4 (V27-V29)  
 400 mV  $\approx$ , F

13.2V =, F

13.5V =, F

8.5V<sub>ss</sub>

Abgleich des Ziehbereiches  
 des Quarzoszillator bei A1A  
 (< 198,8 bis > 199,5) kHz

Maximumabgleich  
 198,095 kHz Ausgangs-  
 spannung

Maximumabgleich  
 201,905 kHz Ausgangs-  
 spannung

5.0V =, A1A  
 100 mV  $\approx$ , A1A

Minimumabgleich der  
 Welligkeit für 201,905 kHz

6V =

10 mV  $\approx$ , A1A

10 mV  $\approx$ , F


9.0V =, R3E  
 6.3V =, A1A

Maximumabgleich  
 für Ausgangsspannung  
 A1Aoder F  $\square \square \square \square \square \square$

35  $U_A = (80 \text{ bis } 170) \text{ mV}$  an 680  $\Omega$   
 $f_A \approx f_U$

200 mV  $\approx$ , F 0 bis 9.5V =, A1A

**TRAGEROSZILLATOR**  
**1340.037-01355**



Pos.	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15
WV	500k ± 1%	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k
WV	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k
WV	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k
WV	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k
WV	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k	10k

- Autokontaktesener SC237
- KP307
- SZ21V... SAY12 A K
- V4051
- A281, A221
- 80810


ZF 2 / B  
1340.041-01356 Sp



01 5547 5547 -

03 0317

05 5547 5547 -



004-01

051 104

05 5547


05 5547

05 5547

05 5547


05 5547

ZF 2 / B  
1340.041-01356 / 01366



200kHz/20mA  
50V/250mA  
T01  
T02


P11	01	03	05	07	08	09
P12	01	03	05	07	08	09
P13	01	03	05	07	08	09
P14	01	03	05	07	08	09
P15	01	03	05	07	08	09
P16	01	03	05	07	08	09
P17	01	03	05	07	08	09
P18	01	03	05	07	08	09
P19	01	03	05	07	08	09
P20	01	03	05	07	08	09
P21	01	03	05	07	08	09
P22	01	03	05	07	08	09
P23	01	03	05	07	08	09
P24	01	03	05	07	08	09
P25	01	03	05	07	08	09
P26	01	03	05	07	08	09
P27	01	03	05	07	08	09
P28	01	03	05	07	08	09
P29	01	03	05	07	08	09
P30	01	03	05	07	08	09
P31	01	03	05	07	08	09
P32	01	03	05	07	08	09
P33	01	03	05	07	08	09
P34	01	03	05	07	08	09
P35	01	03	05	07	08	09
P36	01	03	05	07	08	09
P37	01	03	05	07	08	09
P38	01	03	05	07	08	09
P39	01	03	05	07	08	09
P40	01	03	05	07	08	09
P41	01	03	05	07	08	09
P42	01	03	05	07	08	09
P43	01	03	05	07	08	09
P44	01	03	05	07	08	09
P45	01	03	05	07	08	09
P46	01	03	05	07	08	09
P47	01	03	05	07	08	09
P48	01	03	05	07	08	09
P49	01	03	05	07	08	09
P50	01	03	05	07	08	09




ZF 2 / A  
1340.041-01357 Sp

Bezeichnung  
1340.041-01367

- 01367



Leistung



- 01357

ZF 2 / A  
1340.041-01357 / 01367

Gilt auch für  
1340.041-01367

max. 150  
min. 20

U<sub>max</sub> 150V  
C<sub>1</sub>


-0.5 96V

96 200-4  
1340.041-01367


U<sub>max</sub> 150V  
C<sub>1</sub>

U<sub>max</sub> 150V  
C<sub>1</sub>


U<sub>max</sub> 150V  
C<sub>1</sub>



Pos.	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15
V01	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12
V02	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12
V03	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12
V04	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12
V05	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12
V06	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12
V07	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12
V08	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12
V09	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12	MP 307	52x21	SAY 12




ZF 2 / B  
1340.041-01366 Sp




+18V  
 50.250mV  
 200kHz ± 41  
 B/R3E  
 B/R8E

(01.08) UH2  
 A7  
 A8  
 A9  
 A10  
 A11  
 A12  
 A13  
 B1  
 B2  
 B3  
 B4  
 B5  
 B6  
 B7  
 B8  
 ZF2/B

01	02	03	04	05	06	07	08	09
10	11	12	13	14	15	16	17	18
19	20	21	22	23	24	25	26	27
28	29	30	31	32	33	34	35	36
37	38	39	40	41	42	43	44	45
46	47	48	49	50	51	52	53	54
55	56	57	58	59	60	61	62	63
64	65	66	67	68	69	70	71	72
73	74	75	76	77	78	79	80	81
82	83	84	85	86	87	88	89	90
91	92	93	94	95	96	97	98	99
100	101	102	103	104	105	106	107	108
109	110	111	112	113	114	115	116	117
118	119	120	121	122	123	124	125	126
127	128	129	130	131	132	133	134	135
136	137	138	139	140	141	142	143	144
145	146	147	148	149	150	151	152	153
154	155	156	157	158	159	160	161	162
163	164	165	166	167	168	169	170	171
172	173	174	175	176	177	178	179	180
181	182	183	184	185	186	187	188	189
190	191	192	193	194	195	196	197	198
199	200	201	202	203	204	205	206	207
208	209	210	211	212	213	214	215	216
217	218	219	220	221	222	223	224	225
226	227	228	229	230	231	232	233	234
235	236	237	238	239	240	241	242	243
244	245	246	247	248	249	250	251	252
253	254	255	256	257	258	259	260	261
262	263	264	265	266	267	268	269	270
271	272	273	274	275	276	277	278	279
280	281	282	283	284	285	286	287	288
289	290	291	292	293	294	295	296	297
298	299	300	301	302	303	304	305	306
307	308	309	310	311	312	313	314	315
316	317	318	319	320	321	322	323	324
325	326	327	328	329	330	331	332	333
334	335	336	337	338	339	340	341	342
343	344	345	346	347	348	349	350	351
352	353	354	355	356	357	358	359	360
361	362	363	364	365	366	367	368	369
370	371	372	373	374	375	376	377	378
379	380	381	382	383	384	385	386	387
388	389	390	391	392	393	394	395	396
397	398	399	400	401	402	403	404	405
406	407	408	409	410	411	412	413	414
415	416	417	418	419	420	421	422	423
424	425	426	427	428	429	430	431	432
433	434	435	436	437	438	439	440	441
442	443	444	445	446	447	448	449	450
451	452	453	454	455	456	457	458	459
460	461	462	463	464	465	466	467	468
469	470	471	472	473	474	475	476	477
478	479	480	481	482	483	484	485	486
487	488	489	490	491	492	493	494	495
496	497	498	499	500	501	502	503	504
505	506	507	508	509	510	511	512	513
514	515	516	517	518	519	520	521	522
523	524	525	526	527	528	529	530	531
532	533	534	535	536	537	538	539	540
541	542	543	544	545	546	547	548	549
550	551	552	553	554	555	556	557	558
559	560	561	562	563	564	565	566	567
568	569	570	571	572	573	574	575	576
577	578	579	580	581	582	583	584	585
586	587	588	589	590	591	592	593	594
595	596	597	598	599	600	601	602	603
604	605	606	607	608	609	610	611	612
613	614	615	616	617	618	619	620	621
622	623	624	625	626	627	628	629	630
631	632	633	634	635	636	637	638	639
640	641	642	643	644	645	646	647	648
649	650	651	652	653	654	655	656	657
658	659	660	661	662	663	664	665	666
667	668	669	670	671	672	673	674	675
676	677	678	679	680	681	682	683	684
685	686	687	688	689	690	691	692	693
694	695	696	697	698	699	700	701	702
703	704	705	706	707	708	709	710	711
712	713	714	715	716	717	718	719	720
721	722	723	724	725	726	727	728	729
730	731	732	733	734	735	736	737	738
739	740	741	742	743	744	745	746	747
748	749	750	751	752	753	754	755	756
757	758	759	760	761	762	763	764	765
766	767	768	769	770	771	772	773	774
775	776	777	778	779	780	781	782	783
784	785	786	787	788	789	790	791	792
793	794	795	796	797	798	799	800	801
802	803	804	805	806	807	808	809	810
811	812	813	814	815	816	817	818	819
820	821	822	823	824	825	826	827	828
829	830	831	832	833	834	835	836	837
838	839	840	841	842	843	844	845	846
847	848	849	850	851	852	853	854	855
856	857	858	859	860	861	862	863	864
865	866	867	868	869	870	871	872	873
874	875	876	877	878	879	880	881	882
883	884	885	886	887	888	889	890	891
892	893	894	895	896	897	898	899	900
901	902	903	904	905	906	907	908	909
910	911	912	913	914	915	916	917	918
919	920	921	922	923	924	925	926	927
928	929	930	931	932	933	934	935	936
937	938	939	940	941	942	943	944	945
946	947	948	949	950	951	952	953	954
955	956	957	958	959	960	961	962	963
964	965	966	967	968	969	970	971	972
973	974	975	976	977	978	979	980	981
982	983	984	985	986	987	988	989	990
991	992	993	994	995	996	997	998	999
1000								





ZF 2 / A  
 1340.041-01367 Sp




10) Abhörverstärker

12) Leitungsverstärker(A)

11) Demodulator



16) Auf die Kontakte gesehen





17) Ansicht von oben




18) Ansicht von unten




19) Ansicht von unten






15) 40-Schalter B8



16) UZF (50 C) UZF-B UZF-A




DEMODULATOR und NF-TEIL  
1340.039-01358 Sp




(95-170)

DEMODULATOR und NF-TEIL  
1340.039-01358




F1-DEMODULATOR  
1340.041-01258 Sp






Anordnung der Bauelemente nach FWB-N 170. D20, siehe St  
Schwelligelötet nach APA  
Menge in ( ) gilt nicht für die Bearbeitung

**F1-DEMODULATOR**  
**1340.041-0125B**



200 kHz / 1.7 kHz - UMSETZER  
 1340.041-01257 Sp



200 kHz / 1.7 kHz - UMSETZER  
1340.041-01257

contained in tables, diagrams and figures of Receiver BKD 500

Order-No. of this list: 1340,042-01702 U1 (4)

Abgleich des Ziehbereiches	balancing of the pull-in range
Abgleich des Ziehbereiches des Quarzoszillators bei ...	balancing the pull-in range of the crystal oscillator with ...
Abgleichstellung	balancing position
Abgleichelemente	balancing elements
Abgleich, Abgleichwert	balancing, balancing value
Abhörverstärker	monitoring amplifier
Abschirmung	screening
Adressen-Dekoder	address decoder
Analysenoszillator	analysis oscillator
Ändern	change
Angriffspunkt für den Ziehler	point of application for extractor
Anschlußadapter	connection adapter
Ansicht von unten	view from below
Antenne oder Antennenverteiler	aerial or aerial distributor
Anzeige	display
Arbeitsweise des Phasendiskriminators	function of the phase discriminator
Aufbau	construction/assembly
auf die Anschlüsse gesehen	view of connections
auf die Kontakte gesehen	view of contacts
Ausgangsspannung	output voltage
Ausgangssignal	output signal
Ausgangsfrequenz im synchronisierten Zustand	output frequency in synchronized condition
Ausgangstreiber	output driver
Ausgangsverstärker	output amplifier
Auswerterschaltung	evaluator circuit
Bandbreite	bandwidth
Basisstrom gemessen über	base current measured via
Batteriebetrieb	battery operation
Batteriekabel	battery cable
Baugruppenübersicht	subassembly survey
Bedeieneinheit	control unit

Befestigung für Bedieneinheit	fastening device for control unit
Befestigung für Frontplatte	fastening device for front panel
Begrenzer	limiter
bei falschen Pegeln werden die entsprechenden Leiterplatten geprüft	in case of wrong levels the corresponding pc boards are checked
Beispiel	example
Belastung	load
Bereich	range
Bereich 1 einschalten	switch on range 1
Bestückungsseite	complementation side
Betriebsspg.	operating voltage
Blockschaltbild PLL 1	block diagram PLL 1
Brücke(n)	bridge(s)
Coder	coder
Codierung der Steckverbindung "8-5"	coding of plug connection "8-5"
Dateneingänge	data inputs
Demodulator u. NF-Teil	demodulator and AF section
Diese Zeichnung besteht aus	this drawing consists of
Detektor, Langzeit-, Kurzzeit-	detector, long-term-, short-term-
Diodenplatte	diode board
Drehimpulsgeber	angular momentum generator
Ein- Ausgabe-Logik	input-output logic
Einfachstrom, Standleitungsbetrieb, 4 Draht-Anschluß	single current, point-to-point operation, 4-wire connection
Eingangspaß	input band filter
Eingangsfrequenz	input frequency
Eingangssignal	input signal
Eingangsschutz	input protection
Einschub	plug-in
Einstellbare Frequenzteilung	adjustable frequency division

unser Eigentum  
 Halbtung oder  
 wird verleiht

Wingangsfrequenz	input frequency
Ausgangsfrequenz	output frequency
im synchronisierten Zustand von PLL 1	in synchronized condition of PLL 1
Teilerfaktor	divider factor
Zählstart ... Ziffernwahl	count start ... digit selection
Zählung ... rückwärts	counting ... down
ellen	set/adjust
llungen (Sollwert)	settings (setpoint value)
ger EKD 500	receiver EKD 500
ssperre	receive blocking
gsteil	receiving section
ten in	contained in
richtung - Quarzfilter:	direction of insertion - crystal filter:
akt = Mischer 1-Seite	colour point = side of mixer
	earth connection
Schraube	earthing screw (side wall of casing)
geseitenwand)	
ungseinrichtungen	supplementary devices
: - Frequenz falsch	wrong: - wrong frequency
- bei falschen Pegeln werden die entsprechenden Leiterplatten geprüft	- in case of wrong levels the corresponding pc boards are checked
- kein Ausgangsimpuls f2/100	- no output pulse f2/100
- PLL 2 synchronisiert nicht	- PLL 2 does not synchronize
- PLL 2 synchronisiert aber Frequenz ist falsch	- PLL 2 synchronizes but wrong frequency
fo (FH)	capture aid
deschlauchleitung	telecom plastic sheathed cable
reiber	teleprinter
	instantaneous
on Lötresten und	free of soldering and flux
telresten	residuals
z falsch	wrong frequency
zabgleich	frequency balancing
zaufbereitung (FA)-	frequency processing survey
ht	

Frequenzeinstellung	frequency setting
Frequenzteiler	frequency divider
Frontplatte, vollst.	front plate, complete
für aktive Antenne	for active aerial
Für jede Taste kann der Code ...	code can be generated for each key if EXT FCT is pressed simultaneously
Gehäuse, vollst.	casing, complete
geseiht	filtered
Gestell, mont.	rack, mounted
Gilt auch für Signalweg 1	also applicable for signal path 1
Gleichstromweiche (gedr. Schaltung)	dc filter (pc)
Haltekreis	holding circuit
HF-Generator	RF generator
HF-Kabel	RF cable
Hochpaß (HP)	high-pass
Hub	deviation
Impulsdiagramme für 2 Beispiele	pulse diagrams for 2 examples
- Ausgangssignal	- output signal
- Rücksetzsignal	- reset signal
- Eingangssignal	- input signal
Impulsschema des Frequenzdiskriminators	pulse scheme of the discriminator
Schaltfolge hervorgerufen durch Zeitverzögerung der Gatter	switching sequence caused by time delay of the gates
Kassettenaufnahme	cassette reception
Kassettenbefestigung	cassette fastening
Kassettendeckel (innere)	cassette lids (inner)
kein Ausgangsimpuls f2/100	no output pulse f2/100
Kenn-Nr. der Bauelemente	code No. of components
Kennzeichnung Farbpunkt "Ein"	marking/colour point "ON"
Klemmbrett	terminal board
Koder	coder
Koder für Oszillator 1-Bereiche	coder for oscillator 1 ranges
kontaktblank	bare contact
Kontrolle	test/check
Korrektur	correction
Kurzzeitdetektor	short-time detector

Dieser Eigenbau  
 ist ein Mächtigkeitsstück  
 und wird versagt.

Lage der Meßpunkte	position of measuring points
LED Zeile 13stellig	LED row 13-digit
Leitersseite	conductor side
Leitung	line
Leitungsverstärker	line amplifier
Linearisierung "E - Anzeige"	linearization "E display"
Maximumabgleich für Ausgangs- spannung ...	max. balancing for output voltage ...
Meßgröße	measuring/test value
Minimalabgleich der Welligkeit für ...	min. balancing of ripple for...
Mischer	mixer
Montageplatte, vorm.	assembly board, premounted
Netzanschluß	mains connection
Netzbetrieb	mains operation
Netzspannung	mains voltage
NF-Ausg.	AF output
NF-Leitungsausgang	AF line output
NF-Tiefpaß	AF low-pass
Nulllage	zero position
offen	open
Offsetabgleich	offset balancing
Oszillator	oscillator
Oszillator defekt	oscillator faulty
paarig	in pairs
Pegelkontrolle	level check
Pegel, Pegelung	level, levelling
Pegelkorrektur	level correction
Periphere Geräte	peripheral units
Phasendetektor	phase detector
Phasendiskriminator	phase discriminator
Programm für die Fehlersuche	program for troubleshooting
Prüfe	check/test
PLL 2 synchronisiert nicht	PLL 2 does not synchronize
PLL 2 synchronisiert aber Frequenz ist falsch	PLL 2 synchronizes but wrong frequency



Prüfe und repariere	check and repair
- Koder	- coder
- Verstärker u. Mischer	- amplifier and mixer
- Verstärker	- amplifier
- Rücksetzeinheit	- reset unit
- Zähler	- counter
- Frequenzeinstellung	- frequency setting
- Einstellbare Frequenz-	- adjustable frequency division
teilung	
- Schalter u. Ver-	- switch and wiring
drahtung	
- 100:1 Teiler	- 100:1 divider
- 4:1 Teilung	- 4:1 division
Prüfprogramm Frequenzteiler 1/2	test program/frequency divider 1/2
Prüfprogramm Oszillator 3	test program/oscillator 3
- Oszillator 3 defekt	- oscillator 3 faulty
- hängt auf Spiegelwelle	- on image wave
- synchronisiert von...	- synchronized by ...
- prüfe Mischer	- test mixer
- prüfe 90°-Versatz	- test 90° offset at ...
an ...	
- prüfe Phasenvergleich	- test phase comparison
Prüfprogramm PLL 1	test program PLL 1
Prüfpunkt	test point
Prüfung des einstellbaren	test of the adjustable frequency
Frequenzteilers 1	divider 1
Referenzfrequenz	reference frequency
Regeleinsatz	control start
Regelgleichlauf A und B	sync control A and B
Regelspannung,	control voltage, control voltage
Regelspannungserzeuger	generator
Regelspannungs-Detektor	control voltage detector
Regelsteilheit	control slope
Regelumfang	control volume
Richtwert	setpoint value
Ruhestrom	rest current
Rücksetzeinheit	reset unit
Rücksetzsignal	reset signal
Rückwand, mont.	rear wall, mounted



Test	test
Tiefpaß (TP)	low-pass
Transistorplatte	transistor board
Transverter, Transverterbetrieb	transverter, transverter operation
Trägeroszillator	carrier oscillator
Trägersynchronisation	carrier synchronization
Trägerverstärker	carrier amplifier
Treiber	driver
Trennverstärker	buffer amplifier
Triggereinstellung, Trigger	trigger setting, trigger
Trimmwert	trimming value
Umschalter LED-Zeile	changeover switch LED row
Umschaltung	changeover
Überlagerte Brummspannung	superposed hum voltage
verbunden	connected
Verdrahtung	wiring
Vereinfachter Übersichtsplan- Frequenzen u. Pegel von Referenz- frequenz	simplified general diagram - frequencies and levels of the reference frequency
Verstärker	amplifier
90° - Versatz	90° offset
Verstärkung	amplification
Verstärker - Mischer: Arbeits- punkte und HF-Pegel verbunden	amplifier - mixer: working points and RF levels connected
Vorselektor	preselector
Vorselektor-Teilbereiche	preselector subranges
Verzögerung	delay
Zählstart ... Ziffernwahl	counting start ... digital selection
Zählende	counting end
Zähler	counter
Zählung ... rückwärts	counting ... down
Zeitglied für Empfangssperre bei SCAN	tuning element for receive blocking with SCAN
ZF-Ausgang	IF output
ZF-Verstärker	IF amplifier
Ziffern im 8-4-2-1-Code	digits in 8-4-2-1 code
Ziffernwahl im 8-4-2-1-Code zu den Registern	digital selection in 8-4-2-1 code to the registers
Zur V24 - Interface	to the V24 interface