

- Engine & Cooling
- Fuel
- Ignition
- Electrical
- Running gear
- Torque settings
- Capacities
- Notes & Illustrations



# Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

## Engine and cooling system Saxo 1.0 1996 to 1997

Type	TU9M/L3/L (CDZ) 37kW	
Capacity (cm <sup>3</sup> ) / number of cylinders	954 / 4	
Compression ratio / pressure	bar	9.4 / _
Oil pressure	bar	[≥4.0]
Oil temperature	°C	90
Valve clearance - inlet	mm	0.20±0.05
Valve clearance - exhaust	mm	0.40±0.05
Firing order	1-3-4-2	
No 1 cylinder position	FE	
Thermostat opening temperature	°C	88
Radiator cap pressure	bar	1.4

## Fuel system Saxo 1.0 1996 to 1997

Idle speed - manual [auto]	rpm	850±50 N/A
Fast idle speed - manual [auto]	rpm	_
CO @ idle speed [3000 rpm] - see page VI	%	≤0.5
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO <sub>2</sub> @ idle speed [3000 rpm] - see page VI	%	≥11.0
O <sub>2</sub> @ idle speed [3000 rpm] - see page VI	%	_
Carburettor / fuel injection	_ Bosch	
Type / ref	MA3.1 Mono-Motronic	
Main jet / needle	_	
Injection pressure	bar	1.00
Pump pressure	bar	_
Octane rating	RON	95[U]

## Ignition system Saxo 1.0 1996 to 1997

Type	Static	
Ignition coil	Bosch BAE 04	
Primary resistance	ohms	0.8
Ballast resistor	ohms	_
Voltage - Tmnl 15(+) to earth	V	_
Distributor	_	
Points gap (air gap)	mm	_
Dwell angle	° (%)	_
Condenser capacity	µF	_
Rotation	_	
Ignition timing - basic [static	° Crankshaft @ rpm	Computer control
V = Vacuum NV = No Vacuum	_	
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	_
Spark plugs	Bosch/Eyquem	
Type	FR8LDC / RFC42LZ2E	
Electrode gap	mm	0.90

## Electrical system Saxo 1.0 1996 to 1997

Battery	V / CC / RC	_
Alternator voltage / full load current / engine rpm	_	
Starter motor current / voltage - cranking	A / V	_
- locked	A / V	_

## Running gear Saxo 1.0 1996 to 1997

<b>Brakes -</b>		
Front (min. friction material thickness)	mm	_
Rear (min. friction material thickness)	mm	1.0

<b>Tyres</b>		
Saloon	Size	155/70x13; 165/70x13
Estate / Van	Size	_
Pressure - front / rear - Saloon	bar	155: 2.3 / 2.0. 165: 2.2 / 2.0
- Estate / Van	bar	_

<b>Front suspension / wheel alignment</b>		
Toe-in (+) / Toe-out (-)	mm [°]	-1.0 to -3.0. PAS: +1.0 to 3.0
Camber	-40'±30'	
Castor	+2°13'±30'. PAS: +3°14'±30'	
King pin inclination	+12°41'±40'. PAS: +12°42'±40'	

<b>Rear suspension / wheel alignment</b>		
Toe-in (+) / Toe-out (-)	mm [°]	+1.49 to 6.39
Camber	-59'±20'	


## Torque wrench settings Saxo 1.0 1996 to 1997

Cylinder head - stage 1	Nm	Bolts ≤176.5mm
- stage 2	Nm	20 oiled
Cylinder head - stage 3	Nm	+ 240±5°
- stage 4	Nm	_
Big-end bearings	Nm	38
Main bearings	Nm	M11: 20 + 45°. M6: 10
Clutch cover	Nm	13
Flywheel [driveplate]	Nm	65 LkC
Front hubs	Nm	250
Rear hubs	Nm	_
Wheel nuts / bolts	Nm	85
Spark plugs	Nm	25

## Capacities Saxo 1.0 1996 to 1997

Engine oil & filter	litres	3.5
Gearbox - 4-speed [5-speed]	litres	2.0
Automatic transmission - refill	litres	_
Final drive	litres	WT
Cooling system	litres	6.1
Fuel tank	litres	45

## Notes and Illustrations



954 cm<sup>3</sup>