

Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system Scorpio 2.9i V6 12V 1994 to 1997

Type		BRG OHV 12V 107kW
Capacity (cm ³) / number of cylinders		2936 / 6
Compression ratio / pressure	bar	9.0 / 11.5 to 12.5
Oil pressure	bar	[≥2.5]
Oil temperature	°C	80
Valve clearance - inlet	mm	0: Hyd.
Valve clearance - exhaust	mm	0: Hyd.
Firing order		1-4-2-5-3-6
No 1 cylinder position		FR
Thermostat opening temperature	°C	—
Radiator cap pressure	bar	—

Fuel system Scorpio 2.9i V6 12V 1994 to 1997

Idle speed - manual [auto]	rpm	900±50
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	≤0.5 N/A
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO ₂ @ idle speed [3000 rpm] - see page VI	%	—
O ₂ @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		_Ford
Type / ref		EEC V
Main jet / needle		—
Injection pressure	bar	3.0
Pump pressure	bar	—
Octane rating	RON	95[U]

Ignition system Scorpio 2.9i V6 12V 1994 to 1997

Type		EEC V
Ignition coil		—
Primary resistance	ohms	—
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor		—
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		—
Ignition timing - basic [static V = Vacuum NV = No Vacuum	° Crankshaft @ rpm	Computer control N/A
Total ignition advance	° Crankshaft @ rpm	Computer control
Centrifugal check.	° Crankshaft @ rpm	Computer control
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs		Motorcraft
Type		AGRF32C1
Electrode gap	mm	1.00

Electrical system Scorpio 2.9i V6 12V 1994 to 1997

Battery	V / CC / RC	—
Alternator voltage / full load current / engine rpm		13.7 to 14.6 / 100 / _
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	—

Running gear Scorpio 2.9i V6 12V 1994 to 1997

Brakes -		
Front (min. friction material thickness)	mm	—
Rear (min. friction material thickness)	mm	—
Tyres		
Saloon	Size	195/65x15:205/60x15:205/55x16
Estate / Van	Size	195/65x15: 205/60x15
Pressure - front / rear - Saloon	bar	2.0 / 2.0. 205: 2.2 / 2.2
- Estate / Van	bar	2.0 / 2.2
Front suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	2.0 ±1.0
Camber		-30'±1°
Castor		4°51'±40'
King pin inclination		—
Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	—
Camber		—


Torque wrench settings Scorpio 2.9i V6 12V 1994 to 1997

Cylinder head - stage 1	Nm	38 N
- stage 2	Nm	73
Cylinder head - stage 3	Nm	+ 90°
- stage 4	Nm	—
Big-end bearings	Nm	30
Main bearings	Nm	97
Clutch cover	Nm	—
Flywheel [driveplate]	Nm	[30]
Front hubs	Nm	420
Rear hubs	Nm	290
Wheel nuts / bolts	Nm	85
Spark plugs	Nm	32

Capacities Scorpio 2.9i V6 12V 1994 to 1997

Engine oil & filter	litres	4.25
Gearbox - 4-speed [5-speed]	litres	—
Automatic transmission - refill	litres	10.3
Final drive	litres	1.3
Cooling system	litres	9.3
Fuel tank	litres	70

Notes and Illustrations



2936 cm³