


Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system Carisma 1.6 1996 to 1997

Type		4G92 SOHC 16V 66kW
Capacity (cm ³) / number of cylinders		1597 / 4
Compression ratio / pressure	bar	10.0 / ≥9.6
Oil pressure	bar	—
Oil temperature	°C	—
Valve clearance - inlet	mm	H: 0.20
Valve clearance - exhaust	mm	H: 0.30
Firing order		1-3-4-2
No 1 cylinder position		TBE
Thermostat opening temperature	°C	82
Radiator cap pressure	bar	0.75 to 1.05

Fuel system Carisma 1.6 1996 to 1997

Idle speed - manual [auto]	rpm	750±100
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	≤0.3
HC @ idle speed [3000 rpm] - see page VI	ppm	≤15
CO ₂ @ idle speed [3000 rpm] - see page VI	%	—
O ₂ @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		_Mitsubishi
Type / ref		MPI
Main jet / needle		—
Injection pressure	bar	2.6
Pump pressure	bar	3.2
Octane rating	RON	95[U]

Ignition system Carisma 1.6 1996 to 1997

Type		Electronic
Ignition coil		—
Primary resistance	ohms	0.5 to 0.7
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor		—
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		—
Ignition timing - basic [static	° Crankshaft @ rpm	5°±3° BTDC @ 750±100 N/A
V = Vacuum NV = No Vacuum		—
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs		NGK/Nippon Denso
Type		BKR6E-11 / K20PRU11
Electrode gap	mm	1.10

Electrical system Carisma 1.6 1996 to 1997

Battery	V / CC / RC	12 / 52Ah
Alternator voltage / full load current / engine rpm		14.6 / 90A
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	—

Running gear Carisma 1.6 1996 to 1997

Brakes -		
Front (min. friction material thickness)	mm	1.0
Rear (min. friction material thickness)	mm	1.0

Tyres		
Saloon	Size	175/65x14
Estate / Van	Size	—
Pressure - front / rear - Saloon	bar	Refer to vehicle
- Estate / Van	bar	—

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	1.0±2.0
Camber		0°00'±30'
Castor		2°12'
King pin inclination		12°41'

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	3.0±2.0
Camber		-0°41'±30'

Torque wrench settings Carisma 1.6 1996 to 1997


Cylinder head - stage 1	Nm	74 oiled ¹
- stage 2	Nm	Slacken
Cylinder head - stage 3	Nm	20 +90°
- stage 4	Nm	+90°
Big-end bearings	Nm	20 +90°
Main bearings	Nm	25 +90°
Clutch cover	Nm	15 to 22
Flywheel [driveplate]	Nm	93 to 103
Front hubs	Nm	216 to 255 N
Rear hubs	Nm	172 N
Wheel nuts / bolts	Nm	98 to 117
Spark plugs	Nm	25

Capacities Carisma 1.6 1996 to 1997

Engine oil & filter	litres	3.8
Gearbox - 4-speed [5-speed]	litres	3.4
Automatic transmission - refill	litres	7.8
Final drive	litres	WT
Cooling system	litres	6.0
Fuel tank	litres	60

Notes and Illustrations

¹Bolt shank length: ≤96.4 mm



1597 cm³, 16V