

Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



# Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

## Engine and cooling system Clio 1.7 (B/C574) 1991 to 1992

Type		F2N-7-70
Capacity (cm <sup>3</sup> ) / number of cylinders		1721 / 4
Compression ratio / pressure	bar	9.5 / _
Oil pressure	bar	2.0 [3.5]
Oil temperature	°C	80
Valve clearance - inlet	mm	0.20
Valve clearance - exhaust	mm	0.40
Firing order		1-3-4-2
No 1 cylinder position		FE
Thermostat opening temperature	°C	89
Radiator cap pressure	bar	1.6

## Fuel system Clio 1.7 (B/C574) 1991 to 1992

Idle speed - manual [auto]	rpm	800±50
Fast idle speed - manual [auto]	rpm	900±50
CO @ idle speed [3000 rpm] - see page VI	%	1.5±0.5
HC @ idle speed [3000 rpm] - see page VI	ppm	≤1200
CO <sub>2</sub> @ idle speed [3000 rpm] - see page VI	%	_
O <sub>2</sub> @ idle speed [3000 rpm] - see page VI	%	_
Carburettor / fuel injection		Solex
Type / ref		32-34 Z13 965 (D)
Main jet / needle		112.5, 135
Injection pressure	bar	_
Pump pressure	bar	0.17 to 0.33
Octane rating	RON	95[E 95 RON]

## Ignition system Clio 1.7 (B/C574) 1991 to 1992

Type		AEI
Ignition coil		Renix
Primary resistance	ohms	0.4 to 0.8
Ballast resistor	ohms	_
Voltage - Tmnl 15(+) to earth	V	_
Distributor		_
Points gap (air gap)	mm	_
Dwell angle	° (%)	_
Condenser capacity	µF	_
Rotation		_
Ignition timing - basic [static	° Crankshaft @ rpm	2±1 BTDC @ 800±50
V = Vacuum NV = No Vacuum		NV
Total ignition advance	° Crankshaft @ rpm	RE293
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Centrifugal check.	° Crankshaft @ rpm	0 to 4 @ 750
	° Crankshaft @ rpm	7 to 12 @ 1550
	° Crankshaft @ rpm	23 to 28 @ 4050
Vacuum range check	mbar	0 to 300
Maximum vacuum advance	° Crankshaft	≥10
Spark plugs		AC/Champion
Type		C41CXLS / N279YC
Electrode gap	mm	0.75 to 0.85

## Electrical system Clio 1.7 (B/C574) 1991 to 1992

Battery	V / CC / RC	_
Alternator voltage / full load current / engine rpm		13.5 to 14.8 / 70, 90 / 4000
Starter motor current / voltage - cranking	A / V	_
- locked	A / V	460 / _

## Running gear Clio 1.7 (B/C574) 1991 to 1992

<b>Brakes -</b>		
Front (min. friction material thickness)	mm	6.0 with backing
Rear (min. friction material thickness)	mm	2.5 with backing <sup>1</sup>
<b>Tyres</b>		
Saloon	Size	165/60x14
Estate / Van	Size	_
Pressure - front / rear - Saloon	bar	2.3 / 2.3
- Estate / Van	bar	_
<b>Front suspension / wheel alignment</b>		
Toe-in (+) / Toe-out (-)	mm [°]	-1.0±1.0 <sup>2</sup>
Camber		-20'±30' <sup>3</sup>
Castor		+1°55'±30' <sup>4</sup>
King pin inclination		+10°±30' <sup>5</sup>
<b>Rear suspension / wheel alignment</b>		
Toe-in (+) / Toe-out (-)	mm [°]	+0.5 to 2.5 <sup>6</sup>
Camber		-50'±30' N/A

## Torque wrench settings Clio 1.7 (B/C574) 1991 to 1992

Cylinder head - stage 1	Nm	30
- stage 2	Nm	70
Cylinder head - stage 3	Nm	Wait 3 mins. Slacken in turn
- stage 4	Nm	20 + 123±2°
Big-end bearings	Nm	45 to 50
Main bearings	Nm	60 to 65
Clutch cover	Nm	25. M8: 30
Flywheel [driveplate]	Nm	50 to 55
Front hubs	Nm	250
Rear hubs	Nm	160. ABS: 175
Wheel nuts / bolts	Nm	90
Spark plugs	Nm	_

## Capacities Clio 1.7 (B/C574) 1991 to 1992

Engine oil & filter	litres	5.2
Gearbox - 4-speed [5-speed]	litres	3.4
Automatic transmission - refill	litres	_
Final drive	litres	WT
Cooling system	litres	6.4
Fuel tank	litres	43

## Notes and Illustrations

<sup>1</sup>ABS: 5.0

<sup>2</sup>ABS: +2.0±1.0


<sup>3</sup>ABS: -1°33'±30'

<sup>4</sup>ABS: +2°5'±30'


<sup>5</sup>ABS: +10°47'±30'

<sup>6</sup>ABS: +1.0 to 3.0


1: Idle speed 2: CO / Mixture



1721 cm<sup>3</sup>



1721 cm<sup>3</sup>



Solex Z13