


[Engine & Cooling](#)
[Fuel](#)
[Ignition](#)
[Electrical](#)
[Running gear](#)
[Torque settings](#)
[Capacities](#)
[Notes & Illustrations](#)


Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

[MENU](#)
[HELP](#)

Engine and cooling system

416i AT 1995 to 1997

Type		D16 SOHC 16V 83kW
Capacity (cm ³) / number of cylinders		1590 / 4
Compression ratio / pressure	bar	9.1 /
Oil pressure	bar	1.4
Oil temperature	°C	80
Valve clearance - inlet	mm	0.17 to 0.22
Valve clearance - exhaust	mm	0.22 to 0.27
Firing order		1-3-4-2
No 1 cylinder position		TBE
Thermostat opening temperature	°C	76 to 80
Radiator cap pressure	bar	1.0 to 1.3

Fuel system

416i AT 1995 to 1997

Idle speed - manual [auto]	rpm	[750±50] N/A
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	≤0.5
HC @ idle speed [3000 rpm] - see page VI	ppm	≤100
CO ₂ @ idle speed [3000 rpm] - see page VI	%	—
O ₂ @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		_Honda
Type / ref		PGM-FI MPI
Main jet / needle		—
Injection pressure	bar	2.5
Pump pressure	bar	4.1
Octane rating	RON	91[U]

Ignition system

416i AT 1995 to 1997

Type		Electronic
Ignition coil		GCL 161
Primary resistance	ohms	0.71 to 0.81
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor		—
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		—
Ignition timing - basic [static	° Crankshaft @ rpm	16±2 BTDC @ 750±50
V = Vacuum NV = No Vacuum		V
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs		Unipart
Type		GSP5658
Electrode gap	mm	1.10

Electrical system

416i AT 1995 to 1997

Battery	V / CC / RC	12 / 36Ah
Alternator voltage / full load current / engine rpm		13.5 / 75A
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	—

Running gear

416i AT 1995 to 1997

Brakes -		
Front (min. friction material thickness)	mm	3.0
Rear (min. friction material thickness)	mm	2.0

Tyres		
Saloon	Size	185/60x14: 185/55x15
Estate / Van	Size	—
Pressure - front / rear - Saloon	bar	2.1 / 2.1
- Estate / Van	bar	—

Front suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	[0°±0°12']
Camber		0°±1°
Castor		1°28'
King pin inclination		10°41'

Rear suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	[+11'±6'] PW
Camber		-55'

Torque wrench settings

416i AT 1995 to 1997


Cylinder head - stage 1	Nm	30
- stage 2	Nm	65
Cylinder head - stage 3	Nm	—
- stage 4	Nm	—
Big-end bearings	Nm	32
Main bearings	Nm	67 oiled
Clutch cover	Nm	—
Flywheel [driveplate]	Nm	[75]
Front hubs	Nm	181
Rear hubs	Nm	181
Wheel nuts / bolts	Nm	98 to 118
Spark plugs	Nm	18

Capacities

416i AT 1995 to 1997

Engine oil & filter	litres	3.3
Gearbox - 4-speed [5-speed]	litres	—
Automatic transmission - refill	litres	2.7
Final drive	litres	WT
Cooling system	litres	4.4
Fuel tank	litres	55

Notes and Illustrations



1590 cm³, SOHC