

Tru64 Unix - Multiple Server FCSW

HSG80 – Dual Controller Pedestal /TruCluster

**Note: This page deals with Storage Configuration only. Contact your local Compaq Sales Office for more information on the Compaq TruCluster solution.*

Step1 – Select Ped

Pedestal Version

Includes: Departmental Cabinet; dual HSG80 - Each controller with 64 MB cache; dual cache battery in SBB with cable; five shelf power supplies optionally expandable to eight; fully redundant cooling; Environmental Monitor Unit (EMU); 5-meter host connection cable; power cord and GLMs.

Description	Compaq
--------------------	---------------

Tip: Choose one

Ped Blue Sing. Ctrl	380560-B21
---------------------	------------

Ped Opal Sing. Ctrl	380560-B22
---------------------	------------

Tip: Choose up to two, each supports 24 drives: Optional

Exp. Ped Blue	380570-B21
---------------	------------

Exp. Ped Opal	380570-B22
---------------	------------

Tip: Choose one per Exp. Cab

Exp. Cable Kit	380563-001
----------------	------------

Redundant Power Options: Optional

Description	Compaq
--------------------	---------------

Tip: Choose up to three per BA370 enclosure

180 Watt Power supply	380565-B21
-----------------------	------------

Tip: Choose one per BA370 enclosure

AC Input Unit	380564-B21
---------------	------------

Tip: Order one per AC Input Unit ordered

AC Pwr Cord	103541-001
-------------	------------

Cache Upgrades – Optional

Description	Compaq
--------------------	---------------

Note: 64, 128, 256 or 512MB supported only...four slots available for cache...all slots must be of like size DIMMS

Tip: RA8000 Choose One (RA8000 comes with 64MB)

64MB – 2x32MB	380673-B21
---------------	------------

Tip: for 256MB or 512MB remove 64MB DIMM and order quantity accordingly

256MB – 2x128MB	380674-B21
-----------------	------------

Step2 – ACS – Firmware (PCMCIA) Card

Tip: One per HSG80 required.

Description	Compaq
--------------------	---------------

ACS v8.4	128697-B21
----------	------------

Step3 – Platform Kit – Includes SWCC

Tip: One per OS type required

Description	Compaq
--------------------	---------------

Tru64 Unix	380553-001
------------	------------

Step4 – Host Adapter

Note: GLM included

Tip: Two adapters required for this configuration.

Description	Compaq
Tru64 Unix	380574-001

Step5 - Disks

Description	Compaq
4GB, 7200 RPM, UWSE	380691-B21
9GB, 7200 RPM, UWSE	DS-RZ1DA-VW
9GB, 10K RPM, UWSE	380588-B21
18GB, 7200 RPM, UWSE	DS-RZ1EA-VW
18GB, 10K RPM, UWSE	380589-B21

Step 6 – FC Switch, GBIC's and Cables

Note: One Switch required...(no GBIC's included)... RACK hardware included...

FC- Switch

Description	Compaq
8 port Switch	380591-B21 (Blue) 380591-B22 (Opal)

OR

16 port Switch	380578-B21 (Blue) 380578-B21 (Blue)
----------------	--

GBIC and Connection Kit

Tip: Six GBICs and cables needed for this config.

Description	Compaq
3GBIC + 2 – 2M Cables	380579-B21
2GBIC + 2 – 2M Cables	380596-B21

CABLES - Optional

Tip: One 5M cable/controller comes with RA8000 and two 2M cables come with the GBIC Kit.

Description	Compaq
2Meter	234457-B21
5Meter	234457-B22
15Meter	234457-B23
30Meter	234457-B24
50Meter	234457-B25